

器具形名	バッテリー形名
KVK4762EF	4N30DA
KYD1011	蛍2N20DA 蛍3N25DA
KYD1011A	蛍2N20DA 蛍3N25DA
KYD2011	蛍3N23DA 蛍3N25DA
KYD2011A	蛍3N23DA 蛍3N25DA
KYD2711MS	蛍4N06DA 蛍3N25DA
KYD2711S	蛍4N06DA 蛍3N25DA
KYD2811A	蛍4NR-AC-TL 蛍3NR-CX-S
KYD2811VA	蛍4NR-AC-TL 蛍3NR-CX-S 音3NR-CX-S
KYD3011	蛍6N23AA 蛍3N25DA
KYD3011A	蛍6N23AA 蛍3N25DA
KYD4011	蛍7N23AA 蛍3N25DA
KYD4011A	蛍7N23AA 蛍3N25DA
KYD4012	蛍7N23AA 蛍3N25DA
KYD4012A	蛍7N23AA 蛍3N25DA
KYD4712MS	蛍4N12DD 蛍3N25DA
KYD4712S	蛍4N12DD 蛍3N25DA
KYD4811A	蛍4NR-AC-TL 蛍3NR-CX-S
KYD4811VA	蛍4NR-AC-TL 蛍3NR-CX-S 音3NR-CX-S
KYH0651	3N12AB
KYH1041	3N12AB
KYH1041A	2N20DA
KYH1061	3N12DA
KYH1071	2N20DA
KYH1071A	2N20DA
KYH1091	FK172
KYH11101	3N12AB
KYH1701	2N06DA
KYH1731	2N06DA
KYH1851	4NR-AC-TL
KYH1851A	4NR-AC-TL
KYH20001	蛍4N19DA 蛍4N20DA 音12N05DA
KYH20001A	蛍3N23DA 蛍3N25DA 音12N05DA
KYH2061	4N19HA
KYH2071	3N23DA
KYH2071A	3N23DA
KYH21101	4N19DA
KYH2111	4N19DA
KYH21111	4N19HA
KYH2611	4N06DA
KYH2711	4N06DA
KYH2711H	4N12DD
KYH2711M	4N06DA
KYH2721M	蛍4N06DA 蛍3N25DA 音12N05DA
KYH2811HA	4NR-CX-S
KYH2851	4NR-AC-TL
KYH2851A	4NR-AC-TL
KYH2871A	4NR-AC-TL
KYH3061	9N19AA
KYH3071	6N23AA
KYH3071A	6N23AA
KYH4061	9N20AA
KYH4062	9N20AA
KYH4071	7N23AA
KYH4071A	7N23AA

器具形名	バッテリー形名
KYH4072	7N23AA
KYH4072A	7N23AA
KYH41101	9N20AA
KYH4612	4N12DD
KYH4712	4N12DD
KYH4712H	4N25HA
KYH4712M	4N12DD
KYH4722M	蛍4N12DD 蛍3N25DA 音12N05DA
KYH4811HA	4NR-CX-S
KYH4851	4NR-AC-TL
KYH4851A	4NR-AC-TL
KYH90001	12N05DA
KYT1851	—
LBB201BK	12N19AA
LBB201W	12N19AA
LBB211G	12N19AA
LBB211S	12N19AA
LBB221BK	12N19AA
LBB221W	12N19AA
LC-A1-101A	6N18EA
LC-A1-201A	12N18RA
LC-A1-202A	12N18RA
LC-A1-203A	12N18RA
LC-A1-206	12N18RA
LC-A1-207	12N18RA
LC-A1-401A	12N40RA
LC-A1-402	12N40RA
LC-A2-01	2N12FA
LC-A2-02	2N12FA
LC-A2-03	2N12FA
LC-A2-04	2N12FA
LCB0901	3N25GA
LCB102	6N19DA
LCB103	6N19DA
LCB11001	3N25GA
LCB11011	3H30GA
LCB1311	4N25GA
LCB15002	4N20DA
LCB2001	9N19EA
LCB2011	9N19GA
LCB2021	9N19GA
LCB2031	9N19GA
LCB210	12N19EA
LCB21001	3N30GA
LCB21011	3H30GA
LCB211	12N19EA
LCB212	12N19EA
LCB213	12N19EA
LCB3011	10N25GA
LCB3021	10N25GA
LCB3031	10N25GA
LCB3041	10N25GA
LCB31001	8N30GA
LCB31002	8N30GA
LCB31003	8N30GA

器具形名	バッテリー形名
LCB31004	8N30GA
LCB31011	3H30GA
LCB31012	3H30GA
LCB31013	3H30GA
LCB31014	3H30GA
LCB4001	9N40EA
LCB4011	15N23GA
LCB4021	15N23GA
LD-A1-101A	6N18EA
LD-A1-103A	6N18EA
LD-A1-202A	12N18RA
LD-A1-204	12N18RA
LD-A1-205	12N18RA
LD-A1-206	12N18RA
LD-A1-207	12N18RA
LD-A1-2402	9N19EA
LD-A1-404	12N40RA
LD-A1-405	12N40RA
LD-A1-408	12N40RA
LD-A1-408WD	12N40RA
LD-A1-4602	9N40EA
LD-A2-625	12N18BA
LDB0901	3N25JA
LDB10002	4N20DA
LDB11001	3N25JA
LDB11011	3H30JA
LDB1201	6N19EA
LDB1301	6N19EA
LDB1302	6N19EA
LDB1311	4N25JA
LDB1321	4N25JA
LDB1401	6N19DB
LDB1411	4N20GA
LDB2001	9N19EA
LDB2011	9N19EA
LDB21001	3N30JA
LDB21001LAW	3N30JA
LDB21011	3H30JA
LDB23001	3N30JA
LDB23011	3H30JA
LDB2403	12N19EA
LDB2404	12N19EA
LDB2405	12N19EA
LDB2411	9N19EA
LDB2411Z	9N19EA
LDB2421	9N19GA
LDB2421Z	9N19GA
LDB2431	9N19GA
LDB2441	9N19GA
LDB2501	12N19EA
LDB2502	12N19EA
LDB2503	12N19EA
LDB2601	12N19AA
LDB2611	9N19GA
LDB2621	9N19GA