

器具形名	バッテリー形名
LDB2631	9N19GA
LDB3011	10N25JA
LDB3021	10N25JA
LDB3031	10N25JA
LDB3041	10N25JA
LDB3051	10N25JA
LDB3061	10N25JA
LDB3071	10N25JA
LDB3081	10N25JA
LDB3091	10N25JA
LDB31001	8N30JA
LDB31002	8N30JA
LDB31003	8N30JA
LDB31004	8N30JA
LDB31011	8H30JA
LDB31012	8H30JA
LDB31013	8H30JA
LDB31014	8H30JA
LDB33001	8N30JA
LDB33002	8N30JA
LDB33003	8N30JA
LDB33011	8H30JA
LDB33012	8H30JA
LDB33013	8H30JA
LDB35001	8N30JA
LDB35003	8N30JA
LDB35011	8H30JA
LDB35013	8H30JA
LDB4011	15N23GA
LDB4021	15N23GA
LDB4611	9N40EA
LDB4611Z	9N40EA
LDB4621	15N23GA
LDB4621Z	15N23GA
LDB4631	15N23GA
LDB4641	15N23GA
LVD6001	12N19EA
LVD60021	12N19EA
LVD6011	12N19EA
OR036311	8N30JA
OR036312	8N30JA
OR036313	8N30JA
OR036316	3N30JA
OR036501	8N30GA
OR036502	8N30GA
OR036503	8N30GA
OR036506	3N30GA
SYH4002	12N19AA
SYH4003	12N19AA
SYH4022	12N19AA
SYH4023	12N19AA
SYH4032	12N19AA
SYH4033	12N19AA
SYH4042	12N19AA
SYH4042E	8N25DA

器具形名	バッテリー形名
SYH4043	12N19AA
SYH4043E	8N25DA
SYH4182E	8N25DA
SYH4183E	8N25DA
SYK4002	4N23AA
SYK4003	4N23AA
SYK4022	4N23AA
SYK4023	4N23AA
SYK4032	4N23AA
SYK4033	4N23AA
SYK4042	4N23AA
SYK4042E	4N25DA
SYK4043	4N23AA
SYK4043E	4N25DA
SYK4182E	4N25DA
SYK4183E	4N25DA
WCB101	6N19RA
WCB1311	4N25GA
WCB21001	3N30GA
WCB21001	8N30GA
WCB3011	10N25GA
WCB3031	10N25GA
WCB31001	8N30GA
WCB31003	8N30GA
WFH21871	6N19EA
WFH21872	6N19EA
WFH22151	4N23DA
WFH22152	4N23DA
WFK41281	4N23AA
WFK41861	6N20AA
WFK42271	4N23AA
WFK42271E	4N25AA
WFK42281E	4N30AA
WHH41311	12N18AA
WHH41312	12N18AA
WHH41501	12N19AA
WHH41502	12N19AA
WHH41571	12N19AA
WHH41571E	8N25AA
WHH41572	12N19AA
WHH41572E	8N25AA
WHK4041	4N23AA
WHK4042	4N23AA
WHK4051	4N23AA
WHK4051E	4N25AA
WHK4061EF	4N30AA
WHK4062	4N23AA
WHK4062E	4N25AA
WHK4072EF	4N30AA
WHK4681	6N20AA
WHK4682	6N20AA
WKH2021	6N19EA
WKH2031	4N23AA
WKH2041	4N23AA
WKH2051	4N23AA

器具形名	バッテリー形名
WKH41041	12N19AA
WKH41321	12N19AA
WKH41321E	8N25AA
WKH41371	12N19AA
WKH41371E	8N25AA
WKK4041	4N23AA
WKK4041E	4N25AA
WKK4051	4N23AA
WKK4051E	4N25AA
WKK4061E	4N30AA
WKK4681	6N20AA
WPH2001	4N23AA
WSH1051	3N12DA
WSH1051A	3N12DA
WSH1051B	2N23DA
WSH1051C	2N23DA
WSH1061	3N12DA
WSH1061A	3N12DA
WSH1061B	2N23DA
WSH1061C	2N23DA
WSH11041	3N12DA
WSH11121	3N12DA
WSH11121A	3N12DA
WSH11121B	2N23DA
WSH1711	FK112
WSH1851	4NR-AC-TL
WSH1851A	4NR-AC-TL
WSH1862	4NR-AC-TL
WSH1862A	4NR-AC-TL
WSH1871A	4NR-AC-TL
WSH1882A	4NR-AC-TL
WSH2071	4N19DA
WSH2071A	4N19DA
WSH2071B	3N23DB
WSH2081	4N19DA
WSH2081A	4N19DA
WSH2081B	3N23DB
WSH2711	FK610
WSH2851	4NR-AC-TL
WSH2851A	4NR-AC-TL
WSH2862	4NR-AC-TL
WSH2862A	4NR-AC-TL
WSH2871A	4NR-AC-TL
WSH2882A	4NR-AC-TL
WSH2891A	4NR-AC-TL
WSH41031	9N20AA
WSH41032	9N20AA
WSH41041	9N20AA
WSH41042	9N20AA
WSH42111	7N23AA
WSH42111A	7N23AA
WSH42111B	7N23AB
WSH42112	7N23AA
WSH42112A	7N23AA
WSH42112B	7N23AB