


Automating the World

FACTORY AUTOMATION

Mitsubishi Electric AC Servo System MELSERVO-J5

Innovate Together











Our Factory Automation business is focused on "Automating the World" to make it a better, more sustainable environment supporting manufacturing and society, celebrating diversity and contributing towards an active and fulfilling role.



The Mitsubishi Electric Group is actively solving social issues, such as decarbonization and labor shortages, by providing production sites with energy-saving equipment and solutions that utilize automation systems, thereby helping towards a sustainable society. Mitsubishi Electric is involved in many areas including the following:

Energy and Electric Systems

A wide range of power and electrical products from generators to large-scale displays.

Electronic Devices

A wide portfolio of cutting-edge semiconductor devices for systems and products.

Home Appliance

Dependable consumer products like air conditioners and home entertainment systems.

Information and Communication Systems

Commercial and consumer-centric equipment, products and systems.

Industrial Automation Systems

Maximizing productivity and efficiency with cutting-edge automation technology.

OVERVIEW

Concept ····· 4
■ Product Lines
Servo System ······ 14
Servo System Controllers24
■ Embedded Type Servo System Controller 60
■ MELSERVO-J5 68
■ Utilization of SSCNET III/H Device Assets ······ 100
■ Mitsubishi Electric Solutions/Partners/FA Global Website
Common Specifications (Combinations of Servo Motors and Servo Amplifiers, etc.) 1-1
■ Product Specifications of Servo System Controllers2-1
MELSERVO-J5 Product Specifications
Servo Amplifiers3-1Direct Drive Motors6-1Rotary Servo Motors4-1Options/Peripheral Equipment7-1Linear Servo Motors5-1Low-Voltage Switchgear/Wires8-1
■ Product List ······9-1
■ Precautions
■ Support11-1


Compliance with the indicated global standards and regulations is current as of the release date of this catalog. Contact your local sales office for the latest information. 3



Create new value with **MELSERVO-J5**. **Unlock** performance with a total drive solution.

Maximize system performance





Predictive/preventative maintenance

Corrective maintenance

Zero maintenance

 Interchangeability with previous generation models

For quick operation start

Create a cutting-edge servo system together with MELSERVO-J5

Maximize the performance of your system and equipment with MELSERVO-J5 total drive solutions

Progressiveness



For evolution of machines

The dramatically improved basic performance of MELSERVO-J5 and CC-Link IE TSN enable total drive solutions that help to increase production efficiency and keep your equipment on the cutting edge.

Performance improvement

- High-speed/high-accuracy/multi-axis
- Vibration suppression
- Compact and energy efficient

Program standardization

- Conforms to IEC 61131-3
- Function blocks for motion control
- Synchronous control /cam control

Connectivity



For flexible system configurations

CC-Link IE TSN enables a high degree of compatibility with IoT technology. Our servo system provides new opportunities for value creation with highly integrated connectable devices and a dramatically expanded range of compatible devices.

Integration with connectable devices

- CC-Link IE TSN
- Connection with TCP/IP devices

Usability



For quick operation start


Our intuitive and user-friendly products are designed to make program development as simple as possible. From system design to maintenance, efficiency is improved at each step of the development process through software and sizing tool enhancement.

Tool enhancement

- Simple programming
- Drive system sizing software/ FA Integrated Selection Tool
- Collaboration with partners

Improved drive system usability

- Single connector/one-touch lock
- Single/dual cable types
- Servo adjustment



Maintainability



For prompt detection and diagnosis of failures

Not only realization of zero maintenance, but the machine downtime can be significantly reduced by prompt error detection and diagnostics.

Years of technical know-how and state of the art drive technology can realize predictive and planned maintenance.

Predictive/preventive maintenance

Machine diagnosis

Zero maintenance

Batteryless absolute position encoder

Heritage



For utilization of existing devices

Incorporate existing manufacturing devices into your new system and benefit from reduced costs and faster construction speed.

Interchangeability with previous generation models

- Simple Motion mode
- SSCNET III/H-compatible MR-J5-B

Corrective maintenance

Servo system recorder

Created using a brand-new approach, this new-generation servo system contributes to reducing the TCO through improved productivity

Focused on improving total performance.

The MELSERVO-J5 series servo system boasts industry-leading level basic performance. The high-speed, high-precision capabilities of MELSERVO-J5 help to increase the productivity of your machines.



CC-Link IE TSN

CC-Link IE TSN supports TCP/IP communications and applies it to industrial architectures through its support of TSN enabling real-time communications. With its flexible system architecture and extensive setup and troubleshooting features make CC-Link IE TSN ideal for building an IIoT infrastructure across the manufacturing enterprise.

* TSN: Time Sensitive Networking * IIoT: Industrial Internet of Things



Motion modules and Motion Control Software are available in our product lines. Select a controller suitable for your machine.

Motion Modules

The following operation modes are selectable: Simple Motion mode that enables utilization of existing projects and PLCopen® motion control FB mode that enables structured programming. MELSEC iQ-R series Motion modules utilize a multi-core processor to achieve enhanced performance.

Motion Control Software

Installed on a personal computer, Motion Control Software can perform motion control.



Servo Amplifiers

The MELSERVO-J5 series high-performance, industry-leading servo amplifiers feature a unique control engine that is more powerful than ever before.

MR-J5W-G/MR-J5W-B multi-axis servo amplifiers and MR-J5D-G4 drive units simplify wiring and enable a compact machine.

CC-Link IE TSN-Compatible Servo Amplifiers

MR-J5-G/MR-J5D-G4 servo amplifiers can connect to CC-Link IE TSN to perform high-speed, high-precision control.

SSCNET III/H-Compatible Servo Amplifiers

MR-J5-B servo amplifiers can connect to SSCNET III/H and utilize the existing program assets to improve the machine performance.

Rotary Servo Motors

The HK series rotary servo motors are equipped with a 26-bit resolution batteryless absolute position encoder as standard.

Batteryless Absolute Position Encoders

Mitsubishi Electric's unique multi-revolution detection method allows the saving of absolute position data without a battery.

Single Connector/One-Touch Lock/Single Cable Type


The servo motor power supply, encoder, and electromagnetic brake can be connected using only a single cable.

The one-touch lock makes wiring easy.

* "Industry-leading level" refers to results from a Mitsubishi Electric December 2023 research study.



Innovate Together






We take full advantage of Mitsubishi Electric's technological capability that achieved development of FA devices, along with our connectivity technology which makes it possible to connect FA with IT.

e-F@ctory optimizes manufacturing overall by connecting all devices and equipment, and then analyzing and utilizing the vast amount of data collected.

Create new value with MELSERVO-J5. Unlock performance with a total drive solution





Through powerful alliances between Mitsubishi Electric, who boasts a broad-ranging product appeal in the FA domain, and partners that participate in the FA partnership program (e-F@ctory Alliance) promoted by Mitsubishi Electric, we will achieve new business creation and new monozukuri.

Servo System Controllers (Note 3)

	Servo system controller	Number of control axes	Features
Motion m	RD78G RD78GH	RD78G: 4, 8, 16, 32, 64 RD78GH: 128, 256	 MELSEC iQ-R series CC-Link IE TSN-compatible Motion module Performs motion control (positioning, synchronous, cam, speed, and torque control) Maximum number of connectable stations: 120 ^(Nole 2) Minimum operation cycle RD78G: 62.5 [μs], RD78GH: 31.25 [μs] Number of slots occupied RD78G: 1, RD78GH: 2
modules	FX5-SSC-G	FX5-40SSC-G: 4 FX5-80SSC-G: 8	 MELSEC iQ-F series CC-Link IE TSN-compatible Motion module Performs motion control (positioning, synchronous, cam, speed, and torque control) Maximum number of connectable stations FX5-40SSC-G: 20, FX5-80SSC-G: 24 ^(Note 2) Minimum operation cycle: 500 [µs] Number of connectable modules: 4 modules/FX5U or FX5UC
Motion Control Software	SWM-G (Note 4)	16, 32, 64, 128	 CC-Link IE TSN-compatible Motion Control Software for personal computers (Note 1) Performs motion control (positioning, synchronous, cam, speed, and torque control) Maximum number of connectable stations: 128 (Note 2) Includes Real Time OS (RTX64), which enables SWM-G to perform a real-time operation without being affected by the operation on Windows[®] Programming language: Visual C++[®]

 Notes: 1. A personal computer and Visual Studio[®] are not included and must be prepared by the user.

 2. The multi-axis servo amplifiers MR-J5W2-G/MR-J5D2-G4/MR-J5D3-G4 occupy one station.

 3. For SSCNET III/H-compatible servo system controllers, refer to catalogs and manuals of MELSEC iQ-R series and MELSEC-Q series.

 4. SWM-G-N1 is also compatible with EtherCAT[®].

Servo Amplifiers

∎Se	rvo Amplifi	ers																	•: S	upp	orteo	- b	-: N	ot su	uppo	rted
					i		mma face		3)	Control mode					Compatible servo motor series											
Ser	vo amplifiers	Number of control axes	Power supply specifications (Note 2)	Rated output [kW] (Note 1)	CC-Link IE TSN	EtherCAT [®] (Note 5)	SSCNET III/H	Pulse train	Analog voltage	Position	Velocity/Speed	Torque	Fully closed loop control	НК-КТ	HK-MT	HK-ST	HK-RT	LM-H3	LM-AJ	LM-F	LM-K2	LM-U2	LM-AU	TM-RG2M	TM-RU2M	TM-RFM
	MR-J5-G	1 axis	200 V AC	0.1, 0.2, 0.4, 0.6, 0.75, 1, 2, 3.5, 5, 7	•	•	-	_	-	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
		T dxis	400 V AC	0.6, 1, 2, 3.5, 5, 7	•	•	-	-	-	•	•	•	•	•	_	•	•	-	-	-	-	-	-	-	-	-
CC-Link IE TSN	MR-J5W-G	2 axes	200 V AC	0.2, 0.4, 0.75, 1	•	•	-	_	-	•	•	•	•	•	•	•	•	•	•	-	•	•	•	•	•	•
(IE TSN		3 axes	200 7 110	0.2, 0.4	•	•	-	-	-	•	•	•	-	•	•	•	-	•	•	-	•	•	•	•	•	•
	MR-J5D-G4 (Note 4)	1 axis		1, 2, 3.5, 5, 7	•	•	-	-	-	•	•	•	•	•	-	•	\bullet	-	-	-	-	-	-	-	-	-
		2 axes	400 V AC	1, 2, 3.5, 5, 7	•	•	-	-	-	•	•	•	•	•	-	•	•	-	-	-	-	-	-	-	-	-
		3 axes		1, 2	•	•	-	-	-	•	•	•	-	•	_	•	•	-	_	-	-	-	-	-	-	_
	MR-J5-B	1 axis	200 V AC	0.1, 0.2, 0.4, 0.6, 0.75, 1, 2, 3.5, 5, 7	-	-	•	-	-	•	•	•	•	•	•	•	•	•	-	•	•	•	-	•	•	
SSCNET III/H		Tuxis	400 V AC	0.6, 1, 2, 3.5, 5, 7	-	-	•	-	-	•	•	•	•	•	-	•	•	-	-	-	-	-	-	-	-	-
ET III/H	MR-J5W-B	2 axes	200 V AC	0.2, 0.4, 0.75, 1	-	-	•	-	-	•	•	•	•	•	•	•	•	•	-	-	•	•	-	•	•	•
		3 axes	200 V AO	0.2, 0.4	-	-	•	-	-	•	•	•	-	•	•	•	-	•	-	-	•	•	-	•	•	•
General-purpose interface	MR-J5-A	200 V A0	200 V AC	0.1, 0.2, 0.4, 0.6, 0.75, 1, 2, 3.5, 5, 7	-	-	-	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
purpose face			400 V AC	0.6, 1, 2, 3.5, 5, 7	-	-	-	•	•	•	•	•	•	•	-	•	•	-	-	-	-	-	-	-	-	-

Notes: 1. The value listed is the serve amplifier rated output. Refer to "Combinations of Serve Motors and Serve Amplifiers" for compatible serve motors.
2. 200 V AC serve amplifiers are also compatible with DC power supply input as standard.
3. MR-JS-GMR-JSD1-G4 are also compatible with CC-Link IE Field Network Basic.
4. An MR-CV_4 power regeneration converter unit is required for MR-JSD-G4 drive units.
5. EtherCAT[®] is supported by MR-JS-G-N1/MR-JSD-G4-N1.

■Rot	ary Servo Motor	S						•: Suppor	ted -: Not supported
Rotary servo motor serio		Rated speed [r/min] (Note 2)	Rated output [kW] ^(Note 1)	With an electro- magnetic brake (B)	With a gear reducer (G1, G5, G7) (Note 4)	gear IP educer rating , G5, G7) ^(Note 3)		Features	Application examples
Small capacity	HK-KT series	3000 (6700)	0.05, 0.1, 0.15, 0.2, 0.4, 0.6, 0.75, 1.0, 1.5, 2.0 0.4, 0.6, 0.75, 1.0, 1.5, 2.0	•	•	IP67		Low inertia Batteryless absolute position encoder Includes flat type models Has a single connector	Belt drives Robots X-Y tables Semiconductor manufacturing systems
apacity	HK-MT series	3000 (6700/ 10000)	0.05, 0.1, 0.15, 0.2, 0.4, 0.6, 0.75, 1.0	•	_	IP67	HG-MR	Ultra-low inertia Batteryless absolute position encoder Includes high-speed type models (^{Note 5)} Has a single connector	Inserters Mounters Ultra-high-throughput material handling systems
Medium c	HK-ST series	2000/ 3000 (4000/ 6700)	0.5, 0.75, 1.0, 1.75, 2.0, 3.0, 3.5, 5.0, 7.0 0.5, 1.0, 1.75, 2.0, 3.0, 3.5, 5.0, 7.0	•	•	IP67	HG-SR HG-JR HG-UR	Medium inertia Batteryless absolute position encoder Includes flat type models Offers two rated speeds	Material handling systems Battery manufacturing systems Printing systems Food packaging machines
capacity	HK-RT series	3000 (6700)	1.0, 1.5, 2.0, 3.5, 5.0, 7.0 1.0, 1.5, 2.0, 3.5, 5.0, 7.0	•	_	IP67	HG-RR	Ultra-low inertia Batteryless absolute position encoder Has a single connector (1 to 2 kW)	X-Y tables Ultra-high-throughput material handling systems

 Notes: 1.
 : For 400 V.

 2.
 The value in brackets indicates the maximum speed. The speed varies by the model type. Refer to "Rotary Servo Motors Specifications" for details.

 3.
 The shaft-through portion is excluded. For general area workers, IP rating of the reducer part is equivalent to IP44.

 4.
 G1 indicates a gear reducer for general industrial machines, and G5 and G7 indicate a gear reducer for high precision applications. HK-KT series servo motors are available in 200 V only. Refer to "Rotary Servo Motors Specifications" for details.

 5.
 The high-speed type models (maximum speed of 10000 r/min) are equipped with an incremental encoder.

■Linear Servo Motors

Linea	r servo motor series	Maximum speed [m/s]	Continuous thrust [N]	Maximum thrust [N]	Cooling method	Features	Application examples
	LM-H3 series	3.0	70, 120, 240, 360, 480, 720, 960	175, 300, 600, 900, 1200, 1800, 2400	Natural cooling	Suitable for space-saving Compact size and high thrust	Mounters Wafer cleaning systems FPD assembly machines Material handlings
Co	LM-AJ series	2.0 to 6.5		214.7, 369.0, 429.4, 550.2, 704.5, 738.1, 1100.4, 1409.1	Natural cooling	Low installation height, and suitable	Semiconductor manufacturing systems FPD assembly machines
Core type	LM-F series	2.0	300, 600, 900, 1200	1800, 3600, 5400,	Natural cooling	The integrated liquid cooling	Press feeders NC machine tools
		2.0	600, 1200, 1800, 2400	7200	Liquid cooling	system doubles the continuous	Material handlings
	LM-K2 series	2.0	120, 240, 360, 720, 1200, 1440, 2400	300, 600, 900, 1800, 3000, 3600, 6000	Natural cooling	Magnotic attraction counter toreo	Mounters Wafer cleaning systems FPD assembly machines
Coreless type	LM-U2 series	2.0	50, 75, 100, 150, 225, 400, 600, 800	150, 225, 300, 450, 675, 1600, 2400, 3200	Natural cooling		Screen printing systems Scanning exposure systems Inspection systems Material handlings
ss type	LM-AU series	2.0 to 4.5	28, 44, 57, 85, 88, 113, 132, 176, 264, 350	122, 274, 280, 411, 549, 561, 842, 970, 1684, 1764	Natural cooling	structure extends life of the linear	Screen printing systems Scanning exposure systems Inspection systems Material handlings

Direct Drive Motors

Direct	t drive motor series	Motor outer diameter [mm]	Hollow shaft diameter [mm]	Rated speed [r/min]	Maximum speed [r/min]	Rated torque [N⋅m]	Maximum torque [N·m]	IP rating (Note 1)	Features	Application examples
6	TM-RG2M series/ TM-RU2M series	ø130	ø20	300	600	2.2	8.8	IP40	Suitable for low-speed and	
Low-profile		ø180	ø47	300	600	4.5	13.5	1P40	high-torque operations Smooth operation with	Semiconductor
ïle		ø230	ø62	300	600	9	27	IP40	The motor's low-profile	manufacturing devices
т	TM-RFM series	ø130	ø20	200	500	2, 4, 6	6, 12, 18	1 1242		Liquid crystal manufacturing
High-rigidity	and p	ø180	ø47	200	500	6, 12, 18	18, 36, 54		a low center of gravity for enhanced machine	devices Machine tools
igidity	19	ø230	ø62	200	500	12, 48, 72	36, 144, 216	IP42	stability. Clean room compatible	
		ø330	ø104	100	200	40, 120, 240	120, 360, 720	IP42	clean room compatible	

13

Notes: 1. Connectors and the gap along the rotor (output shaft) are excluded.

Construct a high-performance servo system using our extensive product line

We understand that each system is different and has unique drive control requirements. To meet these demands, we have expanded the product line for our next-generation servo system to offer simple converters, engineering software, servo system controllers, servo amplifiers, servo motors, and a variety of other components.

Mitsubishi Electric is dedicated to satisfying all of our customers' needs.



e Fectory Alliance

Collaboration with partners

Inverte

Collaborating with our extensive group of partners allows us to flexibly support your system needs

Servo systems are constructed using iQ Platform devices such as controllers, servo drivers, actuators, and sensors, and collaboration with our partner companies allows us to expand the number of possibilities available to customers. For example, partner products such as stepping motors, direct drive motors, vision systems, and various types of software are available to keep your equipment on the cutting edge.

Single network

CC-Línk**IE TSN**

Safety I/O combined module

I/O module

Servo Motors

CC-Link IE TSN safety communication function Deterministic control even when mixed with TCP/IP communication and safety control communication

CC-Link IE TSN enables mixing of safety and non-safety communications.*¹ Safety sub-functions (STO, SS1, SS2, SOS, SLS, SBC, SSM, SDI, SLI, SLT) are also supported for drive-control devices that are on the network.


Deterministic performance of cyclic communication is maintained even when mixed with slower information data (non real-time). This enables TCP/IP communication devices to be used without affecting overall control.

*1. Some devices cannot be connected to CC-Link IE TSN depending on the system configuration.

Analog output module

Open integrated networking across the manufacturing enterprise CC-LínkIE TSN

CC-Link IE TSN supports TCP/IP communications and applies it to industrial architectures through its support of TSN enabling real-time communications. With its flexible system architecture and extensive setup and troubleshooting features make CC-Link IE TSN ideal for building an IIoT infrastructure across the manufacturing enterprise. *TSN: Time Sensitive Networking * IIoT: Industrial Internet of Things



Real-Time Network Performance Even When Integrated with Information Data


TSN technology enables mixing of deterministic communications with IT system information data on the same network. Giving higher priority to CC-Link IE TSN cyclic communications and TCP/IP communications by allocating increased network bandwidth, devices using general Ethernet communications can be connected on the same network while maintaining real-time control communication performance.

CC-Link IE)	CC-Link IE)	CC-Link IE	
Other ne) TCP/IP) tworks) Other networks	тсрлр	ther networks	
		e protocols on sam			
CC-Link IE TSN	TCP/IP Time slot B	Other networks Time slot C	CC-Link IE TSN	TCP/IP Time slot B	

Deterministic Control Even When Mixed with TCP/IP Communication

Deterministic performance of cyclic communication is maintained even when mixed with slower information data (non real-time). This enables TCP/IP communication devices to be used without affecting overall control.






*1. Class B switching hub supporting CC-Link IE TSN recommended by the CC-Link Partner Association

Integrated Network

Current network systems use multiple networks to enable communication between IT and control systems on the shop floor. CC-Link IE TSN is a one-stop solution for integrating different networks, thereby realizing flexibility in topology and reducing wiring cost.




Network configuration example (includes functions and products planned for future support/release.)

High-Speed, High-Accuracy Motion Control


CC-Link IE TSN controls I/O modules while also maintaining high-speed motion control. The single network boosts machine performance.

- Motion control (high-speed processing)
- I/O control (low-speed processing)



Time Synchronization


Set time is completely synchronized among servo amplifiers, Motion modules, and PLC CPUs. This time synchronization enables accurate recording of the event history in chronological order, making it simple to identify the cause of errors.



Seamless Connectivity Between TCP/IP Devices and a Servo System


TCP/IP communication (information communication) can be mixed in the same line with the real-time control communications of CC-Link IE TSN.

CC-Link IE TSN device stations and TCP/IP devices can be connected on the same network, achieving a flexible and integrated network system. Note that the TCP/IP devices must be connected after servo amplifiers and I/O modules.



Large-Capacity Data Communications

CC-Link IE TSN is a high-speed, large-capacity 1 Gbps communications network that is capable of sending and receiving large amounts of data, such as manufacturing, quality, and control data from the production process. The network can transmit large recipe data or traceability data at high speeds without degrading the performance of servo system communications. In addition, Ethernet supported devices can directly and seamlessly connect to controllers on the same network line.



Network configuration example (includes functions and products planned for future support/release.)

Simple maintenance

Comprehensive diagnostic functions contribute to improved maintenance

Increasing the capacity of your production line is an important factor in this fiercely cost-competitive market. The MELSERVO-J5 series servo system provides various kinds of maintenance functions that predict and prevent unforeseen problems and enable quick recovery when trouble arises. These functions contribute to reduced downtime and increased productivity while protecting the quality of your products.

MELSERVO-J5 series servo amplifiers and servo motors are equipped with various predictive and preventative maintenance functions.

Predictive Maintenance (CBM)

Predictive maintenance, also known as Condition Based Maintenance (CBM), is the practice of detecting changes in machine vibration and friction so that parts can be replaced accordingly before they fail.


Performing predictive maintenance leads to increased machine capacity and helps to avoid system failure, reduce maintenance time, and improve both productivity and product quality.

Detects Changes in Vibration and Friction to Predict the Service Life of Mechanical Drive Components


[Machine diagnosis function]

The machine diagnosis function detects age-related deterioration based on the frictions and vibrations of mechanical drive components such as ball screws, belts, and gears. This function automatically generates a failure warning limit, detects errors, and outputs a warning upon signs of failure. Results of the failure are transmitted via CC-Link IE TSN to the Motion module and IT system and can be used for maintenance and overall machine diagnostics.





Estimated friction value is displayed.



Estimated backlash value is displayed.

Motors


Preventative Maintenance (TBM) *1

*1. TBM stands for Time Based Maintenance

Machine Diagnosis (Mechanical Drive Components)

This function estimates when a machine failure will occur based on the total travel distance of the servo motor and notifies when it is time for replacement if the rated service life of the mechanical drive components is set.


• Machine total travel distance failure prediction



Corrective Maintenance

Servo System Data Recording

The servo system recorder of RD78G/RD78GH Motion module automatically collects data of all the servo amplifiers when an error occurs. The drive recorder of the servo amplifier continuously monitors the servo status and records the status transition such as a trigger condition before and after an alarm for a fixed period of time.



Servo Amplifier Life Diagnosis

This function displays the cumulative energization time and the number of inrush relay on/off times. The data can be used to check service life of the parts as a rough guide.

- Cumulative energization time (Smoothing condenser/ cooling fan life span)
- The number of inrush relay on/off times (Inrush relay life)




An engineering environment that provides common, consistent usability throughout all product development phases

Programmable Controller Engineering Software

MELSOFT GX Works3

Program creation is largely dependent on the ability of the programmer; therefore, an enormous amount of time is often spent on creating a servo program where a high level of programming expertise is required.


"MELSOFT GX Works3" introduces a more intuitive, efficient, and user-friendly programming environment that revolutionizes the programming process and minimizes hassles.




[MELSOFT MR Configurator2]

The software has a variety of features which help users start up and conduct maintenance for servo amplifiers. Parameter settings, monitor display, diagnosis, test operation, and servo adjustments are easily performed.

-	-			-	-	-	-		-											
and in the lotson	E				22		5		-											
E.a.H	10	1	12	-	10	12	-			~			-	-	-					
No. No.	-	-	-	-	-	-	-													
ial bil constant a later fallen	-	-	-	-	4	-	-													
2 2	-	-	-	-	-	-	-													
	-		4	-		-														
ALL AND A	-	-	-	-	-	-	-													
And Address	-	-	4	-	-	-	-													
And Annual Annual	-		4	-	4		-													
	-	1	-	-	-	-	-													
			1	-	-66		-													
81.	10	1	e	5	p.	10	6	- 1				÷			-	-	-	-	-	÷



• All-in-one engineering platform MELSOFT GX Works3 allows you to set different modules in a single project, including the setting of a wide range of areas from servo amplifier parameters to PLC CPU data.



Globalization

[PLCopen® Motion Control FB]

[Conforms to IEC 61131-3]


PLCopen[®] Motion Control FB is a standardized interface, and therefore people other than the program designer can understand the programming, leading to reduced design and maintenance time.

MELSOFT GX Works3 realizes structured programming such as ladder and ST, making

To adhere to today's global production needs, MELSOFT GX Works3 supports multi-

language features at various levels, from the multiple language software menu system to





Servo System

device comment language switching features. Supported languages: English, Japanese, and Chinese.

project standardization across multiple users even easier.

[Multi-language support for global operations]

Heritage


Simple Motion Mode Simple Motion

The Simple Motion mode is an operation mode that enables the Motion module to utilize an existing project for driving servo amplifiers via CC-Link IE TSN. Reusing existing projects helps reduce program development time.



Features of Simple Motion Mode

- Positioning control can be easily performed with motion profile tables. Synchronous control can be executed only with parameter settings.
- Remote devices are connected via CC-Link IE TSN and programmed from PLC CPUs.
- Data that is synchronized with the motion operation cycle can be collected with the digital oscilloscope. The collected data is displayed in waveforms for operation verification.



Product Lines



CC-Línk**IE TSN** MELSEC iQ·R RD78G4: 4 axes RD78G8: 8 axes RD78G16: 16 axes



CC-Link**IE TSN** MELSEC iQF FX5-40SSC-G: 4 axes FX5-80SSC-G: 8 axes

24

Progressiveness



Select

PLCopen[®] Motion Control FB Mode PLCopen[®]

The PLCopen[®] motion control FB mode is an operation mode that supports programming with PLCopen[®] Motion Control FBs, enabling structured/component programming for standardization. When selecting this mode, the Motion module executes motion control with various advanced technologies such as

programming using PLCopen[®] Motion Control FBs in ST language and logging of motion control data.

Motion Module MELSEC i Q-R RD78GH RD78G

CC-Línk IE TSN



Motion Control FB Logging

ST language

PLCopen[®]

Advanced synchronous control FB

Program

ST language

<u>Motion m</u>odule

Motion control setting function

Motion control

Positioning control

Synchronous con

An example of programming by each module

.

ST

language

[Programming by PLC CPU and Motion modules]

Starts ST

language

Share

Motion modules can execute operations in place of the PLC

CPU. This reduces the operation burden on the PLC CPU and

Program

Ladder, FBD/LD,


ST language

C CPU

GX Works3

Features of PLCopen[®] Motion Control FB Mode

- The Motion modules are programmed in ST language. PLC CPUs are in ladder, FBD/LD, and ST language.
- The library of PLCopen® Motion Control FBs, which are compliant with international standards, is available for programming.
- Users can analyze the operation status with logging data on GX LogViewer, which improves debug efficiency.



A PLC CPU program starts operation of the Motion module, eliminating the need for users to create another program for the Motion module, reducing programming burden.

Product Lines







results in a shorter cycle time.

CC-Línk**IE TSN** MELSEC iQ R

RD78G4: 4 axes RD78G8: 8 axes RD78G16: 16 axes RD78G32: 32 axes RD78G64: 64 axes

Taking evolution to the next step with Simple Motion mode



Combined with a CC-Link IE TSN-compatible servo amplifier, the Motion modules create a high-performance servo system that improves machine capability.

- Connects remote I/O modules and FR-A800-GN inverters via CC-Link IE TSN.
- Connects TCP/IP devices, enabling a flexible system configuration.
- Possible to reuse the existing projects of Simple Motion modules.

Product Lines



MELSEC i Q-R RD78G4 RD78G8 RD78G16

- Maximum number of control axes: RD78G16: 16 axes/module
- Minimum operation cycle^{*1}: 250 [µs]



- Maximum number of control axes: FX5-80SSC-G: 8 axes/module
- Minimum operation cycle^{*1}: 500 [µs]
- Maximum number of connected modules*2: 4 modules/system

Simple Motion

 *1. The operation cycle varies by the number of control axes and the models.
 *2. This refers to the total number of the Motion modules and one FX5-CCLGN-MS (master station).


1X5-00EGIN-IVIS (master stati

Reuse of Existing Projects

The existing projects of a Simple Motion module can be reused. This enables reduction in program development time.


RD77MS**⇒**RD78G

Select [Change Module] in the navigation menu of GX Works3 to convert the Simple Motion module project to a Motion module project. After the conversion, set the network parameters, servo amplifier parameters, and other parameters.



QD77MS⇒RD78G

Select [Import Simple Motion Module Data] in the navigation menu of GX Works3 to import the parameters of QD77MS. After the import, set the network parameters, servo amplifier parameters, and other parameters.




Improved Performance Simple Motion The minimum operation cycle of RD78G in Simple Motion mode is approximately 1.7 to 3.5 times faster than that of the previous models. The data from the servo amplifiers and input/output signals can be received at high speeds, which reduces the cycle time. Approx. Approx. Minimum operation cycle 1.7 times faster 1.7 times faster RD78G4 250 µs FX5-40SSC-G 500 µs RD77MS4 444 µs FX5-40SSC-S 888 µs Approx. 3.5 times faster RD78G4 250 µs QD77MS4 888 µs

System Configuration

The Motion module can function as a master station of CC-Link IE TSN.*1

This feature enables users to create a system more flexibly by connecting various devices, such as servo amplifiers, remote I/O modules, and TCP/IP devices, to the Motion module.*⁴



*1. Sub-master station is not supported.

*2. Standard stations refer to device stations other than motion control stations on CC-Link IE TSN

3. TCP/IP devices are not included in the standard stations.
 *4. Refer to manuals for precautions when CC-Link IE TSN Class B and A devices are mixed.


5. RD786 can connect up to 120 stations, which is the total number of the motion control stations and standard stations. FX5-SSC-G can connect 16 standard stations and the motion control stations.

Simple Motion

Positioning Control

Positioning control is easily executed using a motion profile table.


- To meet various application needs, the Motion module offers various types of positioning control, such as linear interpolation, 2-axis circular interpolation, fixedpitch feed, and continuous path control.
- Positioning control can be executed easily by setting the positioning address, the speed, and other setting items in a sequence program.
- Powerful sub-functions, such as M-code output, skip, speed change, and target position change functions, are available.



Simple Motion


Programming

The Motion module easily executes positioning operation with the instruction in a sequence program that starts a positioning data of the motion profile table.



Target Position Change Function


The target position can be changed at any time even when the products are being moved (1-axis linear control). The product is examined with the vision system while being moved to the next line. If a faulty product is found, the target position is changed so that the faulty product is put in a separate tray for those rejected.



Advanced Synchronous Control

Synchronous control can be achieved using software instead of controlling mechanically with gears, shafts, clutches, speed change gears, cams, etc.

- Synchronous control can be flexibly started/ended for each axis, enabling the synchronous control axis and positioning control axis to be used within the same program.
- Command generation axis, servo input axis, or synchronous encoder axis can be set as the input axis.
- The output axis is operated with a cam. The following three operations can be performed with the cam functions: linear operation, two-way operation, and feed operation.
- An incremental synchronous encoder*1 can be connected via a servo amplifier.




*1. When connecting an absolute position synchronous encoder, use an encoder of HK series servo motors.

[Command generation axis]

Command generation axis is the axis that performs only the command generation.


It is controlled independently of other axes connected to servo amplifiers. (not counted as a control axis)

Parameter Settings



Synchronous control is executed by setting parameters of the input axis, output axis, gear, and clutch for synchronous control and turning on the synchronous control start signal.


Cam Data (Operation Profile Data)



The cam graph can be flexibly and easily created through drag & drop. The waveform is changed according to the pointer's movement.

Start/Stop

Synchronous control can be executed after synchronous parameters are set for each output axis. When synchronous control start signal is turned on, the synchronous control parameters are analyzed, and the status is changed to during synchronous control. The output axis is operated by the commands transmitted from the input axis.




Simple Motion

Selectable Speed Control to Best Fit Your System Needs

Two types of speed control are available: speed control that includes position loop and speed control that does not include position loop.

Speed Control That Does Not Include Position Loop


- Control mode setting of the servo amplifier: velocity control mode
- Minimizes speed deviation by flexibly responding to speed changes, such as those that occur when the load changes.
- Suitable for machines which keep driving the motors at constant speed, such as a wind/unwind machine.



Simple Motion

Speed Control That Includes Position Loop

- Control mode setting of the servo amplifier: position control mode
- Suitable for operations that repeatedly switch between speed and position control.



Belt conveyor

Simple Motion

Torque Control

Torque Control

The axes in torque control are controlled to run at the constant torque by following the torque command.


When the load is light and the speed increases to the set limit, the torque control switches to speed control.



Continuous Operation to Torque Control

The axes are controlled to run at the constant torque by following the torque command while the current position is being tracked.

The position control can be switched smoothly to the torque control without stopping the servo motor.




30

Auxiliary Functions

Inter-Module Synchronization*1

The inter-module synchronization function can synchronize the control timing between multiple Motion modules on the same base unit.


Even different machines can be synchronized through this function when each machine uses Motion modules.



*1. The function is available with RD78G.

Read/Write Operation of Standard Stations


- The PLC CPU sends/receives link devices to/from standard stations (device stations other than the motion control stations) through a Motion module.
- One-to-one communication is possible between the master and device stations.
- The PLC CPU can be programmed using the signals of the device stations.



Automatic Return

When device stations are back to normal status after disconnected due to a data link error, this function automatically returns the disconnected stations to the network and restarts data link. Only the machine where an error occurred can be turned off, and parts can be replaced without turning off the power of the entire system.

Simple Motion




Mark Detection

This function latches data responding to a trigger signal input to a servo amplifier.

The compensation amount is calculated based on the latched data, and the error is compensated using a compensation axis.

A high-accuracy mark detection at 1 µs is possible.



CC-Link IE TSN Safety Communication Function


CC-Link IE TSN enables control of safety and non-safety communications realizing a flexible system whereby safety communications can be easily incorporated into the main control network.

Simple Motion

Simple Motion

In the following system which integrates safety and non-safety communications, the safety CPU checks the safety signals received via the safety remote I/O module and outputs the safety signals (STO, etc.) to the servo amplifiers. Outputting safety signals via the network eliminates the need for wiring of safety signals to a safety controller and a servo amplifier.


The CC-Link IE TSN safety communication function is available with iQ-R series Motion modules.



*1. For servo amplifiers that support the safety communication function, refer to "Safety Sub-Functions" in section 1 of this catalog.


Optional Data Monitor

Servo operation is monitored with extensive servo data acquired via CC-Link IE TSN. The acquired data can be transferred to IT system or transferred and displayed on any user-created GOT screen in the network. The target data for monitoring can be flexibly changed during operation.



Driver Communication Function*1

By using the driver communication function of the servo amplifier, the master axis is controlled with the Motion module, while the following axes are controlled by data communication between servo amplifiers (driver communication) without using the Motion module. The Motion module can drive multiple axes by controlling only the master axis.



A Wide Variety of Features

JOG operation

Moves a workpiece in the designated direction while the JOG start signal is ON.

JOG operation can be executed without completing home position return.

Absolute position system

Restores the absolute position of the designated axis.

Once the home position return is executed at the start of the system, it is unnecessary to perform the home position return again when the power is turned ON next time.

Stop operation functions

Simple Motion

The forced stop, the axis stop, and the forced stop of servo amplifiers are available.

Virtual servo amplifier

Enables operations of a virtual servo amplifier as if an actual unit is connected.

When the virtual servo amplifier is set as a servo input axis of synchronous control, the Motion module executes synchronous control with virtually generated input commands.

In addition, this function is used to simulate an axis without an actual connection.

Stroke limit functions

Establish the physical movable range for a machine. The hardware stroke limit function and the software stroke limit function are available.

Target position change

Changes a target position to a newly designated target position at any timing during the position control (1-axis linear control).

Home position return control

Establishes a position as the starting point (or "Home position") of positioning control and performs positioning toward that starting point.

Torque limit function

Limits the torque generated by the servo motor. This function is used to protect the gear reducer and limit the pushing force applied to a stopper. It can control torque so that excessive force will not be applied to loads and machines.

Event history

Saves the error information and the operation for the module as an event in the CPU module and the Motion module.


Acceleration/deceleration processing function

Adjusts the acceleration/deceleration of each motion control so that the acceleration/deceleration curve is suitable for the machine.

Override

Changes the command speed by a specified percentage (0 to 300 %) for all controls to be executed.

One software, many possibilities



MELSOFT GX Works3 covers various aspects of development processes - parameter settings, servo adjustments, and debugging of Motion modules as well as sequence program creation. This software offers an engineering environment that provides comfortable design environment.

Engineering Environment

Various features are integrated into GX Works3, which allows users not only to easily create projects but also maintain consistency through the entire development processes.

Programming

creation with a variety of

Synchronous control only

with parameter settings

Highly flexible cam data

Easy positioning data

functions

creation



- System configuration by simply selecting modules from a list
- Easy parameter settings for each module
- Parameters settable for reduction ratio and electronic gear




Simple Motion

- Simulation without actual devices
 - Automatic servo adjustments
 - Digital oscilloscope that allows operation verification and quick troubleshooting






- Module configuration
- Network configuration
- Data settings for servo amplifiers
- Settings for remote I/O
- Parameter conversion function



- Synchronous control parameter
- Cam data creation, cam data list

Programming (Positioning)



Programming

- Programming with Ladder, SFC, FBD/LD
- Positioning data settings
- Offline simulation, automatic calculation of command speed
- <image><section-header><complex-block>
 - Event history
 - Current value history, start history, axis monitor
 - Servo monitor
 - Digital oscilloscope

0 5

Servo System Controllers

Unlock new system capabilities together with CC-Link IE TSN



These Motion modules with multiple-core processors enable to configure a high-speed, large system by supporting the CC-Link IE TSN real-time open network.

- Performs positioning control such as linear interpolation using function blocks. The programming is easy: users just need to set
 positioning data to the function blocks.
- Connects to various modules such as servo amplifiers and I/O modules via CC-Link IE TSN. This connectivity allows you to configure a servo system more flexibly.
- Supports a consistent engineering environment that is capable of handling tasks ranging from system design to debugging and maintenance.

Product Lines



CC-Línk**IE TSN** MELSEC iQ-R RD78GHV RD78GHW

- Maximum number of control axes: RD78GHV: 128 axes/module RD78GHW: 256 axes/module
- Minimum operation cycle *¹: 31.25 μs
- ST language program capacity: Built-in ROM max. 64 MB
 + SD memory card

RD78GHV/RD78GHW are designed with a quad-core processor that enables higher-speed control. These Motion modules can be directly programmed to distribute load control with PLC CPUs.

This ensures that performance will not be degraded even when the number of axes is increased.



CC-Línk**IE TSN** MELSEC iQ-R RD78G4/RD78G8 RD78G16/RD78G32 RD78G64

PLCopen[®]

 Maximum number of control axes: RD78G64: 64 axes/module

- Minimum operation cycle *1: 62.5 µs
- ST language program capacity: Built-in ROM max. 16 MB + SD memory card

RD78G4/RD78G8/RD78G16/RD78G32/RD78G64 are designed with a dual-core processor and can be programmed to enable various types of control, such as positioning, synchronous, cam, speed, and torque control.

*1. The operation cycle varies by the number of control axes and the models.

Improved Performance


The minimum operation cycle of RD78GH in PLCopen[®] motion control FB mode is approximately 4.1 to 6.2 times faster than that of the previous models, and the number of maximum control axes is 4 to 8 times more. The data from the servo amplifiers and input/ output signals can be received at high speeds, which reduces the cycle time.

Maximum number of control axes		Operation cycle	Approx. 6.2 times faster
RD78GHW 256 axes		RD78GHW	125 μs/ 14 axes Approx. 4.1 times faster
RD78G64 64	4 times more	RD78G64	250 μs/ 14 axes
R64MTCPU 64 axes		R64MTCPU	222 μs/ 6 axes
Q173DSCPU 32 axes	8 times more	Q173DSCPU	222 μs/ 4 axes

System Configuration

PLCopen[®]

The Motion Module executes motion control while functioning as a master station of CC-Link IE TSN.*1 This feature enables users to create a system more flexibly by connecting various devices, such as servo amplifiers, remote I/O modules, and TCP/IP devices, to the Motion module.*^2




*1. Sub-master station is not supported. *2. Refer to manuals for precautions when CC-Link IE TSN Class B and A devices are mixed.

Inter-Module Synchronization

The inter-module synchronization function can synchronize the control timing between multiple Motion modules on the same base unit.

Even different machines can be synchronized through this function when each machine uses Motion modules.



PLCopen[®]

PLCopen[®]


Positioning Control


Two types of positioning control are available: single-axis and multi-axis positioning control. This variety allows you to meet various control needs.

Item	Control types		
Single-axis control	Positioning	Absolute positioning	
	Fositioning	Relative positioning	
	Homing		
	JOG operation		


Item	Control types		
	Linear	Absolute linear interpolation	
Multi ovio	interpolation	Relative linear interpolation	
Multi-axis control	Circular	Absolute circular interpolation	
CONTION	interpolation	Relative circular interpolation	
	Multiple axes positioning data operation		

Main Control





Multiple axes positioning data operation



vo System

39

Acceleration/Deceleration Methods

Three types of acceleration/deceleration methods are available: trapezoidal acceleration/deceleration, jerk acceleration/deceleration, and acceleration/deceleration time fixed.

Trapezoidal acceleration/deceleration

After starting, maximum acceleration is maintained until the target speed is reached.

For example, when a vehicle loaded with a workpiece accelerates suddenly, the workpiece will swing back and forth due to the impact of the sudden acceleration.

To reduce impacts and vibrations in a case such as this, the vehicle must accelerate at a slower rate.

The speed creates a trapezoidal shape.

Jerk acceleration/deceleration

PLCopen[©]

The acceleration changes gradually.

Gradual acceleration

Position

Speed

Jerk

Acceleration[®]

For example, when a vehicle loaded with a workpiece accelerates gradually, the load will not swing back and forth after acceleration. The jerk is maintained during acceleration. When the vehicle has almost reached the target speed, the jerk is decelerated. Adjusting jerk in this way achieves smooth acceleration/deceleration while also shortening the time it takes to reach the target speed. The speed creates a S-curve shape.


S-curve waveform

Set jerk

Acceleration time


Gradual deceleration

Time



Acceleration/deceleration time fixed method

This method executes acceleration/deceleration based on the time specified, regardless of the commanded speed.



*1. Input acceleration.*2. Specify acceleration time.

41

Synchronous Control


Synchronous control is performed using function blocks that operate as software-based mechanical modules such as gears, shafts, speed change gears, and cams.

PLCopen[®]

- Positioning and synchronous control can be performed together in the same program.
- Synchronous control using a synchronous encoder as an input axis is also possible.
- The output axis is operated based on cam data (operation profile).


Flexibly Combining Synchronous Modules

The number and the combination of the synchronous modules are flexibly selected, achieving optimized operation.




[Packing machines]

This application synchronizes all the axes, from the cutting axis through the unwinding axis, with the master axis. Cutting operation is performed with the cutting axis and the feeding axis 3.



Advanced Synchronous Control FB Settings with Graphic-Based Interface


Synchronous control can be executed by setting synchronous modules with parameters and starting the advanced synchronous control FB. Synchronous modules such as the auxiliary shafts, gears, clutches, and speed change gears can be set with a graphic-based interface.



Advanced synchronous control data

Images of enabled synchronous modules are highlighted, allowing easy verification of set data through visualization.

- Input axis data
- Synchronous parameter (output axis)
- Auxiliary shaft data
- Clutch data
- Gear data
- Speed change gear data
- Cam data (operation profile)
- Cam waveform type



43

Clutch

The clutch is used to transmit/disengage command pulses from the main/auxiliary shaft input side through turning the clutch ON/OFF, which controls the operation/stop of the output axis.

The clutch can be set to the main shaft clutch and the auxiliary shaft clutch.


Clutch ON control mode	Clutch OFF control mode	
Invalid	Invalid	
(Direct coupled operation)	(OFF control invalid)	
Clutch command	Clutch command	
Clutch command	(One-shot operation)	
Clutch command leading edge	Clutch command leading edge	
Clutch command trailing edge	Clutch command trailing edge	
Address mode	Address mode	
I/O data specification	I/O data specification	


A clutch can be used through the advanced synchronous control FB.

Restarting synchronous control

In case that the synchronous positions become misaligned due to an emergency stop, etc., synchronous control can be restarted by using the synchronous control analysis mode.

In the synchronous control analysis mode, the cam set position is updated on the basis of the input axis. The synchronous position can be aligned using the updated cam set position before starting synchronous control.






Advanced synchronous control data

Synchronous Encoder


The Motion module easily performs synchronous control by setting a synchronous encoder to "Real encoder axis" and creating a program with function blocks.

The number of command pulses can be adjusted using the function block (MC_Gearin) or a parameter. An incremental synchronous encoder^{*1} can be connected via a servo amplifier.



Switching Cam Control

The cam being executed can be flexibly switched to another cam without stopping the servo motor. Similarly, cam control is smoothly switched to position control with no need of stopping the motor.



45



Create cam data (operation profile data*1) according to your application. The created cam data is used to control an output axis. *1. "Operation profile data" is a general name for waveform data, which is used for various applications.


Cam Operation

The following three cam operations are available: linear operation, two-way operation, and feed operation. Choose one according to your application.

Linear operation

The cam pattern is a linear line.

This pattern is used for a ball screw and a rotary table.






Two-way operation

PLCopen[®]

The beginning and the end of the cam pattern are the same. Mechanical cams fall into this category.




Feed operation

The beginning and the end of the cam pattern differ.


This pattern is used for fixed-amount feed operations and intermittent operations.

Set the end point for the feed operation to a position of your choice.



Rotary table [Unit: degree]


Application examples



Only two axes synchronized Two arms synchronized

[Machine with only certain of the axes synchronized]

Only two axes are synchronized. The other axes perform positioning operation while the two axes execute synchronous control.




The two arms can avoid interference by synchronizing with each other, shortening the cycle time.



Cam Data Types

The cam data (operation profile data) has the following two types.



Easy Cam Creation for a Rotary Knife


Cam for a rotary knife is easily created by setting the sheet length and sheet synchronization width.

[Automatic cam creation from the motion control FB]

Setting the sheet length and sheet synchronization width, etc., to the function block and starting it create a cam automatically.


[Cam creation with MELSOFT GX Works3]

Setting the sheet length and sheet synchronization width, etc. creates a cam.



Cam Data in CSV Format

The cam data (operation profile data) in a CSV format on a personal computer can be imported directly to a Motion module.



Servo Amplifier Control Mode

PLCopen®

PLCopen[®]

The servo amplifier has three control modes: position, velocity, and torque control modes.

Execution of MC_MoveVelocity transitions the mode to the velocity control mode, and execution of MC_TorqueControl to the torque control mode.


In the velocity control mode or torque control mode, the mode

transitions to the position control mode in the following cases.

- At stop completion or error occurrence
- When a Motion control FB is changed/aborted

[Control mode]

Position control mode:	Moves to the target position
	(Speed control that includes position
	loop)
Velocity control mode:	Drives at the specified speed
	(Speed control that does not include
	position loop)
Torque control mode:	Drives at the specified torque




Selectable Speed Control to Best Fit Your System Needs

Two types of speed control are available: speed control that includes position loop and speed control that does not include position loop.


Speed Control That Does Not Include Position Loop

- Control mode setting of the servo amplifier: velocity control mode
- Minimizes speed deviation by flexibly responding to speed changes, such as those that occur when the load changes.
- Suitable for machines which keep driving the motors at constant speed, such as a wind/unwind machine.



Speed Control That Includes Position Loop

- Control mode setting of the servo amplifier: position control mode
- Suitable for operations that repeatedly switch between speed and position control.



Belt conveyor

Torque Control

Torque Control Mode

The axes in torque control are controlled to run at the constant torque by following the torque command. When the load is light and the speed increases to the set limit, the torque control switches to speed control.


Constant torque Speed control Torque control

PLCopen[®]

Application example

[Unwinding axis of converting machines]


Torque control unwinds film at constant tension to prevent wrinkling in the film. The tension can be kept constant by sequentially controlling the torque commands. This type of control is perfect for unwinding machines that need to keep the tension of unwound materials constant.




Continuous Operation to Torque Control Mode

The axes are controlled to run at the constant torque by following the torque command while the current position is being tracked.

The position control can be switched smoothly to the torque control without stopping the servo motor.



Application example






Flexible System Configuration with Multiple Topologies

PLCopen[®]

Line, star, and ring topologies are supported, allowing a flexible system configuration.


[Line topology]

Use a line topology for high-speed, high-performance control. This is realized when a system is configured with CC-Link IE TSN-compatible device stations only without additional branch lines.




[Star topology]

Choose a star topology if a more flexible system configuration is needed. Using Ethernet switches, device stations can be easily distributed to achieve the desired system configuration.



[Ring topology]*1 NEW

A ring topology is ideal for systems requiring high reliability. Data communication continues via multi-directional communication with normal stations even if a cable is disconnected or an error occurs on a device station.




*1. Available with RD78GH

Servo System Recorder

The Motion module automatically collects data of all servo amplifiers when an error occurs. The collected data, such as the command and the feedback values, greatly helps you analyze the error cause.

- Automatic collection of data, such as position, speed, and torque data, without programming
- Collecting data of all axes helps you locate the error cause even when the error is caused by the other axes without an error.
- The co-recording function collects data even when an error occurs in other recording devices.

[Data collection]




GX LogViewer

The collected data can be checked on GX LogViewer. The operation status before and after an error is displayed in waveforms, which allows more detailed analysis and identification of the error cause.

[Features]

- Displays the collected data and events graphically.
- Enables users to adjust a graph easily by automatic adjustment function and drag operation.




Analyzing Data

Analyzing operation transition of the Motion modules and the servo amplifiers before and after an error helps you locate the error cause.


[Example]

- 1. An error has occurred.
- 2. The speed and torque decreased even though the command position was increasing.

By analyzing the data in the recorder (1 and 2 above), users can find out a possible cause of the error, such as a disconnection of a power cable during operation.



PLCopen[©]



Servo data can be monitored during operation. Operation status of servo amplifiers and servo motors can be obtained via CC-Link IE TSN and transferred to IT system or displayed on any user-created GOT screen in the network.




CC-Link IE TSN Safety Communication Function

PLCopen[®]

CC-Link IE TSN enables control of safety and non-safety communications realizing a flexible system whereby safety communications can be easily incorporated into the main control network.

In the following system which integrates safety and non-safety communications, the safety CPU checks the safety signals received via the safety remote I/O module and outputs the safety signals (STO, etc.) to the servo amplifiers. Outputting safety signals via the network eliminates the need for wiring of safety signals to a safety controller and a servo amplifier. The CC-Link IE TSN safety communication function is available with iQ-R series Motion modules.



*1. For servo amplifiers that support the safety communication function, refer to "Safety Sub-Functions" in section 1 of this catalog.

A Wide Variety of Features

JOG operation

The Motion module outputs commands to an axis and operates the axis to the specified direction while the positive/ reverse rotation JOG command is inputted.

Absolute position system

Restores the absolute position of the designated axis. Once the home position return is executed at the start of the system, it is unnecessary to perform the home position return again when the power is turned ON next time.

Stroke limit functions

Establish the physical movable range for a machine. The hardware stroke limit function and the software stroke limit function are available.

Target position change

A target position can be changed using the buffer mode. During execution of an FB for position control, another FB to move to a new target position can be started at any timing.

Stop operation functions

PLCopen

The forced stop, the axis stop, the axes group stop, and the forced stop of the servo amplifier are available.

Axis emulate

Enables operations of a virtual servo amplifier as if an actual unit is connected.

This function enables to debug the user program at the startup of the device or verify the positioning operation.

File transfer

Executes file operation and data backup/restore based on the specified command.

Torque limit function

Limits the torque generated by the servo motor. This function is used to protect the gear reducer and limit the pushing force applied to a stopper. It can control torque so that excessive force will not be applied to loads and machines. The following two methods are available for changing the torque limit value: a method of using the dedicated FB and a method of changing the control data.

Event history

Saves the error information and the operation for the module as an event in the CPU module and the Motion module.

Acceleration/deceleration processing function

Adjusts the acceleration/deceleration of each motion control so that the acceleration/deceleration curve is suitable for the machine.

Override

Sets the factor for the velocity and performs the control to change the target velocity.

The following two methods are available for changing the override factor: a method of using the dedicated FB and a method of changing the control data.

One software, many possibilities



MELSOFT GX Works3 covers various aspects of development processes - parameter settings, servo adjustments, and debugging of Motion modules as well as sequence program creation. This software offers an engineering environment that provides comfortable design environment.

Engineering Environment

Various features are integrated into GX Works3, which allows users not only to easily create projects but also maintain consistency through the entire development processes.



System Design

- Network configuration settings
- Automatic detection of network configuration

Programming

- Easy programming in ST language
- More intuitive programming, which eliminates the need to remember devices or buffer memory addresses
- Easy access to axis information
- Operation profile data

Debug

- Various monitor functions, such as axis monitor, and ST language program monitor
- A simulator that debugs a program without an actual machine
- Real-time monitor of GX LogViewer

Maintenance

- Various monitor functions, such as axis monitor, and event history
- Security key authentication

Network Configuration Settings

[Network configuration settings]

• Intuitive network settings with drag-and-drop operations and a graphical screen view

[Automatic detection]

• By clicking the [Connected/Disconnected Module Detection] button, the connection status of device stations is automatically detected and the CC-Link IE TSN configuration screen is generated.



Programming

System Design Programming Debug Maintenance

PLCopen[©]

Maintenance

PLCopen


Operation Profile Data with Simple Settings

Operation profile data, such as cam data and cam for a rotary knife, is easily created.

• The cam graph can be flexibly and easily created through drag & drop. The waveform is changed according to the pointer's movement.

System Design 🗡

- Stroke, speed, acceleration, and jerk can be set while monitoring the changes on the graph.
- By setting "5th Curve (Adj)" for the cam curve types, the speed on a section border becomes smooth.
- Operation profile data for a rotary knife can be automatically generated by settings sheet length, synchronization width, cam resolution, etc.
- The created operation profile data can be checked on the list.



Lant -

5th Curve (Adj)


System Design Programming Debug	
Easy Programming through Structured Text Language	PLCopen [®]

. .

- Structured text programs are composed of function blocks, increasing program readability.
- Modularization of the programs increases their reusability.
- The consistent, common operability on a single engineering tool improves usability further.
- A wide selection of programming elements in the MELSOFT Library contributes to reducing programming time.
- The program is created by dragging & dropping programming elements, which simplifies the programming process.
- A startup time is reduced using the simulator of MELSOFT GX Works3 that can debug a program without an actual machine.

Programming Using Labels

- The control axes of the Motion modules and I/O signals are defined as label variables, which enables easy reuse of programs and helps to improve programming efficiency.
- The global labels created in the Motion module project can be used in PLC CPUs.



Axis Information is Easily Accessible

- Axis label variables can be used as an argument to refer axes in positioning function blocks.
- IntelliSense[®] function reduces programming mistakes.
- Access by variable names increases readability.

[Structured text editor]

19 20 21 22 23	bExecuteD # lePositionO bRelativeO : wExecutionMc deOptionsO :	:= 0.0; = FALSE; de0 := 1; = 0;		//Execute→IRUE //Target position is //Relative position s //Start mode=limeOue //option (Do not allo	ele ued	ction = absolute position (Stop and run)
24	Axis0001.Md.	-	UREAL	Acceleration Limit Value		1
26	bExecute1 ::	AccelerationOverride	LREAL	Acceleration Override Coefficient	÷.	
27 28	bContinuousl leVelocity1	Acceleration2eroBehavior		Operation Selection at Start Accelera	-	
28	leaccelerati		BOOL	Analysing		
30	Laflaca Larat I	-	BOOL	Automatically Decelerating		
31	leJerk1 ## 5	autoliame	WSTRING(127)			
32		avisStatus	INT	Axis Status		
33 34	THE REPORT OF THE PROPERTY OF	E BufferingFBs	DIT	Number of Buffering FBs		ration / deceleration desi
35	areperoner .	CmdinPos	8001	Command In-position		action y deceneration dest.
36		CondorPos_Width	UREAL	Command In-position Width		
37 38 39				Setto	a	

GX LogViewer with Enhanced Waveform Display

The graph data of both PLC CPU modules and Motion modules can be checked on GX LogViewer. This tool helps you efficiently analyze data from two different modules. The following two functions are provided for logging: data logging function (offline) and real-time monitor.

System Design Programming

Debug

Maintenance


PLCopen

Data Logging Function

The function performs data logging by a specified time interval based on the logging setting (trigger condition, data collection) written to the Motion module from the engineering tool. The results are saved as a data logging file.


Up to 10 data settings can be simultaneously logged for the Motion module.

The operation status before and after an error is displayed in waveforms, which allows more detailed analysis and identification of the error cause.



Real-Time Monitor

Up to 32 data collected from a Motion module can be displayed in real time.






System Simulation

The system simulator enables the Motion module and PLC CPU programs to be simulated interactively.

A program operation can be checked without an actual machine during debugging process, which shortens the startup time.



Event History

Event history lists information about executed operations and errors that have occurred on each module in chronological order, which helps to conduct troubleshooting.

et very (scontinue)			
Martin Independent		Mail: I	
Ferritage .			
and the second s	ou has the beaters		
· Barta a Instatus			
	-		
	_		-
Composite one part made		de la	- bellets
to increasing harden	Max Burniss	i intra	
n sarenin berin n arraits barin n arraitstansen n arra	-3- are	The strategies are	ALCOHOL: UNDER STREET, ST.
and inclusion of the lower	-1- arm	Page and the second of the	
and interference has		Name and a to the second second	
an personal land	-0- mm	100.00.00.00.00	
an province and province of the	1.00	Page de la force de la re-	111111-0-1011
ant international land	A 144	These effects in the second second	
The second se			
	2011 A. B. M. M.		Low Horn
diana di termin			And I
an 2,01007322			
Restantion in the Physical and	eren der softe	de Ministeren Anna As	and other the series
	_		_
inter the			1.04

Axis Monitor

Users can customize the axis monitor items according to their machine, improving debug efficiency. The axis monitor can also be used during simulation.

Transfering the states				- 0 >
4 75 78				
And Mandalow		aller apprint	1.1	an Marine
	SAL Note 1	Per Partition Add	1000	
				Name and Address
Contraction (see	THE MARK	- Balancer		Red Reads
			12	And And
An Arm	ALC: NO.	Aure -	12	Industry in
110 1000	a tighty	+ Harthy		Loter Rev Los Notes Assessy Tra
General-Los		1.0		And the cost of the second second
Party Ground and				Name and Add Incide and Address of Street, or
Capital Concentration of the local Concentration	-	-		
specif comment will begin		100		Later has \$1.0 being \$1.0
General Garant Publics	\$3 yrs.	Man		and the second se
Perdiat Autor	8.8.00	Adum .	1.4	Ramon Kang Sada Sanang Sada Sana
Specified Institute	20.00	10.0		Name and Add Street, of Street, or other
Conversed Convert Reveal	8.0 (10)	10.000		
Panfield Send	Ad units	March .		Name and Address of the Address of Taxaban Propagation.
Aprendiant Aprendi	Rif units	All and		
Long Land	20000000.0 ores	2010/0012-045		Database Cold Restored in Street Cold
Postur Reador Spectrum	December 1 Acre	Second to the		Berne Lin Mench Lin De
Adventisity Decembers	Male .	PLB .		Read the brailing
downed in-poster.	Angel Contraction	nut l	1.5	Note Autor for Interior
Insight-or Dealton Torice Unit Lines	10.1%	464%		Later Name States Store Sale
Poster Dealer Talan	bit.47b.	144.0 Th		and the second se
Link risks			1.4	more lighter interruptions for
name Parties Selan				Concrete Concentration of the
Completed.	14.H	14.8	1	South Submar
mone instant keture	194	104	1.1	
Resident				Television and
That Barrisson & Horse Frontier makers proceedings	And Market	m/6		Real Andre Saliness Street
taken simt Same Select	ALC: NO.	TAR		
Torrer Lots Name Ratio	84,00	19.10		Bart Selvers Spinst
Period lines Consuling	1918	75.0		
And drive Defaultion	11.00	144		Induced Real Professor Innon-
Aut (Introduce	100	888		
And Harrison Defaultion	Au 81	TAL M		
AND TOPY OF	100	1001		
Drug Rady Dr Status	78.8	74		
Bride Serve Dr. Balan	10.4	-		

Program Monitor

Debugging can be executed through both the program monitor and the watch window by using the common interface.

	Constanting of the second seco	All accounts within All accounts within All accounts and All ac	Table (a tradit + 1, 2001 - 2005) Table (a tradit + 1, 2001 - 200) Table (a tradit + 1, 2001 - 200) Addition (a tradit + 1, 2001 - 20) Addition (a tradit + 1, 2001 - 20) Ad	
1		17 member - 1988 17 Bertramssemellen 17 Bertramssemellen 18 Menderste 18 Menderste 18 Menderste 18 Menderste 19 Menderste	Advantured - 1.400-000 International - 1.400-000 International and - 1.400-000 International - 1.000-000 International - 1.000-000 International - 1.000 International - 1.0000 International - 1.0000	
41 1	detied a fa //les	ter mede (D) Marrieral) as (DeMM): Associations / Associated has Assignables as	delet and - ha	_

n monitor

-	The state of the s					- 1
	48 or 48 octor sign 2	Ciplers -				
Num		Careet Value	Date front	Data Tape	Connect	1.0
	C.Inen.ot		-	STOAKS MORNER	50 Menory Card Manuation	_
_	Charge all Faced traded	ALC: N	10	-	30 Wenny Card Force Disabled	_
-	Parage utilitated	IND	-	84	20 Menoy Carl Isarted	
_	Comprise National	AND		-	50 Nonero Card Protected	_
-	C. Donas, and		-	STOAKE MORE THE	Solan Dros Manadan	
	A los	THE .		-	Serdiverse las	
	e.lonedaniloit	1000	E	CICIL MINE	Sector Basic Code Maritar	
_	Clotendanijsk Jaarte	4948	165	Mod Stopped/St Deep [10-54]	Barten Basit Garle Gautter	_
	Veron Basilymails	- F	100	Mar Shiged St Stop [1-14]	Base Lotus Salvare Incom	

Watch window

Security Key Authentication Function

The security key authentication prevents programs from being opened on personal computers where the security key has not been registered. Furthermore, because programs can be executed only by Motion modules with the security key registered, the integrity of customer technologies and other intellectual property is not compromised.



System Design Programming Debug

Maintenance

PLCopen[®]

59

Software-based controller for high-precision motion control



Installed on a personal computer, SWM-G Motion Control Software can perform motion and network control.

- Supports a CC-Link IE TSN servo control system with the personal computer where RTX64 (real-time extension) is installed. (RTX64 is included with SWM-G.)
- Meets various application needs by offering various types of motion control, such as positioning, synchronous, cam, speed, and torque control using API library for motion control.
- Utilizes network control to connect and set various device stations (remote I/O modules, etc.) and TCP/IP devices.



SWM-G*³

Maximum number of control axes: 128

• Minimum operation cycle*2: 125 µs

Programming language: Visual C ++[®]

USB key for Motion Control Software

MR-SWMG16-U: 16 axes MR-SWMG64-U: 64 axes

MR-SWMG32-U: 32 axes MR-SWMG128-U: 128 axes


*1. SWM-G Motion Control Software includes SWM-G Engine, SWM-G API, Network API, SWM-G Operating Station, and Real Time OS (RTX64).

*2. The minimum operation cycle depends on the number of control axes and the CPU of the personal computer.

SWM-G-N1 is also compatible with EtherCAT[®].
 A USB key (license) is not required for the free trial version SWM-G-W. To obtain SWM-G-W, contact your local sales office.

Covering a Wide Range of Multi-Axis Applications

 SWM-G Motion Control Software is available in 16 to 128axis control models, enabling multi-axis synchronization of various scales of machines.




Reduced Machine Design and Startup Time

- The integrated test tool SWM-G Operating Station covers the development processes of SWM-G from design to simulation, contributing to reduction in the total cost of ownership.
- The Operating Station enables users to check the communication settings and status of the master/remote stations, leading to reduced design time.

195	2.14	they make a			
	12 I A	to the first			
				and the second se	
			0-0-0-	AN THE OWNER	· · · · · · · · · · · · · · · · · · ·
1 21			-		
1.54		April and April 201	N 100 10	1.00	
		wheel law house	_	1 mm	
1.44		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		1 m m	
	10 C	where the party of the local	_		
- 123	10.00			the second se	
		8.1 ·	18		
		the state of the s			
1.2	the state of the s	take too in the local division of the	And in case of the local division of the loc	-	
1.41				-	
1 21		and the second s	And and a state of the local division of the	a and	
1 2 1		restored and the second	Andrea (MAR	and and	
		Andread and Address of		the literature	
		Andread and an owner of	_		
1 2 3		and the second	100 million (1977) (197		
the second second					
		ng tighten t			
	_				
1.0	-	Annual second second			
1.4		Spratter Long			
		And and a second se			

Single-axis control

 A CPU core of the industrial personal computer is assigned for running SWM-G processing, and that enables SWM-G to perform a high-speed, real-time operation without being affected by the operation on Windows[®].





Maintenance Solution by MELIPC with SWM-G Installed

When SWM-G is installed and operated on the MELIPC (industrial personal computer), the system offers a powerful maintenance solution utilizing the Edgecross-compatible software.

N # 0 8 N 8 4 A


ź


[Predictive/preventive maintenance]

- The user application collects data of machine diagnosis function, etc. from MR-J5-G through the communication API of SWM-G.
- The MELIPC analyzes the collected data by using the Edgecrosscompatible real-time data analyzer.

[Corrective maintenance]

 SWM-G collects data from the drive recorder of MR-J5-G through TCP/IP communications, which reduces troubleshooting time.





Servo System




System Configuration



SWM-G Motion Control Software executes motion control while functioning as a master station of CC-Link IE TSN. *¹ This feature enables users to create a system more flexibly by connecting various devices, such as servo amplifiers, remote I/O modules, and TCP/IP devices, to SWM-G.

High-speed control is achieved even when control at low- and high-speed communication cycles is mixed within the same control communication.



*1. The following functions are not provided; sub-master station, local station, multi-master configuration, backup/restore function, data communication function with standard stations, and safety communication.

Integrated Test Tool SWM-G Operating Station

• Displays a list of the master communication setting

• Displays the system status, allowing users to check

This tool provides a variety of features - parameter settings required for application development and the test operation for JOG, inching, and positioning operations. In addition, each axis status and sampled waveforms can be displayed to help user check the start timing and the operation pattern.

SWM-G Operating Station

[Single-axis control]

- Performs a test operation for single-axis control
- Performs a reciprocating operation that is often used for a test operation

1 4 2

		taninamatan at ka fana	
Name Name Name Name Na		A second	
per danes		P agreen wing again	e alt Longen factor le formendig
(PROFIL) PROFILE (PROFILE)	COMPANY OF THE OWNER.	E BOR D'ON'S THE LOLDS	

Multiple Servo Amplifier Settings and Adjustments

MR Configurator2 enables users to easily set and adjust multiple servo amplifiers through CC-Link IE TSN which enables mixing of TCP/IP communication and other communications.

Using MR Configurator2 with the integrated test tool, users can adjust servo amplifiers while checking the servo amplifier communication status.

- Supports MR-J5-G
- Manages a multi-axis system as one project

[Communication monitor]

communication status

8

4088994

100

10.0


• Parameters and the machine diagnosis can be set for all axes in a batch on MR Configurator2.




*MR Configurator2 is not included with SWM-G Motion Control Software.




Positioning Control




Continuous path control (path interpolation)





Helical interpolation



Triggered motion

Position Speed Acceleration Jerk

In this method, an axis can be accelerated gradually through adjusting jerk so that the vibrations of the machine can be minimized.

In the example above, the constant positive jerk is applied at the start of the operation to achieve smooth acceleration. When the axis is shifted to the constant-speed operation, the same amount of negative jerk is applied.

Adjusting jerk in this way achieves smooth acceleration/ deceleration while also shortening the time it takes to reach the target speed.

The speed creates a S-curve shape.

The triggered motion is a type of command that delays the execution of the motion command until the specified trigger condition is satisfied.

Axes can be started automatically based on the specified conditions by using this command, reducing the cycle time of conveyor systems, etc.

In the operation example above, right after the axis 2 starts execution of normal motion commands, the axis 1 executes the triggered motion command (delaying the execution of the command until the condition is satisfied).

When the condition is satisfied (start trigger ON) during the axis 2 operation, the axis 1 starts executing the motion command.

Jerk acceleration/deceleration

Cantry home position return

After the master and following axes pass their respective dogs, the gantry home position return stops both of the axes at the Z-phase of the master axis.

This method enables two or more axes to execute home position return simultaneously, supporting gantry systems.

A Wide Variety of Features

Master axis

axes.

Hot connect (disconnection/reconnection)

Motion Control Software enables tandem operation where the

same commands can be outputted to master and following

Synchronous control (tandem drive)

Synchronized

Following axis

The hot connect enables a topology change during operation without requesting a communication stop.

The user application disconnects and reconnects the network through API library.

Position synchronous output (cam switch)

The output signal is turned on when a specified condition is satisfied. This function can be used as an alternative to a limit switch.

Monitoring of servo data

The controller obtains the status data of servo amplifiers, such as machine diagnosis information and encoder temperature, via CC-Link IE TSN. This enables visualization of machine status.

Touch probe (mark detection)

The current value of the servo motor can be read when the touch probe signal is inputted.

Software and hardware touch probes are available. Select the touch probe according to your application.

Backlash compensation

The set offset is applied when the axis changes the travel direction.

The backlash of ball screws can be compensated, which improves operation accuracy of machines.

Pitch error compensation

The set offset is applied at regularly spaced command positions. The position error of ball screws can be compensated, improving the operation accuracy.

Acceleration/deceleration methods

The controller offers 24 types of acceleration/deceleration methods, such as trapezoidal, S-curve, jerk ratio, parabolic, sine curve, time acceleration trapezoidal, etc. Select the method according to your application.






Programming Utilizing API Library



Development environment *1 (Microsoft[®] Visual Studio[®])


Add the SWM-G API library to the project of Microsoft® Visual Studio® and create a user program.




- C++, C# compile
- Debug of C language programs

*1. Prepare a development environment with Microsoft Visual Studio®.


A program that starts positioning







A program that continuously starts positioning of another axis based on the specified trigger condition



Reach new limits while inheriting existing assets.

Maximize the performance of your system with MELSERVO-J5 total drive solutions.





MR-J5-G/MR-J5W-G/MR-J5D-G4 servo amplifiers can connect to CC-Link IE TSN to perform high-speed, high precision control.

The performance and the functions have been greatly improved, contributing to innovative evolution of the machines.


CC-Línk**IE TSN** Servo amplifiers

MR-J5-G(4) MR-J5W-G MR-J5D-G4



Features of CC-Link IE TSN-Compatible Servo Amplifiers

- Features the minimum communication cycle of 31.25 µs to perform high-speed, high-precision control
- Allows both control communication and information communication on one network and thus enables a flexible system
- Sends and receives large amounts of data, such as recipe data with a high-speed, large-capacity 1 Gbps communications network






MELSEC iQ-R series Motion modules collect data of servo

Servo system recorder

CC-Línk**IE TSN**

Position, speed, torque data, etc.

• Features safety communications via CC-Link IE TSN



- Compatible Servo System Controllers

MELSEC i Q R Motion module RD78GHV RD78GHW



MELSEC iQ-R Motion module RD78G4 RD78G8 RD78G16 RD78G32 RD78G64





GX LogViewer

amplifiers when an error occurs

MELSEC iQ R

Motior

Personal Computer Embedded Type Servo System Controller SWM-G



68

Heritage

SSCNET III/H-Compatible Servo Amplifiers MR-J5-B



MR-J5-B/MR-J5W-B servo amplifiers can connect to SSCNET III/H and utilizes the existing program assets to improve the performance of the machines.


Transition from MELSERVO-J4 series to MELSERVO-J5 is supported.




Features of SSCNET III/H-Compatible Servo Amplifiers

Allows the user to build a MELSERVO-J5 series servo system that utilizes the existing assets of Motion controllers and Simple Motion modules

• Enables function improvement of the machines by combining MR-J5-B servo amplifiers and HK series rotary servo motors





• Changing the servo amplifier setting from MR-J4-B to

MR-J5-B converts the parameters Engineering software MELSOFT MT Work2

MELSOFT GX Work3/GX Work2

 MELSEC iQ-R series Motion modules collect data of servo amplifiers when an error occurs Servo system recorder MELSEC iQ R Motion MR-.15-B



Compatible Servo System Controllers



MELSEC iQ R Motion controller **R16MTCPU** R32MTCPU **R64MTCPU**



MELSEC iQ R Simple Motion module RD77MS2 RD77MS4 **RD77MS8 RD77MS16**

Servo amplifier setting





Driving a wider range of motors with more flexible options





CC-Línk**IE TSN MR-J5-G(4)**

Supports Ethernet-based CC-Link IE TSN, featuring high-speed, large-capacity communication (1 Gbps). Communication cycle of \ge 31.25 µs and speed frequency response of 3.5 kHz enable advanced motion control.



CC-Línk**IE TSN** MR-J5W2-G MR-J5W3-G

Drives a maximum of two/three servo motors. This simplifies wiring, saves energy, and enables a compact machine.

Product Lines

vo amplifier

Servo amplifier Supported O: Future support planned -: Not support				ed -: Not supported			
	Power supply specifications	Command interface (Note 4)	Fully closed loop control ^(Note 2)	Compatible servo motors			
Model	(Note 1)			Rotary	Linear ^(Note 3)	Direct drive	
MR-J5-G	200 V AC	CC-Link IE TSN – EtherCAT ^{® (Note 5)}		•	•	•	
MIR-JO-G	400 V AC		•	•	0	-	
MR-J5W2-G	200 V AC						
MR-J5W3-G	200 V AC		-	•	•	•	
MR-J5D1-G4	400 V AC		•	•	-	-	
MR-J5D2-G4			•	•	-	-	
MR-J5D3-G4			-	•	-	-	
MR-J5-B	200 V AC	- SSCNET III/H	•	•	•	•	
INIU-10-D	400 V AC		•	•	0	-	
MR-J5W2-B	200 V AC			•	•	•	
MR-J5W3-B	200 V AC		-	•	•		
MR-J5-A	200 V AC	Pulse train/Analog voltage		•	•	•	
WIT-05-A	400 V AC			•	0	-	

Notes: 1. 200 V AC servo amplifiers are also compatible with DC power supply input as standard. 2. The indicated servo amplifiers are compatible with a two-wire type serial encoder. For four-wire type serial encoders and pulse train interface (A/B/Z-phase differential output type) encoders, use MR-J5-G-RJ/MR-J5-G4-HS/MR-J5D1-G4/MR-J5-B-RJ/MR-J5-A-RJ servo amplifiers.

The indicated serve amplifiers are compatible only with two-wire type and four-wire type serial linear encoders. For a pulse train interface (A/B/Z-phase differential output type) linear encoder, use MR-J5-G-RJ/MR-J5-G4-HS/MR-J5-B-RJ/MR-J5-A-RJ serve amplifiers.
 MR-J5-G(MR-J5D-G4-MR-J5-D4-RZ) are also compatible with CC-Link IE Field Network Basic.
 EtherCAT[®] is supported by MR-J5-G-N1/MR-J5W2-G-N1/MR-J5D1-G4-N1/MR-J5D2-G4-N1/MR-J5D3-G4-N1.





CC-Línk**IE TSN** MR-J5D-G4

The drive unit is a converter separate type servo amplifier (1/2/3-axis type available). Combined with an MR-CV_4 power regeneration converter unit, the drive unit can create an energy-saving servo system.



1.0 kW

Supports optical network SSCNET III/H. Communication cycle of \geq 0.222 ms and speed frequency response of 3.5 kHz enable advanced motion control.

Jp to 22 kV

Up to 22 kW

p to 22 kW to 22 kW

10 kW



General purpose interface **MR-J5-A(4)** Enables position control by


pulse train command and speed/torque control by analog voltage command. The maximum command pulse frequency is 4 Mpulses/s.

: Future release planned

Servo Amplifiers


Tuning Functions

Use the tuning methods that are optimal for your machines.



Quick Tuning

This function automatically performs easy-to-use auto tuning that controls vibration and overshoot just by turning on the servo-on command. Before normal operation, the servo amplifier sets control gain and machine resonance suppression filters in 0.3 seconds by inputting torque to the servo motor automatically. After completing the setting, the servo amplifier starts operation normally.





One-Touch Tuning

This function automatically completes servo gain adjustment according to the mechanical characteristics and reduces the settling time just by turning on the one-touch tuning. The servo gain adjustment includes the machine resonance suppression filter, advanced vibration suppression control II, and the robust filter. Controlling overshoot and vibration is improved, maximizing your machine performance.

Advanced Vibration Suppression Control II

This function suppresses two types of low frequency vibrations, owing to vibration suppression algorithm which supports three-inertia system. This function is effective in suppressing residual vibration with relatively low frequency of approximately 100 Hz or less generated at the end of an arm and in a machine, enabling a shorter settling time. Adjustment is easily performed on MR Configurator2.





Command Notch Filter

The frequency can be set close to the machine vibration frequency because the command notch filter has an applicable frequency range between approximately 1 Hz and 2000 Hz.


Machine Resonance Suppression Filter

The expanded applicable frequency range is between 10 Hz and 8000 Hz. Five filters are simultaneously applicable, improving vibration suppression performance of a machine. The machine resonance frequency is detected by the machine analyzer function in MR Configurator2.

Energy/Space Saving and Simple Wiring (200 V Class)

Simple Converter MR-CM

The MR-CM simple converter saves energy by efficiently using regenerative power through a common bus connection and reduces the number of molded-case circuit breakers and magnet contactors, resulting in space-saving and simple wiring. The simple converter can connect to up to six compatible servo amplifiers having a total capacity of 3 kW or lower. Using daisy connectors for passing wiring simplifies the wiring for the bus and the control circuit power supply.



Application Examples

[Vertical form, fill & seal]

The simple converter uses regenerative energy of the packing film unwinding axis for other axes such as conveying rollers.



Multi-Axis Servo Amplifiers

The 2-axis and 3-axis servo amplifiers are available for operating two and three servo motors, respectively. These servo amplifiers enable an energy-saving and compact machine.


Different types of servo motors including rotary servo motors, linear servo motors, and direct drive motors are freely combined as long as the servo motors are compatible with the servo amplifier.


[2-axis servo amplifier]

CC-Link IE TSN-compatible: MR-J5W2-G SSCNET III/H-compatible: MR-J5W2-B [3-axis servo amplifier] CC-Link IE TSN-compatible: MR-J5W3-G SSCNET III/H-compatible: MR-J5W3-B

[Wafer prober]

The simple converter saves installation space for semiconductor manufacturing equipment in a clean room.






Converter Separate Type Drive Unit in 400 V Class MR-J5D-G4


- The product lines of the 400 V include converter separate type drive units of MR-J5D-G4 available in 1-axis/2-axis/3-axis types.
- Combined with an MR-CV_4 power regeneration converter unit, MR-J5D-G4 can configure a servo system with energy and space savings and less wiring.
- MR-J5D-G4 supports safety communication of CC-Link IE TSN, enabling functional safety without a dedicated unit. Even for a
 multi-axis servo system, functional safety can also be applied with network cables.

Features of MR-J5D-G4 Drive Units

- The common DC bus connection saves energy and space, and reduces wiring.
- MR-J5D2-G4 (2-axis drive unit)/MR-J5D3-G4 (3-axis drive unit) save space and reduce wiring further.
- MR-J5D1-G4/MR-J5D2-G4/MR-J5D3-G4 support safety sub-functions as standard. The safety communication of CC-Link IE TSN enables the safety sub-functions such as STO to be set for each axis of the multi-axis drive units.
- The drive units are equipped with a replaceable cooling fan unit, which can be easily replaced by users.




Space-Saving with 3-Axis Drive Units (Smaller Width)



Further Energy-Saving with Common DC Bus Connection and Power Regeneration System

Connecting multiple MR-J5D-G4 drive units to an MR-CV_4 power regeneration converter unit by a common DC bus connection allows the drive units to use regenerative energy from the other drive units on the connection. Furthermore, the MR-CV_4 power regeneration converter unit has a power regeneration system which returns the regenerative energy to the power supply. Other systems can use this returned regenerative energy for operation, promoting efficient energy use. A system with MR-CV_4 does not require a regenerative option and thus reduces heat generation.



Application Examples

[Printing systems]

Optimal for rotary presses using sectional drive system where each printing unit is driven individually.


[Slitting machines]

Optimal for converting machines consisting of unwinding axes, roller axes, and winding axes.




Wider Combinations with Servo Motors (400 V Class Systems)

The 400 V class servo amplifiers can drive the HK-KT/HK-ST/HK-RT series servo motors ranging 50 W to 7 kW. The flexible combination can optimize your machines. For the available combinations, refer to "Combinations of Servo Motors and Servo Amplifiers" in this catalog.



Small capacity, low inertia HK-KT series



Medium capacity, medium inertia HK-ST series



Medium capacity, ultra-low inertia

HK-RT series

Predictive Maintenance



The servo amplifiers detect signs of machine failure by monitoring the operation status. Maisart is an abbreviation for "Mitsubishi Electric's AI creates the State-of-the-ART in technology." Mitsubishi Electric is leveraging original AI technology to make devices smarter.

Machine Diagnosis (Ball Screws/Linear Guides)


This function supports predictive maintenance by Ball screw estimating frictions and vibrations of mechanical drive components such as ball screws and linear guides. • Friction failure prediction with the friction estimation function • Vibration failure prediction with the vibration estimation function Estimated friction is displayed. Estimated vibration is displayed. Maintenance Maintenance Machine Machine notification failure notification failure Kinetic friction Vibration level 2.00 Failure warning limi Failure warning limi ut MIT Time Time

Machine Diagnosis (Belts)

This function detects aging deterioration of belts in advance by the static friction failure prediction and the tension deterioration prediction with the belt tension estimation.

- Static friction failure prediction
- Belt tension deterioration prediction





Machine Diagnosis (Gears) *¹

With this function, the servo amplifier generates commands automatically, and executes to-and-fro positioning operation to estimate the amount of gear backlash. Gear failure is predicted based on the set nominal values for backlash.


- Gear Gear Estimated backlash is displayed.
- Backlash estimation function
- Gear failure prediction

Preventive Maintenance

Machine Diagnosis (Mechanical Drive Components)

This function estimates when a machine failure will occur based on the total travel distance of the servo motor and notifies when it is time for replacement if the rated service life of the mechanical drive components is set.

Machine total travel distance failure prediction



Servo Amplifier Life Diagnosis

This function displays the cumulative energization time and the number of inrush relay on/off times. The data can be used to check the service life of the parts as a rough guide.


- Cumulative energization time (Smoothing condenser/cooling fan life span)
- The number of inrush relay on/off times (Inrush relay life)



Corrective Maintenance

Drive Recorder

This function continuously monitors the servo status and records the status transition such as a trigger condition before and after an alarm for a fixed period of time. Reading the servo data on MR Configurator2 helps you analyze the cause of the alarm. In addition to the monitor values and the waveform of the past 16-time alarms in the alarm history, the system configuration and the servo parameters are displayed. Alarm occurrence time is also displayed when the servo amplifier and the controller are normally in communication on CC-Link IE TSN. The data can be outputted to a GX LogViewer format file.






Connection/Communication Diagnosis

Disconnection Detection

The servo amplifiers are equipped with both input open-phase detection and output open-phase detection. Input open-phase detection detects an open phase of the main circuit power supply of the servo amplifier, and output open-phase detection detects an open phase of the servo motor power supply. The alarm can be distinguished from other alarms such as the overload alarm, reducing the time required to restore the system. MR-J5D-G4 drive units support only output openphase detection.




Servo Motor Incorrect Wiring Detection


Multi-axis servo amplifiers MR-J5W2-G/ MRJ5W3-G detect servo motors with a different capacity that are incorrectly connected to the A-axis/B-axis/C-axis, contributing to servo motor protection. The servo amplifiers obtain the capacity information of the connected servo motors from the encoders and check whether the servo motors which are connected to the power connectors match the capacity information. If the information is not matched, an alarm occurs. *1

*1. The incorrect wiring detection does not work for servo motors with the same capacity.

Encoder Communication Diagnosis

The encoder communication diagnosis checks the encoder communication circuit in the servo amplifier. This function is useful for classifying the cause of errors (such as disconnected encoder cables) when the encoder communication alarm occurs.






Path Control


Super Trace Control

This function reduces a position deviation to nearly zero not only during constantvelocity operation, but also during constant acceleration/deceleration. The path accuracy will be improved in highrigidity machines.



Lost Motion Compensation


This function suppresses quadrant protrusion caused by friction and torsion generated when the servo motor rotates in a reverse direction. Therefore, the accuracy of circular path will be improved in path control used in XY table, etc.



Suppression of quadrant protrusion of circular path

Path Tracking Model Adaptive Control


This function reduces path errors which occur when the servo motor reciprocates. Normally, when positioning control is executed, the model adaptive control adjusts the control to shorten a settling time. Instead, this function reduces overshooting to improve path accuracy, which is suitable for machines that require high-accuracy path control such as processing machines.



Safety Sub-Functions

Built-in Safety Functions and a Wide Range of Safety Sub-Functions

MR-J5-G-RJ/MR-J5-G4-HS/MR-J5W2-G/MR-J5W3-G/MR-J5D-G4 have a built-in safety control part, supporting safety sub-functions without a functional safety unit. Combining the servo amplifiers with HK-_WS servo motors with functional safety further enhances the safety level. The servo amplifiers support the safety sub-functions of STO/SS1/SS2/ SOS/SBC/SLS/SSM/SDI/SLI/SLT at a safety level of SIL 2 or SIL 3.



Servo motors with functional safety support the safety sub-functions at a higher safety level. The functional safety encoders provide the servo motor positions and speeds necessary for the safety sub-functions at a safety level of Category 4 PL e, SIL 3.

Encoder cables for the servo motors with functional safety are the same as for the standard servo motors.


Safety Communication Function via CC-Link IE TSN*2

CC-Link IE TSN enables control of safety and non-safety communications realizing a flexible system whereby safety communications can be easily incorporated into the main control network. When combined with R_SFCPU-SET safety CPU and RD78G Motion module, MR-J5-G-RJ/MR-J5-G4-HS/MR-J5W2-G/ MR-J5W3-G/MR-J5D-G4 can receive safety signal data of the safety CPU through CC-Link IE TSN. Wiring the safety signals to the servo amplifiers is not necessary.


- *1. Refer to "Safety Sub-Functions" in section 1 of this catalog for the compatible servo amplifiers.
- MR-J5-G-RJN1/MR-J5-G4-HSN1/MR-J5W2-G-N1/MR-J5W3-G-N1/ MR-J5D-G4-N1 support Safety over EtherCAT[®] (safety data communication protocol) of EtherCAT[®].


STO Function Compliant with IEC/EN 61800-5-2





Functional safety is supported





- STO shuts off the power to the servo motor without turning off the control circuit power supply of the servo amplifier, thus shortening the restart time and eliminating the need for homing.
- A magnetic contactor for preventing unexpected motor start is not needed.*1


Servo amplifier model	Safety level
MR-J5-G/MR-J5-B/MR-J5-B-RJ/MR-J5W2-B/	Category 3 PL e, SIL 3
MR-J5W3-B/MR-J5-A/MR-J5-A-RJ	Calegory 3 PL e, SIL 3
MR-J5-G-RJ/MR-J5W2-G/MR-J5W3-G/	Category 4 PL e, SIL 3 *2
MR-J5D-G4/MR-J5-G4-HS	Calegory 4 PL e, SIL 3
*1 Magnetic contractors are not required to meet the STO requirements. How	anne this illustration as seen and the cost

 Magnetic contactors are not required to meet the STO requirements. However, this illustration recommends the use of a magnetic contactor which shuts off the main circuit power supply of the servo amplifier at an alarm occurrence.

*2. The listed safety level is applicable when one of the following executes safety sub-function control. • MR-J5-G4-HS • Resemption controller, and the controller that mode Category 4 PL or SIL 2

Programmable controller, safety CPU, or safety controller that meets Category 4 PL e, SIL 3
 When a switch such as a safety switch is directly connected to the servo amplifier, the safety level is Category 3 PL d, SIL 2. For details, refer to "MR-J5 User's Manual".

[Shut-off by STO]



Servo System


zation of SSCNET III/H ice Assets

81

Safety Sub-Functions Compliant with IEC/EN 61800-5-2

MR-J5-G-RJ/MR-J5-G4-HS/MR-J5W2-G/MR-J5W3-G/MR-J5D-G4 support safety sub-functions, STO/SS1/SS2/SOS/SBC/SLS/ SSM/SDI/SLI/SLT.

Refer to "Safety Sub-Functions" in section 1 of this catalog for the safety sub-functions and the safety levels, which vary depending on the combinations of the servo amplifiers and the rotary servo motors (including servo motors with functional safety)/linear servo motors/direct drive motors.




Supporting Flexible Driving System

Fully Closed Loop Control

Supporting a fully closed loop control system*¹ as standard, MR-J5-G/MR-J5W2-G/ MR-J5D1-G4/MR-J5D2-G4/MR-J5-B/ MR-J5W2-B/MR-J5-A servo amplifiers enable further precise positioning.

*1. MR-J5-G/MR-J5W2-G/MR-J5-B/MR-J5W2-B/MR-J5-A servo amplifiers are compatible only with two-wire type serial encoders. For four-wire type serial and pulse train interface (AB/Z-phase differential output type) encoders, use MR-J5-G-RJ/MR-J5-G4-HS/MR-J5D1-G4/MR-J5-B-R-J/MR-J5-A-RJ.



Scale Measurement Function


The scale measurement function transmits scale measurement data of a scale measurement encoder to a controller via network when the scale measurement encoder such as a linear or rotary encoder is connected to a servo amplifier. This function enables flexible wiring from the scale measurement encoder.

Servo amplifiers supporting the scale measurement function [CC-Link IE TSN-compatible]

For two-wire type encoder: MR-J5-G/MR-J5-G-RJ/MR-J5-G4-HS/ MR-J5W2-G/MR-J5D1-G4/MR-J5D2-G4

For four-wire type encoder: MR-J5-G-RJ/MR-J5-G4-HS/MR-J5D1-G4 [SSCNET III/H-compatible] For two-wire type encoder:

MR-J5-B/MR-J5-B-RJ/MR-J5W2-B Four-wire type encoder: MR-J5-B-RJ



Touch Probe Function


When a touch probe (sensor) that detects the position of workpieces is connected to a servo amplifier, the touch probe function latches (stores) the position detected by the touch probe. The controller reads and uses the latched value for position correction. The latch accuracy of this function is 1 μ s.

Servo amplifiers supporting the touch probe function

[CC-Link IE TSN-compatible]

MR-J5-G*1/MR-J5-G-RJ/MR-J5-G4-HS/ MR-J5W2-G/MR-J5W3-G/MR-J5D-G4

*1. Use MR-J5-G manufactured in June 2021 or later. Note that, depending on the stock status, the servo amplifiers with both the former and the new specifications may be distributed in the market around the same time. Contact the local sales office when the touch probe function is needed.




Supporting Flexible Driving System

Positioning by Using a CC-Link IE TSN-Compatible RJ71GN11-T2

An RJ71GN11-T2 master/local module that supports CANopen can control the servo amplifiers.*¹ The servo amplifiers support both the profile mode (position/velocity *²/torque *²) and the positioning mode (point table). *³ In the profile position mode, for example, the target positions and speeds can be set from the master station. The servo amplifier generates commands to the target positions with a start signal and starts positioning operations.


[Profile position mode continuous operation]



[Profile position mode continuous operation (point table)]


- RD78G/FX5-SSC-G Motion modules also support CANopen.
 The profile modes (velocity/torque) are not supported by MR-J5W2-G/ MR-J5W3-G/MR-J5D2-G4/MR-J5D3-G4.
- *3. For the modes supported by the master station, refer to the master station specifications.

No.	data	speed	constant	constant	Dweii	function	IVI CODE
1	1000	2000	200	200	0	1	1
2	2000	1600	100	100	0	0	2
:	:	:	:	:	:		÷
255	3000	3000	100	100	0	2	99



Driver Communication Function

The controller controls the master axis by using the driver communication function of the servo amplifiers (MR-J5-G/MR-J5D1-G4/MR-J5-B). The servo amplifier of the master axis transmits the torque data to the servo amplifiers of the following axes on the same network, and the servo amplifiers also drive the servo motors on the basis of the torque data transmitted from the master axis. The data is transmitted via network, and thus no special wiring is necessary.



Compliance with SEMI-F47

MELSERVO-J5 series servo amplifiers comply with SEMI-F47 standard*1 for semiconductors and FPD manufacturing systems. (SEMI-F47 is not applicable to 1-phase 200 V AC input, DC input, and MR-J5D-G4.)

*1. The backup capacitor may be required depending on the power impedance and operating situation for the instantaneous power failure of the main circuit power supply. Be sure to perform a test on your machine to meet the SEMI-F47 (Specification for Semiconductor Processing Equipment Voltage Sag Immunity) standard. Please use the 3-phase power supply for the servo amplifier input.

Command Interface

CC-Link IE TSN


The servo amplifiers receive commands (position/ velocity/torque) from a CC-Link TSN-compatible controller at regular intervals through synchronous communication and drive the servo motors. When combined with a Motion module or Motion Control Software, the servo amplifiers perform exact synchronous operation of axes and machines through high-speed, high-precision time synchronization.

The servo amplifiers support CiA 402 drive profile and enable the profile mode (position/velocity^{*2}/ torque^{*2}) and the positioning mode (point table). When combined with the controllers supporting the profile mode, the servo amplifiers generate a positioning command to a target position, reducing loads of the controllers.

[CC-Link IE TSN-compatible]


MR-J5-G/MR-J5W2-G/MR-J5W3-G/MR-J5D1-G4/ MR-J5D2-G4/MR-J5D3-G4

- *1. The communication cycle of \geq 31.25 μs is applicable when MR-J5-G/MR-J5D1-G4 are combined with RD78GH.
- The profile modes (velocity/torque) are not supported by MR-J5W2-G/MR-J5W3-G/MR-J5D2-G4/MR-J5D3-G4.



SSCNET III/H

Replacement of the servo amplifiers in the existing system with MR-J5-B/MR-J5W2-B/MR-J5W3-B is possible, which enables the MELSERVO-J5 series servo system to be configured with the use of the existing programs of the servo system controller. The parameter conversion function of the engineering software and "Transition from MELSERVO-J4 Series to J5 Series Handbook" are available to support the replacement.




CC-Link IE Field Network Basic

CC-Link IE Field Network Basic-compatible master stations such as an FX5U CPU module can control MR-J5-G/MR-J5D1-G4 servo amplifiers. The servo amplifier can be operated as a CANopen device via a link device.


The profile mode (position/velocity/torque) and the positioning mode (point table) are supported. MR-J5-G/MR-J5D1-G4 servo amplifiers can be connected to existing systems using MR-J4-GF. In addition, MR-J5-G newly supports the line topology.*1

*1. When a device which does not support the line topology is used, the line/star mixed topology is applicable.



General-Purpose Interface

General-purpose interface-compatible MR-J5-A servo amplifiers support pulse trains and analog input. The control mode can be switched between position/speed/torque control modes. When an open collector is used, both sink and source inputs are enabled.





Command Interface

EtherCAT[®]

EtherCAT[®]-compatible servo amplifiers are available, enabling higher-performance MR-J5 servo amplifiers with enhanced functions on the EtherCAT® system.

The servo amplifiers*3 support the touch probe. (Latch accuracy: 1 µs)

[EtherCAT®-compatible]

MR-J5-G-N1/MR-J5W2-G-N1/MR-J5W3-G-N1/ MR-J5D1-G4-N1/MR-J5D2-G4-N1/MR-J5D3-G4-N1

Communication specification	CANopen over EtherCAT [®] (CoE) Ethernet over EtherCAT [®] (EoE) Safety over EtherCAT [®] (FSoE)
Drive profile	CiA 402
Communication cycle *1	125 µs, 250 µs, 500 µs, 1 ms, 2 ms, 4 ms, 8 ms
	Cyclic synchronous position mode (csp)
	Cyclic synchronous velocity mode (csv)
	Cyclic synchronous torque mode (cst)
Control mode	Profile position mode (pp)
	Profile velocity mode (pv)*2
	Profile torque mode (tq)*2
	Homing mode (hm)

*1. The minimum communication cycle varies by the model type. *2. The control modes (pv/tq) are not supported by MR-J5W2-G-N1/MR-J5W3-G-N1/MR-J5D2-G4-N1/MR-J5D3-G4-N1. *3. Use MR-J5-G-N1 manufactured in June 2021 or later. Note that, depending on the stock status, the serve amplifiers with both the former and the new specifications may be distributed in the market around the same time. Contact the local sales office when the touch probe function is needed.



Enhanced functions

Servo Engineering Software MELSOFT MR Configurator2

Tuning, monitor display, diagnosis, reading/writing parameters, and test operations are easily performed on a personal computer. This powerful software tool supports a stable machine system and optimum control, and moreover, shortens setup time.


Parameter setting and docking help

Set parameters using the function display in the list without worries about the parameter No. and digits. Information related to the parameter being set is displayed in the docking help window. The latest e-Manual is also displayed in the docking help.




Supporting multi-axis project

Set parameters and monitor operation for multiple servo amplifiers through connecting to one of the servo amplifiers. Connecting via the Ethernet switching hub and the controller is also possible.



Graph function

Obtain graphs of 7 channels for analog and 8 channels for digital. Various servo statuses are displayed in the waveform at one measurement, supporting setting and adjustment. Convenient functions such as [Overwrite] for overwriting multiple data and [Select history] for displaying graph history are available. Two types of signals can be used as a trigger signal with an OR/AND condition.




Software reset

Reset the software for the servo amplifier with this new function. Setting switches and parameters is enabled without turning off the main circuit power supply of the servo amplifier.




Tuning function

Adjust control gains finely on the [Tuning] window manually for further performance after the quick tuning and the one-touch tuning.




Machine analyzer function

Input random torque to the servo motor automatically and analyze frequency characteristics (0.1 Hz to 8 kHz) of a machine system just by clicking the [Start] button. This function supports setting of machine resonance suppression filter, etc.




Drive System Sizing Software MELSOFT Motorizer

Select the most suitable servo motors, servo amplifiers, and regenerative options for your machine just by setting machine specifications and operation patterns. You can select a suitable combination from various results. This software also supports multi-axis systems, enabling you to set operation patterns and select options for multiple axes.



Flexible support for load mechanisms

- Select a load mechanism from 13 common types.
- Add transmission mechanisms such as a coupling.
- Set an inclination angle of the load mechanisms as desired.




Selection of several patterns

- Displays a list of load to motor inertia ratio, peak torque, etc., of each selection.
- Compatible with the expanded combinations of the servo amplifiers and the servo motors.
- Set threshold values for judgment.
- Displays energy-saving effect by multi-axis system

И				Water .	Matter-sepecity/citit	214	Dire (query, Brit)	Torque effective load emphil	Part load unit?()	(Notice test and ending No.	Matter autput weight:
	*		0	18.4712-08	6,000	NO 12-2002	8,000	100		047	1 10
		2	0	10.010	6.400	MR-11-495/R	1.400	and the second se	-	41	1.14
			۰	18.612336	6,700	MR /3-MIC/R	0.400		30.4		1 20
		1	0	HE-CORE	1.00	10.0.2004	1000	and the second se	and the local division of the local division	MP CO	1 84
				HE KNOW	4.78	AR IS 195.4	4.000	and the second se	and the second se	100 M 107	8 1 M 8

Compatible with multi-axis systems

- Supports the multi-axis servo amplifiers and the converters.
- Set operation patterns for multiple axes.
- Select regenerative options for a multi-axis system.



Tutorial video

• Illustrates how to use the software and select drive systems in the video.



servo Systen

FA Integrated Selection Tool

FA Integrated Selection Tool is available on the global website, so you can select multiple devices/entire system with one tool. Using "Select by device" or "Select by network" helps you to select devices such as programmable controllers and AC servos. Select necessary options such as encoder cables. Easily create system configuration diagrams and lists of necessary purchases to prevent mistakes when ordering.




Selection of controllers/servo motors/servo amplifiers

• Read selection results from Motorizer.

	formation Constant				10.1	
e.ene						
Status .	 1000	1	-		. 2	8
-	Contraction Contraction of Contract	1			1	•
1.000	(market			and the second se	1 11	
-Basi	Private manufactor Research Change Change		-	Annual Oral Annual Ottom, All Constant		2
	(market		-	Annuage of the Annual Office, Protocouper and		
@ truthe	C November New York Institute New York	L	-	HT state		
· Calerina	Descentive provider		mailure	Annual Control and Control of Control		
· Canada	CONTRACTOR CONTRACTOR CONTRACTOR					
	Name and Address of States	L • 1	-	Anti-specific Web Arecard Million. History pair out- this conduct		
4-8-mm	 					
+ B	Property and an		4.000	Rescouper 1 100 New year Officers, 1011 Investor,		
	Con.		-	And other 1 with And and Period Without Street Street Street, Street Str		


Selection of options

• Prevent selection mistakes.



Configuration

• Check a configuration of each axis.



Purchase list

• Export to a file in Excel format.

۰.	- mm.us		- California de Calegoria				
-	Participant.	-	Sectors.	 Beyrard (-	-	
	Augustalia antoine (h)	-	And and a start of the second start of the sec				
1	Balance at		144				
÷	from some state	-	Statement and				
	-	-	Manual and Manual Annual Annua				
,	L				- 1	1.0	ļ
	L			 -	-	1	
	-		and provide the second	-	-	1	
	-	-	age intel on their	 -	-		
	Patrone .	-	an kari u kan karikan Kan Marina Arris	-	-		
	National Society	844 10110	201 ISBN 19-1488 Series Start 19-15 - Start Starts, Starts, Start 19-15 - Starts, Starts,	-	-		
•	Takanan Secondari Secondaria Secondaria		ag kini waka Kata Maraka Kata Maraka Antas Kata Maraka Antas Kata Maraka Antas	-			

e-Manual

Instruction manuals for the MELSERVO-J5 series are available in e-Manual format. These manuals are linked with manuals for other products such as servo motors and controllers. The e-Manual lets you obtain necessary information quickly and also allows you to keep an enormous number of manuals as one database.

Currently supported languages: English, Japanese, Chinese

Features

- Use all necessary manuals as one database
- Download and use manuals in your local environment
- Use the e-Manual application on tablets
- Download and update manuals quickly and easily
- Search for desired information across multiple manuals



МЕМО	

A broader selection of capacities to match various applications for smart equipment







Small capacity, low inertia HK-KT Series

Servo motors with a 26-bit batteryless absolute position encoder

Rated speed: 3000 r/min *¹ Maximum speed: 6700 r/min *¹ Our product line includes 400 V and flat type models.

The servo motors have an all-in-one connector, making the connection simple.

*1. The speed varies by the model type.



Small capacity, ultra-low inertia

Servo motors with a 26-bit batteryless absolute position encoder

Rated speed: 3000 r/min Maximum speed: 10000 r/min (available with the high-speed type models*²)

The servo motors have an all-in-one connector, making the connection simple.

*2. The high-speed type models are equipped with an incremental encoder.



Medium capacity, medium inertia

Servo motors with a 26-bit batteryless absolute position encoder Rated speed: 2000 r/min, 3000 r/min

Two types of rated speed are available.

Our product line includes 400 V and flat type models.

The cables for the encoder, the electromagnetic brakes, and the power are equipped with one-touch lock.



Medium capacity, ultra-low inertia




Servo motors with a 26-bit batteryless absolute position encoder Rated speed: 3000 r/min Maximum speed: 6700 r/min *1 Our product line includes 400 V and flat type models.

The servo motors (1 to 2 kW) have an all-in-one connector, making the connection simple.

*1. The speed varies by the model type.

The HK series boasts a product line that offers servo motors of four different capacities and inertia: HK-KT series (small capacity, low inertia), HK-MT series (small capacity, ultra-low inertia), HK-ST series (medium capacity, medium inertia), and HK-RT series (medium capacity, ultra-low inertia). The servo motors are equipped with a batteryless absolute position encoder as standard.



Notes: The motor types are classified by the power class (200 V or 400 V) of the servo motors. The servo motors can be driven regardless of the servo amplifier power supply. For details of the rotary servo motors, refer to "4 Rotary Servo Motors".

Batteryless Absolute Position Encoder as Standard





Servo motors come equipped with a batteryless absolute position encoder as standard, making it possible to configure absolute position systems without the use of batteries or any other options.

Moreover, maintenance costs are reduced as a result of eliminating the battery replacement and stock control.

Reduce Wiring for Multi-Axis Systems

In a conventional multi-axis system, battery cables are necessary between the servo amplifiers. Now that the batteries are not required with the use of the batteryless absolute position encoders, wiring battery cables for multi-axis systems is not required.





Save Time in Transporting

Position data remains stored even when the rotary servo motors are disconnected from the servo amplifiers. Thus, control cabinets can be separated from the machines without losing the position data, making it easy to transport machines for use at a new location. The encoder does not require lithium metal batteries, allowing machines to be transported by air or sea without special handling.




Batteryless design eliminates the danger and hassle of lithium metal batteries.


Single Connector/One-Touch Lock/Single Cable Type

Single Connector/Single Cable Type/One-Touch Lock

The single connector for the HK-KT/HK-MT/HK-RT *¹ series combines the motor power supply, encoder, and electromagnetic brake into a single cable. The one-touch lock eliminates the need for tightening screws, making wiring easy. The servo motors are also compatible with the dual cable type. The cables can be mounted either horizontally or vertically according to your selection. Refer to "Options/Peripheral Equipment" for details of servo motor cables.

*1. The single connector is available for 1 to 2 kW of HK-RT series.








*1. The one-touch lock is available for 3.5 to 7 kW of HK-RT series.

Expanding Combinations of Servo Amplifiers and Servo Motors

The combinations of servo amplifiers and servo motors have been expanded to offer more flexible options for driving servo motors, such as combining a large-capacity servo amplifier for increased torque or combining a servo motor in a different power class. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" for details of the combinations.

Increases Maximum Torque by Combining with Larger-Capacity Servo Amplifiers


Combining the servo motor with a larger-capacity servo amplifier increases the maximum torque, leading a shorter cycle time.



Drives Smaller Capacity Servo Motors


Servo amplifiers are able to drive servo motors with a smaller capacity than the servo amplifier being used, reducing the kinds of spare parts that are needed.

For example, 400 W servo amplifiers are compatible with the following servo motors: 50 W, 100 W, 150 W, 200 W, and 400 W models.




Drives 200 V/400 V Class Servo Motors

The 200 V servo amplifiers can drive both 200 V and 400 V servo motors, and the 400 V servo motors may produce torque that is sufficient for operation when combined with smaller-capacity 200 V servo amplifiers. Lowering of the capacity of the servo amplifier contributes to lower costs and reduced installation space.



Compact Servo Motors with a Batteryless Absolute Position Encoder

HK-KT series servo motors come equipped with a batteryless absolute position encoder and are more compact than the previous generation HG-KR series. Flat types are also available in the HK-KT product line, contributing to a compact machine design.




Improved Environmental Resistance

Servo motors feature enhanced environmental resistance.

Ingress protection (IP) rating of the servo motors: IP67 \star1 Designed for an ambient temperature of up to 60 $^\circ\text{C}.^{\star2}$

*1. If the IP rating of the servo motor differs from those of option cables and connectors, overall IP rating depends on the lowest of all.

Perate the speed/torque when using the servo motors at high ambient temperatures.



Application Examples

Semiconductor/FPD/photovoltaic manufacturing systems	Mounters/bonders	X-Y tables	Robots
 Loaders/unloaders, feeders, and sliders	Food processing machines (filling machines, mixers, measuring machines, etc.)	Food packaging machines	Press machines

High-Response Operation by Ultra-Low Inertia Servo Motors

The product lines includes HK-MT series (small capacity, ultra-low inertia) and HK-RT series (medium capacity, ultra-low inertia). The ultra-low inertia servo motors enable a high-response operation that reduces the cycle time of an ultra-high-throughput material handling system.

Compact, High-Power Rate Servo Motors for High-Speed Operation Medium-capacity HK-RT series 1 to 7 kW

Comparison of HG-RF	R (previous s	eries) and HK-RT in 1 kW	(): Increased	torque
Servo motor mo	del	HG-RR103	HK-RT103W	
Rated output of a combined serv	vo amplifier [kW]	2.0	1.0 (2.0)	Smaller capacity servo amplifier
Flange size	[mm]	100	90	Reduced flange size (by 10 %)
Rated torque	[N·m]	3.3	2	
Maximum torque	[N·m]	8.0	8.0 (9.5)	Increased torque (to 118 %)
Maximum speed	[r/min]	4500	6700	Increased speed (to 148 %)
Moment of inertia J	[× 10 ⁻⁴ kg⋅m ²]	1.50	0.721	Lower inertia (by 52 %)
Power rate at rated torque	[kW/s]	67.4	141	Increased responsivity (to 209 %)
Motor length	[mm]	145.5	118.9	Reduced motor length (by 26.6 mm)

Comparison of HK-KT	Γ (low inertia)	and HK-RT in 2 kW	(): Increased	torque
Servo motor mo	del	HK-KT203W	HK-RT203W	
Flange size	[mm]		90	
Rated torque	[N⋅m]		6.4	
Maximum torque	[N⋅m]	19.1 (25.5)	15.9 (19.1)	
Maximum speed	[r/min]	6000	6700	 Increased speed (to 111 %)
Moment of inertia J	[× 10 ⁻⁴ kg⋅m ²]	5.65	1.28	Lower inertia (by 77 %)
Power rate at rated torque	[kW/s]	71.7	317	 Increased responsivity (to 442 %)
Motor length	[mm]	136.9	172.9	

Maximum Speed of 10000 r/min

The high-power rate servo motors are optimal for packaging machines and material handling systems. Servo motors with maximum speed of 10000 r/min *¹ are added to the product lines, contributing to a shorter cycle time.

*1. The high-speed type models have "V" in the model name and are equipped with an incremental encoder.

Small-capacity HK-MT series 0.05 to 1 kW




Maximum speed Standard servo motor: 6700 r/min High-speed servo motor: 10000 r/min *1 .

Servo motors for high-speed, high-accuracy, linear drive systems



Product Lines

Six series are available depending on applications.



Linear Servo Motors

Basic Performance

- Maximum speed: 3 m/s (LM-H3 series), 6.5 m/s (LM-AJ series)
- Maximum thrust range: 122 N to 7200 N. Small size and high thrust are achieved by the increased winding density and the optimized core and magnet geometries as a result of electromagnetic field analysis.
- Six series are available: core (two series), liquid-cooling core, magnetic attraction counter-force core, and coreless (two series) types.
- The linear servo motors are compatible with a variety of serial interface linear encoders. The linear encoder resolution ranges from 1 nm and up.
- High-performance systems such as high-accuracy tandem synchronous control are achieved with CC-Link IE TSN.
- The linear servo motors feature environmental resistance, designed for an altitude of 2000 m and an ambient temperature of up to 60 °C. *1.2
- *1. Derate the speed/thrust when using the linear servo motors at an altitude exceeding 1000 m and at high ambient temperatures.
- *2. LM-AJ series/LM-AU series are designed for an altitude of 1000 m and an ambient temperature of up to 40 °C.

[Offers more advantage than conventional ball screw driving

Higher Machine Performance

For higher machine performance

• Improved productivity due to high-speed driving part.

For easier use

- The linear servo motors enable a simple and compact machine with high rigidity.
- Smooth operation and clean systems are achieved.

For flexible machine configurations

- Multi-head and tandem systems are easily configured.
- The linear servo motors are suitable for long-stroke applications.


Application Examples

Optimum for a linear drive system which requires a high speed and high accuracy. Easily achieve a tandem configuration or multi-head configuration.




Tandem configuration


The linear servo motors configured in tandem are suitable for large systems that require highly accurate synchronous operation between two axes.



Multi-head configuration

Multi-head systems enable control of two motor coils independently, thereby simplifying machine mechanisms. This system is suitable for machines that require a short cycle time.





Compact and robust direct drive motors for high-accuracy applications







Low-profile for space and weight saving






High torque for high-weight capacity

Product Lines

18 models with 4 different diameters are available.



Direct Drive Motors

Basic Performance

High performance with the latest technologies

Our latest magnetic design and winding technologies enable high torque density. In addition, extremely smooth rotation is achieved by the minimized torque ripple.

High-resolution absolute position encoder

The direct drive motors are equipped with a high-resolution absolute position encoder (1,000,000 to 4,000,000 pulses/rev) as standard. High-accuracy machines are achieved.

Enhanced environmental resistance

The direct drive motors feature environmental resistance, designed for an altitude of 2000 m and an ambient temperature of 60 °C. \ast1

*1. Derate the speed/torque when using the direct drive motors at an altitude exceeding 1000 m or at high ambient temperatures.

Higher Machine Performance

For higher machine performance

- Suitable for low-speed and high-torque operations.
- High-accuracy positioning is achieved because the motors are directly coupled to a load.

For easier use

- Since mechanical transmission is no longer required, no backlash and no abrasion occurs, enabling smooth operation with less audible noise, a clean system, and easy maintenance.
- Less components are required for the system.

Compact and low-profile design

Due to high level of structural design technology, compact and low-profile design is achieved. This design enables a small mounting space and a low center of gravity.

Hollow shaft diameter range: ø20 mm to 104 mm

The motors are equipped with a large hollow shaft resulting from using bearing and encoder with large diameter. It allows cables and air tubing to pass through.

For flexible machine configurations

- A simple, compact, and high-rigid machine is achieved.
- Machine stability is enhanced due to the low-profile design and a low center of gravity.
- The motors have an inner rotor with hollow shaft that allows cables and pipes to pass through.

[No mechanical transmission contributing to no warp or distortion]



Application Examples

Suitable for low speed and high torque applications.

Coating and vapor deposition systems	Spin-type cleaning systems for FPD/semiconductor	FPD/semiconductor testing systems (XY0 tables)
Index table for machine tools	Rotary axis for polishing systems	Rotary axis for material handling robots
	Material handling/loader saction	





Taking evolution to the next step by supporting SSCNET III/H




Incorporate existing manufacturing devices into your new system and benefit from reduced costs and faster construction speed.

SSCNET III/H-Compatible Servo System

- The servo amplifiers allow the user to build a system that utilizes the existing assets of the servo system controllers. Servo parameters are converted when the servo amplifier is changed on the engineering software.
- MELSEC iQ-R series Motion controllers are equipped with servo system recorder, helping to locate the cause when trouble arises.

Utilizing MELSERVO-J5 Series Functions

- The servo amplifiers support functions of MELSERVO-J5 series such as quick tuning, machine diagnosis, and flexible combinations of the servo amplifiers and the servo motors.
- Servo motors with a batteryless absolute position encoder can be operated.




Corrective Maintenance

Servo System Recorder

The Motion controller automatically collects data of all servo amplifiers when an error occurs. The collected data, such as the command and the feedback values, greatly helps you analyze the error cause.

- Automatic collection of servo system data, such as the command and feedback values, without programming
- Data collection of all axes, which helps you locate the error cause even when the error is caused by the other axes without an error
- The co-recording function collects data even when an error occurs in other recording devices.

[Data collection]




GX LogViewer

The collected data can be checked on GX LogViewer. The operation status before and after an error is displayed in waveforms, which allows more detailed analysis and identification of the error cause.

[Features]

- Displays the collected data and events graphically.
- Enables users to adjust a graph easily by automatic adjustment function and drag operation.




Analyzing Data

Analyzing operation transition of the Motion controllers and the servo amplifiers before and after an error helps you locate the error cause.

[Example]

- 1. An error has occurred.
- 2. The speed and torque decreased even though the command position was increasing.


By analyzing the data in the recorder (1 and 2 above), users can find out a possible cause of the error, such as a disconnection of a power cable during operation.



RnMTCPU


SSCNET III/H-Compatible Servo System Controller

MELSEC-Q Series Simple Motion Module QD77MS



*1. For control that requires high-accuracy synchronization of multiple axes at load side, such as interpolation and synchronous control, configure a system using the same series servo amplifiers. *2. When an MR-J5-B is used for the driver communication function, use MR-J5-B for all of the master and following axes to be combined

[Reusing existing programs]





Transition from **MELSERVO-J4** Series to J5 Series Handbook

- The handbook explains the procedures for migrating an SSCNET III/H system with MR-J4-B to MR-J5-B.
- The handbook describes items necessary to be changed at migration and restrictions for when different series are mixed.



*1. The firmware cannot be updated. Use a module with the above serial No.

Addition of Combinations of HG Series Servo Motors and MR-J5 Series **AC Servo Amplifiers**

New functions of the MR-J5 servo amplifier can be used without replacing the existing servo motors used with the MR-J4 servo amplifier, improving the performance and functions of the system. Contact your local sales office for details.

SALES


&

SERVICE



Model Change from **MELSERVO-J4** Series to **MELSERVO-J5 Series**

- Servo parameters are converted when the servo amplifier is changed.
- The parameters that are read and changed by the program will not be changed. Review those parameters.



MELSEC-Q Series Motion Controller Q172DSCPU/Q173DSCPU/Q170MSCPU

*1. For control that requires high-accuracy synchronization of multiple axes at load side, such as interpolation and synchronous control, configure a system using the same series servo amplifiers. *2. When an MR-J5-B is used for the driver communication function, use MR-J5-B for all of the master and following axes to be combined.

MELSERI/O-15 MELSEG O series MELSEC O series Q172DSCPU Q172DSCPU MR-15-B MR-J4-B Q173DSCPU Q173DSCPU Version Q170MSCPU Q170MSCPU Operating system software SV13/SV22: 00Y or later Engineering environment MELSOFT MT Works2: 1.170C or later SALES MELSOFT SERVICE MT Works2



Transition from MELSERVO-J4 Series to J5 Series Handbook

 The handbook explains the procedures for migrating an SSCNET III/H system with MR-J4-B to MR-J5-B.

[Reusing existing programs]

 The handbook describes items necessary to be changed at migration and restrictions for when different series are mixed.



Addition of Combinations of HG Series Servo Motors and MR-J5 Series AC Servo Amplifiers


New functions of the MR-J5 servo amplifier can be used without replacing the existing servo motors used with the MR-J4 servo amplifier, improving the performance and functions of the system. Contact your local sales office for details.



Model Change from MELSERVO-J4 Series to MELSERVO-J5 Series


- Servo parameters are converted when the servo amplifier is changed.
- The parameters that are read and changed by the program will not be changed. Review those parameters.





*1. For control that requires high-accuracy synchronization of multiple axes at load side, such as interpolation and synchronous control, configure a system using the same series servo amplifiers. *2. When an MR-J5-B is used for the driver communication function, use MR-J5-B for all of the master and following axes to be combined

[Reusing existing programs]





Transition from **MELSERVO-J4** Series to J5 Series Handbook

- The handbook explains the procedures for migrating an SSCNET III/H system with MR-J4-B to MR-J5-B.
- The handbook describes items necessary to be changed at migration and restrictions for when different series are mixed.



Addition of Combinations of HG Series Servo Motors and MR-J5 Series **AC Servo Amplifiers**

MELSEC iQ R

RD77MS

New functions of the MR-J5 servo amplifier can be used without replacing the existing servo motors used with the MR-J4 servo amplifier, improving the performance and functions of the system. Contact your local sales office for details.



MELSERI/O-15

MB-J5-B

Model Change from **MELSERVO-J4** Series to **MELSERVO-J5 Series**

• Servo parameters are converted when the servo amplifier is changed.


Version

Software version*1 13 or later

Engineering environment GX Works3: 1.085P or later MR Configurator2:

1.134Q or later


• The parameters that are read and changed by the program will not be changed. Review those parameters.



MELSEC iQ-R Series Motion Controller R16MTCPU/R32MTCPU/R64MTCPU

*1. For control that requires high-accuracy synchronization of multiple axes at load side, such as interpolation and synchronous control, configure a system using the same series servo amplifiers. *2. To use the servo system recorder and digital oscilloscope function simultaneously, use a Motion controller shipped in July 2022 or later.

When an MR-J5-B is used for the driver communication function, use MR-J5-B for all of the master and following axes to be combined.







Transition from MELSERVO-J4 Series to J5 Series Handbook

- The handbook explains the procedures for migrating an SSCNET III/H system with MR-J4-B to MR-J5-B.
- The handbook describes items necessary to be changed at migration and restrictions for when different series are mixed.



Addition of Combinations of HG Series Servo Motors and MR-J5 Series AC Servo Amplifiers


New functions of the MR-J5 servo amplifier can be used without replacing the existing servo motors used with the MR-J4 servo amplifier, improving the performance and functions of the system. Contact your local sales office for details.



Model Change from MELSERVO-J4 Series to MELSERVO-J5 Series

- Servo parameters are converted when the servo amplifier is changed.
- The parameters that are read and changed by the program will not be changed. Review those parameters.

FUTURE MANUFACTURING



The Future of Manufacturing as envisioned by Mitsubishi Electric, e-F@ctory: "Manufacturing" that evolves in response to environmental changes in an IoT enabled world.

Established In 2003, e-F@ctory created a Kaizen^{#1} automation methodology to help optimize and manage the increasingly complex business of "manufacturing".

Continuously evolving itself, it also utilizes the expanded reach of IT, which has brought "cyber world" benefits of analysis, simulation and virtual engineering, and yet has also placed greater demands on the sensing, collection and communication. The continued success of e-F@ctory comes from understanding that each manufacturer has individual needs and investment plans but must still deliver; "Reduced management costs" (TCO); production flexibility to make a multitude of product in varying quantities; continuously enhanced guality. In short e-F@ctory's goal is to deliver operational performance that is "a step ahead of the times", while enabling manufacturing to evolve in

response to its environment. To do this it is supported by three key elements:

- The e-F@ctory Alliance Partners; who bring a wide range of software, devices, and system integration skills that enable the creation of the optimal e-F@ctory architecture.
- "physical" world for increased data sensing, collection and communication. The continued success of e-F@ctory comes from understanding that each manufacturer has individual needs and investment plans but must still deliver; "Reduced management costs" • Advanced communication; utilizing open network technology like CC-Link IE, and communication middleware such as OPC, to open the door to device data, including legacy systems, while supporting high speed extraction.
 - Platform thinking; to reduce the number of complex interfaces making it easier to bring together Robotics, Motion, Open programming languages (C language), PACs etc. strengthening the field of control,

yet operating on industrial strength hardware.





Mitsubishi Electric Partners

e-F@ctory Alliance


The e-F@ctory Alliance is a FA manufacturer partnering program that strongly links the connection compatibility of Mitsubishi Electric FA equipment utilizing excellent software and machinery offered by partners, thereby enabling systems to be built by systems integration partners and the proposal of optimal solutions to customers.



Mitsubishi Electric Servo System Partners

Servo system includes controllers, servo drivers, actuators, sensors, etc. The servo system takes a step further to accelerate the equipment revolution by collaborating with our partner companies. Now that a wide variety of partner products are available such as stepping motors, pressure-resistance, explosion-proof type motors, linear encoders, your system will be configured flexibly. The Mitsubishi Electric Servo System Partner Association is a subcommittee of e-F@ctory Alliance.

Partner product lines supporting CC-Link IE TSN and MELSERVO-J5 have been and will continue to be expanded sequentially.



Mitsubishi Electric FA Global Website

Mitsubishi Electric Factory Automation provides a mix of services to support its customers worldwide, through a consolidated global website. It offers a selection of support tools and a window to its local Mitsubishi Electric sales and support network.

Global & Local Websites

Mitsubishi Electric Factory Automation Global website www.MitsubishiElectric.com/fa



		y Automation								
Facto	ary Auton	nation								
Loc	ations	Vorldw	ride							
	Factory A	utomation	Global							
	· contact									
	Americas		Asia-Pacific	Europe, t	he Middle E	ast and Afr	ica .			
	* Argentina	+ Bulleta	* Australia	• Partal Sile						
	* Bradi * Chile	+ Canadia + Calombia	+ China + India	+ Algeria + Bulgeria	+ Apabria + Croatia	+ Belans + Canth	• Belgium			
	* Gosta Rica	• Econder	Indennial * IB (* ID)			Republic				
	 Goatemale 	· renduces	· Johns	* 520A	* Estoria	* Foliand	* Rance			
	· Western	• Penama	* Roma	* Germany	* Groot	* Hungary	* inclunal			
	+ Peru	 Designed temperature 	 Hutepile Hutepile 	* tonet	+ tely	* Karakhese	· Latvia			
	* Oragony	* Terminelle	* Singapore	· maranza	A hothertands	· Norway	+ Peterd			
			* Talwar	· Romanna	· Avera	+ 1mm	* Inches			
			Thatland (* TH / # IN)			Arabia				
			Weener + W/ + DO	* Donation	· Sevenia	· South Africa	* tpoin			
				* Incolare	 Switzerland 	* Turnin	* Turbey			



e-Manual

Instruction manuals are available in e-Manual format.

- Use the e-Manual application on tablets
- Download and update manuals quickly and easily
- Search for desired information across multiple manuals



FA Integrated Selection Tool

FA Integrated Selection Tool is now available, so you can select options such as encoder cables and power cables which are required to use with controllers, servo motors, servo amplifiers, and regenerative options of your choice.



FA Integrated Selection Tool

Common Specifications

Combinations of Rotary Servo Motors and Servo Amplifiers1	-2
Combinations of Rotary Servo Motors and Drive Units1	-6
Combinations of Geared Servo Motors and Servo Amplifiers or Drive Units1	-7
Combinations of Linear Servo Motors and Servo Amplifiers1	-8
Combinations of Direct Drive Motors and Servo Amplifiers1-	10
Safety Sub-Functions1-	11
Environment1-	13

 * Refer to p. 7-78 in this catalog for conversion of units.

The torque can be increased by combining a large-capacity servo amplifier.

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

1-axis servo amplifier (200 V)

 $\bigcirc:$ Standard torque @: Torque increased

Dotony convo	or (Note 2)		Servo am	plifier MR-J5	(200 V)					
Rotary servo mot	UI (1002)		10G/B/A	20G/B/A	40G/B/A	60G/B/A	70G/B/A	100G/B/A	200G/B/A	350G/B/A
		HK-KT053W	0	0	0	-	-	-	-	-
	40 × 40	HK-KT13W	0	0	0	-	-	-	-	-
		HK-KT1M3W	-	0	0	0	-	-	-	-
		HK-KT13UW	0	0	0	-	-	-	-	-
		HK-KT23W	-	0	0	0	-	-	-	-
	60 × 60	HK-KT43W	-	-	0	0	0	-	-	-
		HK-KT63W	-	-	-	-	0	0	0	-
		HK-KT23UW	-	0	0	0	-	-	-	-
HK-KT_W	00 00	HK-KT43UW	-	-	0	0	0	-	-	-
	80 × 80	HK-KT7M3W	-	-	-	-	0	0	0	-
		HK-KT103W	-	-	-	-	-	0	0	0
		HK-KT63UW	-	-	-	0	0	0	-	-
		HK-KT7M3UW	-	-	-	-	0	0	0	-
		HK-KT103UW	-	-	-	-	-	0	0	0
	90 × 90	HK-KT153W	-	-	-	-	-	-	0	0
		HK-KT203W	-	-	-	-	-	-	0	0
		HK-KT202W	-	-	-	-	-	-	0	0
		HK-KT434W	-	0	0	0	-	-	-	-
	60 × 60	HK-KT634W	-	-	0	0	0	-	-	-
		HK-KT7M34W	-	-	0	0	0	-	-	-
HK-KT_4_W	80 × 80	HK-KT1034W	-	-	-	0	0	0	-	-
		HK-KT1534W	-	-	-	-	0	0	0	-
	90 × 90	HK-KT2034W	-	-	-	-	-	0	0	0
		HK-KT2024W	-	-	-	-	-	0	0	0
		HK-MT053W	0	0	0	-	-	-	-	-
	40 × 40	HK-MT13W	0	0	0	-	-	-	-	-
		HK-MT1M3W	-	0	0	-	-	-	-	-
		HK-MT23W	-	0	0	-	-	-	-	-
HK-MT_W (Note 3)	60×60	HK-MT43W	-	-	0	-	0	-	-	-
		HK-MT63W	-	-	-	-	0	-	0	-
		HK-MT7M3W	-	-	-	-	0	-	0	-
	80 × 80	HK-MT103W	-	-	-	-	-	0	0	-
		HK-MT053VW	0	0	0	-	-	-	-	-
	40 × 40	HK-MT13VW	0	0	0	-	-	-	-	-
_		HK-MT1M3VW	-	0	0	-	-	-	-	-
		HK-MT23VW	-	0	0	-	-	-	-	-
HK-MT_VW (Note 3)	60×60	HK-MT43VW	-	-	-	0	0	-	-	-
		HK-MT63VW	-	-	-	-	0	-	0	-
		HK-MT7M3VW	-	-	-	-	0	-	0	-
	80 × 80	HK-MT103VW	-						0	0

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output. 2. The combinations of servo amplifiers and servo motors with an electromagnetic brake or servo motors with functional safety are the same as those described in this table. Refer to "Combinations of Geared Servo Motors and Servo Amplifiers or Drive Units" for the combinations of geared servo motors and servo amplifiers.

3. Use the servo amplifiers with firmware version C2 or later. If the servo amplifiers with the previous firmware version are connected, an alarm occurs.

The torque can be increased by combining a large-capacity servo amplifier.

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

1-axis servo amplifier (200 V)

○: Standard torque ◎: Torque increased

Specifications Common

Rotary servo m	otor (Note 2)		Servo amp	olifier MR-J5	(200 V)						
notary servo m			40G/B/A	60G/B/A	70G/B/A	100G/B/A	200G/B/A	350G/B/A	500G/B/A	700G/B/A	5
		HK-ST52W	-	0	0	0	-	-	-	-	
		HK-ST102W	-	-	-	0	0	0	-	-	_
		HK-ST172W	-	-	-	-	0	0	-	-	_
	130 × 130	HK-ST202AW	-	-	-	-	0	0	-	-	
		HK-ST302W	-	-	-	-	-	0	O (Note 4)	-	
		HK-ST353W	-	-	-	-	-	0	\odot	-	
IK-ST_W		HK-ST503W	-	-	-	-	-	-	0	0	
		HK-ST7M2UW	-	-	0	0	0	-	-	-	
		HK-ST172UW	-	-	-	-	0	0	-	-	
	176 × 176	HK-ST202W	-	-	-	-	0	0	-	-	
	1/6 × 1/6	HK-ST352W	-	-	-	-	-	0	O (Note 4)	-	-
		HK-ST502W	-	-	-	-	-	-	0	0	
		HK-ST702W	-	-	-	-	-	-	-	0	
		HK-ST524W	0	0	0	-	-	-	-	-	•
		HK-ST1024W	-	0	0	0	-	-	-	-	
	130 × 130	HK-ST1724W	-	-	-	0	0	0	-	-	
		HK-ST2024AW	-	-	-	0	0	0	-	-	
HK-ST_4_W		HK-ST3024W	-	-	-	-	0	0	-	-	-
		HK-ST2024W	-	-	-	-	0	0	-	-	1
	170 170	HK-ST3524W	-	-	-	-	0	0	-	-	
	176 × 176	HK-ST5024W	-	-	-	-	-	0	(Note 4)	-	•
		HK-ST7024W	-	-	-	-	-	-	0	0	•
		HK-RT103W	-	-	-	(Note 3)	0	-	-	-	-
	90 × 90	HK-RT153W	-	-	-	-	0	-	0	-	1
		HK-RT203W	-	-	-	-	0	0	-	-	•
IK-RT_W		HK-RT353W	-	-	-	-	-	0	0	-	
	130 × 130	HK-RT503W	-	-	-	-	-	-	0	0	
		HK-RT703W	-	-	-	-	-	-	-	0	•

2. The combinations of servo amplifiers and servo motors with an electromagnetic brake or servo motors with functional safety are the same as those described in this table. Refer to "Combinations of Geared Servo Motors and Servo Amplifiers or Drive Units" for the combinations of geared servo motors and servo amplifiers.

3. The dynamic brake time constant is longer than that of when the previous HG-RR103 and MR-J4-200_ are combined. When the time constant equivalent to that of the previous series is required, combine HK-RT103W and MR-J5-200_. Refer to "MR-J5 User's Manual" for how to calculate the coasting distance.

4. Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

Support

1-3

The torque can be increased by combining a large-capacity servo amplifier.

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

1-axis servo amplifier (400 V)

Servo amplifier MR-J5-_ (400 V) Rotary servo motor (Note 2) 500G4/B4/A4 60G4/B4/A4 100G4/B4/A4 200G4/B4/A4 350G4/B4/A4 700G4/B4/A4 (Note 3) HK-KT053W (Note 3) HK-KT W (Note 3) (Note 3) 40×40 HK-KT13W (Note 3) (Note 3) HK-KT1M3W (Note 3) (Note 3) HK-KT434W (Note 3) 60×60 HK-KT634W (Note 3) (Note 3) (Note 3) (Note 3) (Note 3) (Note 3) HK-KT7M34W 80×80 HK-KT1034W (Note 3) (Note 3) (Note 3) HK-KT634UW 0 HK-KT_4_W 0 \cap HK-KT1034UW 0 90×90 HK-KT1534W (Note 3) (Note 3) HK-KT2034W (Note 3) (Note 3) HK-KT2024W) (Note 3) (Note 3) (Note 4) (Note 4) HK-ST524W (Note 4) HK-ST1024W (Note 4) (Note 4) (Note 4) HK-ST1724W (Note 4) (Note 4) (Note 5) 130×130 HK-ST2024AW (Note 4) (Note 4) (Note 5) (Note 4) (Note 5) (Note 5) HK-ST3024W HK-ST_4_W HK-ST3534W 0 0 HK-ST5034W O HK-ST2024W (Note 4) (Note 4) (Note 5) (Note 4) (Note 5) HK-ST3524W (Note 5) 176 × 176 HK-ST5024W (Note 5) (Note 5) (Note 5) HK-ST7024W \bigcirc HK-RT1034W \cap 90×90 HK-RT1534W 0 HK-RT2034W С HK-RT 4W HK-RT3534W 0 HK-RT5034W 130×130 \cap HK-RT7034W 0

O: Standard torque O: Torque increased

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output.

2. The combinations of servo amplifiers and servo motors with an electromagnetic brake or servo motors with functional safety are the same as those described in this

table. Refer to "Combinations of Geared Servo Motors and Servo Amplifiers or Drive Units" for the combinations of geared servo motors and servo amplifiers. 3. Use the rotary servo motors manufactured in September 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to

"Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufactured before that date are connected, an atam occurs. Refer to 4. Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to

4. Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

5. Use the rotary servo motors manufactured in April 2021 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

The torque can be increased by combining a large-capacity servo amplifier.

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

Any combination of the rotary servo motors, the linear servo motors, and the direct drive motors with different series and capacities is possible as long as the servo motors are compatible with the servo amplifier.

	(1) (1)		Servo ampl	ifier MR-J5W2-	_		Servo ampl	ifier MR-J5W3	
Rotary servo moto	Or (Note 2)		22G/B	44G/B		1010G/B	222G/B		ed
		HK-KT053W	0	0	-	-	0	0	-
	40 × 40	HK-KT13W	0	0	-	-	0	0	
		HK-KT1M3W	0	0	-	-	0	0	-
		HK-KT13UW	0	0	-	-	0	0	-
	0000	HK-KT23W	0	0	-	-	0	0	-
	60 × 60	HK-KT43W	-	0	0	0	-	0	_
		HK-KT63W	-	-	0	0	-	-	_
HK-KT_W		HK-KT23UW	0	0	-	-	0	0	
	00 00	HK-KT43UW	-	0	0	0	-	0	-
	80 × 80	HK-KT7M3W	-	-	0	0	-	-	-
		HK-KT103W	-	-	-	0	-	-	-
		HK-KT63UW	-	-	0	0	-	-	-
	90 × 90	HK-KT7M3UW	-	-	0	0	-	-	7
		HK-KT103UW	-	-	-	0	-	-	-
		HK-KT434W	0	0	-	-	0	0	-
	60 × 60	HK-KT634W	-	0	0	0	-	0	-
		HK-KT7M34W	-	0	0	0	-	0	
HK-KT_4_W	80 × 80	HK-KT1034W	-	-	0	0	-	-	
		HK-KT1534W	-	-	0	0	-	-	
	90 × 90	HK-KT2034W	-	-	-	0	-	-	-
		HK-KT2024W	-	-	-	0	-	-	-
		HK-MT053W	0	0	_	-	0	0	-
	40 × 40	HK-MT13W	0	0	-	-	0	0	
		HK-MT1M3W	0	0	-	-	0	0	-
		HK-MT23W	0	0	_	_	0	0	-
HK-MT_W (Note 3)	60 × 60	HK-MT43W	-	0	0	0	-	0	-
		HK-MT63W	-	-	0	0	_	-	-
		HK-MT7M3W	-	-	0	0	-	-	-
	80 × 80	HK-MT103W	-	-	-	0	-	-	
		HK-MT053VW	0	0		-	0	0	-
	40 × 40	HK-MT13VW	0	0	-	-	0	0	-1
		HK-MT1M3VW	0	0	-	-	0	0	-
HK-MT_VW (Note 3)		HK-MT23VW	0	0	-	-	0	0	-
	60 × 60	HK-MT43VW	-	-	0	0	-	-	-
		HK-MT63VW	-	-	0	0	-	-	- 1
	80 × 80	HK-MT7M3VW	-	-	0	0	-	-	-
		HK-ST52W	-	-	0	0	-	-	-
HK-ST_W	130 × 130	HK-ST102W	-		-	0	-	-	-
	176 x 176	HK-ST7M2UW	-	-	0	0	-	-	-
		HK-ST524W	-	0	0	-	-	0	-
		HK-ST1024W	-	-	0	0	-	-	-
HK-ST_4_W	130 × 130	HK-ST1724W	-		-	0	-		-
		HK-ST2024AW	-			0	-		-
		111 012024/10				\sim			

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output.

2. The combinations of servo amplifiers and servo motors with an electromagnetic brake or servo motors with functional safety are the same as those described in this

table. Refer to "Combinations of Geared Servo Motors and Servo Amplifiers or Drive Units" for the combinations of geared servo motors and servo amplifiers. 3. Use the servo amplifiers with firmware version C2 or later. If the servo amplifiers with the previous firmware version are connected, an alarm occurs.

Support

Combinations of Rotary Servo Motors and Drive Units (Note 1, 2)

The torque can be increased by combining a large-capacity drive unit.

The torque characteristics vary by the combinations. Refer to the list of the specifications of each rotary servo motor.

Any combination of the servo motors with different series and capacities is possible as long as the servo motors are compatible with the multi-axis drive unit.

Drive unit (400 V)

○: Standard torque ◎: Torque increased

Rotary servo r	notor (Note 2)		Drive ur	nit MR-J	5D1			Drive ur	nit MR-J5	5D2			Drive ur MR-J5D	
,			100G4	200G4	350G4	500G4	700G4	100G4	200G4	350G4	500G4	700G4		
		HK-KT053W	(Note 3)	-	-	-	-	(Note 3)	-	-	-	-	O (Note 3)	-
HK-KT_W	40 × 40	HK-KT13W	(Note 3)	-	-	-	-	(Note 3)	-	-	-	-	(Note 3)	-
		HK-KT1M3W	O (Note 3)	-	-	-	-	O (Note 3)	-	-	-	-	O (Note 3)	-
	0000	HK-KT434W	O (Note 3)	O (Note 3)	-	-	-	O (Note 3)	O (Note 3)	-	-	-	O (Note 3)	(Note
	60 × 60	HK-KT634W	(Note 3)	O (Note 3)	O (Note 3)	-	-	(Note 3)	O (Note 3)	O (Note 3)	-	-	(Note 3)	(Note
	0000	HK-KT7M34W	(Note 3)	(Note 3)	O (Note 3)	-	-	(Note 3)	(Note 3)	O (Note 3)	-	-	(Note 3)	(Note
	80 × 80	HK-KT1034W	(Note 3)	(Note 3)	O (Note 3)	-	-	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note
HK-KT_4_W		HK-KT634UW	0	0	-	-	-	0	0	-	-	-	0	0
		HK-KT1034UW	0	0	0	-	-	0	0	0	-	-	0	0
	90 × 90	HK-KT1534W	-	(Note 3)	O (Note 3)	-	-	-	(Note 3)	(Note 3)	-	-	-	(Note
		HK-KT2034W	-	(Note 3)	(Note 3)	-	-	-	(Note 3)	O (Note 3)	-	-	-	(Note
		HK-KT2024W	-	(Note 3)	O (Note 3)	-	-	-	(Note 3)	O (Note 3)	-	-	-	(Note
		HK-ST524W	O (Note 4)	O (Note 4)	-	-	-	O (Note 4)	O (Note 4)	-	-	-	O (Note 4)	(Note
		HK-ST1024W	(Note 4)	O (Note 4)	O (Note 4)	-	-	(Note 4)	O (Note 4)	O (Note 4)	-	-	(Note 4)	(Note
		HK-ST1724W	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note 4)	(Note 4)	(Note 5)	-	-	(Note
	130 × 130	HK-ST2024AW	-	(Note 4)	O (Note 4)	O (Note 5)	-	-	(Note 4)	O (Note 4)	O (Note 5)	-	-	(Note
		HK-ST3024W	-	-	(Note 4)	O (Note 5)	O (Note 5)	-	-	(Note 4)	O (Note 5)	O (Note 5)	-	-
HK-ST_4_W		HK-ST3534W	-	-	0	0	-	-	-	0	0	-	-	-
		HK-ST5034W	-	-	-	0	0	-	-	-	0	0	-	-
		HK-ST2024W	-	(Note 4)	O (Note 4)	O (Note 5)	-	-	(Note 4)	O (Note 4)	O (Note 5)	-	-	(Note
	176 176	HK-ST3524W	-	-	(Note 4)	(Note 5)	O (Note 5)	-	-	(Note 4)	O (Note 5)	O (Note 5)	-	-
	176 × 176	HK-ST5024W	-	-	-	(Note 5)	O (Note 5)	-	-	-	(Note 5)	O (Note 5)	-	-
		HK-ST7024W	-	-	-	-	(Note 5)	-	-	-	-	(Note 5)	-	-
		HK-RT1034W	0	0	-	-	-	0	0	-	-	-	0	0
		HK-RT1534W	-	0	-	0	-	-	0	-	0	-	-	0
		HK-RT2034W	-	0	0	-	-	-	0	0	-	-	-	0
HK-RT_4W		HK-RT3534W	-	-	0	0	-	-	-	0	0	-	-	-
	130 × 130	HK-RT5034W	-	-	-	0	0	-	-	-	0	0	-	-
		HK-RT7034W	-	-	-	-	0	-	-	-	-	0	-	-

Notes: 1. The combinations of servo motors and drive units with special specifications are the same as those of standard drive units.

Refer to the drive units with the same rated output.

2. The combinations of drive units and servo motors with an electromagnetic brake or servo motors with functional safety are the same as those described in this table.

Refer to "Combinations of Geared Servo Motors and Servo Amplifiers or Drive Units" for the combinations of geared servo motors and drive units. 3. Use the rotary servo motors manufactured in September 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

4. Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

5. Use the rotary servo motors manufactured in April 2021 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

Combinations of Geared Servo Motors and Servo Amplifiers or Drive Units (Note 1, 2)

The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers or drive units.

Any combination of the servo motors with different series and capacities is possible as long as the servo motors are compatible with the multi-axis servo amplifier or the multi-axis drive unit. The multi-axis servo amplifier can be used in a mixed combination of the rotary servo motors, the linear servo motors, and the direct drive motors.

1-axis servo amplifier (200 V)

servo motors,	the linear s	servo motors, a	ina the all	ect drive	motors.								S
1-axis servo	o amplifie	r (200 V)									⊖: Sta	ndard torque	Servo System Controllers
Geared servo	motor (Note 2)		Servo an	plifier MR	-J5 (200) V)							Sys
Geared servo			10G/B/A	20G/B/A	40G/B/A	60G/B/A	70G/B/A	100G/B/A	200G/B/A	350G/B/A	500G/B/A	700G/B/A	sten ers
	40 × 40	HK-KT053G_	0	0	0	-	-	-	-	-	-	-	
	40 × 40	HK-KT13G_	0	0	0	-	-	-	-	-	-	-	Se
HK-KT_G_	60 × 60	HK-KT23G_	-	0	0	0	-	-	-	-	-	-	ONI
	60 × 60	HK-KT43G_	-	-	0	0	0	-	-	-	-	-	Am
	80 × 80	HK-KT7M3G_	-	-	-	-	0	0	0	-	-	-	Amplifiers
		HK-ST52G_	-	-	-	0	0	0	-	-	-	-	ers
	130 × 130	HK-ST102G_	-	-	-	-	-	0	0	0	-	-	
		HK-ST152G_	-	-	-	-	-	-	0	0	-	-	Ro
HK-ST_G_		HK-ST202G_	-	-	-	-	-	-	0	0	-	-	Rotary Se Motors
	170 170	HK-ST352G_	-	-	-	-	-	-	-	0	(Note 3)	-	Servo tors
	176 × 176	HK-ST502G_	-	-	-	-	-	-	-	-	0	0	No
		HK-ST702G_	-	-	-	-	-	-	-	-	-	0	

1-axis servo amplifier (400 V)

1-axis servo	amplifier	(400 V)						O: Standard torque	near Sei Motors
Geared servo I	motor (Note 2)		Servo amplifier I	MR-J5 (400 V)					otor.
Geared Servor			60G4/B4/A4	100G4/B4/A4	200G4/B4/A4	350G4/B4/A4	500G4/B4/A4	700G4/B4/A4	s
		HK-ST524G_	(Note 3)	(Note 3)	(Note 3)	-	-	-	0
	130 × 130	HK-ST1024G_	-	(Note 3)	(Note 3)	(Note 3)	-	-	
		HK-ST1524G_	-	-	(Note 3)	(Note 3)	(Note 4)	-	Dire
HK-ST_4G_		HK-ST2024G_	-	-	(Note 3)	(Note 3)	(Note 4)	-	Motors
	176 176	HK-ST3524G_	-	-	-	(Note 3)	(Note 4)	(Note 4)	Driv
	176 × 176	HK-ST5024G_	-	-	-	-	(Note 4)	(Note 4)	Ð
		HK-ST7024G_	-	-	-	-	-	(Note 4)	0

Multi-axis servo amplifier (200 V)

Multi-axis s	ervo amp	lifier (200 V)						O: Standard torque	Equipment
	(Noto 2)		Servo amplifier	MR-J5W2			Servo amplifier I	MR-J5W3	pme
Geared servo	motor (Note 2)		22G/B	44G/B	77G/B	1010G/B	222G/B	444G/B	int
	40 × 40	HK-KT053G_	0	0	-	-	0	0	ž
	40 x 40	HK-KT13G_	0	0	-	-	0	0	
HK-KT_G_	60 × 60	HK-KT23G_	0	0	-	-	0	0	LVS
	00 × 00	HK-KT43G_	-	0	0	0	-	0	≥
	80 × 80	HK-KT7M3G_	-	-	0	0	-	-	ires
HK-ST G	130 × 130	HK-ST52G_	-	-	0	0	-	-	
HK-31_G_	130 × 130	HK-ST102G	-	-	-	0	-	-	

Drive unit (400 V)

												aru torque		
Geared servo	motor (Note 2)		Drive ur	nit MR-J5	5D1			Drive ur	nit MR-J5		Drive unit MR-J5D3			
					350G4	500G4	700G4	100G4	200G4	350G4	500G4	700G4	100G4	200G4
		HK-ST524G_	(Note 3)	(Note 3)	-	-	-	(Note 3)	(Note 3)	-	-	-	(Note 3)	(Note 3)
	130 × 130	HK-ST1024G_	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)	(Note 3)	-	-	(Note 3)	(Note 3)
		HK-ST1524G_	-	(Note 3)	(Note 3)	(Note 4)	-	-	(Note 3)	(Note 3)	(Note 4)	-	-	(Note 3)
HK-ST_4G_		HK-ST2024G_	-	(Note 3)	(Note 3)	(Note 4)	-	-	(Note 3)	(Note 3)	(Note 4)	-	-	(Note 3)
	176 176		-	-	(Note 3)	O (Note 4)	(Note 4)	-	-	(Note 3)	(Note 4)	(Note 4)	-	-
176 × 176 HK-ST5024			-	-	-	(Note 4)	(Note 4)	-	-	-	(Note 4)	(Note 4)	-	-
		HK-ST7024G_	-	-	-	-	(Note 4)	-	-	-	-	(Note 4)	-	-

Notes: 1. The combinations of servo motors and servo amplifiers or drive units with special specifications are the same as those of standard servo amplifiers or drive units. Refer to the servo amplifiers or drive units with the same rated output.

2. The combinations of servo motors with an electromagnetic brake and servo amplifiers or drive units are the same as those described in this table.

3. Use the rotary servo motors manufactured in December 2020 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

4. Use the rotary servo motors manufactured in April 2021 or later. If the rotary servo motors manufactured before that date are connected, an alarm occurs. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for how to check the date of manufacture.

1-7

Product

List

1-axis servo amplifier

O: Standard thrust

Linear se	ervo motor			nplifier MI							
	Primary side (coil)	Secondary side (magnet)	20G/B/A	40G/B/A	60G/B/A	70G/B/A	100G/B/A	200G/B/A	350G/B/A	500G/B/A	700G/B/
		LM-H3S20-288-BSS0									
	LM-H3P2A-07P-BSS0	LM-H3S20-384-BSS0	-	0	-	-	-	-	-	_	-
		LM-H3S20-480-BSS0									
		LM-H3S20-768-BSS0									
	LM-H3P3A-12P-CSS0	LM-H3S30-288-CSS0	-	0	-	-	-	-	-	-	-
M-H3		LM-H3S30-384-CSS0	-	-	-	0	-	-	-	-	-
series	LM-H3P3C-36P-CSS0	LM-H3S30-480-CSS0	-	-	-	0	-	-	-	-	-
	LM-H3P3D-48P-CSS0	LM-H3S30-768-CSS0	-	-	-	-	-	0	-	-	-
	LM-H3P7A-24P-ASS0	I M-H3S70-288-ASS0	-	-	-	0	-	-	-	-	-
	LM-H3P7B-48P-ASS0	LM-H3S70-384-ASS0	-	-	-	-	-	0	-	-	-
	LM-H3P7C-72P-ASS0	LM-H3S70-480-ASS0	-	-	-	-	-	0	-	-	-
	LM-H3P7D-96P-ASS0	LM-H3S70-768-ASS0	-	-	-	-	-	-	0	-	-
	LM-AJP1B-07K-JSS0	LM-AJS10-080-JSS0									
	LIVI-AJP ID-07K-JSSU	LM-AJS10-200-JSS0	-	0	-	-	-	-	-	-	-
	LM-AJP1D-14K-JSS0	LM-AJS10-400-JSS0	-	-	-	0	-	-	-	-	-
	LM-AJP2B-12S-JSS0	LM-AJS20-080-JSS0									
	LINI-AJP2D-123-J330	LM-AJS20-200-JSS0	-	0	-	-	-	-	-	-	-
_M-AJ	LM-AJP2D-23T-JSS0	LM-AJS20-400-JSS0	-	-	-	0	-	-	-	-	-
eries	LM-AJP3B-17N-JSS0	LM-AJS30-080-JSS0		0							
Note 2)	LIVI-AJF3D-17IV-J330	LM-AJS30-200-JSS0	-	0	-	-	-	-	-	-	-
	LM-AJP3D-35R-JSS0	LM-AJS30-400-JSS0	-	-	-	0	-	-	-	-	-
	LM-AJP4B-22M-JSS0	LM-AJS40-080-JSS0		0							
	LIVI-AJF4D-22IVI-J330	LM-AJS40-200-JSS0	-	0	-	-	-	-	-	-	-
	LM-AJP4D-45N-JSS0	LM-AJS40-400-JSS0	-	-	-	0	-	-	-	-	-
	LM-FP2B-06M-1SS0		-	-	-	-	-	0	-	-	-
	LM-FP2D-12M-1SS0	LM-FS20-480-1SS0	-	-	-	-	-	-	-	0	-
M-F	LM-FP2F-18M-1SS0	LM-FS20-576-1SS0	-	-	-	-	-	-	-	-	0
series	LM-FP4B-12M-1SS0	LM-FS40-480-1SS0	-		_	_	_	-	-	0	-
	LM-FP4D-24M-1SS0	LM-FS40-576-1SS0	-	-	-	-	-	-	-		0
	LIVI-FF4D-24IVI-1550		-	-	-	-	-	-	-	-	0
	LM-K2P1A-01M-2SS1	LM-K2S10-288-2SS1	-	0	-	-	-	-	-	-	-
		LM-K2S10-384-2SS1 LM-K2S10-480-2SS1									
	LM-K2P1C-03M-2SS1	LM-K2S10-768-2SS1	-	-	-	-	-	0	-	-	-
		LM-K2S20-288-1SS1				0					
_M-K2	LM-K2P2A-02M-1SS1	LM-K2S20-384-1SS1	-	-	-	0	-	-	-	-	-
series	LM-K2P2C-07M-1SS1	LM-K2S20-480-1SS1	-	-	-	-	-	-	0	-	-
01100	LM-K2P2E-12M-1SS1	LM-K2S20-768-1SS1	-	-	-	-	-	-	-	0	-
		LM-K2S30-288-1SS1	-							-	
	LM-K2P3C-14M-1SS1	LM-K2S30-384-1SS1	-	-	-	-	-	-	0	-	-
		LM-K2S30-480-1SS1									
	LM-K2P3E-24M-1SS1	LM-K2S30-768-1SS1	-	-	-	-	-	-	-	0	-
	LM-U2PAB-05M-0SS0		0	_	-	-	_	-	-	_	-
	LM-U2PAD-10M-0SS0			0	_	_	_	_	_	_	_
	LM-U2PAF-15M-0SS0		-		-	-	-	-	-	-	-
			-	0	-	-	-	-	-	-	-
_M-U2	LM-U2PBB-07M-1SS0		0	-	-	-	-	-	-	-	-
series	LM-U2PBD-15M-1SS0		-	-	0	-	-	-	-	-	-
	LM-U2PBF-22M-1SS0	LM-025B0-420-1551	-	-	-	0	-	-	-	-	-
	LM-U2P2B-40M-2SS0	LM-U2S20-300-2SS1	-	-	-	-	-	0	-	-	-
	LM-U2P2C-60M-2SS0	LM-U2S20-480-2SS1	-	-	-	-	-	-	0	-	-
	LM-U2P2D-80M-2SS0		-	-	-	-	-	-	-	0	-
	LM-AUP3A-03V-JSS0	LM-AUS30-120-JSS0	-	0	-	-	-	-	-	-	-
	LM-AUP3B-06V-JSS0	LM-AUS30-180-JSS0	-	0	-	-	-	-	-	-	-
		LM-AUS30-240-JSS0									
	LM-AUP3C-09V-JSS0	LM-AUS30-300-JSS0	-	0	-	-	-	-	-	-	-
M-AU	LM-AUP3D-11R-JSS0	LM-AUS30-600-JSS0	-	0	-	-	-	-	-	-	-
series	LM-AUP4A-04R-JSS0		-	-	-	0	-	-	-	-	-
Note 2, 3)	LM-AUP4B-09R-JSS0	LM-AUS40-120-JSS0	-	-	-	0	-	-	-	-	-
	LM-AUP4C-13P-JSS0	LM-AUS40-180-JSS0	-	-	-	0	-	-	-	-	-
	LM-AUP4D-18M-JSS0	LM-AUS40-240-JSS0	-	-	-	0	-	-	-	-	-
		LM-AUS40-300-JSS0	-	-	-	-	_	0	-	_	-
	LM-AUP4F-26P-JSS0	LM-AUS40-600-JSS0									

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

2. LM-AJ series and LM-AU series do not support MR-J5-B_

3. Use the servo amplifiers with firmware version D0 or later. If the servo amplifiers with the previous firmware version are connected, an alarm occurs.

Multi-axis servo amplifier

Any com possible	bination of the rotary se as long as the servo mo	rvo motors, the linear servo ptors are compatible with t	vo motors,	and the direc		rs with differen	t series and	capacities is	Common Specifications
Multi-a	xis servo amplifier							O: Standard thrust	ns
Linear se	ervo motor		Servo am	plifier MR-J5V	/2		Servo amp	lifier MR-J5W3	
	Primary side (coil)	Secondary side (magnet)	22G/B	44G/B	77G/B	1010G/B	222G/B	444G/B	Ser
	LM-H3P2A-07P-BSS0	LM-H3S20-288-BSS0 LM-H3S20-384-BSS0 LM-H3S20-480-BSS0 LM-H3S20-768-BSS0	-	0	0	0	-	0	Servo System Controllers
	LM-H3P3A-12P-CSS0	LM-H3S30-288-CSS0	-	0	0	0	-	0	S
LM-H3	LM-H3P3B-24P-CSS0	LM-H3S30-384-CSS0	-	-	0	0	_	-	erv
series	LM-H3P3C-36P-CSS0	LM-H3S30-480-CSS0	-		0	0			. Ar
		LM-H3S30-768-CSS0	-				-	-	. npli
		LM-H3S70-384-ASS0							Servo Amplifiers
	LM-H3P7A-24P-ASS0	LM-H3S70-480-ASS0	-	-	0	0	-	-	
		LM-H3S70-768-ASS0							R
	LM-AJP1B-07K-JSS0	LM-AJS10-080-JSS0	-	0	0	0	-	0	Motors
	LM-AJP1D-14K-JSS0	LM-AJS10-200-JSS0 LM-AJS10-400-JSS0	-	-	0	0	-	-	Rotary Servo Motors
	LM-AJP2B-12S-JSS0	LM-AJS20-080-JSS0	-	0	0	0	_	0	. Vo
LM-AJ	LM-AJP2D-23T-JSS0	LM-AJS20-200-JSS0							
series		LM-AJS20-400-JSS0	-	-	0	0	-	-	
(Note 2)	LM-AJP3B-17N-JSS0	LM-AJS30-080-JSS0 LM-AJS30-200-JSS0	-	0	0	0	-	0	Linear Servo Motors
	LM-AJP3D-35R-JSS0	LM-AJS30-400-JSS0	-	-	0	0	-	-	Ors
	LM-AJP4B-22M-JSS0	LM-AJS40-080-JSS0	-	0	0	0	-	0	õ
	LM-AJP4D-45N-JSS0	LM-AJS40-200-JSS0	-	_	0	0	_	_	
		LM-AJS40-400-JSS0 LM-K2S10-288-2SS1							
LM-K2	LM-K2P1A-01M-2SS1	LM-K2S10-288-2551 LM-K2S10-384-2SS1 LM-K2S10-480-2SS1 LM-K2S10-768-2SS1	-	0	0	0	-	0	Direct Drive Motors
series	LM-K2P2A-02M-1SS1	LM-K2S20-288-1SS1 LM-K2S20-384-1SS1 LM-K2S20-480-1SS1 LM-K2S20-768-1SS1	-	-	0	0	-	-	Options/Peripheral Equipment
	LM-U2PAB-05M-0SS0	LM-U2SA0-240-0SS0	0	0	-	-	0	0	omei
	LM-U2PAD-10M-0SS0	LM-U2SA0-300-0SS0	-	0	0	0	-	0	nt t
LM-U2	LM-U2PAF-15M-0SS0	LM-U2SA0-420-0SS0	-	0	0	0	-	0	
series	LM-U2PBB-07M-1SS0	LM-U2SB0-240-1SS1	0	0	-	-	0	0	
	LM-U2PBD-15M-1SS0	LM-U2SB0-300-1SS1	-	-	0	0	-	-	SN_
	LM-U2PBF-22M-1SS0	LM-U2SB0-420-1SS1	-	-	0	0	-	-	LVS/Wires
	LM-AUP3A-03V-JSS0	LM-AUS30-120-JSS0	-	0	0	0	-	0	.es
	LM-AUP3B-06V-JSS0	LM-AUS30-180-JSS0 LM-AUS30-240-JSS0	-	0	0	0	-	0	
	LM-AUP3C-09V-JSS0	LM-AUS30-240-3330 LM-AUS30-300-JSS0	-	0	0	0	-	0	
LM-AU	LM-AUP3D-11R-JSS0	LM-AUS30-600-JSS0	-	0	0	0	-	0	Product List
Series (Note 2, 3)	LM-AUP4A-04R-JSS0	LM-AUS40-120-JSS0	-	-	0	0	-	-	Juct
	LM-AUP4B-09R-JSS0	LM-AUS40-180-JSS0	-	-	0	0	-	-	List
	LM-AUP4C-13P-JSS0	LM-AUS40-240-JSS0	-	-	0	0	-	-	-
	LM-AUP4D-18M-JSS0	LM-AUS40-600-JSS0	-	-	0	0	-	-	

 Notes:
 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

 2. LM-AJ series and LM-AU series do not support MR-J5W_-B.

3. Use the servo amplifiers with firmware version D0 or later. If the servo amplifiers with the previous firmware version are connected, an alarm occurs.

recautions

Support

Combinations of Direct Drive Motors and Servo Amplifiers (Note 1)

The torque can be increased by combining a large-capacity servo amplifier.

The torque characteristics vary by the combinations. Refer to the list of the specifications of each direct drive motor.

Any combination of the rotary servo motors, the linear servo motors, and the direct drive motors with different series and capacities is possible as long as the servo motors are compatible with the servo amplifier.

1-axis servo amplifier

○: Standard torque ◎: Torque increased

Dive et elvisse un	eter (Note 2)	Servo amp	lifier MR-J5					
Direct drive m	OTOR (Note 2)	20G/B/A	40G/B/A	60G/B/A	70G/B/A	100G/B/A	350G/B/A	500G/B/A
TM-RG2M	TM-RG2M002C30 TM-RU2M002C30	0	-	-	-	-	-	-
series/ FM-RU2M	TM-RG2M004E30 TM-RU2M004E30	0	0	-	-	-	-	-
series	TM-RG2M009G30 TM-RU2M009G30	-	0	-	-	-	-	-
	TM-RFM002C20	0	-	-	-	-	-	-
	TM-RFM004C20	-	0	-	-	-	-	-
	TM-RFM006C20	-	-	0	-	-	-	-
	TM-RFM006E20	-	-	0	-	-	-	-
	TM-RFM012E20	-	-	-	0	-	-	-
TM-RFM	TM-RFM018E20	-	-	-	-	0	-	-
series	TM-RFM012G20	-	-	-	0	-	-	-
	TM-RFM048G20	-	-	-	-	-	0	-
	TM-RFM072G20	-	-	-	-	-	0	-
	TM-RFM040J10	-	-	-	0	-	-	-
	TM-RFM120J10	-	-	-	-	-	0	-
	TM-RFM240J10	-	-	-	-	-	-	0

Multi-axis servo amplifier

O: Standard torque O: Torque increased

Dive et duive un	eter (Note 2)	Servo ampl	Servo amplifier MR-J5W2				Servo amplifier MR-J5W3	
Direct drive m	OLOL (MORE T)	22G/B	44G/B	77G/B	1010G/B	222G/B	444G/B	
TM-RG2M	TM-RG2M002C30 TM-RU2M002C30	0	0	-	-	0	0	
series/ TM-RU2M series	TM-RG2M004E30 TM-RU2M004E30	0	0	-	-	0	0	
	TM-RG2M009G30 TM-RU2M009G30	-	0	0	0	-	0	
TM-RFM series	TM-RFM002C20	0	0	-	-	0	0	
	TM-RFM004C20	-	0	0	0	-	0	
	TM-RFM006C20	-	-	0	0	-	-	
	TM-RFM006E20	-	-	0	0	-	-	
	TM-RFM012E20	-	-	0	0	-	-	
	TM-RFM018E20	-	-	-	0	-	-	
	TM-RFM012G20	-	-	0	0	-	-	
	TM-RFM040J10	-	-	0	0	-	-	

Notes: 1. The combinations of servo motors and servo amplifiers with special specifications are the same as those of standard servo amplifiers.

Refer to the servo amplifiers with the same rated output. 2. Use the direct drive motors manufactured in June 2019 or later when connecting to MR-J5 servo amplifiers. If the direct drive motors manufactured before that date are connected, an alarm occurs. Refer to "Direct Drive Motor User's Manual" for how to check the date of manufacture.

Safety Sub-Functions (Note 1)

Safety Su	b-Functions (Note 1)				S	
Specificatio	ons of servo amplifiers				Corr pecifi	
Item		Specifications		Common Specifications		
		MR-J5-G(4)(-N1) MR-J5-B(4)(-RJ) MR-J5WB MR-J5-A(4)(-RJ)	MR-J5-G(4)-RJ(N1) MR-J5WG(-N1) MR-J5DG4(-N1) MR-J5DG4(-N1)		Servo Syste	
	Standards	IS EN ISO 13849-1:2015 Category 3 PL e, IEC 61508 SIL 3, EN IEC 62061 maximum SIL 3, EN 61800-5-2		EN ISO 13849-1:2015 Category 4 PL e, IEC 61508 SIL 3, EN IEC 62061 maximum SIL 3, EN 61800-5-2		
Safety performance	Mean time to dangerous failure (MTTFd)	MTTFd ≥ 100 [years] (314a)	MTTFd ≥ 100 [years] (750a)	MTTFd ≥ 100 [years] (300a)	Serv	
	Diagnostic coverage (DC)	DC = Medium, 97.6 %	DC = Medium, 96.5 %		O A	
	Probability of dangerous Failure per Hour (PFH)	PFH = 6.4 × 10 ^{.9} [1/h]	PFH = 3 × 10 ⁻⁹ [1/h]	PFH = 7.7 × 10 ⁻⁹ [1/h]	mplifie	
	Mission time (T _M) (Note 3)	T _M = 20 [years]			iers	

Function specifications

			Specifications		Motors
ltem			MR-J5-G(4)(-RJ(N1)) MR-J5WG(-N1) MR-J5DG4(-N1) MR-J5-B(4)(-RJ) MR-J5WB MR-J5-A(4)(-RJ)	MR-J5-G4-HS(N1)	Ś
	STO	Shut-off response time (STO input off → energy shut off)	8 ms or less (using input device) 60 ms or less (using CC-Link IE TSN/Ether	rCAT®) (Note 4, 5, 8)	Motors
	SS1	Deceleration delay time	0 ms to 60000 ms (functional safety param	,	Motors
	SS2	Deceleration delay time	0 ms to 60000 ms (functional safety param	67	ŝ
	SOS	Observation position	0 rev to 1000 rev (functional safety parame	eter setting)	
Safety sub-	SBC	Shut-off response time	8 ms or less (using input device) 60 ms or less (using CC-Link IE TSN/Ether	rCAT®) (Note 4, 5, 8)	
functions	SLS1/2/3/4	Observation speed	0 r/min (mm/s) to 10000 r/min (mm/s) (func	tional safety parameter setting) (Note 6)	Motors
	SSM	Observation speed	0 r/min (mm/s) to 10000 r/min (mm/s) (functional safety parameter setting)		ors
	SDI	Direction monitor delay time 0 ms to 60000 ms (functional safety parameter setting) Observation position 0 rev to 1000 rev (functional safety parameter setting)			
	SLI	Observation position	0 rev to 1000 rev (functional safety parame	eter setting)	
	SLT	Observation torque	-1000.0 % to 1000.0 % (functional safety p	arameter setting)	
		Number of inputs (double wiring)	1 point	3 points	44
		Permissible time for mismatched double inputs	0 ms to 60000 ms (functional safety parameter setting)		Гчирпен
	Input device	Noise elimination filter	1.000 ms to 32.000 ms (functional safety parameter setting)		
		Test pulse off time (Note 7)	1 ms or less		
Input/		Test pulse interval (Note 7)	250 ms to 1000 ms		
output	O struct	Number of outputs (double wiring)	1 point	3 points	
function	Output device	Test pulse off time	0.500 ms to 2.000 ms (functional safety pa	rameter setting)	
	UEVICE	Test pulse interval	1 s or less		
	External	Number of outputs (double wiring)	-	1 point	
	wiring diagnostic	Test pulse off time	-	1.000 ms to 2.000 ms (functional safety parameter setting)	
	output	Test pulse interval	-	1 s or less	
		Response time	250 ms (Note 2)		
Safety cor function	mmunication	Transmission interval monitor time	16.0 ms to 1000.0 ms (functional safety pa $(Note 8)$	rameter setting) (using CC-Link IE TSN)	
IUNCTION		FSoE Watchdog Time	16.0 ms to 65534.0 ms (object setting) (usi	ng EtherCAT®) (Note 8)	
		Safety communication delay time	60 ms or less (using CC-Link IE TSN/Ether	(Note 4, 8) (Note 4, 8)	

Notes: 1. Supported safety sub-functions and their safety levels vary by the combinations of the servo amplifier or the drive unit and the servo motor, and the firmware version of the servo amplifier. Refer to "List of supported safety sub-functions". 2. This value is applicable when the transmission interval monitor time is 64.0 ms or less, or FSoE Watchdog Time is 60 ms or less. 3. The performance of special proof tests within the mission time of the product is regarded as not necessary, however, the diagnostic interval is suggested as at least one

test per three months for Category 3 PL e, SIL 3 on IEC 61800-5-2:2016.

4. This value is applicable when the transmission interval monitor time is 32.0 ms or less, or FSoE Watchdog Time is 30 ms or less.

5. Set the communication cycle as follows:

MR-J5-G(4)-RJ, MR-J5-G4-HS, MR-J5D1-G4: 125 μs or more
 MR-J5-G(4)-RJN1, MR-J5-G4-HS, MR-J5D1-G4-N1: 250 μs or more
 MR-J5W_-G(-N1), MR-J5D2-G4(-N1), MR-J5D3-G4(-N1): 500 μs or more

6. The observation speed can be set separately.

7. The test pulse is a signal for the external circuit to perform self-diagnosis by turning off the signals to the servo amplifier or the drive unit instantaneously at regular intervals.

8. The listed value is applicable when the safety sub-functions through the network connection are executed.

Support

Safety Sub-Functions (Note 10)

List of supported safety sub-functions

Supported safety sub-functions and their safety levels vary by the combinations of the servo amplifier or the drive unit and the servo motor. Refer to the table below.

			Safety	sub-fun	ction (IE	C/EN 6	1800-5-	2)					
Servo amplifier model (Note 11)	Connection method	Servo motor type	STO	SS1		SS2 (Note 3, 6)	SOS	SBC	SLS	SSM	SDI	SLI	SLT
model ()	(connector)		510	SS1-t	SS1-r (Note 3, 6)	SS2-t, SS2-r	(Note 3, 6)	300	(Note 3, 6)	(Note 3, 6)	(Note 3, 6)	(Note 3, 6)	(Note 6)
MR-J5-G(4)(-N1) MR-J5-B(4)(-RJ) MR-J5WB MR-J5-A(4)(-RJ)	DI/O connection (CN8)	Servo motor with functional safety Rotary servo motor Linear servo motor Direct drive motor	Cat. 3 PL e, SIL 3	- (Note 8)	-	-	-	-	-	-	-	-	-
MR-J5-G(4)-RJ(N1) (Note 14)	DI/O connection	Servo motor with functional safety	Cat. 4 PL e, SIL 3			Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2				
MR-J5-G4-HS(N1) MR-J5WG(-N1) (Note 4, 9, 14)	(Note 2) (CN8/CN3)	Rotary servo motor Linear servo motor Direct drive motor	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	-	-	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	-	Cat. 3 PL d, SIL 2
MR-J5D1-G4(-N1) (Note 14) MR-J5D2-G4(-N1) (Note 9, 14)	Network connection	Servo motor with functional safety	Cat. 4 PL e, SIL 3		Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2					
MR-J5D3-G4(-N1) (Note 9, 14)	(Note 1, 5, 7, 12, 13, 15) (CN1A/CN1B)	Rotary servo motor Linear servo motor Direct drive motor	Cat. 4 PL e, SIL 3	Cat. 4 PL e, SIL 3	Cat. 3 PL d, SIL 2	-	-	Cat. 4 PL e, SIL 3		Cat. 3 PL d, SIL 2	Cat. 3 PL d, SIL 2	-	Cat. 3 PL d, SIL 2

Notes: 1. Combine the servo amplifier with an R_SFCPU safety CPU with firmware version of 20 or later. 2. The listed safety levels are applicable when one of the following executes safety sub-function control with a diagnosis using test pulses

MR-J5-G4-HS(N1)

•Safety CPU or safety controller that meets Category 4 PL e, SIL 3

When a forced stop switch, a safety switch, or an enable switch is directly connected to the servo amplifier and a diagnosis using test pulses is not executed, the safety level is Category 3 PL d, SIL 2.

3. A fully closed loop system does not support SS1-r, SS2, SOS, SLS, SSM, SDI, and SLI.

4. The safety sub-functions are supported by MR-J5W_-G manufactured in November 2019 or later.

5. Set the communication cycle as follows:

•MR-J5-G(4)-RJ, MR-J5-G4-HS, MR-J5D1-G4: 125 µs or more

•MR-J5-G(4)-RJN1, MR-J5-G4-HSN1, MR-J5D1-G4-N1: 250 µs or more

•MR-J5W_-G(-N1), MR-J5D2-G4(-N1), MR-J5D3-G4(-N1): 500 µs or more

- 6. When used with CC-Link IE Field Network Basic, SS1-r, SS2, SOS, SLS, SSM, SDI, SLI, and SLT are available on servo amplifiers or drive units with firmware version D8 or later.
- 7. The safety sub-functions through the network connection are not available when the servo amplifiers or drive units use CC-Link IE Field Network Basic.

8. The servo amplifiers support SS1-t when combined with MR-J3-D05. Refer to p. 7-48 in this catalog for details

9. The STO function can be set for each axis.

10. For 200 V class servo amplifiers, the firmware version B2 or later is required.

11. The functional safety unit (MR-D30) cannot be connected.

12. When used with CC-Link IE TSN Class A, the safety sub-functions through the network connection are available on servo amplifiers or drive units with firmware version D4 or later.

The safety sub-functions through the network connection are not available when the servo amplifier uses driver communication function.

14. For MR-J5-G(4)-RJN1, MR-J5W_-G(-N1), and MR-J5D_-G4-N1, SS1-r, SS2, SOS, SLS, SSM, SDI, SLI, and SLT are available on servo amplifiers or drive units with firmware version D8 or later.

15. For MR-J5-G(4)-RJN1, MR-J5W_-G(-N1), and MR-J5D_-G4-N1, the safety sub-functions through the network connection are available on servo amplifiers or drive units with firmware version D8 or later.

Environment

Motion module

Environment			്വ	
Motion module			Common Specifications	
Item	Operation	Storage	nmoi cati	
Ambient temperature	0 °C to 55 °C 0 °C to 60 °C (when using the extended temperature range base unit) $^{(Note 2)}$	-25 °C to 75 °C (non-freezing)	n ons	
Ambient humidity	5 %RH to 95 %RH (non-condensing)		Se	
Ambience	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust			
Altitude	000 m or less			
	Under intermittent vibration (directions of X, Y, and Z axes): 5 Hz to 8.4 Hz, displacement amplitude 3.5 mm 8.4 Hz to 150 Hz, acceleration amplitude 9.8 m/s ²		ervo System Controllers	
Vibration resistance	Under continuous vibration: 5 Hz to 8.4 Hz, displacement amplitude 1.75 mm 8.4 Hz to 150 Hz, acceleration amplitude 4.9 m/s ²		Servo An	

Item	Operation	Transportation	Storage	mplifiers
Ambient temperature	0 °C to 60 °C (non-freezing) Class 3K3 (IEC 60721-3-3)	-25 °C to 70 °C (non-freezing) Class 2K12 (IEC 60721-3-2)	-25 °C to 70 °C (non-freezing) Class 1K4 (IEC 60721-3-1)	Rotary Mot
Ambient humidity	5 %RH to 95 %RH (non-condensing)		·	
Ambience	Indoors (no direct sunlight); no corrosive	RH to 95 %RH (non-condensing) brs (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust de: 2000 m or less (Note 1) de: 2000 m or less (Note 1) or intermittent vibration: z to 57 Hz, displacement itude 0.075 mm 2 Hz to 9 Hz, displacement amplitude	Serv	
Altitude/atmospheric pressure	Altitude: 2000 m or less (Note 1)	transporting on an airplane whose cargo compartment is pressurized at	1060 hPa (Equivalent to altitudes from -400 m to	o Linear Mot
	Under intermittent vibration: 10 Hz to 57 Hz, displacement amplitude 0.075 mm	2 Hz to 9 Hz, displacement amplitude	2 Hz to 9 Hz, displacement amplitude	ear Servo Motors
Vibration resistance	amplitude 9.8 m/s ² Class 3M1 (IEC 60721-3-3) Under continuous vibration (directions of X, Y, and Z axes): 10 Hz to 55 Hz, acceleration amplitude 5.9 m/s ²	(single amplitude) 7.5 mm 9 Hz to 200 Hz, acceleration amplitude 20 m/s ² Class 2M3 (IEC 60721-3-2)	(single amplitude) 1.5 mm 9 Hz to 200 Hz, acceleration amplitude 5 m/s ² Class 1M2 (IEC 60721-3-1)	Direct Drive Motors

Power regeneration converter unit

Item	Operation	Transportation	Storage	quipr		
Ambient temperature	0 °C to 55 °C (non-freezing)	-20 °C to 65 °C (non-freezing)	-20 °C to 65 °C (non-freezing)	quipment		
Ambient humidity	Class 3K3 (IEC 60721-3-3) 5 %RH to 90 %RH (non-condensing)	Class 2K12 (IEC 60721-3-2)	Class 1K4 (IEC 60721-3-1)			
Ambience	ndoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust					
Altitude	2000 m or less (Note 1)		1000 m or less			
	Under intermittent vibration: 10 Hz to 57 Hz, amplitude 0.075 mm 57 Hz to 150 Hz, acceleration	2 Hz to 9 Hz, displacement amplitude (single amplitude) 7.5 mm	2 Hz to 9 Hz, displacement amplitude (single amplitude) 1.5 mm	VVIIES		
Vibration resistance	amplitude 9.8 m/s ² (IEC 60068-2-6 Test Fc) Under continuous vibration (directions of X, Y, and Z axes): 10 Hz to 55 Hz, acceleration amplitude 5.9 m/s ²	9 Hz to 200 Hz, acceleration amplitude 20 m/s ² Class 2M3 (IEC 60721-3-2)		Froquet List		

Notes: 1. Refer to User's Manuals of each servo amplifier, drive unit, and power regeneration converter unit for the restrictions on using the servo amplifiers, the drive units, and the power regeneration converter units at an altitude exceeding 1000 m and up to 2000 m. 2. The extended temperature range base unit is compatible with RD78G only.

Environment

Rotary servo motor

Item	Operation	Storage	
Ambient temperature	0 °C to 60 °C (non-freezing) (Note 2)	-15 °C to 70 °C (non-freezing)	
Ambient humidity	10 %RH to 90 %RH (non-condensing)		
Ambience (Note 1)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust, no object generating a strong magnetic field		
Altitude	2000 m or less (Note 3)		
External magnetic field	10 mT or less		
Vibration resistance	Refer to the specifications of each rotary	y servo motor.	

Linear servo motor (LM-H3/LM-F/LM-K2/LM-U2 series)

Item	Operation	Storage	
Ambient temperature	0 °C to 60 °C (non-freezing) (Note 2)	-15 °C to 70 °C (non-freezing)	
Ambient humidity	10 %RH to 80 %RH (non-condensing)	10 %RH to 90 %RH (non-condensing)	
Ambience (Note 1)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust		
Altitude	2000 m or less (Note 5)		
Vibration resistance	Refer to the specifications of each linear	servo motor.	

Linear servo motor (LM-AJ series/LM-AU series)

Item	Operation	Storage	
Ambient temperature	0 °C to 40 °C (non-freezing)	-15 °C to 70 °C (non-freezing)	
Ambient humidity	10 %RH to 80 %RH (non-condensing)	10 %RH to 90 %RH (non-condensing)	
Ambience (Note 1)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust		
Altitude	1000 m or less		
Vibration resistance	Refer to the specifications of each linear	r servo motor.	

Direct drive motor

Item	Operation	Storage	
Ambient temperature	0 °C to 60 °C (non-freezing) (Note 2)	-15 °C to 70 °C (non-freezing)	
Ambient humidity	10 %RH to 80 %RH (non-condensing)	10 %RH to 90 %RH (non-condensing)	
Ambience (Note 1, 4)	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust		
Altitude	2000 m or less (Note 3)		
Vibration resistance	Refer to the specifications of each direct	drive motor.	

Notes: 1. Do not use the servo motors in the environment where the servo motors are exposed to oil mist, oil and/or water.

2. Refer to User's Manuals of each servo motor for the restrictions on the ambient temperature.

3. Refer to User's Manuals of each servo motor for the derating condition when using the servo motors at an altitude exceeding 1000 m and up to 2000 m.

4. Do not place any object (such as a magnet) which generates a magnetic force near the direct drive motor. If it is unavoidable, take a measure such as mounting a shielding plate and so on to cut off the magnetic force.

5. Refer to "Linear Servo Motor User's Manual (LM-H3/LM-U2/LM-F/LM-K2)" for the restrictions on using the linear servo motor at an altitude exceeding 1000 m and up to 2000 m.



Motion Module	2-2
Engineering Software	2-14
Motion Control Software	2-15

Motion Module RD78G (Simple Motion Mode)

Item		Specifications			Comparison with the previous models (Simple Motion modules		
		RD78G4	RD78G8	RD78G16	RD77MS	QD77MS	
Maximun control a	n number of [axis] xes	4	8	16	2, 4, 8, 16	2, 4, 16 (QD77MS2 and QD77MS4 use the buffer memory assignment for 4 axes)	
Commar	nd interface	CC-Link IE TS			SSCNET III/H		
Servo an	•		J5W2-G, MR- MR-J5D2-G4,		MR-J5-B, MR-J5W2-B, MR-J5\ MR-J4-B, MR-J4W2-B, MR-J4\		
Operatio (operatio	n cycle [µs] on cycle setting)	250, 500, 1000), 2000, 4000		444, 888, 1777, 3555	888, 1777	
Interpola	tion function	Linear interpol helical interpol	•••	axes), 2-axis cir	cular interpolation,	Linear interpolation (up to 4 axes), 2-axis circular interpolation	
Control n Accelerat		synchronous c	ontrol, continue	ous operation to	and helical (Note 1)), speed control, o torque control ve acceleration/deceleration	speed-torque control,	
Compen	sation function	Backlash com	pensation, elec	ctronic gear, nea	ar pass function		
Synchror	nous control	Synchronous e command gen phase comper	eration axis, ca	am,	Synchronous encoder input, cam, phase compensation	Synchronous encoder input, command generation axis, cam, phase compensation	
Cam	Maximum number of cam registrations (Note 2)	256					
control	Cam data Cam auto-generation	Stroke ratio da	ta format, coor	rdinate data fori	mat		
<u> </u>	function	Cam for a rota	-				
	ng control method	Motion profile					
Control u	Init	mm, inch, deg	'ee, pulse			600 data (positioning data No.	
Number	of positioning data	600 data (positioning data No. 1 to 600)/axis (Set with MELSOFT GX Works3 or a sequence program (No. 1 to 600).)			600 data (positioning data No.1 to 600)/axis1 to 600)/axis(Set with MELSOFT GXWorks3 or a sequence program(QD77MS16 (No. 1 to 100).)(No. 1 to 100).)QD77MS2/QD77MS4600).)600).)		
Backup		Parameters, p	ositioning data,	, and block star	t data can be saved on flash RC	M (batteryless backup)	
Home position return		Driver home position return (Note 3)		Proximity dog method, count method 1, count method 2, data set method, scale home position signal	Proximity dog method, count method 1, count method 2, data set method,		
Home pc	osition return				detection method,	scale home position signal detection method	
	ng control	(up to 4 axes), control, speed position-speed NOP instruction	2-axis circular i control (up to 4 switching contr	interpolation (au axes), speed-p rol, current value ction (conditiona		detection method eed)), fixed-pitch feed control nt-specified), helical interpolatior de, ABS mode), No. for a current value changing)	
	ng control JOG operation	(up to 4 axes), control, speed position-speed NOP instruction	2-axis circular i control (up to 4 switching contr n, JUMP instruc	interpolation (au axes), speed-p rol, current value ction (conditiona	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I	detection method eed)), fixed-pitch feed control nt-specified), helical interpolatior de, ABS mode), No. for a current value changing)	
	ng control JOG operation Inching operation Manual	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Provided Up to 1 module	2-axis circular i control (up to 4 switching contr n, JUMP instruc ous start, repe	interpolation (au axes), speed-p rol, current value ction (conditiona ated start	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I II, unconditional), LOOP, LEND, b	detection method eed)), fixed-pitch feed control nt-specified), helical interpolation de, ABS mode), No. for a current value changing) lock start, condition start, wait	
Positionin	ng control JOG operation Inching operation	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Provided Up to 1 module	2-axis circular i control (up to 4 switching contr n, JUMP instruct ous start, reper- e (incremental) ion (1 to 10000	interpolation (au axes), speed-p rol, current value ction (conditiona ated start	detection method, driver home position return (Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I II, unconditional), LOOP, LEND, b	detection method eed)), fixed-pitch feed control nt-specified), helical interpolation de, ABS mode), No. for a current value changing) lock start, condition start, wait mes),	
Positionin Manual control Speed-tcc	IDG operation Inching operation Manual pulse generator operation prque control	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Provided Up to 1 module unit magnificat via a CPU (Note Speed control	2-axis circular i control (up to 4 switching contr n, JUMP instruc- eous start, repe- e (incremental) ion (1 to 10000 9	interpolation (au axes), speed-p rol, current value ction (conditiona ated start), D times),	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I II, unconditional), LOOP, LEND, b Up to 1 module (incremental), unit magnification (1 to 10000 t	detection method eed)), fixed-pitch feed control nt-specified), helical interpolatior de, ABS mode), No. for a current value changing) lock start, condition start, wait mes), connector	
Positionin Manual control Speed-tcc	ng control JOG operation Inching operation Manual pulse generator operation	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Provided Up to 1 module unit magnificat via a CPU (Note Speed control Provided	2-axis circular i control (up to 4 switching contr n, JUMP instruc cous start, reper e (incremental) ion (1 to 10000 (0) not including p	interpolation (au axes), speed-p rol, current value ction (conditiona ated start), D times),	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I I, unconditional), LOOP, LEND, b Up to 1 module (incremental), unit magnification (1 to 10000 t an external input connection rque control, continuous operatio	detection method eed)), fixed-pitch feed control nt-specified), helical interpolatior de, ABS mode), No. for a current value changing) lock start, condition start, wait mes), connector	
Positionin Manual control Speed-tc Absolute	IDG operation Inching operation Manual pulse generator operation prque control	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Up to 1 module unit magnificat via a CPU (Note Speed control Provided Up to the num connected service (via a servo arr	2-axis circular i control (up to 4 switching contr n, JUMP instruc- ous start, reper- e (incremental) ion (1 to 10000 (0) not including p ber of axes of t vo amplifiers nplifier or a CP	interpolation (au axes), speed-p rol, current value ction (conditiona ated start), D times), position loop, top the PU (Note 6))	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I II, unconditional), LOOP, LEND, b Up to 1 module (incremental), unit magnification (1 to 10000 ti an external input connection	detection method eed)), fixed-pitch feed control nt-specified), helical interpolation de, ABS mode), No. for a current value changing) lock start, condition start, wait mes), connector on to torque control	
Positionii Manual control Speed-tc Absolute Synchror Speed lir	ng control JOG operation Inching operation Manual pulse generator operation orque control position system nous encoder axis	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Up to 1 module unit magnificat via a CPU (Note Speed control Provided Up to the num connected ser (via a servo an Speed limit val	2-axis circular i control (up to 4 switching contr n, JUMP instruc- ous start, repe- e (incremental) ion (1 to 10000 6) not including p ber of axes of t vo amplifiers nplifier or a CP lue, JOG speed	interpolation (au axes), speed-p rol, current value ction (conditiona ated start), D times), bosition loop, top the PU (Note 6)) d limit value	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I II, unconditional), LOOP, LEND, b Up to 1 module (incremental), unit magnification (1 to 10000 t an external input connection rque control, continuous operation (An external input connection amplifier, or via a CPU ^(Note 6))	detection method eed)), fixed-pitch feed control nt-specified), helical interpolation de, ABS mode), No. for a current value changing) lock start, condition start, wait mes), connector on to torque control	
Positionii Manual control Speed-tc Absolute Synchror Speed lir	ng control JOG operation Inching operation Manual pulse generator operation orque control position system nous encoder axis	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Up to 1 module unit magnificat via a CPU (Note Speed control Provided Up to the num connected ser (via a servo an Speed limit val	2-axis circular i control (up to 4 switching contr n, JUMP instruc- ous start, repe- e (incremental) ion (1 to 10000 6) not including p ber of axes of t vo amplifiers nplifier or a CP lue, JOG speed	interpolation (au axes), speed-p rol, current value ction (conditiona ated start), D times), bosition loop, top the PU (Note 6)) d limit value	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I II, unconditional), LOOP, LEND, b Up to 1 module (incremental), unit magnification (1 to 10000 t an external input connection rque control, continuous operation (An external input connection amplifier, or via a CPU ^(Note 6)) value individual setting	detection method eed)), fixed-pitch feed control nt-specified), helical interpolation de, ABS mode), No. for a current value changing) lock start, condition start, wait mes), connector on to torque control	
Positionin Manual control Speed-tcc Absolute Synchror Speed lir Torque lin	ng control JOG operation Inching operation Manual pulse generator operation orque control position system nous encoder axis	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Up to 1 module unit magnificat via a CPU (Note Speed control Provided Up to the num connected ser (via a servo an Speed limit va Torque limit va	2-axis circular i control (up to 4 switching contr n, JUMP instruc- ous start, repe- e (incremental) ion (1 to 10000 6) not including p ber of axes of t vo amplifier or a CP lue, JOG speed lue same settir emory, valid/inv	interpolation (au axes), speed-p rol, current value ction (conditiona ated start), D times), bosition loop, top the PU (Note 6)) d limit value ng, torque limit valid setting	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I al, unconditional), LOOP, LEND, b unit magnification (1 to 10000 t an external input connection rque control, continuous operation (An external input connection amplifier, or via a CPU ^(Note 6)) value individual setting An external input connection memory, valid/invalid setting	detection method eed)), fixed-pitch feed control nt-specified), helical interpolation de, ABS mode), No. for a current value changing) lock start, condition start, wait mes), connector on to torque control	
Positionin Manual control Speed-tc Absolute Synchror Speed lin Torque lin Forced s	ng control JOG operation Inching operation Manual pulse generator operation orque control e position system nous encoder axis mit function mit function	(up to 4 axes), control, speed position-speed NOP instruction start, simultane Provided Up to 1 module unit magnificat via a CPU (Note Speed control Provided Up to the num connected ser (via a servo an Speed limit va Torque limit va	2-axis circular i control (up to 4 switching contr n, JUMP instruc- ous start, repe- e (incremental) ion (1 to 10000 6) not including p ber of axes of t vo amplifier or a CP lue, JOG speed lue same settir emory, valid/inv	interpolation (au axes), speed-p rol, current value ction (conditiona ated start), D times), bosition loop, top the PU (Note 6)) d limit value ng, torque limit valid setting	detection method, driver home position return ^(Note 3) (vector speed, reference axis sp ixiliary point-specified, central poi osition switching control (INC mo e change (positioning data, start I al, unconditional), LOOP, LEND, b Up to 1 module (incremental), unit magnification (1 to 10000 t an external input connection rque control, continuous operation (An external input connection amplifier, or via a CPU ^(Note 6)) value individual setting An external input connection	detection method eed)), fixed-pitch feed control nt-specified), helical interpolatio de, ABS mode), No. for a current value changing) lock start, condition start, wait mes), connector on to torque control	

Motion Module RD78G (Simple Motion Mode)

Motion Module RD78G (Simple M	otion Mod	de)			S
Control specifications					Items in bold: differences	Common Specifications
Itom	Specifications			Comparison with the previous models (Simple Motion module		nmo icati
Item	RD78G4	RD78G8	RD78G16	RD77MS	QD77MS	ions
Override function	0 to 300 %					
Acceleration/deceleration processing change	Acceleration/	cceleration/deceleration time				
Torque limit change	Provided					Servo System Controllers
Target position change function	The target po	osition address	s and the speed	to the target position can be cha	nged.	ŝyst ⊃lle⊧
M-code output function	WITH mode/	AFTER mode				:em rs
Step function	Deceleration	unit step, data	a No. unit step			
Skip function	Via a CPU or	r an external c	command signal			S
Parameter initialization function	Provided					NO
External input signal select function	Via a CPU or	r a servo ampl	ifier	An external input connection servo amplifier	n connector, via a CPU, or via a	Servo Amplifiers
Mark detection function	Continuous o	detection mode	e, specified num	ber of detections mode, ring buff	er mode	iers
Mark detection signal		umber of axes servo amplifie		20	4 (QD77MS2: 2 points)	
Number of mark detection settings	Up to 16 QD77MS16: up to 16 QD77MS4/QD77MS2: u				QD77MS16: up to 16 QD77MS4/QD77MS2: up to 4	Rotary Servo Motors
Optional data monitor function	Up to 4 point	s/axis				Serv
Functional safety	connection)	munication (n), ection of the se		DI/DO connection of the servo	amplifier	
Driver communication function	Provided					Line
Inter-module synchronization function	Provided					Linear Servo Motors
Automatic return	Provided			Connect/disconnect function of	f SSCNET communication	VO
Digital oscilloscope function	l oscilloscope function Bit data: 16 channels (Note 5), word data: 16 channels (Note 5) Bit data: 16 channel For QD77MS4/QD77M Bit data: 8 channels,		Bit data: 16 channels (Note 5), Word data: 16 channels (Note 5) For QD77MS4/QD77MS2,	Direct Drive Motors		
 Notes: 1. The helical interpolation is available with RD78G and RD77MS. 2. The number of cam registrations depends on the memory capacity, cam resolution, and number of coordinates. 3. The home position return method set in a driver (servo amplifier) is used. 4. 4-axis linear interpolation control is enabled only at the reference axis speed. 5. Eight channels of each word data and bit data can be displayed in real time. 6. Use a high-speed counter module. 						Options/Peripheral Equipment

Support

Motion Module FX5-SSC-G (Simple Motion Mode)

Item	Item Specifications				previous models (Simple Motion module		
		FX5-40SSC-G	FX5-80SSC-G	FX5-40SSC-S	FX5-80SSC-S		
Maximur control a	m number of [axis]	4	8	4	8		
	nd interface	CC-Link IE TSN		SSCNET III/H			
Servo ar		MR-J5-G, MR-J5W2	-G, MR-J5W3-G, 5D2-G4, MR-J5D3-G4	MR-J4-B, MR-J4W2	-B, MR-J4W3-B		
Operatio	1911	500, 1000, 2000, 400		888, 1777			
	on cycle setting)	Linear interpolation (up to 4 axes), 2-axis cire				
					-torque control, synchronous control,		
Control r		continuous operation	to torque control				
	tion/deceleration processing				on		
	isation function		tion, electronic gear, nea				
Synchro	nous control	Synchronous encode	er input, command gene	ration axis, cam, phase co	ompensation		
Cam	Maximum number of cam registrations (Note 1)	128		64	128		
control	Cam data	Stroke ratio data form	nat, coordinate data forr	nat			
	Cam auto-generation function	Cam for a rotary knife	е				
Positioni	ing control method	Motion profile table					
Control ι	unit	mm, inch, degree, pu	ulse				
Number	of positioning data	600 data (positioning	data No. 1 to 600)/axis				
Backup		Parameters, position	ing data, and block star		sh ROM (batteryless backup)		
Home po	osition return	Driver home position return (Note 2) Proximity dog method, count method 1, count method data set method, scale home position signal detection method, driver home position return (Note 2)					
Positioning control		(up to 4 axes), 2-axis circular interpolation (auxiliary point-specified, central point-specified), speed control (up to 4 axes), speed-position switching control (INC mode, ABS mode), position-speed switching control (INC mode), current value change (positioning data, start No. for a current value changing) NOP instruction, JUMP instruction (conditional, unconditional), LOOP, LEND, block start, condition start, wait start, simultaneous start, repeated start					
	JOG operation	Provided					
Manual	Inching operation	Provided					
control	Manual	Up to 1 module (incre			p to 1 module (incremental), nit magnification (1 to 10000 times),		
	pulse generator operation	unit magnification (1 via a CPU (Note 5)	to 10000 times),				
Speed-to	orque control	via a CPU (Note 5) an external input connection connector Speed control not including position loop, torque control, continuous operation to torque control					
•	e position system	Provided					
	nous encoder axis	Up to 4 modules (via	a servo amplifier or a C		4 modules (An external input connection ector, via a servo amplifier, or via a CPU (Note 5))		
Speed lii	mit function	Speed limit value, JC	DG speed limit value				
•	change function			ing. forward/reverse torgu	le limit value individual setting		
-	stop function	Via a buffer memory,			5		
Software	e stroke limit function	Movable range checl	k with feed current value	or with machine feed val	ue		
Hardwar	re stroke limit function	Provided					
Speed c	hange function	Provided					
Override	function	0 to 300 %		1 to 300 %			
	ation/deceleration ing change	Acceleration/deceleration time					
	imit change	Provided					
Target position change function		The target position address and the speed to the target position can be changed.					
M-code	output function	WITH mode/AFTER	mode				
Step fun	ction	Deceleration unit ste	p, data No. unit step				
Skip fun	ction	Via a CPU or an exte	ernal command signal				
Paramet	ter initialization function	Provided					
External i	input signal select function	Via a CPU or a serve	o amplifier				
Mark det	tection function	Continuous detection	n mode, specified numbe	er of detections mode, ring	g buffer mode		
		Up to the number o	f axes of the connecte	d Up to 4 points			
	Mark detection signal	servo amplifiers		op to 4 points			

Motion Module FX5-SSC-G (Simple Motion Mode)

Control specifications				Items in bold: differences
ltom	Specifications		Comparison with the pre	evious models (Simple Motion modules) FX5-80SSC-S
Item	FX5-40SSC-G	FX5-80SSC-G	FX5-40SSC-S	FX5-80SSC-S
Optional data monitor function	Up to 4 points/axis			
Functional safety	DI/DO connection of the	e servo amplifier		
Driver communication function	-		Provided	
Automatic return	Provided		Connect/disconnect fu	unction of SSCNET communication
Digital oscilloscope function	Bit data: 16 channels, w	vord data: 16 channels	S (Note 4)	unction of SSCNET communication

Notes: 1. The number of cam registrations depends on the memory capacity, cam resolution, and number of coordinates.

The home position return method set in a driver (servo amplifier) is used.
 4-axis linear interpolation control is enabled only at the reference axis speed.
 Eight channels of each word data and bit data can be displayed in real time.

5. Use the built-in high-speed counter of a CPU module or a high-speed pulse input/output module.

Support

Motion Module (RD78G/FX5-SSC-G) (Simple Motion Mode)

Synchronous control

Item –		Number of settable axes					
		RD78G4	RD78G8	RD78G16	FX5-40SSC-G	FX5-80SSC-G	
Servo input axis	[axes/module]	4	8	16	4	8	
Command generation axis	[axes/module]	4	8	8	4	8	
Synchronous encoder axis	[axes/module]	4	8	16	4	4	
Composite main shaft gear	[module/output axis]	1					
Main shaft main input axis	[module/output axis]	1					
Main shaft sub input axis	[module/output axis]	1					
Main shaft gear	[module/output axis]	1					
Main shaft clutch	[module/output axis]	1					
Auxiliary shaft	[module/output axis]	1					
Auxiliary shaft gear	[module/output axis]	1					
Auxiliary shaft clutch	[module/output axis]	1					
Composite auxiliary shaft gea	ar [module/output axis]	1					
Speed change gear	[module/output axis]	1					
Output axis (cam axis)	[axes/module]	4	8	16	4	8	

Cam control

Item			RD78G4	RD780	G8	RD78	G16	FX5-4	OSSC-G	FX5-8	0SSC-G
Memory	Cam storage a	irea	256 k bytes			-		128 k	128 k bytes		
capacity	Cam working a	area	1024 k bytes								
Maximum number of	Cam storage a	irea	256 (Note 1)						module: module:		1
registrations	Cam working area		256 (Note 1)								
Comment			Up to 32 characte	ers for e	ach cam	data					
	Stroke ratio data type	Maximum number of cam registrations (Note 2)	Cam resolution RD78G FX5-SSC-G	256 256 128	512 128 64	1024 64 32	2048 32 16	4096 16 8	8192 8 4	16384 4 2	32768 2 -
Cam data		Stroke ratio	-214.7483648 to	214.748	3647 %						
Camuala		Maximum number of cam registrations	Cam resolution RD78G	256	256 128	512 64	1024 32	2048 16	4096 8	8192 4	16384 2
	data type	(Note 2)	FX5-SSC-G	128	64	32	16	8	4	2	-
		Coordinate data	Input value: 0 to 2	214748	3647 Out	put value	: -214748	3648 to 2	21474836	47	
Cam auto-ger	neration function	1	Cam for a rotary	knife							

 Notes:
 1. The maximum number of registrations depends on the memory capacity, cam resolution, and number of coordinates.

 2. This is the maximum number of cam registrations for the cam storage area.

Servo System Controllers

MEMO

Motion Module RD78GH/RD78G (PLCopen® Motion Control FB Mode)

Control specifications

lå e ver		Specifications Motion module					
Item							
		RD78GH	RD78G				
			RD78G4: 4 axes RD78G8: 8 axes				
Maximum nu	mber of control axes	RD78GHV: 128 axes	RD78G16: 16 axes				
viaximani na		RD78GHW: 256 axes	RD78G32: 32 axes				
			RD78G64: 64 axes				
Maximum nu	mber of connectable stations	120 stations					
Command in		CC-Link IE TSN					
Servo amplifi		MR-J5-G, MR-J5W2-G, MR-J5W3-G, MR-J5					
Operation cy	cle vcle settings) ^(Note 1) [µs	31.25, 62.5, 125, 250, 500, 1000, 2000, 4000, 8000	62.5, 125, 250, 500, 1000, 2000, 4000, 8000				
operation cy	cie settings) (Real drive axis, virtual drive axis, real encode	r axis virtual encoder axis virtual linked axis				
		0: Unset					
Axis	Axes group	1 or later: the axes group No. for the setting a	xis				
	Real drive axis	Servo amplifier					
	Real encoder axis	Via a servo amplifier					
nterpolation	function	Linear interpolation (2 to 4 axes), 2-axis circul	ar interpolation				
Control meth	od	Positioning control, direct control					
Acceleration/	deceleration processing	Acceleration/deceleration specification method	d (acceleration, deceleration, jerk),				
		time-fixed acceleration/deceleration method					
Compensatio		Driver unit conversion					
Synchronous control	Master axis	Master axis, cam, gear Real drive axis, virtual drive axis, real encode	r avis virtual ancoder avis virtual linked evis				
	Cam data	Cam data, cam for a rotary knife	raxis, virtual encoder axis, virtual linked axis				
Operation profile	Motion control FB						
cam data)	(Cam auto-generation)	Cam for a rotary knife					
Control unit		pulse, m, degree, Revolution, inch, arbitrary u	nit character string				
		PLC CPU: ladder diagram, function block diag					
Programming		Motion module: structured text language					
Backup		Parameters and programs can be saved on a flash ROM (batteryless backup)					
Start/stop op	eration	Start, stop, restart, buffer mode, forced stop					
Home positio	on return control	Driver homing method, data set type homing					
Positioning	Linear control	Linear interpolation (2 to 4 axes)					
control	2-axis circular interpolation	Border point-specified, central point-specified, radius-specified circular interpolation					
Manual contr		JOG operation					
Direct contro	Speed control	Speed control not including position loop, speed control including position loop					
	Iorque control	Torque control, continuous operation to torque	e control				
Absolute pos		Provided					
Speed limit fu		Speed command range					
Torque limit f		Torque limit value (positive/negative direction)					
Forced stop f Software stro		Valid/Invalid setting					
Hardware str		Movable range check with an address of the set position or the feed machine position.					
	beed change	Provided Provided					
	ion change function	Provided					
	deceleration processing						
change	and a second and proceeding	Acceleration/deceleration, acceleration/deceleration time					
	value change	Provided					
Override fund		Provided					
listory data		Event history, position data history					
_ogging		Data logging, real-time monitor					
Axis emulate		Provided					
	(mark detection)	Provided					
Monitoring of	f servo data	Cyclic transmission, transient transmission					
Servo system		Provided					
Safety comm		Provided					
	unication function	Provided					
inter-module	synchronization function	Provided					

Notes: 1. The number of controllable axes varies depending on the operation cycle.

Motion Module RD78GH/RD78G (PLCopen® Motion Control FB Mode)

Synchronous control specifications

Perform synchronous control with a combination of function blocks. For the function blocks to be used, refer to "Function blocks (FB) list" of this catalog.

Program capacity and operation profile (cam) specifications

Item		RD78GH	RD78G		
Program/data	a capacity (Note 1)	Built-in ROM max. 64 [MB] + SD memory card	Built-in ROM max. 16 [MB] + SD memory card		
Maximum nur	mber of cam registration	60000 (1024 out of 60000 can be set on engineeri	ng tool)		
	Cam type	Cam data, cam for a rotary knife			
	Interpolation method	Section interpolation, linear interpolation, spline in	terpolation		
	Profile ID	1 to 60000			
Cam data	Resolution	8 to 65535 (any resolution within the range)			
	Units for cam length per cycle	mm, inch, pulse, degree			
	Units for stroke	%, mm, inch, pulse, degree			
Cam auto-generation Cam for a rotary knife					

Notes: 1. Total capacity including system management area. The available capacity is smaller.

Servo System Controllers

Motion Module RD78GH/RD78G (PLCopen® Motion Control FB Mode)

Function blocks (FB) list

Туре	Motion control FB	Name
	MC_GroupEnable	Axes Group Enabled
	MC_GroupDisable	Axes Group Disabled
	MC_Power	Operation Available
	MC_SetPosition	Current Position Change
	MCv_SetTorqueLimit	Torque Limit Value
	MC_SetOverride	Override Value Setting
	MC_ReadParameter	Parameter Read
	MC_WriteParameter	Parameter Write
	MC_Reset	Axis Error Reset
Management FBs	MC_GroupReset	Axes Group Error Reset
	MC_TouchProbe	Touch Probe Enabled
	MC_AbortTrigger	Touch Probe Disabled
	MC_CamTableSelect	Cam Table Selection
	MCv_ChangeCycle	Current Value Change per Cycle
	MCv_AllPower	All Axes Operation Available
	MC_GroupSetOverride	Axes Group Override Value Setting
	MCv_MotionErrorReset	Motion Error Reset
	MCv_AdvPositionPerCycleCalc	Advanced Synchronous Control Position per Cycle Calculation
	MCv_AdvCamSetPositionCalc	Advanced Synchronous Control Cam Set Position Calculation
	MC_Home	OPR
	MC_Stop	Forced Stop
	MC_GroupStop	Group Forced Stop
	MC_MoveAbsolute	Absolute Value Positioning
	MC_MoveRelative	Relative Value Positioning
	MCv_Jog	JOG
	MC_MoveVelocity	Speed Control
	MC_TorqueControl	Torque Control
	MCv_SpeedControl	Speed Control (Including Position Loop)
	MCv_MoveLinearInterpolateAbsolute	Absolute Value Linear Interpolation Control
Onevetien EDe	MCv_MoveLinearInterpolateRelative	Relative Value Linear Interpolation Control
Operation FBs	MCv_MoveCircularInterpolateAbsolute	Absolute Value Circular Interpolation Control
	MCv_MoveCircularInterpolateRelative	Relative Value Circular Interpolation Control
	MC_CamIn	Cam Operation Start
	MC_GearIn	Gear Operation Start
	MC_CombineAxes	Addition/Subtraction Positioning
	MCv_BacklashCompensationFilter	Backlash Compensation Filter
	MCv_SmoothingFilter	Smoothing Filter
	MCv_DirectionFilter	Moving Direction Restriction Filter
	MCv_SpeedLimitFilter	Speed Limit Filter
	MCv_AdvancedSync	Advanced Synchronous Control
	MCv_MovePositioningData	Multiple Axes Positioning Data Operation
	MCv_ReadProfileData	Profile Read
Standard FBs		

* The number of usable function blocks depends on the program capacity.

Servo System Controllers

Motion Module

CC-Link IE TSN

CC-Link IE TSN		RD78GH	RD78G	FX5-40SSC-G	FX5-80SSC-G	Common Specifications
Communications sp	peed	1 Gbps/100 Mbps				n ons
Maximum number on network	of connectable stations per	121 stations (including the master station)		21 stations (including the master and four motion control stations) motion control station		Servo Cont
Connection cable		Ethernet cable (catego	ry 5e or higher, double	e shielded/STP), straight ca	able	o S
Maximum distance	between stations	100 m				ervo System Controllers
Maximum number of	of networks	239				s
Topology		Line topology, star topology, coexistence of line and star topologies, ring topology (Note 1, 2) Time-sharing method	Line topology, star topology, coexistence of line and star topologies			Servo Amplifiers
	t transmission capacity	1920 bytes				rs
	RX/RY	16K points		8K points		т
points per network	RWr/RWw	8K points		1K points		Rotary Mot
Maximum link	RX/RY	16K points		8K points		ntary Se Motors
points per station	RWr/RWw	8K points		1K points		' Servo tors
	Maximum number of safety connections per station	120 connections		-		0
communications Maximum number of link points per safety connection		8 words (input: 8 words, output: 8 words) -				Linear Servo Motors


[Note when connecting devices]

Connect class A remote stations after class B remote stations.

CC-Link IE TSN Class

CC-Link IE TSN certifies nodes and switches to a specific class level according to its functionality and performance classification. Products can be classified as either class A or B. For the CC-Link IE TSN Class of each product, please check the CC-Link Partner Association website or the relevant product catalog or manual. Supported functions and system configuration may differ according to the CC-Link IE TSN Class of products used. For example, products compatible with class B are necessary to configure a high-speed motion control system. For details of configuring systems with both class A and class B devices, please refer to relevant master product manual.

System configuration



Synchronous accuracy of a system varies relative to the combination of connected devices and switches CC-Link IE TSN Class

• Use class B Ethernet switch when configuring a star topology with class B devices

- Use class B devices when configuring a system within ±1 μs high-accuracy synchronization, connect
- class A devices to a separate branch line from class B devices (for details of system configuration, please refer to relevant master product manual)
- Mitsubishi Electric's block type remote modules comply both class B and A

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product

List

Precautions

Support

Motion Module

Module specifications RD78GH/RD78G

Item	RD78GH	RD78G		
Maximum number of control axes	RD78GHV: 128 axes RD78GHW: 256 axes	RD78G4: 4 axes RD78G8: 8 axes RD78G16: 16 axes RD78G32: 32 axes RD78G64: 64 axes		
Maximum number of connectable stations	121 stations (including the master station)			
Servo amplifier connection method	CC-Link IE TSN			
CC-Link IE TSN Class	В			
Maximum distance between stations [m]	100			
PERIPHERAL I/F	Via a CPU module (USB, Ethernet)			
Extended memory	SD memory card			
Number of ports for CC-Link IE TSN	2 ports	1 port		
Number of I/O points occupied	48 points (I/O assignment: 16 points (empty slot) + 32 points)	32 points		
Number of slots occupied	2 slots	1 slot		
Internal current consumption (5 V DC) [A]	2.33	1.93		
Mass [kg]	0.44	0.26		
Dimensions [mm]	106.0 (H) × 56.0 (W) × 110.0 (D)	106.0 (H) × 27.8 (W) × 110.0 (D)		

Module specifications FX5-40SSC-G/FX5-80SSC-G

Item	FX5-40SSC-G	FX5-80SSC-G		
Maximum number of control axes	4 axes	8 axes		
Maximum number of connectable stations	21 stations (including the master and four motion control stations)	25 stations (including the master and eight motion control stations)		
Servo amplifier connection method	CC-Link IE TSN			
CC-Link IE TSN Class	B			
Maximum distance between stations [m]	100			
Maximum input current of external 24 V DC power [A]	0.24			
Mass [kg]	0.3			
Dimensions [mm]	90 (H) × 50 (W) × 83 (D)			
Applicable CPU (Note 1)	FX5U, FX5UC (Note 2)			

Notes: 1. Use a CPU module with firmware version 1.230 or later.

The following CPU modules can be updated to that firmware version.
 CPU module with serial No. 17X**** or later

FX5UC-32MT/DS-TS and FX5UC-32MT/DSS-TS with serial No. 178**** or later.
 FX5-CNV-IFC is required to connect the Motion module to an FX5UC CPU module.

Products on the Market

Manual Pulse Generator


Mitsubishi Electric has confirmed the operation of the following manual pulse generator. Contact the manufacturer for details.


Product name	Model	Description	Manufacturer
Manual pulse generator	BE46A2(:02B	Number of pulses per revolution: 25 pulses/rev (100 pulses/	Tokyo Sokuteikizai
		rev after magnification by 4)	Co.,Ltd.

Motion Module

Dimensions


RD78G4/RD78G8/RD78G16/






[Unit: mm]

●RD78GHV/RD78GHW







[Unit: mm]

Dimensions

●FX5-40SSC-G



●FX5-80SSC-G





50 PRS-B05SC-G CCLIMAE TSW CCL

[Unit: mm]

Mounting

RD78G4/RD78G8/RD78G16/RD78G32/RD78G64 RD78GHV/RD78GHW





Notes: 1. Provide clearance of 30 mm or more when the height of a wiring duct is 50 mm or less. In other cases, provide clearance of 40 mm or more. 2. Provide clearance of 20 mm or more when an extension cable is connected/removed without removing a power supply module. Common Specifications

Servo System Controllers

Servo Amplifiers

Support

Engineering Software

MELSOFT GX Works3 operating environment (Note 1)

Item		Description	
OS		Microsoft® Windows® 11 (Home, Pro, Enterprise, Education) Microsoft® Windows® 10 (Home, Pro, Enterprise, Education, IoT Enterprise 2016 LTSB ^{*1} , IoT Enterprise 2019 LTSC ^{*1}) *1: 64-bit version only	
CPU	Windows® 11	2 or more cores on a compatible 64-bit processor or System on a Chip (SoC)	
CPU	Windows [®] 10	Intel [®] Core [™] 2 Duo Processor 2 GHz or more recommended	
Required	Windows [®] 11	4 GB or more recommended	
memory Windows® 10		64-bit OS: 2 GB or more recommended 32-bit OS: 1 GB or more recommended	
Required hard disk shace		For installation: 22 GB or more free hard disk space For operation: 512 MB or more free virtual memory space	
Monitor		Resolution 1024 × 768 or more	

Notes: 1. Refer to Installation Instructions for precautions and restrictions regarding the operating environment.

Engineering software list

Item	Model	Description	
MELSOFT GX Works3	SW1DND-GXW3-E	Programmable Controller Engineering Software [MELSOFT GX Works3, GX Works2, GX Developer, PX Developer] MITSUBISHI ELECTRIC FA Library	DVD
MELSOFT iQ Works	SW2DND-IQWK-E	 FA engineering software (Note 1) System Management Software [MELSOFT Navigator] Programmable Controller Engineering Software [MELSOFT GX Works3, GX Works2, GX Developer, PX Developer] Motion Controller Engineering Software [MELSOFT MT Works2] Screen Design Software [MELSOFT GT Works3] Robot Programming Software [MELSOFT RT ToolBox3 (Note 2)] Inverter Setup Software [MELSOFT FR Configurator2] Servo Engineering Software [MELSOFT MR Configurator2] C Controller setting and monitoring tool [MELSOFT CW Configurator] MITSUBISHI ELECTRIC FA Library 	DVD

Notes: 1. Refer to each product manual for the software supported by the model. 2. RT ToolBox3 mini (simplified version) will be installed if iQ Works product ID is used. When RT ToolBox3 (with simulation function) is required, please purchase RT ToolBox3 product ID.

Motion Control Software SWM-G(-N1)

Control specifications

	Control Software SWM-C	G(-N1)	Spe
Control s	specifications		Common Specifications
Item		Specifications	cati
Maximum number of control axes (Note 1)		16, 32, 64, 128 axes	ion:
Command	interface	CC-Link IE TSN EtherCAT® (Note 3)	
CC-Link IE	TSN Class	В	Con
Communica	ation cycle (operation cycle settings) [µs]	125, 250, 500, 1000, 2000, 4000, 8000	Servo System Controllers
Communic	cation specifications	Mixture of hot connect, SDO communication, and TCP/IP communication	ervo Syster Controllers
Developm	ent environment	Microsoft® Visual Studio® 2017, 2019 Programming languages supported by API library: C/C++, .NET (C#, VB.NET, etc.)	rs
	Control method	Position, speed, torque	Se
	Positioning	Up to 128 axes simultaneously (absolute value command, relative value command), override	No
	Acceleration/deceleration processing	Trapezoidal, S-curve, jerk ratio, parabolic, sine, time acceleration trapezoidal, etc. (24 types)	Servo Amplifiers
	Interpolation function	2- to 4-axis linear interpolation, 2-axis/3-axis circular interpolation, 3-axis helical interpolation, PVT	hplif
	Continuous path	Combination of linear and circular interpolation, spline interpolation, pre-read speed automatic control, linear/circular continuous path with rotation stage	iers
	JOG operation	Provided	
	Real-time control	Event, triggered motion, position synchronous output	Rotary Mot
Functions	Synchronous control	Simple synchronization, synchronous gear ratio, synchronous phase offset, synchronous compensation, dynamic establishment/cancellation of synchronization, multiple pairs (up to 64 pairs) of synchronization between 1 axis and multiple axes (synchronous group)	tary Servo Motors
	Electronic cam	Cam curves of eight systems can be defined, cam curve per communication cycle, phase operation, clutch	-
	Home position return (Note 2)	Home position return using the Z-phase, home position sensor, limit sensor, limit proximity sensor, external input signal, mechanical end, and gantry axis can be performed.	Linear Mot
	I/O size	Input: 8000 bytes, output: 8000 bytes	ear Se Motors
	Compensation function	Backlash/pitch error compensation, plane strain (straightness) compensation	Servo tors
	Auxiliary function	Touch probe, logging	0

Notes: 1. The maximum number of control axes differs among the USB keys for Motion Control Software. 2. SWM-G does not support the home position return mode of the servo amplifier. 3. SWM-G-N1 is also compatible with EtherCAT[®].

CC-Link IE TSN

 SWM-G does not support the home position return mode of the servo amplifier. SWM-G-N1 is also compatible with EtherCAT[®]. CC-Link IE TSN		
Item Specifications		
Communications speed [bps]	1 G/100 M (Note 1, 2)	
Connectable stations per network	Up to 128 stations	Opt
Connection cable	Ethernet cable (category 5e or higher, double shielded/STP), straight cable	Equ
Maximum distance between stations [m]	100	ons/Periph Equipment
Topology (Note 3)	Line topology, star topology, coexistence of line and star topologies	riph
Communications method Time-sharing method		
Maximum transient transmission capacity	1920 bytes	_

Notes: 1. When two ports are available, a 1 Gbps device and a 100 Mbps device can be assigned to each port. 2. When devices of different CC-Link IE TSN Class are mixed, the functions and performance equivalent to those of the lower CC-Link IE TSN Class are applied to part of or the entire network. 3. Use class B Ethernet switch when configuring a star topology with class B devices.

Operating environment

Item		Specifications	
Personal computer		Microsoft® Windows® supported personal computer	Pro
OS		Microsoft® Windows® 10 (Pro, Enterprise, IoT Enterprise LTSC (Note 1)) (64-bit)	Ddu
CPU		Intel [®] Atom [™] 2 GHz, 2Core or higher is recommended	. ct
Memory		4 GB or more	ist
Required hard disk space		For installation: 5 GB or more	
Network interface	SWM-G	Intel® I210, I350, I211-AT	Pre
(network interface cards)	SWM-G-N1	Intel® I210, I350, I211-AT, I217LM, I218V, I219 Realtek 8168/8111, etc.	cautions
Notes: 1. Windows [®] 10 IoT Enterprise LTSC is recommer		anded.	SU

Notes: 1. Windows® 10 IoT Enterprise LTSC is recommended.

Support

LVS/Wires

Motion Control Software SWM-G(-N1)

Motion Control Software list

Product name		Model	Description
Motion Control Software (Note 1)	SWM-G	SW1DNN-SWMG-M	CC-Link IE TSN compatible • SWM-G Engine • SWM-G Operating Station • Network API • SWM-G API • Real Time OS (RTX64)
	SWM-G-N1	SW1DNN-SWMGN1-M	CC-Link IE TSN/EtherCAT®-compatible
USB key for Motion Control Software	SWM-G	MR-SWMG16-U MR-SWMG32-U MR-SWMG64-U MR-SWMG128-U	Maximum number of control axes: 16 axes, USB key (license) Maximum number of control axes: 32 axes, USB key (license) Maximum number of control axes: 64 axes, USB key (license) Maximum number of control axes: 128 axes, USB key (license)
	SWM-G-N1	MR-SWMG16N1-U MR-SWMG32N1-U MR-SWMG64N1-U MR-SWMG128N1-U	Maximum number of control axes: 16 axes, USB key (license) Maximum number of control axes: 32 axes, USB key (license) Maximum number of control axes: 64 axes, USB key (license) Maximum number of control axes: 128 axes, USB key (license)

Notes: 1. Download and install Motion Control Software from Mitsubishi Electric FA global website.

API Library

■ Main functions of API library

	ning by using a dedicated library s	suite for access to Motion Control Software.	Specifications
Class	Function	Description	- าร
	StartEngine	Starts SWM-G engine.	
	StopEngine	Stops SWM-G engine.	Controllers
	CreateDevice	Creates a device to interface with the SWM-G engine.	Controllers
SSCApi	CloseDevice	Closes a device.	olle
	StartCommunication	Starts communication with the servo network.	- rs
	StopCommunication	Stops communication with the servo network.	-
CoreMotion	GetStatus	Reads the current system status from SWM-G engine.	- S
	SetServoOn	Executes servo on or servo off.	Servo Amplifiers
	SetAxisCommandMode	Sets the command mode of the axis.	- Am
	GetAxisCommandMode	Obtains the command mode of the axis.	- plifi
AxisControl	GetPosCommand	Obtains the commanded position of the axis.	ers
	GetPosFeedback	Obtains the feedback position of the axis.	-
	GetVelCommand	Obtains the commanded velocity of the axis.	- 2
	GetVelFeedback	Obtains the feedback velocity of the axis.	
	SetParam	Sets the system parameters.	Motors
	GetParam	Obtains the system parameters.	Rotary Servo Motors
- <i>"</i>	SetAxisParam	Sets the axis parameters.	-
Config	GetAxisParam	Obtains the axis parameters.	-
	Export	Exports the system and axis parameters to xml file.	Motors
	Import	Imports the system and axis parameters from xml file.	Motors
	StartHome	Starts home position return.	ors
Home	SetCommandPos	Sets the commanded position to a specified value.	- 6
	StartPos	Executes positioning (absolute position).	-
	StartMov	Executes positioning (relative position).	-
	StartLinearIntplPos	Starts linear interpolation (absolute position).	
	StartLinearIntplMov	Starts linear interpolation (relative position).	Motors
	StartCircularIntplPos	Starts circular interpolation (absolute position).	- 0
	StartCircularIntplMov	Starts circular interpolation (relative position).	- `
	StartHelicalIntplPos	Starts helical interpolation (absolute position).	-
	StartHelicalIntplMov	Starts helical interpolation (relative position).	Equipment
	StartJog	Starts JOG operation.	quip
Notion	Stop	Decelerates the axis to stop.	me
	ExecQuickStop	Decelerates the axis to stop with Quick Stop Dec parameter.	- + -
	ExecTimedStop	Decelerates the axis to stop with the specified time.	- 5
	Wait	Executes the blocking wait command.	-
	Pause	Pauses the positioning operation.	
	Resume	Restarts the paused positioning operation.	LVS/Wires
	OverridePos	Overrides the target position (absolute position) during positioning operation.	lires
	OverrideMov	Overrides the target position (relative position) during positioning operation.	
	OverrideProfile	Overrides the velocity pattern during positioning, JOG operation, and speed control.	-
	StopJogAtPos	Decelerates the axis in JOG operation to stop at the specified position.	- Pro

API Library

Simpler programming by using a dedicated library suite for access to Motion Control Software.

Main functions of API library

Class	Function	Description
Ourse	SetSyncMasterSlave	Establishes synchronization between the master and following axes.
Sync	ResolveSync	Cancels synchronization of the specified following axes.
Valaaitu	StartVel	Starts speed control.
Velocity	Stop	Stops speed control.
T	StartTrq	Starts torque control.
Torque	StopTrq	Stops torque control.
	CreatePathIntplBuffer	Assigns the buffer memory for path interpolation to an axis.
	FreePathIntplBuffer	Frees up the buffer memory for path interpolation.
A	StartPathIntplPos	Starts path control (absolute position).
AdvMotion	StartPathIntplMov	Starts path control (relative position).
	StartPathIntpl3DPos	Starts 3D path interpolation (absolute position).
	StartPathIntpl3DMov	Starts 3D path interpolation (relative position).
A -1 - 0	StartECAM	Starts E-CAM control.
AdvSync	StopECAM	Stops E-CAM control.
	SetEvent	Sets an event.
	SetSoftwareTouchProbe	Sets the parameter of the software touch probe channel.
- .	GetSoftwareTouchProbeStatus	Obtains the parameters and the current status of software touch probe.
Event	SetHardwareTouchProbe	Sets the parameters of hardware touch probe.
	GetHardwareTouchProbeStatus	Obtains the parameters and the current status of hardware touch probe.
	StartPSO	Starts the position synchronous output channel.
	SetOutBit	Sets the output bit values.
	SetOutByte	Sets the output byte values.
1.0	SetOutAnalogDataShort	Sets two-byte output data.
lo	GetInBit	Obtains the input bit values.
	GetInByte	Obtains the input byte values.
	GetInAnalogDataShort	Obtains two-byte input data.
	SetMBit	Sets the user memory bit values.
	SetMByte	Sets the user memory byte values.
le eul de maint	SetMAnalogDataShort	Sets two-byte user memory data.
UserMemory	GetMBit	Obtains the user memory bit value.
	GetMByte	Obtains the user memory byte value.
	GetMAnalogDataShort	Obtains two-byte user memory data.
	StartLog	Starts logging data.
Log	StopLog	Stops logging data.
	SetLog	Specifies the data to be collected by logging operation.
	StartHotconnect	Starts the hot connect.
CCLink	SdoDownload	Downloads the SDO data of the specified remote station.
	SdoUpload	Uploads the SDO data of the specified remote station.
	SetAxisMode	Sets the control mode of the axis of the specified remote station.
	StartAxisHM	Starts HM mode control of the axis of the specified remote station.
	SImpSendBySlaveId	Transmits SLMP to the specified remote station.

B Servo Amplifiers

Model Designation	3-3
MR-J5-G_ Connections with Peripheral Equipment	3-7
MR-J5-G_ Specifications	3-9
MR-J5-G_ Standard Wiring Diagram Example	3-12
Functional Safety I/O Signal Connector (CN8) Connection Example	3-15
Main/Control Circuit Power Supply Connection Example	
Servo Motor Connection Example (for MR-J5-G(-N1)/MR-J5-B/MR-J5-A)	3-18
Linear Encoder Connection Example (for MR-J5-G(-N1)/MR-J5-B/MR-J5-A)	3-22
External Encoder Connection Specifications	3-24
Servo Motor Connection Example (for MR-J5-G-RJ(N1)/MR-J5-G4-HS(N1)/MR-J5-B-RJ/MR-J5-A-R	J)3-25
Linear Encoder Connection Example (for MR-J5-G-RJ(N1)/MR-J5-G4-HS(N1)/MR-J5-B-RJ/MR-J5-A-R	J)3-29
MR-J5-G_ Dimensions	3-30
MR-J5W_G(-N1) Connections with Peripheral Equipment	3-35
MR-J5W_G(-N1) Specifications	3-36
MR-J5W_G(-N1) Standard Wiring Diagram Example	3-38
Main/Control Circuit Power Supply Connection Example	3-40
Servo Motor Connection Example	3-41
External Encoder Connection Specifications	3-42
Linear Encoder Connection Example	3-46
MR-J5W_G(-N1) Dimensions	3-48
MR-J5DG4(-N1) Connections with Peripheral Equipment	3-50
MR-J5DG4(-N1) Specifications	3-51
MR-J5DG4(-N1) Standard Wiring Diagram Example	3-54
Main/Control Circuit Power Supply Connection Example	3-57
Servo Motor Connection Example	3-58
External Encoder Connection Specifications	3-59
Linear Encoder Connection Example	3-62
MR-J5DG4(-N1) Dimensions	3-63
Positioning Function	3-67
Restrictions	3-69

MR-J5-B_ Connections with Peripheral Equipment	3-70
MR-J5-B_ Specifications	3-71
MR-J5-B_ Standard Wiring Diagram Example	3-73
MR-J5-B_ Dimensions	3-74
MR-J5WB Connections with Peripheral Equipment	3-79
MR-J5WB Specifications	3-80
MR-J5WB Standard Wiring Diagram Example	3-82
MR-J5WB Dimensions	3-84
MR-J5-A_ Connections with Peripheral Equipment	3-86
MR-J5-A_ Specifications	3-87
MR-J5-A_ Standard Wiring Diagram Example	3-90
MR-J5-A_ Dimensions	3-93
MR-CM3K Specifications	3-98
MR-CM3K Wiring Diagram Example	3-99
MR-CM3K Dimensions	3-100
MR-CV_ Specifications	3-101
MR-CV_ Dimensions	3-102
Selection of Converter Unit, Servo Amplifier, and Drive Unit	3-104

^{*} Refer to p. 7-78 in this catalog for conversion of units.
* In this section, a term of servo amplifier includes a combination of a drive unit and a converter unit.

Servo Amplifiers

Model Designation for 1-Axis Servo Amplifier (Note 1)

G G-RJ G-HS Common Specifications M R - J 5 - 10 G Special specifications (Note 2, 4) Symbol CC-Link IE TSN-compatible Servo System Controllers Mitsubishi None Symbol Power supply standard Electric AC 3-phase 200 V AC, CC-Link IE TSN-compatible, servo amplifier 1-phase 200 V AC, None Symbol Interface Fully closed loop control MELSERVO-J5 or DC input Network four-wire type, series G RJ 4 3-phase 400 V AC compatible Load-side encoder A/B/Z-phase input compatible, Servo Amplifiers Safety sub-function Rated output [kW] Symbol CC-Link IE TSN-compatible, 10 0.1 Fully closed loop control 20 0.2 four-wire type, 40 0.4 Load-side encoder A/B/Z-phase HS 60 0.6 input compatible, Rotary Servo Motors 70 0.75 Safety sub-function, 100 3 points of functional safety I/O 1 sianals 200 2 MR-J5-_G_ without 350 3.5 ED a dynamic brake (Note 3) 500 5 MR-J5-_G_-RJ without RU 700 7 a dynamic brake (Note 3) Linear Servo Motors MR-J5- G4-HS without ΗU a dynamic brake (Note 3) N1 EtherCAT®-compatible standard EtherCAT®-compatible, Fully closed loop control four-wire type, RJN1 Direct Drive Motors Load-side encoder A/B/Z-phase input compatible, Safety sub-function EtherCAT[®]-compatible, Fully closed loop control four-wire type, Options/Peripheral Equipment Load-side encoder A/B/Z-phase HSN1 input compatible, Safety sub-function, 3 points of functional safety I/O signals MR-J5-_G_-N1 without EDN1 a dynamic brake (Note 3) LVS/Wires MR-J5-_G_-RJN1 without RUN1 a dynamic brake (Note 3)

MR-J5-_G4-HSN1 without

a dynamic brake (Note 3)

HUN1

Support


Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

2. For the servo amplifier firmware version supporting each function, refer to "MR-J5 User's Manual".

3. A dynamic brake which is built in the 7 kW or smaller servo amplifiers is removed. When the servo amplifiers without the dynamic brake are used, the servo motors coast to a stop and do not stop immediately at alarm occurrence or power failure. Take measures to ensure safety on the entire system. When specified servo motors are used. the electronic dynamic brake may activate at an alarm occurrence. The dynamic brake can be disabled with a servo parameter setting. Refer to "MR-J5 User's Manual" for details

4. For the restrictions on the communication cycle of each function, refer to "Restrictions" in this catalog

Model Designation for 1-Axis Servo Amplifier (Note 1)




B B-RJ

Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

2. For the servo amplifier firmware version supporting each function, refer to "MR-J5 User's Manual".

3. A dynamic brake which is built in the 7 kW or smaller servo amplifiers is removed. When the servo amplifiers without the dynamic brake are used, the servo motors coast to a stop and do not stop immediately at alarm occurrence or power failure. Take measures to ensure safety on the entire system. When specified servo motors are used, the electronic dynamic brake may activate at an alarm occurrence. The dynamic brake can be disabled with a servo parameter setting. Refer to "MR-J5 User's Manual" for details.




Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

2. A-axis, B-axis, and C-axis indicate names of axes of the multi-axis servo amplifier. The C-axis is available for the 3-axis servo amplifier.

3. Dynamic brakes which are built in the servo amplifiers are removed. When the servo amplifiers without the dynamic brakes are used, the servo motors coast to a stop and do not stop immediately at alarm occurrence or power failure. Take measures to ensure safety on the entire system. When specified servo motors are used, the electronic dynamic brake may activate at an alarm occurrence. The dynamic brake can be disabled with a servo parameter setting. Refer to "MR-J5 User's Manual" for details. Precautions

Model Designation for Drive Unit (Note 1)



Model Designation for Power Regeneration Converter Unit

M R - C V 1 1 K 4 Power supply Symbol 4 3-phase 400 V AC Symbol Capacity [kW] 11K 11 18K 18 30K 30 37K 37 45K 45 55K 55 75K 75


Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

A dynamic brake which is built in the drive units is removed. When the drive units without the dynamic brake are used, the servo motors coast to a stop and do not stop immediately at alarm occurrence or power failure. Take measures to ensure safety on the entire system. When specified servo motors are used, the electronic dynamic brake may activate at an alarm occurrence. The dynamic brake can be disabled with a servo parameter setting. Refer to "MR-J5D User's Manual" for details.
 MR-J5D1-G4(-N1) supports fully closed loop control four-wire type input and the load-side encoder A/B/Z-phase input as standard.

4. A-axis, B-axis, and C-axis indicate names of axes of the multi-axis drive unit. The B-axis is available for the 2-axis drive unit and the 3-axis drive unit. The C-axis is available for the 3-axis drive unit.

DG

DG




Notes: 1. The connection with the peripheral equipment is an example for MR-J5-350G(4)(-(RJ)(N1)) or smaller servo amplifiers. Refer to "MR-J5 User's Manual" for the actual connections.

- 2. This picture shows when the display cover is open.
- 3. For specifications of the Ethernet cable, refer to "Ethernet Cable Specifications" on p. 7-30 in this catalog.

MR-J5-G4-HS(N1) Connections with Peripheral Equipment (Note 1)

Peripheral equipment is connected to MR-J5-G4-HS(N1) as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the servo amplifier easily and start using it right away.

G-HS



Notes: 1. The connection with the peripheral equipment is an example for MR-J5-700G4-HS(N1) or smaller servo amplifiers. Refer to "MR-J5 User's Manual" for the actual connections.

2. This illustration shows when the display cover is closed.

3. For specifications of the Ethernet cable, refer to "Ethernet Cable Specifications" on p. 7-30 in this catalog.

Servo an	nplifier mo	del MR-	J5(-(RJ)(N1))	10G	20G	40G	60G	70G	100G	200G	350G	500G	700G	Specifications				
Output	Voltage				e 0 V A	C to 240	V AC							fica				
Output	Rated cu	Rated current [A]			1.8	2.8	3.2	5.8	6.0	11.0	17.0	28.0	37.0	37.0 tör				
	Voltage/ frequence	(Note 1)	AC input		3-phase or 1-phase 200 V AC to 3-phase or 1-phase 3-phase or 1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz 3-phase 200 V AC to 240 V AC, 50 Hz/60 Hz 50 Hz/60 Hz						240 V AC,							
Main			DC input (Note 8)	283 V	283 V DC to 340 V DC									. On				
circuit power supply input	Rated cu	Rated current (Note 6) [A] 0.9 (1.5)	1.5 (2.5)	2.6 (4.5)	3.2 (5.0)	3.8 (6.5)	5.0 (10.5)	10.5 (15.8)	16.0	21.7	28.9	Controllers				
	Permissi voltage		AC input	264 V /	AC	hase 17		to		or 1-phase 170 64 V AC (Note 7)	3-phase	170 V AC to	264 V AC	-				
	fluctuatio		DC input (Note 8)	Note 8) 241 V DC to 374 V DC														
	Permissi fluctuatio				±5 % maximum								-					
	Voltage/		AC input					C, 50 Hz/	60 Hz					-				
Control	frequenc	-	DC input (Note 8)		DC to 3	40 V DC	;							-				
	Rated cu] 0.2								0.3		-				
circuit	Permissi	ble	AC input	1-phas	e 170 V	AC to 2	264 V AC)						Motors				
power supply	voltage	n	DC input (Note 8)	241 V	DC to 3	74 V DC	;						·	Motors				
input	Permissi													SJC				
	fluctuatio		1	±5 % n	naximur	n												
	Power co		tion [W] 30										-				
Interface	power sup	ply		-	C ± 10	% (requi	red curr	ent capa	city: 0.3 A	(including CN8	connector	signals))		-				
Control n	nethod			Sine-w	ave PW	/M contr	ol/currei	nt contro	l method					Motors				
Permissil	Pormissible regenerative power of		ower of	1	10			20		100		100	170	tors				
the built-i	the built-in regenerative resistor (Note 2, 3) [W]			1 -	10			30		100		130	170					
Dynamic brake (Note 4)			Built-in	Built-in							_							
CC-Link IE TSN Communication cycle				31.25 μs, 62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 1.5 ms, 2 ms, 2.5 ms, 3 ms, 3.5 ms, 4 ms, 4.5 ms, 5 ms, 5.5 ms, 6 ms, 6.5 ms, 7 ms, 7.5 ms, 8 ms														
Class B (Note 13) (Note 10, 12)					6 ms, 6.	5 ms, 7	ms, 7.5 I	ns, 8 ms										
(MR-J5-G(-RJ)) Protocol version		1.0/2.0	(Note 5)									Motors						
CC-Link		(Note 10)	unication cycle	500 μs	500 μs to 500 ms								SIC					
Class A (NR-J5-C			ol version	2.0										-				
EtherCA	. ,,		unication cycle	2.0														
	G-(RJ)N1)	(Note 10, 1		125 µs	125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms													
	. , ,	etwork E	Basic (Note 5, 14)	0	ما م									Equipment				
(MR-J5-0	G(-RJ))			Suppor	nea									ome				
Commun	nication	USB		Conne	ct a ner	sonal co	mouter	(MB Cor	figurator?	compatible)				'nŧ				
function		000			· ·		· · · · · · · · · · · · · · · · · · ·	<u>`</u>	ingulatorz	compatible)								
	output pul	se		-		/B/Z-pha	ase puls	e)						-				
Analog m				2 chan										- 5				
	ng mode ^{(N}				able me									- 4				
Fully clos			-G(-N1)		Two-wire type communication method Two-wire/four-wire type communication method													
			-G-RJ(N1)											-				
Load-side			-G(-N1)		bishi Electric high-speed serial communication								-					
Internace		WIR-J5	-G-RJ(N1)		Mitsubishi Electric high-speed serial communication, A/B/Z-phase differential input signal Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning,						- :							
										der function, m		0.	0,					
Servo fur	nctions					0. 0				motion compe		•		ç				
					scale measurement function (Note 5, 12), super trace control (Note 5), continuous operation to torque control							ġ						
									function (Not									
							-		-	ut-off, overload	,							
Protectiv	e functions	3							•	otection, regen		•	٦,	-				
									•	ure protection, n protection, lir	•	•	t protection					
Safety si	ub-function	Safety	/ performance					<u> </u>	tion 1 of this			control lau	protection	-				
			penormance			-						Force of	ooling, open	-				
Structure	e (IP rating))		Natura	l cooling	g, open ((IP20)	Force	cooling, ope	en (IP20)		(IP20) (N						
Close	3-phase	power	supply input	Possib	le (Note 11)									·				
Close 3-phase power supply input nounting 1-phase power supply input				Possib	le (Note 11)				Not possi	ble	-							
mounting	prideo	po																

MR-J5-G (Network Compatible) Specifications (200 V)

MR-J5-G_ (Network Compatible) Specifications (200 V)

Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.
2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.

- 3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
- 4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.
- 5. For the servo amplifier firmware version supporting this function, refer to "MR-J5 User's Manual".
- 6. The values in brackets are the rated current for the 1-phase power supply input. 7. When the servo amplifier is used with a 1-phase power supply and combined with a servo motor of over 750 W, use the servo amplifiers at 75 % or less of the effective load ratio.
- 8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".
- 9. The connector part is excluded.
- 10. The communication cycle depends on the controller specifications and the number of device stations connected.
- 11. When the servo amplifiers at 75 % or less of the effective load ratio. 12. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 13. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.
- 14. For the restrictions on the network, refer to "MR-J5 User's Manual".
- 15. The function is not available with MR-J5-G-(RJ)N1.

G G-RJ

MR-J5-G (Network Compatible) Specifications (400 V)

Servo a	mplifier model	MR-J5		60G4(-(RJ)(N1))	100G4(-(RJ)(N1)) 200G4(-(RJ)(N1)) 350G4(-(RJ)(N1))	500G4(-(HS)(N1))	700G4(-(HS)(N1))	Specifications		
	Voltage			3-phase 0 V AC	to 480 V AC		· · · · · · · · · · · · · · · · · · ·					
Output	Rated current	8			2.8	5.5	8.6	14	17	tior		
Main	Voltage/frequ	ency (Note 1)	AC input	3-phase 380 V /	AC to 480 V AC,	50 Hz/60 Hz				. าร		
circuit	Rated current		[A]	1.4	2.5	5.1	7.9	10.8	14.4			
oower supply	fluctuation		3-phase 323 V /	AC to 528 V AC			·		Controllers			
nput	Permissible fi	equency fl	uctuation	±5 % maximum						rolle		
	Voltage/frequ	ency	AC input	1-phase 380 V /	AC to 480 V AC,	50 Hz/60 Hz				Sle		
Control	Rated current [A]			0.1				0.2		•		
circuit oower	Permissible v fluctuation	oltage	AC input	1-phase 323 V AC to 528 V AC								
supply nput	Permissible fi	equency fl	uctuation	±5 % maximum	⊧5 % maximum							
nput	Power consu	nption	[W]	30				45				
nterfac	e power supply	/		24 V DC ± 10 %	(required curre	nt capacity: 0.3 A	(including CN8 c	onnector signals))			
Control	method			Sine-wave PWN	I control/current	control method			<u>.</u>	· (
Permiss	ible regenerat	ve power o	of nam	15	15	100	100	100	170	-		
he built	-in regenerativ	e resistor (M	Note 2, 3) [VV]	CI	15	100	120	130	170	~		
Dynami	c brake (Note 4)			Built-in						Note		
CC-Link	IE TSN	Communi		31.25 µs, 62.5 µ	ιs, 125 μs, 250 μ	μs, 500 μs, 1 ms,	1.5 ms, 2 ms, 2.	5 ms, 3 ms, 3.5 m	ns, 4 ms, 4.5 ms,	Motors		
Class B	(Note 7)	cycle (Note 5	5, 6)	5 ms, 5.5 ms, 6	ms, 5.5 ms, 6 ms, 6.5 ms, 7 ms, 7.5 ms, 8 ms							
	MR-J5-G4(-RJ)/ MR-J5-G4(-HS) Protocol version		1.0/2.0 (Note 9)									
CC-Link IE TSN Communi Class A ^(Note 7, 8, 9) cycle ^{(Note 5}			500 μs to 500 ms									
MR-J5-G4(-RJ)/ MR-J5-G4(-HS)		Protocol v	version	2.0						Motors		
EtherCAT® MR-J5-G4-RJ(N1)/ MR-J5-G4-HS(N1)			125 µs, 250 µs,	125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms								
CC-Link IE Field Network Basic (Note 8, 9) MR-J5-G4(-RJ)/MR-J5-G4(-HS)			Supported						Motors			
Commu function	nication	USB		Connect a personal computer (MR Configurator2 compatible)						· 0		
Encode	r output pulse			Compatible (A/B/Z-phase pulse)								
Analog	monitor			2 channels								
Position	ing mode (Note 6	, 9)		Point table method								
		MR-J5-G4	4(-N1)	Two-wire type c	ommunication m	nethod				pme		
control ⁽	Note 6)	MR-J5-G4 MR-J5-G4	4-RJ(N1) 4-HS(N1)	Two-wire/four-wire type communication method						Equipment		
		MR-J5-G4		Mitsubishi Elect	ric high-speed se	erial communicat	ion					
interface	de encoder e	MR-J5-G4 MR-J5-G4	· · ·	Mitsubishi Electric high-speed serial communication, A/B/Z-phase differential input signal						[
Servo functions			Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, scale measurement function (Note 6), super trace control, continuous operation to torgue control mode (Note 6, 10),									
Protective functions				driver communication function (Note 6, 9, 10) Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection								
		afetv perfo	rmance	,		in section 1 of th	0					
	ub-function, S			Natural cooling, open (IP20) Force cooling, open (IP20)								
Safety s	ub-function, S e (IP rating)			Natural cooling,	open (IP20)	Force cooling,	open (IP20)					
Safety s Structur	· · · · · · · · · · · · · · · · · · ·			Natural cooling, Not possible	open (IP20)	Force cooling, o	open (IP20)					

2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.

3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.

4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio.

5. The communication cycle depends on the controller specifications and the number of device stations connected.


6. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 7. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 μs.
 8. For the restrictions on the network, refer to "RR-J5 User's Manual".

For the servo amplifier firmware version supporting this function, refer to "MR-J5 User's Manual".
 The function is not available with MR-J5-G4-N1, MR-J5-G4-RJN1, and MR-J5-G4-HSN1.

3-11

MR-J5-G(4)(-(RJ)(N1)) Standard Wiring Diagram Example

G G-RJ



Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable device stations depends on the controller specifications

- 2. This is for sink wiring. Source wiring is also possible.
- 3. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details.
- Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
 Devices for these pins can be changed with [Pr. PD07], [Pr. PD08], and [Pr. PD09].
- 8. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.

9. For MR-J5-G(4)-RJ(N1), this device can be changed to TPR3 (Touch probe 3) with [Pr. PD05]. When TPR3 is set, connect by using a normally open contact switch as the same as TPR1 (Touch probe 1) and TPR2 (Touch probe 2).


10. For MR-J5-G(4)(-N1), use the servo amplifiers with firmware version C0 or later and manufactured in June 2021 or later. Note that, depending on the stock status, the servo amplifiers with both the former and the new specifications may be distributed in the market around the same time. Contact the local sales office when the touch probe function is needed

- 11. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog
- 12. The forced stop signal is issued for the servo amplifier. For overall system, apply the emergency stop on the controller side.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

G-HS

MR-J5-G4-HS(N1) Standard Wiring Diagram Example



MR-J5-G4-HS(N1) Standard Wiring Diagram Example

Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable device stations depends on the controller specifications.


- 2. This is for sink wiring. Source wiring is also possible.
- 3. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog.
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details. 6. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05]. 7. Devices for these pins can be changed with [Pr. PD07], [Pr. PD08], and [Pr. PD09].
- 8. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 9. This device can be changed to TPR3 (Touch probe 3) with [Pr. PD05]. When TPR3 is set, connect by using a normally open contact switch as the same as TPR1 (Touch probe 1) and TPR2 (Touch probe 2).


G-HS


- The forced stop signal is issued for the servo amplifier. For overall system, apply the emergency stop on the controller side.
 The functional safety cannot be used with the factory setting. When using the functional safety, follow the instructions in "MR-J5 User's Manual" and set the functional safety parameters.
- 12. SDO1A, SDO2A, SDO1B, and SDO2B can be used only for source wiring.
- 13. The frame of the CN3 connector is not connected to the protective earth (PE) terminal. Grounding with a shield connection clamp (SCC 15-F) is recommended. For details, refer to "Products on the Market for Servo Amplifiers" in this catalog.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.










5. Do not ground the servo amplifier between L11 and L21 even when the control circuit power supply is separated from the main circuit power supply using an uninterruptible power supply (UPS) or an isolation transformer.

Į


Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Servo Motor Connection Example (Rotary Servo Motor) Semi Closed Loop Control System with MR-J5-G(4)(-N1)/MR-J5-B(4)/MR-J5-A(4)

●For HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series



●For HK-ST series/HK-RT (3.5 kW to 7.0 kW) series




Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

G B A

1




- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.
- 9. For fully closed loop control, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5 User's Manual" for the fully closed loop control with a rotary encoder.
- 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5 User's Manual" and "Rotary Servo Motor User's Manual (For MR-J5)"
- 12. When configuring a fully closed loop control system with MR-J5-G(4)(-N1)/MR-J5-B(4)/MR-J5-A(4), connect MR-J4FCCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set to CN2 connector

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Servo Motor Connection Example (Linear Servo Motor) Linear Servo System with MR-J5-G(-N1)/MR-J5-B/MR-J5-A

●For LM-H3 series/LM-F series/LM-K2 series/LM-U2 series



G B A

Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor. 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.

3. MR-J4THCBL03M junction cable for linear servo motor is compatible with both two-wire and four-wire type linear encoders.

4. When using a linear servo motor with MR-J5-G(-N1)/MR-J5-B/MR-J5-A, connect MR-J4THCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set to CN2 connector.

5. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

ļ

G A

Common Specifications


Servo System Controllers

Servo Amplifiers


Rotary Servo Motors

Servo Motor Connection Example (Linear Servo Motor) Linear Servo System with MR-J5-G(-N1)/MR-J5-A

For LM-AJ series



For LM-AU series




Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.


- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 4. Create a relay circuit to turn off the main circuit power supply when the thermal protector is opened by overheating. Use a relay designed for a flowing current of 1000 mA or less. If a mechanical relay is used, use a relay designed for a flowing current of 50 mA to 1000 mA.



Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Linear Encoder Connection Example (for MR-J5-G(4)(-N1)/MR-J5-B(4)/MR-J5-A(4)) G B





Α

- Notes: 1. For the number of the wire pairs for LG and P5, refer to "MR-J5 Partner's Encoder User's Manual".
 - 2. When the fully closed loop control system is configured with a rotary servo motor, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used.
 - 3. For the fully closed loop control, MR and MRR of the servo amplifier-side connectors will be connected to MX and MXR of the SCALE connectors of MR-J4FCCBL03M.

0

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Servo Motor Connection Example (Direct Drive Motor) G G-RJ B B-RJ A A-RJ For TM-RG2M series/TM-RU2M series/TM-RFM series (incremental system) Servo amplifier MR-J5-G MR-J5-B_ MR-J5-A CNP3 Direct drive motor UA υ¢ VB V Μ wc wÓ (Note 3) E D CN2 1 P5 P5 9 Encoder LG 10 2 LG 3 MR MR 7

(Note 2)

MRR 8

FG 5

THM1 6 THM2 11 -**_**


For TM-RG2M series/TM-RU2M series/TM-RFM series (absolute position detection system)

4 MRR

Plate SD

5 THM1

6 THM₂



Notes: 1. An MR-BTAS01 absolute position storage unit, and MR-BAT6V1SET or MR-BAT6V1SET-A battery (sold as options) are required for absolute position detection system. Refer to "MR-J5 User's Manual" and "Direct Drive Motor User's Manual" for details of absolute position detection system.

2. Fabricate this encoder cable. Refer to "Direct Drive Motor User's Manual" when fabricating the encoder cable

1

3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

External Encoder Connection Specifications

G G-RJ G-HS B B-RJ A A-RJ

Refer to the following table for the encoder communication method compatible with each system and for the servo amplifier connector to which a load-side encoder should be connected.

	External encoder	Connector to be connected with the external encoder						
Operation mode	communication method	MR-J5-G(4)(-N1)/ MR-J5-B(4)	MR-J5-G(4)-RJ(N1)/ MR-J5-G4-HS(N1)/ MR-J5-B(4)-RJ	MR-J5-A(4)	MR-J5-A(4)-RJ			
	Two-wire type	CN2 (Note 1)	CN2 (Note 1)	CN2 (Note 1)	CN2 (Note 1)			
Linear servo	Four-wire type	CINZ (Mar)		GINZ (******)	CINZ (
system (Note 3)	A/B/Z-phase differential output method		CN2L (Note 2)		CN2L (Note 2)			
	Two-wire type	CN2 (Note 4, 5)		CN2 (Note 4, 5)				
Fully closed	Four-wire type				_			
loop control system (Note 6, 7)	A/B/Z-phase differential output method		CN2L		CN2L			
	Two-wire type	CN2 (Note 4, 5)						
Scale	Four-wire type							
measurement function (Note 6, 7)	A/B/Z-phase differential output method		CN2L					

Notes: 1. MR-J4THCBL03M junction cable is required.

2. Connect a thermistor to CN2 connector.

Refer to "Combinations of Linear Servo Motors and Servo Amplifiers" in this catalog for servo amplifiers that are compatible with linear servo motors.
 MR-J4FCCBL03M junction cable is required.
 MR-J5-G(4)(-N1)/MR-J5-B(4)/MR-J5-A(4) does not support a servo motor encoder with the four-wire type communication method.

Use MR-J5-G(4)-RJ(N1)/MR-J5-G4-HS(N1)/MR-J5-B(4)-RJ/MR-J5-A(4)-RJ.

6. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.

7. For the servo amplifier firmware version supporting this function, refer to "MR-J5 User's Manual".

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product


List

G-RJ G-HS B-RJ A-RJ


Servo Motor Connection Example (Rotary Servo Motor)

Fully Closed Loop Control System with MR-J5-G(4)-RJ(N1)/MR-J5-G4-HS(N1)/MR-J5-B(4)-RJ/MR-J5-A(4)-RJ

●For HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series



●For HK-ST series/HK-RT (3.5 kW to 7.0 kW) series



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.

ļ


- 8. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.
- 9. The load-side encoder and the servo motor encoder are compatible with both two-wire and four-wire type communication methods.
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5 User's Manual" for the fully closed loop control with a rotary encoder. 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5 User's Manual" and "Rotary Servo Motor User's Manual (For MR-J5)".
- Necessary encoder cables vary depending on the load-side encoder. Here to "MH-J5 Oser's Manual.
 This wiring of the servo motor encoder is applicable for the two-wire type communication method.
- When configuring a fully closed loop control system with MR-J5-G(4)-RJ(N1)/MR-J5-G4-HS(N1)/MR-J5-B(4)-RJ/MR-J5-A(4)-RJ, connect a servo motor encoder to CN2 connector and a load-side encoder to CN2L connector. Do not use MR-J4FCCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.




Servo Motor Connection Example (Linear Servo Motor: LM-H3 Series/LM-F Series/LM-K2 Series/LM-U2 Series) Linear Servo System with MR-J5-G-RJ(N1)/MR-J5-B-RJ/MR-J5-A-RJ

Connecting a serial linear encoder



G-RJ B-RJ A-RJ

•Connecting an A/B/Z-phase differential output linear encoder



Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.

- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 4. When configuring a linear servo system with MR-J5-G-RJ(N1)/MR-J5-B-RJ/MR-J5-A-RJ and a serial linear encoder, connect MR-J4THCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set to CN2 connector.
- 5. When configuring a linear servo system with MR-J5-G-RJ(N1)/MR-J5-B-RJ/MR-J5-A-RJ and an A/B/Z-phase differential output type linear encoder, connect a thermistor to CN2 connector and the linear encoder to CN2L connector. Do not use MR-J4THCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set.
- 6. MR-J4THCBL03M junction cable for linear servo motor is compatible with both two-wire and four-wire type linear encoders.


Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

ļ


G-RJ A-RJ

Servo Motor Connection Example (Linear Servo Motor: LM-AJ Series) Linear Servo System with MR-J5-G-RJ(N1)/MR-J5-A-RJ

Connecting a serial linear encoder



Connecting an A/B/Z-phase differential output linear encoder



Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.

- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 4. Create a relay circuit to turn off the main circuit power supply when the thermal protector is opened by overheating. Use a relay designed for a flowing current of 1000 mA or less. If a mechanical relay is used, use a relay designed for a flowing current of 50 mA to 1000 mA.




Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Product

List


Servo Motor Connection Example (Linear Servo Motor: LM-AU Series) Linear Servo System with MR-J5-G-RJ(N1)/MR-J5-A-RJ

•Connecting a serial linear encoder



G-RJ A-RJ

Connecting an A/B/Z-phase differential output linear encoder



Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.


- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 4. Create a relay circuit to turn off the main circuit power supply when the thermal protector is opened by overheating. Use a relay designed for a flowing current of 1000 mA or less. If a mechanical relay is used, use a relay designed for a flowing current of 50 mA to 1000 mA.



Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Linear Encoder Connection Example (for MR-J5-G(4)-RJ(N1)/MR-J5-G4-HS(N1)/MR-J5-B(4)-RJ/MR-J5-A(4)-RJ)

G-RJ G-HS B-RJ A-RJ



Options/Peripheral Equipment

LVS/Wires

Product List


Precautions

MR-J5-G_ Dimensions

•MR-J5-10G(-N1), MR-J5-10G-RJ(N1)


•MR-J5-20G(-N1), MR-J5-20G-RJ(N1)

•MR-J5-40G(-N1), MR-J5-40G-RJ(N1)



[Unit: mm]

•MR-J5-60G(-N1), MR-J5-60G-RJ(N1)




Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-G(-N1) servo amplifiers. G G-RJ

G G-RJ




•MR-J5-70G(-N1), MR-J5-70G-RJ(N1)

•MR-J5-100G(-N1), MR-J5-100G-RJ(N1)



•MR-J5-200G(-N1), MR-J5-200G-RJ(N1) (Note 3)

•MR-J5-350G(-N1), MR-J5-350G-RJ(N1) (Note 3)



Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.

2. CN2L connector is not available for MR-J5-G(-N1) servo amplifiers.

3. For the servo amplifiers manufactured in August 2022 or later, the fan unit is mounted with two screws. Refer to "Mitsubishi Electric AC Servo System Sales and Service No. 22-02E" for details.

Direct Drive Motors


Options/Peripheral Equipment

LVS/Wires


Product List

MR-J5-G_ Dimensions


•MR-J5-500G(-N1), MR-J5-500G-RJ(N1)



•MR-J5-700G(-N1), MR-J5-700G-RJ(N1)



Notes: 1. CNP1A, CNP1B, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-G(-N1) servo amplifiers. G G-RJ



Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.


2. CN2L connector is not available for MR-J5-G4(-N1) servo amplifiers.

3. For the servo amplifiers manufactured in August 2022 or later, the fan unit is mounted with two screws. Refer to "Mitsubishi Electric AC Servo System Sales and Service No. 22-02E" for details.


Precautions

MR-J5-G_ Dimensions

•MR-J5-500G4(-N1), MR-J5-700G4(-N1)




•MR-J5-500G4-HS(N1), MR-J5-700G4-HS(N1)



Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.

G G-HS



Notes: 1. The connection with the peripheral equipment is an example for MR-J5W3-222G(-N1). CNP3C and CN2C connectors are not available on MR-J5W2-G(-N1). Refer to "MR-J5 User's Manual" for the actual connections of each multi-axis servo amplifier.

2. This picture shows when the display cover is open.

3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.

4. For specifications of the Ethernet cable, refer to "Ethernet Cable Specifications" on p. 7-30 in this catalog.

Servo ai	mplifier mod	del MR-	J5W2(-N1)		22G	44G	77G	1010G		
0	Voltage				3-phase 0 V AC to 240	V AC				
Output	Rated current (each axis) [A]			[A]	1.8	2.8	5.8	6.0		
	Voltage/ frequency	(Note 1)	AC input		3-phase or 1-phase 200	V AC 2.8 5.8 00 V AC to 240 V AC, 50 Hz/60 Hz 5.2 7.5 (9.0) (13.0) 70 V AC to 264 V AC 2 240 V AC, 50 Hz/60 Hz 2 264 V AC 2 red current capacity: 0.35 A (includ ol/current control method 100 100 100 100 12,5 2 ms, 4 ms, 8 ms omputer (MR Configurator2 compa e pulse) (Note 12)	Hz/60 Hz	3-phase 200 V AC to 240 V AC, 50 Hz/60 H		
Vlain	inequency		DC input (Note	8)	283 V DC to 340 V DC					
circuit oower	Rated curr	ent (Note	6)	[A]	2.9 (5.0)			9.8		
upply nput	Permissibl voltage	е	AC input		3-phase or 1-phase 170	VAC to 264 VAC		3-phase 170 V AC to 264 V AC		
	fluctuation		DC input (Note 8)		241 V DC to 374 V DC					
	Permissible frequency fluctuation		±5 % maximum							
	Voltage/		AC input		1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz					
Control	frequency		DC input (Note		283 V DC to 340 V DC					
ircuit	Rated curr		1	[A]	0.4					
ower	Permissibl voltage	Permissible AC input			1-phase 170 V AC to 26	64 V AC				
supply nput	fluctuation		DC input (Note	8)	241 V DC to 374 V DC					
iput	Permissible frequency fluctuation			n	±5 % maximum					
	Power con	sumptio	on	[W]	55					
nterface	e power sup	ply			24 V DC ± 10 % (requir	ed current capacity: 0.3	35 A (including CN8 co	nnector signals))		
Control	method				Sine-wave PWM contro	I/current control metho	d			
	ible regene		ower of sistor ^(Note 2, 3)	[W]	20		100			
Dynamio	c brake (Note)	4)			Built-in					
	IE TSN		unication cycle	e			, 2 ms, 2.5 ms, 3 ms, 3	3.5 ms, 4 ms, 4.5 ms, 5 ms		
Class B (Note 9) (Note 5, 12) MR-J5W2-G) Protocol vers				5.5 ms, 6 ms, 6.5 ms, 7 ms, 7.5 ms, 8 ms 1.0/2.0 ^(Note 11)						
	,	Protocol version		1.0/2.0 (Note 11)						
	(Note 9, 11, 13)	(Note 5)	unication cycle	e	500 μs to 500 ms					
MR-J5\	,	Protoco	ol version		2.0					
EtherCA MR-J5\		Comm cycle ^{(N}	unication lote 5, 12)		250 μs, 500 μs, 1 ms, 2	2 ms, 4 ms, 8 ms				
CC-Link	IE Field Ne	etwork E	Basic		Not supported					
Commu unction	nication	USB			Connect a personal con	nputer (MR Configurate	or2 compatible)			
Encoder	r output puls	se			Compatible (A/B-phase	pulse) (Note 12)				
Analog i	monitor		-		2 channels					
Position	ing mode ^{(Ne}	ote 11, 12)			Point table method					
ully clo	sed loop co	ontrol (No	te 11, 12)		Two-wire type communi	cation method				
oad-sic	de encoder	interfac	e (Note 10)		Mitsubishi Electric high-	speed serial communi	cation			
Servo fu	inctions				one-touch tuning, tough (including failure predict	drive function, drive retion), power monitoring	corder function, mach function, lost motion c	ine diagnosis function compensation function,		
Protectiv	ve functions	3			servo motor overheat pl undervoltage protection	rotection, encoder erro , instantaneous power	r protection, regenerat failure protection, over	ive error protection, rspeed protection,		
Safety s	ub-function	, Safety	performance			inctions" in section 1 o	f this catalog.			
	e (IP rating)				Natural cooling, open (IP20)					
Close m	ounting				Possible (Note 7)	1				
					1					

Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.

2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.

Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.
 The communication cycle depends on the controller specifications and the number of device stations connected.

6. The values in brackets are the rated current for the 1-phase power supply input.

7. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio.

8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".

9. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.
 10. Not compatible with pulse train interface (A/B/Z-phase differential output type).
 11. For the servo amplifier firmware version supporting this function, refer to "MR-J5 User's Manual".

3-36 12. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 13. For the restrictions on the network, refer to "MR-J5 User's Manual".

14. The function is not available with MR-J5W_-G-N1.

WG (

MR-J5W3-G(-N1) (3-Axis, Network Compatible) Specifications

Servo a	mplifier mod	el MR-	J5W3(-N1)	222G 444G	Deci				
Output	Voltage			3-phase 0 V AC to 240 V AC	Common Specifications				
Output	Rated current (each axis) [A]			[A] 1.8 2.8	tion				
Main	Voltage/ AC input frequency (Note 1) DC input (Note 8)		AC input	3-phase or 1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz	SI				
			DC input (Note 8)	283 V DC to 340 V DC					
Main circuit	Rated current (Note 6) [A]		6)	4.3 7.8					
power				[^{AJ}] (7.5) (13.5)	ontr				
supply	Permissible AC input		AC input	3-phase or 1-phase 170 V AC to 264 V AC	ervo Syster Controllers				
input	fluctuation		DC input (Note 8)	241 V DC to 374 V DC	Servo System Controllers				
	Permissible frequency fluctuation		ency fluctuation	±5 % maximum	S				
	Voltage/		AC input	1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz	Servo Amplifiers				
Control	frequency		DC input (Note 8)	283 V DC to 340 V DC					
Control circuit	Rated curre	ent).4					
power	Permissible)	AC input	1-phase 170 V AC to 264 V AC	ifier				
supply input	voltage fluctuation		DC input (Note 8)	241 V DC to 374 V DC					
input	Permissible	freque	ency fluctuation	±5 % maximum	Rot				
	Power cons	sumptio	on [W] 55	Rotary Servo Motors				
Interfac	e power sup	ply		24 V DC ± 10 % (required current capacity: 0.45 A (including CN8 connector signals))	lors				
Control	method			Sine-wave PWM control/current control method	NO				
	sible regener t-in regenera			w] 30					
Dynamic brake (Note 4)			Built-in	Lin					
CC-Link IE TSN Communication cycle		nunication cycle	125 μs, 250 μs, 500 μs, 1 ms, 1.5 ms, 2 ms, 2.5 ms, 3 ms, 3.5 ms, 4 ms, 4.5 ms, 5 ms, 5.5 ms,	Linear Servo Motors					
Class B (Note 9) (Note 5, 11)		11)	6 ms, 6.5 ms, 7 ms, 7.5 ms, 8 ms	lors					
(MR-J5)	(MR-J5W3-G) Protocol version		col version	1.0/2.0 (Note 10)	No				
	CC-Link IE TSN Communication cycle Class A (Note 9, 10, 13) (Note 5)		nunication cycle	500 μs to 500 ms					
	MR-J5W3-G) Protocol version		col version	2.0	Dir				
	EtherCAT [®] Communication (MR-J5W3-G-N1) cycle ^(Note 5, 11)			250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms	Motors				
`	IE Field Ne	twork E	Basic	Not supported					
Commu function	inication	USB		Connect a personal computer (MR Configurator2 compatible)					
	r output	MR-J	5W3-G	Compatible only with A-axis and B-axis (A/B-phase pulse) (Note 11, 12)	Options/Peripheral Equipment				
pulse		MR-J	5W3-G-N1	Not compatible					
Analog	monitor			2 channels					
	ning mode (No	te 10, 11)		Point table method	hera t				
Fully clo	osed loop co	ntrol		Not available	=				
Servo functions				Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, super trace control (Note 10), continuous operation to torque control mode (Note 10, 14)					
				Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection,					
Protecti	ve functions			undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection					
Safety	sub-function	Safety	/ performance	Refer to "Safety Sub-Functions" in section 1 of this catalog.	Product List				
	e (IP rating)	20.00		Force cooling, open (IP20)	list				
	nounting			Possible (Note 7)					
Mass			r	xg] 1.8					
			L	notor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the	Preca				

servo amplifier is operated within the specified power supply voltage and frequency.

2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.

Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.

5. The communication cycle depends on the controller specifications and the number of device stations connected.

6. The values in brackets are the rated current for the 1-phase power supply input.

7. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio.

8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".

9. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.


For the servo amplifier firmware version supporting this function, refer to "MR-J5 User's Manual".
 For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 When the command unit selection function (command unit/s) or the touch probe function is enabled, encoder output pulses are not outputted.

13. For the restrictions on the network, refer to "MR-J5 User's Manual".

14. The function is not available with MR-J5W_-G-N1.


cautions

MR-J5W2-G(-N1) Standard Wiring Diagram Example



Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable device stations depends on the controller specifications.


- 2. This is for sink wiring. Source wiring is also possible.
- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details.
- When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 7. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for two axes of the servo amplifier. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2), and TPR3 (Touch probe 3) with [Pr. PD05] and [Pr. PD51].
- 12. For the servo amplifier firmware version supporting the touch probe function, refer to "MR-J5 User's Manual"
- 13. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
- 14. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog.



1

WG





Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2) Note that the number of the connectable device stations depends on the controller specifications.

- 2. This is for sink wiring. Source wiring is also possible.
- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08]
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details
- 6. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 7. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for three axes of the servo amplifier. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2), and TPR3 (Touch probe 3) with [Pr. PD05]
- 12. For the servo amplifier firmware version supporting the touch probe function, refer to "MR-J5 User's Manual"
- 13. For the availability of the encoder output pulse, refer to "MR-J5W3-G(-N1) (3-Axis, Network Compatible) Specifications" in this catalog
- For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog.
- - Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Support


List


Precautions

Main/Control Circuit Power Supply Connection Example (Note 6)


WG WB

- Driving on/off of main circuit power supply with AC power supply for 3-phase 200 V AC
- Driving on/off of main circuit power supply with DC power supply for 3-phase 200 V AC





wer supplyDriving on/off of main circuit power supplyase 200 V ACwith DC power supply for 1-phase 200 V AC



Notes: 1. For 1-phase 200 V AC to 240 V AC, connect the power supply to L1 and L3 terminals. Do not connect anything to L2.

- 2. Disconnect a short-circuit bar between P+ and D when connecting the regenerative option externally.
- 3. When wires used for L11 and L21 are thinner than those for L1, L2, and L3, use a molded-case circuit breaker or a fuse. Refer to "MR-J5 User's Manual" for details.
- 4. Select either of the following functions for CALM (AND malfunction) with the controller.
- The contact opens when an alarm occurs on one of the axes.
 The contact opens when an alarm occurs on all axes.
- 5. Do not use the 24 V DC interface power supply for the magnetic contactor. Provide a dedicated power supply to the magnetic contactor.
- 6. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual"


When connecting a linear servo motor with a thermal protector, add a contact to shut off by being interlocked with the thermal protector output of the linear servo motor.
 Do not ground the servo amplifier between L11 and L21 even when the control circuit power supply is separated from the main circuit power supply using an uninterruptible power supply (UPS) or an isolation transformer.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.


WG WB

Servo Motor Connection Example (Rotary Servo Motor) Semi Closed Loop Control System with MR-J5W_-G(-N1)/MR-J5W_-B

●For HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series



For HK-ST series



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. CNP3C and CN2C connectors are available for MR-J5W3-G(-N1)/MR-J5W3-B servo amplifiers.
- Install a surge absorber between B1 and B2.
 This is for using an option dual cable type. Single cable types are also available.
- This is for using an option dual cable type. Singl 8. Encoder cables are available as an option.

9. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Support

External Encoder Connection Specifications

WG WB

Refer to the following table for the encoder communication method compatible with each system and for the servo amplifier connector to which a load-side encoder should be connected.

Operation	External encoder	Connector to be connected with the external encoder					
mode	communication method	MR-J5W2-G(-N1)/MR-J5W2-B	MR-J5W3-G(-N1)/MR-J5W3-B				
Linear servo	Two-wire type	CN2A (Note 1)	CN2A ^(Note 1)				
ex vet ever (Noto 2)		CN2B (Note 1)	CN2B (Note 1)				
System	Four-wire type		CN2C (Note 1)				
Fully closed loop control system (Note 2, 5)	Two-wire type	CN2A (Note 4, 6) CN2B (Note 4, 6)					
Scale measurement function (Note 2, 5)	Two-wire type	CN2A (Note 4, 6) CN2B (Note 4, 6)					


Notes: 1. MR-J4THCBL03M junction cable is required. 2. For the servo amplifier firmware version supporting this function, refer to "MR-J5 User's Manual". 3. Refer to "Combinations of Linear Servo Motors and Servo Amplifiers" in this catalog for servo amplifiers that are compatible with linear servo motors.

4. MR-J4FCCBL03M junction cable is required.

5. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.

6. MR-J5W2-G(-N1)/MR-J5W2-B does not support a servo motor encoder with the four-wire type communication method. Use MR-J5-G(4)-RJ(N1)/MR-J5-G4-HS(N1)/ MR-J5-B(4)-RJ.

Servo Amplifiers




Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

ļ

Servo Motor Connection Example (Linear Servo Motor) Linear Servo System with MR-J5W_-G(-N1)/MR-J5W_-B

For LM-H3 series/LM-K2 series/LM-U2 series



Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.

2. For linear encoders, refer to "List of Linear Encoders" in this catalog.

3. MR-J4THCBL03M junction cable for linear servo motor is compatible with both two-wire and four-wire type linear encoders.

- 4. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 5. CNP3C and CN2C connectors are available for MR-J5W3-G(-N1)/MR-J5W3-B servo amplifiers.


Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.




1

Servo Motor Connection Example (Linear Servo Motor) Linear Servo System with MR-J5W_-G(-N1)

For LM-AJ series



For LM-AU series



Notes: 1. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.

- 2. For linear encoders, refer to "List of Linear Encoders" in this catalog.
- 3. Necessary cables vary depending on the linear encoder. Refer to "MR-J5 Partner's Encoder User's Manual" for details.
- 4. Create a relay circuit to turn off the main circuit power supply when the thermal protector is opened by overheating. Use a relay designed for a flowing current of 1000 mA or less. If a mechanical relay is used, use a relay designed for a flowing current of 50 mA to 1000 mA. 5. CNP3C and CN2C connectors are available for MR-J5W3-G(-N1)/MR-J5W3-B servo amplifiers.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

WG

Product

Linear Encoder Connection Example (for MR-J5W_-G(-N1)/MR-J5W_-B)

WG WB


Heidenhain Linear encoder

0\

5\

SD /SD RQ

/RQ



Notes: 1. For the number of the wire pairs for LG and P5, refer to "MR-J5 Partner's Encoder User's Manual".


2. For fully closed loop control, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used.

3. For the fully closed loop control, MR and MRR of the servo amplifier-side connectors will be connected to MX and MXR of the SCALE connectors of MR-J4FCCBL03M.

0

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Servo Motor Connection Example (Direct Drive Motor) WG WB Common Specifications For TM-RG2M series/TM-RU2M series/TM-RFM series (incremental system) Servo amplifier MR-J5W_-G(-N1) MR-J5W_-B Direct drive motor (Note 4) CNP3A/B/C Servo System Controllers U U v v в Μ W w С Е (Note 3) D € Servo Amplifiers (Note 4) CN2A/B/C P5 P5 9 Encoder 2 LG LG 10 MR 3 MR 7 (Note 1) 4 MRR MRR 8 Rotary Servo Motors Plate SD FG 5 5 THM1 Thermistor THM2 6 θ HM1 6 HM2 11 Linear Servo Motors For TM-RG2M series/TM-RU2M series/TM-RFM series (absolute position detection system) Direct Drive Motors Servo amplifier



Notes: 1. Fabricate this encoder cable. Refer to "Direct Drive Motor User's Manual" when fabricating the encoder cable.

- 2. An MR-BTAS01 absolute position storage unit, MR-BT6VCASE battery case, and MR-BAT6V1 batteries (sold as options) are required for absolute position detection system. Refer to "MR-J5 User's Manual" and "Direct Drive Motor User's Manual" for details of absolute position detection system.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.
- 4. CNP3C and CN2C connectors are available for MR-J5W3-G(-N1)/MR-J5W3-B servo amplifiers.



Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Options/Peripheral Equipment

LVS/Wires

Product

List


Precautions

Support


MR-J5W2-G(-N1) Dimensions

•MR-J5W2-22G(-N1)

•MR-J5W2-44G(-N1)




•MR-J5W2-77G(-N1)



Notes: 1. CNP1, CNP2, CNP3A, and CNP3B connectors are supplied with the servo amplifier.

WG

Servo Amplifiers



Notes: 1. CNP1, CNP2, CNP3A, CNP3B, and CNP3C connectors are supplied with the servo amplifier.

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product List


Precautions

Support

MR-J5D_-G4(-N1) Connections with Peripheral Equipment (Note 1)

Peripheral equipment is connected to MR-J5D_-G4(-N1) as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the drive unit easily and start using it right away.

DG



Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor.

4. For specifications of the Ethernet cable, refer to "Ethernet Cable Specifications" on p. 7-30 in this catalog.

MR-J5D1-G4(-N1) (1-Axis, Network Compatil	ble) Specifications (400 V)
---	-----------------------------

Drive unit	model M	R-J5D1	(-N1)	100G4	200G4	350G4	500G4	700G4	Dec			
Compatib	le conver	ter unit	model	MR-CV_4 (Note	8)				Specifications			
Output	Voltage			3-phase 0 V A	C to 480 V AC				tion			
Output	Rated cu	urrent	[A]	3.0	5.5	8.6	14.0	17.0	0			
Main circu	· ·		nput	Main circuit po	ower is supplied from	m the power regener	ration converter unit t	to the drive unit.	- ,			
	Voltage/ frequenc		AC input	1-phase 380 V	phase 380 V AC to 480 V AC, 50 Hz/60 Hz							
Control	Rated cu	urrent	[A]	0.2					Controllers			
circuit power supply	Permissi voltage fluctuatio		AC input	1-phase 323 \	AC to 528 V AC							
input	Permissi fluctuatio		luency	±5 % maximu	m				Servo Amplifiers			
	Power c	onsump	otion [W]	40					mp			
Interface	nterface power supply			24 V DC ± 10	% (required current	capacity: 0.3 A (incl	uding CN8 connecto	r signals))	lifie			
Control m					VM control/current c	control method			ร			
Dynamic brake (Note 2)				Built-in								
	CC-Link IE TSN Class B (Note 5) (Note 3, 4)			5 ms, 5.5 ms,	.25 μs, 62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 1.5 ms, 2 ms, 2.5 ms, 3 ms, 3.5 ms, 4 ms, 4.5 ms, ns, 5.5 ms, 6 ms, 6.5 ms, 7 ms, 7.5 ms, 8 ms							
(MR-J5D1	-G4)	Protoc	ol version	1.0/2.0 (Note 6)				Motors				
	Link IE TSN SS A (Note 5, 6, 7) (Note 3)			500 μs to 500	500 μs to 500 ms							
(MR-J5D1	-G4)	Protoc	ol version	2.0	2.0							
EtherCAT (MR-J5D1		Comm (Note 3, 4)	unication cycle	125 μs, 250 μ	125 μs, 250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms							
CC-Link II (MR-J5D1		etwork I	Basic (Note 7)	Supported	Supported							
Communi function	cation	USB		Connect a pe	rsonal computer (MI	R Configurator2 com	ipatible)					
Encoder c	output pul	se		Compatible (A	Compatible (A/B/Z-phase pulse)							
Analog m				2 channels					Motors			
Positionin	-			Point table me	ethod				SJC			
Fully close					-wire type communi				-			
Load-side	encoder	interfac	e		0 1		A/B/Z-phase different	1 0	-			
Servo functions		one-touch tun (including failu measurement	ing, tough drive fund are prediction), powe	ction, drive recorder er monitoring functio er trace control, conti	function, machine di n, lost motion compe	ick tuning, auto tuning, agnosis function ensation function, scale orque control mode ^(Note 4, 9) ,	Equipment					
Protective	functions	3		error protectio	n, undervoltage prot	ection, instantaneous	s power failure protec	rheat protection, encoder tion, overspeed protection, control fault protection				
Safety sul	o-function	, Safety	/ performance			n section 1 of this ca			LVS/Wires			
Structure		· ·			g, open (IP20) (Note 1)			, open (IP20) (Note 1)	WIr			
	lass [k											

Notes: 1. IP20 requires a side protection cover (an option).
2. When using the dynamic brake, refer to "MR-J5D User's Manual" for the permissible load to motor inertia ratio.
3. The communication cycle depends on the controller specifications and the number of device stations connected.
4. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
5. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 μs.
6. For the serve amplifier firmware version supporting this function, refer to "MR-J5D User's Manual"

7. For the restrictions on the network, refer to "MR-J5D User's Manual".

MR-CV_4 power regeneration converter units require a mounting attachment. Some drive units also require a mounting attachment depending on the power regeneration converter unit to be used. Refer to "Mounting Attachment" in this catalog for details.
 The function is not available with MR-J5D_-G4-N1.

Product List

Drive unit model MR-J5D2(-N1)		R-J5D2	(-N1)	100G4	200G4	350G4	500G4	700G4			
Compatik	ole conver	ter unit	model	MR-CV_4 (Note 2)	MR-CV_4 (Note 2)						
Outraut	Voltage			3-phase 0 V AC to 480 V AC							
Output	Rated cu	urrent (e	each axis) [A] 3.0	5.5	8.6	14.0	17.0			
Main circ	uit power :	supply i	nput	Main circuit power	is supplied from	the power regener	ation converter unit t	o the drive unit.			
	Voltage/ frequenc		AC input	1-phase 380 V AC	1-phase 380 V AC to 480 V AC, 50 Hz/60 Hz						
			[A] 0.2							
circuit power supply	Permissi voltage fluctuatio		AC input	1-phase 323 V AC	to 528 V AC						
input		Permissible frequency uctuation		±5 % maximum							
Power consumption [V			otion [W] 40							
	Interface power supply					cluding CN8 connect	or signals))				
Control method		Sine-wave PWM c	ontrol/current co	ntrol method							
Dynamic brake (Note 4)		Built-in									
CC-Link IE TSN Class B (Note 7) Class B (Note 7)		62.5 μs, 125 μs, 250 μs, 500 μs, 1 ms, 1.5 ms, 2 ms, 2.5 ms, 3 ms, 3.5 ms, 4 ms, 4.5 ms, 5 ms, 5.5 ms, 6 ms, 6.5 ms, 7 ms, 7.5 ms, 8 ms									
(MR-J5D2-G4) Protocol version		1.0/2.0 (Note 9)									
CC-Link IE TSN Class A (Note 7, 9, 10) (Note 5)		500 µs to 500 ms									
(MR-J5D	2-G4)	Protoc	ol version	2.0							
EtherCAT (MR-J5D	Г® 2-G4-N1)	Comm (Note 5, 6)	unication cycle	250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms							
CC-Link	IE Field Ne	etwork I	Basic	Not supported							
Commun function	ication	USB		Connect a personal computer (MR Configurator2 compatible)							
Encoder	output pul	se		Compatible (A/B-p	hase pulse) ^{(Note}	i, 8)					
Analog m	nonitor			2 channels							
	ng mode ^{(N}			Point table method							
	sed loop co			Two-wire type communication method							
Load-side	e encoder	interfac	Ce (Note 3)	Mitsubishi Electric high-speed serial communication							
Servo fur	nctions			Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, scale measurement function (Note 6), super trace control, continuous operation to torque control mode (Note 6, 11)							
Protective	e functions	6		Overcurrent shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection							
Safety su	b-function	, Safety	/ performance	Refer to "Safety Su	ub-Functions" in	section 1 of this ca	talog.				
Structure	(IP rating)		Natural cooling, open (IP20) (Note 1)							
Mass			[ka] 5.7	5.6		6.2				

Notes: 1. IP20 requires a side protection cover (an option).

2. MR-CV_4 power regeneration converter units require a mounting attachment. Some drive units also require a mounting attachment depending on the power regeneration converter unit to be used. Refer to "Mounting Attachment" in this catalog for details.

Not compatible with pulse train interface (A/B/Z-phase differential output type).
 When using the dynamic brake, refer to "MR-J5D User's Manual" for the permissible load to motor inertia ratio.
 The communication cycle depends on the controller specifications and the number of device stations connected.
 For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.

7. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.

8. When the safety sub-function (network connection) is enabled, encoder output pulses are not outputted.

For the servo amplifier firmware version supporting this function, refer to "MR-J5D User's Manual"
 For the restrictions on the network, refer to "MR-J5D User's Manual".

11. The function is not available with MR-J5D_-G4-N1.

DG

MR-J5D3-G4(-N1) (3-Axis, Network Compatible) Specifications (400 V)

Drive unit	model M	R-J5D3	(-N1)	100G4	200G4	Cor	
Compatibl	e conver	ter unit	model	MR-CV_4 (Note 3)		Common Specifications	
Output	Voltage			3-phase 0 V AC to 480 V AC		tion	
Output	Rated cu	urrent (e	each axis) [A]	3.0	5.5	SI	
Main circu	it power :	supply i	nput	Main circuit power is supplied from the power re	generation converter unit to the drive unit.		
	Voltage/ frequenc	ÿ	AC input	1-phase 380 V AC to 480 V AC, 50 Hz/60 Hz		Servo System Controllers	
Control	Rated cu	urrent	[A]	0.2		rolle	
circuit power supply	Permissi voltage fluctuatio		AC input	1-phase 323 V AC to 528 V AC		_	
input	Permissi fluctuatio		luency	±5 % maximum		Servo Amplifiers	
	Power consumption [V			40		mp	
Interface p	power sup	oply		24 V DC ± 10 % (required current capacity: 0.45	A (including CN8 connector signals))	lifie	
Control me	Control method			Sine-wave PWM control/current control method		sle	
Dynamic b	orake (Note	4)		Built-in			
	C-Link IE TSN Communication cycle Ass B (Note 2) (Note 5, 6)			250 μs, 500 μs, 1 ms, 1.5 ms, 2 ms, 2.5 ms, 3 ms, 3.5 ms, 4 ms, 4.5 ms, 5 ms, 5.5 ms, 6 ms, 6.5 ms, 7 ms, 7.5 ms, 8 ms			
(MR-J5D3	8-G4)	Protoc	ol version	1.0/2.0 (Note 8)		tors	
CC-Link IE Class A (No		Comm (Note 5)	unication cycle	500 μs to 500 ms		Rotary Servo Motors	
(MR-J5D3	3-G4)	Protoc	ol version	2.0			
EtherCAT® (MR-J5D3		Comm (Note 5, 6)	unication cycle	250 μs, 500 μs, 1 ms, 2 ms, 4 ms, 8 ms			
CC-Link IE	E Field No	etwork I	Basic	Not supported		Linear Servo Motors	
Communio function	cation	USB		Connect a personal computer (MR Configurator	2 compatible)	NO	
Encoder o	output	MR-J5	D3-G4	Compatible only with A-axis and B-axis (A/B-pha	se pulse) (Note 6, 7)		
pulse		MR-J5	D3-G4-N1	Not compatible		Dir	
Analog mo	onitor			2 channels		Motors	
Positioning	g mode ^{(N}	ote 6)		Point table method		Direct Drive Motors	
Fully close	ed loop co	ontrol		Not compatible		ē	
Servo functions			Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, super trace control, continuous operation to torque control mode (Note 6, 10)				
Protective		-		error protection, undervoltage protection, instanta error excessive protection, magnetic pole detection		Options/Peripheral Equipment	
		· · ·	performance	Refer to "Safety Sub-Functions" in section 1 of the			
Structure	(IP rating)		Natural cooling, open (IP20) (Note 1)	Force cooling, open (IP20) (Note 1)	LVS/W	
Mass	; [k			5.9	5.8	Ŵ	

Notes: 1. IP20 requires a side protection cover (an option).

2. A communication speed of 1 Gbps/100 Mbps can be selected. When 100 Mbps is selected, the minimum communication cycle is 500 µs.

MR-CV_4 power regeneration converter units require a mounting attachment. Some drive units also require a mounting attachment depending on the power regeneration converter unit to be used. Refer to "Mounting Attachment" in this catalog for details.
 When using the dynamic brake, refer to "MR-J5D User's Manual" for the permissible load to motor inertia ratio.

5. The communication cycle depends on the controller specifications and the number of device stations connected.

6. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.

7. When the command unit selection function (command unit/s), the safety sub-function (network connection), or the touch probe function is enabled, encoder output pulses are not outputted.

For the servo amplifier firmware version supporting this function, refer to "MR-J5D User's Manual"
 For the restrictions on the network, refer to "MR-J5D User's Manual".

10. The function is not available with MR-J5D_-G4-N1.


Vires

Product

List

Precautions

MR-J5D1-G4(-N1) Standard Wiring Diagram Example



Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable device stations depends on the controller specifications.

2. This is for sink wiring. Source wiring is also possible.


- 3. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used.
- 4. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner
- Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details.
- 6. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 7. Devices for these pins can be changed with [Pr. PD07], [Pr. PD08], and [Pr. PD09].
- 8. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog.
- 9. This device can be changed to TPR3 (Touch probe 3) with [Pr. PD05]. When TPR3 is set, connect by using a normally open contact switch as the same as TPR1 (Touch probe 1) and TPR2 (Touch probe 2)
- 10. The forced stop signal is issued for the drive unit. For overall system, apply the emergency stop on the controller side.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions

Servo Amplifiers

DG

MR-J5D2-G4(-N1) Standard Wiring Diagram Example



Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable device stations depends on the controller specifications.


- 2. This is for sink wiring. Source wiring is also possible.
- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner
- Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details
- 6. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog
- 7. Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for two axes of the drive unit. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used.
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2), and TPR3 (Touch probe 3) with [Pr. PD05] and [Pr. PD51].
- For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 For the availability of the encoder output pulse, refer to "MR-J5D2-G4(-N1) (2-Axis, Network Compatible) Specifications (400 V)" in this catalog.
 - Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

List

Precautions

Support

MR-J5D3-G4(-N1) Standard Wiring Diagram Example



DG

Notes: 1. The node address or the 4th octet of the IP address can be set to between 1 and 254 with a combination of the ID setting switches or the rotary switches (SW1 and SW2). Note that the number of the connectable device stations depends on the controller specifications.

2. This is for sink wiring. Source wiring is also possible.

- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner
- Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details
- For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.
 Devices for these pins can be changed with [Pr. PD03], [Pr. PD04], and [Pr. PD05].
- 8. The forced stop signal is issued for three axes of the drive unit. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used
- 11. These devices can be changed to TPR1 (Touch probe 1), TPR2 (Touch probe 2), and TPR3 (Touch probe 3) with [Pr. PD05].
- 12. For the restrictions on the communication cycle of the touch probe function, refer to "Restrictions" in this catalog.
- 13. For the availability of the encoder output pulse, refer to "MR-J5D3-G4(-N1) (3-Axis, Network Compatible) Specifications (400 V)" in this catalog.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.


ļ

3-56

DG

Main/Control Circuit Power Supply Connection Example (Note 11)

For connecting MR-CV_ and MR-J5D_-G4(-N1)



Notes: 1. To prevent an unexpected restart of the drive unit, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.

2. This is for sink wiring. Source wiring is also possible.

3. A step-down transformer is required if the power regeneration converter unit is in 400 V class, and coil voltage of the magnetic contactor is in 200 V class. 4. When connecting multiple drive units, create a sequence in which the servo system controller stops all axes and a sequence that shuts off the main circuit power if an

- alarm occurs on one axis.
- 5. Attach a short-circuit connector supplied with the drive unit when the functional safety (STO function) is not used.
- 6. Install an overcurrent protection device (molded-case circuit breaker, fuse, etc.) to protect the branch circuit.
- 7. Terminal varies depending on the capacity of the power regeneration converter unit and the drive unit. Refer to "MR-CV_ Power Regeneration Converter Unit Dimensions" and "MR-J5D_-G4(-N1) Dimensions" in this catalog.
- 8. To stop the servo motor by forcibly decelerating with EM2, parameter setting is required. Refer to "MR-J5 User's Manual" for details
- 9. Refer to the controller manual for the forced stop input of the servo system controller.
- 10. The bus bar varies depending on the combination of the power regeneration converter unit and the drive unit. Refer to "Bus Bar" in this catalog for details.
- 11. This example is for when magnetic contactor drive output is enabled.
- 12. The control circuit power supply (L11/L21) can be connected by passing wiring. Refer to "MR-J5D User's Manual" for details.
- 13. Do not ground the drive unit between L11 and L21 even when the control circuit power supply is separated from the main circuit power supply using an uninterruptible power supply (UPS) or an isolation transformer.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.


Product

List


Precautions

Servo Motor Connection Example (Rotary Servo Motor) Semi Closed Loop Control System with MR-J5D_-G4(-N1)

●For HK-KT series/HK-RT (1.0 kW to 2.0 kW) series



●For HK-ST series/HK-RT (3.5 kW to 7.0 kW) series



- Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.
 - 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals do not have polarity.
 - 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor.
 - 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
 - 5. CNP3B and CN2B connectors are available for MR-J5D2-G4(-N1) and MR-J5D3-G4(-N1) drive units. CNP3C and CN2C connectors are available for MR-J5D3-G4(-N1) drive units.
 - 6. Install a surge absorber between B1 and B2.
 - 7. This is for using an option dual cable type. Single cable types are also available.
 - 8. Encoder cables are available as an option.
 - 9. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

A

External Encoder Connection Specifications

Refer to the following table for the encoder communication method compatible with each system and for the drive unit connector to which a load-side encoder should be connected.

Operation	External encoder	Connector to be connected	with the external encoder		tions
mode	communication method	MR-J5D1-G4(-N1)	MR-J5D2-G4(-N1)	MR-J5D3-G4(-N1)	
	Two-wire type		CN2A (Note 1, 2) CN2B (Note 1, 2)		Controllers
system (Note 3)	Four-wire type	-CN2AL			rolle
	A/B/Z-phase differential output method				
Coolo	Two-wire type		CN2A (Note 1, 2) CN2B (Note 1, 2)		Servo A
Scale measurement	Four-wire type	-CN2AL			Amplifiers
function (Note 3)	A/B/Z-phase	CINZAL			lifie
iunction -	differential output				S
	method				

Notes: 1. MR-J4FCCBL03M junction cable is required.

2. MR-J5D2-G4(-N1) does not support a servo motor encoder with the four-wire type communication method. Use MR-J5D1-G4(-N1).


3. For the restrictions on the communication cycle, refer to "Restrictions" in this catalog.

DG


Precautions

Servo Motor Connection Example (Rotary Servo Motor) Fully Closed Loop Control System with MR-J5D1-G4(-N1)

For HK-KT series/HK-RT (1.0 kW to 2.0 kW) series



For HK-ST series/HK-RT (3.5 kW to 7.0 kW) series



Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals do not have polarity.

3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor. 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.

- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available
- 7. Encoder cables are available as an option.
- 8. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.

9. The load-side encoder and the servo motor encoder are compatible with both two-wire and four-wire type communication methods.


10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5D User's Manual" for the fully closed loop control with a rotary encoder


11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5D User's Manual" and "Rotary Servo Motor User's Manual (For MR-J5)".

12. This wiring of the servo motor encoder is applicable for the two-wire type communication method.

13. When configuring a fully closed loop control system with MR-J5D1-G4(-N1), connect a servo motor encoder to CN2A connector and a load-side encoder to CN2AL connector. Do not use MR-J4FCCBL03M junction cable or a junction cable fabricated using MR-J3THMCN2 connector set.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.





Notes: 1. Create the circuit in order to shut off by being interlocked with the emergency stop switch.

- 2. This is for the servo motors with an electromagnetic brake. The electromagnetic brake terminals do not have polarity.
- 3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the drive unit for grounding the servo motor.
- 4. Do not use the 24 V DC interface power supply for the electromagnetic brake. Provide a dedicated power supply to the electromagnetic brake.
- 5. Install a surge absorber between B1 and B2.
- 6. This is for using an option dual cable type. Single cable types are also available.
- 7. Encoder cables are available as an option.

Д


- 8. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.
- 9. For fully closed loop control, the load-side encoder and the servo motor encoder are compatible only with two-wire type communication method. Four-wire type cannot be used
- 10. For linear encoders, refer to "List of Linear Encoders" in this catalog. Refer to "MR-J5D User's Manual" for the fully closed loop control with a rotary encoder
- 11. Necessary encoder cables vary depending on the load-side encoder. Refer to "MR-J5D User's Manual" and "Rotary Servo Motor User's Manual (For MR-J5)".
- 12. MR-J5D3-G4(-N1) does not support the fully closed loop control.
 - Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

LVS/Wires

Product

List

Linear Encoder Connection Example (for MR-J5D1-G4(-N1)/MR-J5D2-G4(-N1))



DG


- Notes: 1. For the number of the wire pairs for LG and P5, refer to "MR-J5 Partner's Encoder User's Manual"
 - 2. If the encoder's current consumption exceeds 350 mA, supply power from an external source.
 - 3. When configuring a fully closed loop control system with MR-J5D2-G4(-N1), connect MR and MRR of the drive unit-side connectors to MX and MXR of the SCALE connectors of MR-J4FCCBL03M.
 - 4. This is for MR-J5D1-G4(-N1).



Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

3-63


Servo Amplifiers



Notes: 1. CNP3A connector is supplied with the drive unit.


MR-J5D_-G4(-N1) Dimensions

•MR-J5D2-100G4(-N1)



•MR-J5D2-200G4(-N1)

•MR-J5D2-350G4(-N1)



Notes: 1. CNP3A and CNP3B connectors are supplied with the drive unit.

DG

3-65


Servo Amplifiers

MR-J5D_-G4(-N1) Dimensions DG Common Specifications •MR-J5D2-500G4(-N1) •MR-J5D2-700G4(-N1) CN40B CN40A CNE T CN1A Servo System Controllers CN1B Approx. 40 280 30 5. (75) ø6 mounting (100) Cooling fan Terminal diagram (with front cover open) 30 hole (10) 2-M5 screw 9 Exhaust Û Screw size T TE2: M6 Servo Amplifiers CN5 TE3: M4 CN3 PE: M5 Terminal arrangement CNP3A/CNP3B w (380) 360 380 350 360 V TE2 TE3 U L11 L21 TE2 L+ Rotary Servo Motors 258.5 Е L-TE3 ωĤ 255.5 0 CN4 124.5 0 ⊕ îî la ੂੰ Intake 53 58.5 2 30 10) (120) Linear Servo Motors Mounting hole process drawing CNP3A CNP3B ⊕ PE e 1) 66666 66666 nn CN2 [Unit: mm] Direct Drive Motors •MR-J5D3-100G4(-N1) <u>CN40B</u> CN40A Г CN1A CN1B Options/Peripheral Equipment Approx. 4 280 60 30 5.5 (60) ø6 mounting (100) Terminal diagram (with front cover open) 30 hole 10 의 2-M5 screw Screw size TE2: M6 CN5 TE3: M4 CN3 PE: M5 LVS/Wires Terminal arrange CNP3A/CNP3B/CNP3C W 360 350 360 88 V TE2 TE3 TE2 U E L+ L-L11 L21 258.5 TE3 Product List 團 255.5 e CN4 24. d PE n Deljî ę 38 30 10) (120) 43.5 Mounting hole process drawing Precautions CNP3C (Note 2) CNP3A CNP3B 🕀 PE 66666 CN2A /CN2B /CN2 [Unit: mm] Support

Notes: 1. CNP3A and CNP3B connectors are supplied with the drive unit. 2. CNP3A, CNP3B, and CNP3C connectors are supplied with the drive unit.

MR-J5D_-G4(-N1) Dimensions

•MR-J5D3-200G4(-N1)



Notes: 1. CNP3A, CNP3B, and CNP3C connectors are supplied with the drive unit.

G G-RJ G-HS WG DG

MR-J5-G_/MR-J5W_-G(-N1)/MR-J5D_-G4(-N1) Positioning Function: Point Table Method

Set the position and speed data to the point table, and select the point table No. with the command interface signal to start the positioning operation.

Item		Description	1
Command interface		Object dictionary	Se
Operation specifications		Positioning by specifying the point table No. (255 points)	ervo Syster Controllers
System		Signed absolute value command method	Sys
Position command input	Absolute value command method	Setting in the point table Setting range of feed length for one point: -2147483648 to 2147483647 [µm], 214748 2648 to 214748 2647 [inch]	н
		-214748.3648 to 214748.3647 [inch], -2147483648 to 2147483647 [pulse], -360.000 to 360.000 [degree] Set the servo motor speed in the point table.	Servo Amplifiers
Speed command input		Set the acceleration/deceleration time constants and acceleration/deceleration in the point table. Set the S-pattern acceleration/deceleration time constant in [Pr. PT51].	
Torque limit		The speed unit can be selected ([r/min], command unit/s) The acceleration/deceleration unit can be selected ([ms], command unit/s ²).	Rotary Servo Motors
orque limit		Set by the servo parameter or object dictionary.	rs .
	One positioning operation	Point table No. input method Perform one positioning operation based on the position command and speed command.	Ö
Point table mode (pt)	Continuous positioning operation	Speed change operation (2nd gear to 255th gear)/ Continuous positioning operation (2 points to 255 points)/ Continuous operation to the point table selected at startup/ Continuous operation to the point table No. 1	Linear Servo Motors
JOG operation mode (jg)	JOG operation	Perform inching operation in the network communication function based on the speed command.	VO
		Dog type (rear end detection, Z-phase reference), stopper type (stopper position reference), count type (front end detection, Z-phase reference), dog type (rear end detection, rear end reference), count type (front end detection, front end reference), dog cradle type, dog type last Z-phase reference, dog type front end reference, dogless Z-phase reference, Homing on negative limit switch and index pulse (method 1),	Direct Drive Motors
Homing mode (hm) (Note 1)		Homing on positive limit switch and index pulse (method 2), Homing on positive home switch and index pulse (method 3, 4), Homing on negative home switch and index pulse (method 5, 6), Homing on home switch and index pulse (method 7, 8, 9, 10, 11, 12, 13, 14), Homing without index pulse (method 17, 18, 19, 20, 21, 22, 23, 24, 27, 28), Homing on index pulse (method 33, 34), Homing on current position (method 35, 37)	Options/Peripheral Equipment
Function on positioning open Notes: 1. For the servo amplifier		Absolute position detection/external limit switch/software position limit/ function for positioning to the home, etc. e methods of No. 9, 10, 13, 14, 17, 18, refer to "MR-J5 User's Manual".	LVS/Wires

MR-J5-G_/MR-J5W_-G(-N1)/MR-J5D_-G4(-N1) Positioning Function: Point Table Method

G G-RJ G-HS WG DG

Absolute value command method: travels to a specified address (absolute value) with reference to the home position

Item	Setting range	Description
Point table No.	1 to 255	Specify a point table in which a target position, servo motor speed, acceleration, deceleration, acceleration time constant/deceleration time constant, dwell, auxiliary function, and M code will be set.
Target position (Note 1) (position data)	-2147483.648 to 2147483.647 [mm] -214748.3648 to 214748.3647 [inch] -360.000 to 360.000 [degree] -2147483648 to 2147483647 [pulse]	 Set a travel distance. (1) When using as absolute position command method Set a target address (absolute value). (2) When using as relative position command method Set a travel distance. Reverse rotation command is applied with a minus sign.
Servo motor speed	0 to maximum speed [r/min] 0 to 2147483.647 [mm/s] 0 to 214748.3647 [inch/s] 0 to 2147483.647 [degree/s] 0 to 2147483647 [pulse/s]	Set a command speed for the servo motor in positioning.
Acceleration	0 to 2147483.647 [mm/s ²] 0 to 214748.3647 [inch/s ²] 0 to 2147483.647 [degree/s ²] 0 to 2147483.647 [pulse/s ²]	Set an acceleration for the servo motor to reach the set speed. (Acceleration time [s] = Servo motor speed/Acceleration)
Acceleration time constant	0 to 20000 [ms]	Set a time period for the servo motor to reach the rated speed.
Deceleration	0 to 2147483.647 [mm/s ²] 0 to 214748.3647 [inch/s ²] 0 to 2147483.647 [degree/s ²] 0 to 2147483.647 [pulse/s ²]	Set a deceleration for the servo motor to decelerate from the set speed to a stop. (Deceleration time [s] = Servo motor speed/Deceleration)
Deceleration time constant	0 to 20000 [ms]	Set a time period for the servo motor to decelerate from the set speed to a stop.
Dwell	0 to 20000 [ms]	Set a dwell. When the dwell is set, the position command for the next point table will be started after the position command for the selected point table is completed and the set dwell is passed. The dwell is disabled when the auxiliary function is set to 0 or 2. Continuous operation is enabled when the auxiliary function is set to 1, 3, 8, 9, 10, or 11 and the dwell is set to 0.
Auxiliary function	0 to 3, 8 to 11	 Set auxiliary function. (1) When using the point table with the absolute position command method 0: Automatic operation for a selected point table is performed. 1: Automatic operation is performed to the next point table. 8: Automatic operation for a point table selected at startup is performed. 9: Automatic operation of the point table No. 1 is performed. (2) When using the point table with the relative position command method 2: Automatic operation for a selected point table is performed. (3: Automatic operation for a selected point table is performed. 3: Automatic operation is performed to the next point table. 10: Automatic operation for a point table selected at startup is performed. 11: Automatic operation of the point table selected at startup is performed.
M code	0 to 255	Set a code to be outputted when the positioning is complete.


 Notes:
 1. Change the unit to mm/inch/degree/pulse with [Pr. PT01].

 2. The speed unit is r/min for the rotary servo motors and the direct drive motors, and mm/s for the linear servo motors.

Example of setting point table data

Point table example

Point table No.	Target position (position data)	Servo motor speed [r/min]	Acceleration time constant [ms]	Deceleration time constant [ms]	Dwell [ms]	Auxiliary function	M code
1	1000	2000	200	200	0	1	1
2	2000	1600	100	100	0	0	2
:	:	:	:	:	:	:	:
255	3000	3000	100	100	0	2	99



G G-RJ G-HS WG DG

Restrictions

The restrictions on the communication cycle for the functions in the list are as follows.

Communication cycle

•For MR-J5-G(4)/MR-J5-G(4)-RJ/MR-J5-G4-HS/MR-J5W_-G/MR-J5D_-G4

		Communicat	ion cycle (min	imum)						
Category	Function	MR-J5-G(4) (Note 1, 4)	MR-J5-G(4)-RJ (Note 1, 4)/ MR-J5-G4-HS	,	MR-J5W3-G (Note 4)	MR-J5D1-G4 (Note 4)	MR-J5D2-G4 (Note 4)	MR-J5D3-G4 (Note 4)	Controllers	
	Profile position mode (pp)	250 µs	250 µs	500 µs	500 μs	250 µs	500 μs	500 μs	rs	
	Profile velocity mode (pv)	250 μs	250 µs	-	-	250 µs	-	-		
	Profile torque mode (tq)	250 µs	250 µs	-	-	250 µs	-	-	Se	
Control mode	Continuous operation to torque control mode (ct)	62.5 µs	62.5 µs	Not restricted	Not restricted	62.5 μs	Not restricted	Not restricted	Servo Amplifiers	
	Positioning mode (point table method)	250 µs	250 µs	500 µs	500 µs	250 µs	500 µs	500 μs	nplifier	
Network	Driver communication function	125 µs (Note 3)	125 µs (Note 3)	-	-	125 µs (Note 3)	-	-		
Position	Fully closed loop control	125 µs	125 µs	250 µs	-	125 µs	250 µs	-	Nota	
detection S	Scale measurement function	125 µs	125 µs	250 µs	-	125 µs	250 µs	-	loto	
	A/B/Z-phase output	Not restricted	Not restricted	125 µs	250 µs	Not restricted	125 µs	Not restricted	Rotary Servo Motors	
I/O, monitor	Touch probe function	62.5 µs	62.5 µs	250 µs	250 µs	62.5 μs	250 µs	Not restricted	_	
	Safety sub-function (Note 2)	-	125 µs	125 µs	Not restricted	125 µs	125 µs	Not restricted	Linear Servo Motors	
Functional	Safety sub-function (Network connection) (Note 2, 5)	-	125 µs	500 µs	500 µs	125 µs	500 µs	500 μs	Servo ors	
safety	Safety sub-function (position/speed observation by using a servo motor with functional safety) ^(Note 2)	-	125 µs	500 µs	500 µs	125 µs	500 µs	500 μs	Direct Drive Motors	
Linit	Command unit selection function (degree unit) (Note 2)	250 µs	250 µs	500 µs	500 µs	250 µs	500 µs	500 µs	tors	
Unit	Command unit selection function (command unit/s) (Note 2)	125 µs	125 µs	250 µs	250 µs	125 µs	250 µs	Not restricted	0	

For MR-J5-G(4)-N1/MR-J5-G(4)-RJN1/MR-J5-G4-HSN1/MR-J5W_-G-N1/MR-J5D_-G4-N1

		Communicat	ion cycle (min	imum)					pheral Int
Category	Function	MR-J5- G(4)-N1	MR-J5-G(4)- RJN1/ MR-J5-G4- HSN1	MR-J5W2- G-N1	MR-J5W3- G-N1	MR-J5D1- G4-N1	MR-J5D2- G4-N1	MR-J5D3- G4-N1	al LVS/Wires
	Profile position mode (pp)	250 µs	250 µs	500 µs	500 µs	250 µs	500 µs	500 μs	Wire
	Profile velocity mode (pv)	250 µs	250 µs	-	-	250 µs	-	-	S
Control mode	Profile torque mode (tq)	250 µs	250 µs	-	-	250 µs	-	-	
	Positioning mode (point table method)	250 µs	250 µs	500 µs	500 µs	250 µs	500 µs	500 µs	Pro
	Safety sub-function (Network connection) (Note 2)	-	250 µs	500 μs	500 µs	250 µs	500 µs	500 µs	Product L
Functional safety	Safety sub-function (position/speed observation by using a servo motor with functional safety) ^(Note 2)	-	250 µs	500 µs	500 µs	250 µs	500 µs	500 µs	List Pr
Unit	Command unit selection function (degree unit) (Note 2)	250 µs	250 µs	500 μs	500 µs	250 µs	500 µs	500 µs	Precautio

Notes: 1. When connecting a servo amplifier with a communication cycle of 31.25 μs and 62.5 μs, use the servo amplifier firmware version A6 or later.
 2. For details of the function, refer to "MR-J5 User's manual".
 3. When using the driver communication function, set the network communication cycle to 125 μs or 250 μs.


4. When connecting a servo amplifier with a communication cycle of 1.5 ms, 2.5 ms, 3 ms, 3.5 ms, 4.5 ms, 5 ms, 5.5 ms, 6 ms, 6 ms, 7 ms, or 7.5 ms, use the servo amplifier firmware version E0 or later.

5. When the safety sub-function through the network connection is used, the driver communication function is not available.

MR-J5-B_ Connections with Peripheral Equipment (Note 1)

B B-RJ

Peripheral equipment is connected to MR-J5-B_ as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the servo amplifier easily and start using it right away.



Notes: 1. The connection with the peripheral equipment is an example for MR-J5-350B(4)(-RJ) or smaller servo amplifiers. Refer to "MR-J5 User's Manual" for the actual connections. 2. This picture shows when the display cover is open.

Servo Amplifiers

MR-J5-B	(SSCNET III/H)) Specifications	(200 V)	
---------	----------------	------------------	---------	--

Servo am	Servo amplifier model MR-J5(-RJ)				20B	40B	60B	70B	100B	200B	350B	500B	700B
Q	Voltage			3-phas	se 0 V A	C to 24	0 V AC			1		I	
Output	Rated cur	Rated current [A]			1.8	2.8	3.2	5.8	6.0	11.0	17.0	28.0	37.0
	Voltage/ frequency		AC input			phase 20 Hz/60 H	00 V AC Iz	to	3-phase or 1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz ^(Note 7)		3-phase 200 V AC to 240 V AC, 50 Hz/60 Hz		
Main			DC input (Note 8)										
power supply input	Rated current (Note 6) [A			(1.5)	1.5 (2.5)	2.6 (4.5)	3.2 (5.0)	3.8 (6.5)	5.0 (10.5)	10.5 (15.8)	16.0	21.7	28.9
	Permissit voltage		AC input	3-phase or 1-phase 170 V AC to 264 V AC 3-phase or 1-phase 170 V AC to 264 V AC (Note 7) 3-phase 170 V AC to 264 V AC								264 V AC	
	fluctuation		DC input (Note 8)	241 V DC to 374 V DC									
	Permissible frequency fluctuation			±5 % maximum									
	Voltage/ frequency		AC input	1-phase 200 V AC to 240 V AC, 50 Hz/60 Hz ^{B)} 283 V DC to 340 V DC									
			DC input (Note 8)		DC to 3	40 V D0	2		-				
Control	Rated cu] 0.2 0.3									
circuit power	Permissible voltage		AC input	1-phase 170 V AC to 264 V AC									
supply	fluctuation	n	DC input (Note 8)	241 V DC to 374 V DC									
input	Permissit	Permissible frequen		±5 % maximum									
	Power co	ower consumption [W			30								
Interface	nterface power supply				24 V DC \pm 10 % (required current capacity: 0.3 A (including CN8 connector signals))								
Control m	Control method				Sine-wave PWM control/current control method								
Permissible regenerative power of he built-in regenerative resistor (Note 2, 3) [W]			-	10			30		100		130	170	
Dynamic	Dynamic brake (Note 4)			Built-ir	Built-in								
SSCNET III/H Communication cycle			0.222 ms, 0.444 ms, 0.888 ms										
Communi function	communication USB			Connect a personal computer (MR Configurator2 compatible)									
Encoder	Encoder output pulse			Comp	Compatible (A/B/Z-phase pulse)								
Analog monitor			2 channels										
Fully closed loop MR-J5-B				Two-wire type communication method									
	control MR-J5-B-RJ								n method				
_oad-side encoder MF					Mitsubishi Electric high-speed serial communication								
				Mitsubishi Electric high-speed serial communication, A/B/Z-phase differential input signal									
	Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including taken and integration) as a superior function for the particular function for the particular function.												
Servo functions				failure prediction), power monitoring function, lost motion compensation function, scale measurement function, super trace control, continuous operation to torque control mode, driver communication function									
									rvoltage shut-	off overload	shut-off (e	electronic the	-rmal)
Protective functions				Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection,									
				error e	xcessiv	e protec	ction, ma	ignetic p	ole detection	protection, lin	near servo	control fault	protection
Safety su	b-function,	Safety	/ performance	Refer	to "Safe	ty Sub-	Function	s" in sec	tion 1 of this of	catalog.			
Structure (IP rating)			Natura	Natural cooling, open (IP20) Force cooling, open (IP20) Force cooling, open (IP20)							ooling, open		
Close	· · ·		supply input	Possible (Note 5)									
mounting	1-phase p	Possib	le (Note 5)				Not possible	è	-				
nounting	1-pilase	000001		0.8				1.4	1.101 000000	2.2		3.7	6.2

Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.

Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
 Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.

5. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio.

6. The values in brackets are the rated current for the 1-phase power supply input. 7. When the servo amplifier is used with a 1-phase power supply and combined with a servo motor of over 750 W, use the servo amplifiers at 75 % or less of the effective load ratio.

For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".
 The connector part is excluded.

10. The communication cycle depends on the controller specifications and the number of axes connected.

3-71

recautions

Support

	Servo amplifier model MR-J5(-RJ)					100E	34	200B4	350B4	500B4	700B4	
Output	Voltage			3-phase 0 V	' AC to 48	O V AC						
Output	Rated current [A]			[A]	1.6	2.8		5.5	8.6	14	17	
Main	Voltage/ frequency (Note 1) AC input		3-phase 380 V AC to 480 V AC, 50 Hz/60 Hz									
Main circuit	Rated current [A]			[A]	1.4	2.5		5.1	7.9	10.8	14.4	
power supply input	Permissil voltage fluctuatio	AC input			3-phase 323 V AC to 528 V AC							
	Permissible frequency fluctuation			±5 % maxim	num							
	Voltage/ frequenc				1-phase 380 V AC to 480 V AC, 50 Hz/60 Hz							
Control circuit power supply			0.1					0.2				
	Permissil voltage fluctuatio	e AC input			1-phase 323	3 V AC to	528 V AC					
input	Permissible frequency fluctuation				±5 % maxim	num						
	Power consumption [W]											
nterface power supply				24 V DC ± 10 % (required current capacity: 0.3 A (including CN8 connector signals))								
Control method				Sine-wave F	PWM cont	trol/current of	control meth	od				
Permissible regenerative power of the built-in regenerative resistor (Note 2, 3) [W]				15	15		100	120	130	170		
Dynamic brake (Note 4)				Built-in								
SSCNET III/H Communication cycle			0.222 ms, 0.444 ms, 0.888 ms									
Communication function		USB			Connect a personal computer (MR Configurator2 compatible)							
Encoder output pulse			Compatible (A/B/Z-phase pulse)									
			2 channels									
Fully closed loop		MR-J5-B4			Two-wire type communication method							
control		MR-J5-B4-RJ			Two-wire/four-wire type communication method							
			Mitsubishi Electric high-speed serial communication Mitsubishi Electric high-speed serial communication, A/B/Z-phase differential input signal									
Servo functions				Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, scale measurement function, super trace control, continuous operation to torque control mode, driver communication function								
Protective functions				servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection Refer to "Safety Sub-Functions" in section 1 of this catalog.								
Safety sub-function, Safety performance									0			
Structure (IP rating) Close mounting				Natural cool	lina, open	(IP20)	Force cooli	ng, open (IP20))			
					Not possible		(- /		5, 1 (/		


Notes: 1. Rated output and speed of a rotary servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.
2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.

When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio.
 The communication cycle depends on the controller specifications and the number of axes connected.

Servo Amplifiers

B B-RJ

MR-J5-B_Standard Wiring Diagram Example



- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. For details such as the servo system controller settings, refer to the controller manuals
- 6. Devices can be assigned to DI1, DI2 and DI3 with servo system controller setting. Refer to the controller manuals for details on setting
- 7. Devices for these pins can be changed with [Pr. PD07], [Pr. PD08], and [Pr. PD09].
- 8. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 9. Connections for the second and following axes are omitted.

10. The forced stop signal is issued for the servo amplifier. For overall system, apply the emergency stop on the controller side

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

Precautions


Support

MR-J5-B_ Dimensions


•MR-J5-10B, MR-J5-10B-RJ

•MR-J5-20B, MR-J5-20B-RJ

•MR-J5-40B, MR-J5-40B-RJ




•MR-J5-60B, MR-J5-60B-RJ




[Unit: mm]

Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-B servo amplifiers.

Servo Amplifiers





Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.

2. CN2L connector is not available for MR-J5-B servo amplifiers.


3. For the servo amplifiers manufactured in August 2022 or later, the fan unit is mounted with two screws. Refer to "Mitsubishi Electric AC Servo System Sales and Service No. 22-02E" for details.

LVS/Wires

Product List

MR-J5-B_ Dimensions


•MR-J5-500B, MR-J5-500B-RJ




[Unit: mm]

B B-RJ

•MR-J5-700B, MR-J5-700B-RJ



Notes: 1. CNP1A, CNP1B, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-B servo amplifiers.



Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.


2. CN2L connector is not available for MR-J5-B4 servo amplifiers

3. For the servo amplifiers manufactured in August 2022 or later, the fan unit is mounted with two screws. Refer to "Mitsubishi Electric AC Servo System Sales and Service No. 22-02E" for details.

MR-J5-B_ Dimensions


•MR-J5-500B4, MR-J5-500B4-RJ

•MR-J5-700B4, MR-J5-700B4-RJ



B B-RJ

Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-B4 servo amplifiers.



User's Manual" for the actual connections of each multi-axis servo amplifier.

2. This picture shows when the display cover is open.

3. Connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier for grounding the servo motor.

MR-J5W2-B (2-Axis, SSCNET III/H) Specifications

Servo a	mplifier model	MR-	J5W2	22B	44B	77B	1010B		
Output	Voltage			3-phase 0 V AC to 240	V AC				
Output	Rated curren	nt (ead	ch axis) [A	1.8	2.8	5.8	6.0		
Maria	Voltage/ frequency (Not	ie 1)	AC input	3-phase or 1-phase 200) V AC to 240 V A	C, 50 Hz/60 Hz	3-phase 200 V AC to 240 V AC, 50 Hz/60 Hz		
Main			DC input (Note 8)	283 V DC to 340 V DC					
circuit power	Rated curren	nt ^{(Note}	⁶⁾ [A	^{2.9} (5.0)	5.2 (9.0)	7.5 (13.0)	9.8		
supply input	Permissible voltage		AC input	3-phase or 1-phase 170) V AC to 264 V A	C	3-phase 170 V AC to 264 V AC		
	fluctuation		DC input (Note 8)	241 V DC to 374 V DC					
	Permissible f	reque	ency fluctuation	±5 % maximum					
	Voltage/		AC input	1-phase 200 V AC to 24	40 V AC, 50 Hz/60	Hz			
	frequency		DC input (Note 8)	283 V DC to 340 V DC					
Control	Rated curren	nt	[/	0.4					
circuit power	Permissible voltage		AC input	1-phase 170 V AC to 26	64 V AC				
supply input	fluctuation		DC input (Note 8)	241 V DC to 374 V DC					
input	Permissible f	reque	ency fluctuation	±5 % maximum					
	Power consu	Imptic	on [V	/] 55					
Interface	e power supply	у		24 V DC ± 10 % (requir	ed current capacit	y: 0.35 A (including CN8	connector signals))		
Control	ontrol method			Sine-wave PWM contro	l/current control m	nethod			
	armiacible regenerative power of			/] 20		100			
	c brake (Note 4)			Built-in		ļ			
SSCNE		ommi /cle ^{(N}	unication ote 5)	0.222 ms, 0.444 ms, 0.8	888 ms				
Commur function	nication U	SB		Connect a personal cor	nputer (MR Config	jurator2 compatible)			
Encoder	output pulse			Compatible (A/B-phase	pulse)				
Analog ı	nonitor			Not supported	•				
Fully clo	sed loop cont	rol		Two-wire type commun	ication method				
Load-sic	le encoder int	erfac	e (Note 9)	Mitsubishi Electric high-	-speed serial com	munication			
Servo fu	Inctions			one-touch tuning, tough (including failure predic	drive function, drition), power monit	ive recorder function, ma oring function, lost motion	filter, quick tuning, auto tuning, chine diagnosis function n compensation function, ation to torque control mode		
Protectiv	ve functions			Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection					
Safety s	ub-function, S	afety	performance	Refer to "Safety Sub-Fu	unctions" in section	n 1 of this catalog.			
Structur	e (IP rating)			Natural cooling, open (IP20)	Force cooling, o	pen (IP20)			
Close m	ounting			Possible (Note 7)					
Mass			[kg	J] 1.5		1.9			

WB

Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.

Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
 Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.

5. The communication cycle depends on the controller specifications and the number of axes connected.

6. The values in brackets are the rated current for the 1-phase power supply input.

7. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio. 8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".

9. Not compatible with pulse train interface (A/B/Z-phase differential output type).

MR-J5W3-B (3-Axis, SSCNET III/H) Specifications

Servo a	amplifier model N	1R-J5W3	222B	444B	ec Co
Output	Voltage		3-phase 0 V AC to 240 V AC		Common Specifications
Output	Rated current (each axis)	[A] 1.8	2.8	tion
	Voltage/	AC input	3-phase or 1-phase 200 V AC to	240 V AC, 50 Hz/60 Hz	SI
Main	frequency (Note 1)	DC input (Note 8)	283 V DC to 340 V DC		
Main circuit	Rated current (N	lote 6)	[A] ^{4.3} (7.5)	7.8 (13.5)	Servo System Controllers
power supply	Permissible	AC input	3-phase or 1-phase 170 V AC to	264 V AC	roll
input	voltage fluctuation	DC input (Note 8)	241 V DC to 374 V DC		ers
	Permissible free	quency fluctuation	±5 % maximum		(0
	Voltage/	AC input	1-phase 200 V AC to 240 V AC,	50 Hz/60 Hz) en
	frequency	DC input (Note 8)	283 V DC to 340 V DC		0 A
Control	Rated current		[A] 0.4		duv
circuit power	Permissible	AC input	1-phase 170 V AC to 264 V AC		Servo Amplifiers
supply	voltage fluctuation	DC input (Note 8)	241 V DC to 374 V DC		
input	Permissible free	quency fluctuation	±5 % maximum		Ro
	Power consum	otion	[W] 55		Rotary Servo Motors
Interfac	e power supply		24 V DC ± 10 % (required curre	nt capacity: 0.45 A (including CN8 connector signals))	fors
Control	method		Sine-wave PWM control/current	control method	N
	sible regenerative t-in regenerative		[W] 30		
Dynam	ic brake (Note 4)		Built-in		Line
SSCNE		mmunication	0.222 ms, 0.444 ms, 0.888 ms		Linear Servo Motors
Commu function	inication US	В	Connect a personal computer (N	IR Configurator2 compatible)	NO
Encode	er output pulse		Compatible only with A-axis and	I B-axis (A/B-phase pulse)	
Analog	monitor		Not supported		
Fully cl	osed loop contro	l	Not available		Mot
Servo f	unctions		one-touch tuning, tough drive fu (including failure prediction), po	a control II, adaptive filter II, robust filter, quick tuning, auto tuning, nction, drive recorder function, machine diagnosis function wer monitoring function, lost motion compensation function, operation to torque control mode	Direct Drive Op Motors
Protect	ive functions		Overcurrent shut-off, regenerative servo motor overheat protection undervoltage protection, instant	ve overvoltage shut-off, overload shut-off (electronic thermal), , encoder error protection, regenerative error protection, aneous power failure protection, overspeed protection, netic pole detection protection, linear servo control fault	Options/Peripheral Equipment
Safety	sub-function, Saf	ety performance	Refer to "Safety Sub-Functions"	in section 1 of this catalog.	
Structu	re (IP rating)		Force cooling, open (IP20)		\leq
Close r	nounting		Possible (Note 7)		LVS/Wires
Mass			[kg] 1.8		Vire
Votes: 1	Rated output and a	peed of a rotary service	motor and a direct drive motor: and continuou	is thrust and maximum speed of a linear servo motor are applicable when the	š

Notes: 1. Rated output and speed of a rotary servo motor and a direct drive motor; and continuous thrust and maximum speed of a linear servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.


servo amplitier is operated within the specified power supply voltage and requency.
 Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
 Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
 When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.
 The communication cycle depends on the controller specifications and the number of axes connected.

6. The values in brackets are the rated current for the 1-phase power supply input.

7. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio. 8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".

Product List

MR-J5W2-B Standard Wiring Diagram Example




Notes: 1. Up to 64 axes can be set with a combination of rotary switches (SW1 and SW2). Note that the number of the connectable axes depends on the controller specifications. 2. This is for sink wiring. Source wiring is also possible.

- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. For details such as the servo system controller settings, refer to the controller manuals.
- 6. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism.
- 7. Devices can be assigned to these signals with the controller setting. Refer to the controller manuals for details on setting.
- 8. The forced stop signal is issued for two axes of the servo amplifier. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 11. Connections for the third and following axes are omitted.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

.



Notes: 1. Up to 64 axes can be set with a combination of rotary switches (SW1 and SW2). Note that the number of the connectable axes depends on the controller specifications 2. This is for sink wiring. Source wiring is also possible.

- 3. CINP (AND in-position) is assigned to this pin as default. A device for this pin can be changed with [Pr. PD08].
- 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 5. For details such as the servo system controller settings, refer to the controller manuals.
- 6. When using a linear servo motor or direct drive motor, use MBR (Electromagnetic brake interlock) for an external brake mechanism
- 7. Devices can be assigned to these signals with the controller setting. Refer to the controller manuals for details on setting.
- 8. The forced stop signal is issued for three axes of the servo amplifier. For overall system, apply the emergency stop on the controller side.
- 9. Devices for these pins can be changed with [Pr. PD07] and [Pr. PD09].
- 10. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
- 11. Connections for the fourth and following axes are omitted.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.


Lisi

Precautions


MR-J5W2-B Dimensions

•MR-J5W2-22B

•MR-J5W2-44B




•MR-J5W2-77B



Notes: 1. CNP1, CNP2, CNP3A, and CNP3B connectors are supplied with the servo amplifier.

WB




Notes: 1. CNP1, CNP2, CNP3A, CNP3B, and CNP3C connectors are supplied with the servo amplifier.

Direct Drive Motors

MR-J5-A_ Connections with Peripheral Equipment (Note 1)

A A-RJ

Peripheral equipment is connected to MR-J5-A_ as described below. Connectors, cables, options, and other necessary equipment are available so that users can set up the servo amplifier easily and start using it right away.



Notes: 1. The connection with the peripheral equipment is an example for MR-J5-350A(4)(-RJ) or smaller servo amplifiers. Refer to "MR-J5 User's Manual" for the actual connections.

2. This picture shows when the display cover is open.

Servo ampl	· ·			10A 20		40A	60A	70A	100A	200A	350A	500A	700A	pe
	Voltage	IVIR-	J2(-KJ)	3-phase 0		-		70A	TUUA	200A	350A	AUUG	700A	Specifications
Output –			[0]			1		5.0	0.0	11.0	17.0	00.0	07.0	. ati
	Rated curre	ent	[A]	1.3 1.8	8	2.8	3.2	5.8	6.0	11.0	17.0	28.0	37.0	. ons
	Voltage/ requency №		AC input	3-phase o 240 V AC,				to		or 1-phase 200 240 V AC, 50 2 (Note 7)	3-phase 2 50 Hz/60	200 V AC to Hz	240 V AC,	
Main	roquonoy		DC input (Note 8)	283 V DC	to 34	40 V D(2			-				Controllers
oirouit			•	0.9 1.		2.6	3.2	3.8	5.0	10.5				- tro
power F	Rated curre	ent (Noi	te 6) [A]		.5)	(4.5)	(5.0)	(6.5)	(10.5)	(15.8)	16.0	21.7	28.9	ller
	Permissible /oltage	;	AC input	3-phase o 264 V AC	r 1-pl	hase 17	70 V AC	to		or 1-phase 170 264 V AC (Note 7)	3-phase	170 V AC to	264 V AC	
	luctuation	ľ	DC input (Note 8)	241 V DC	to 37	74 V DC	5				1			. (
	Permissible Iuctuation	e freq	uency	±5 % max	imun	n								-
	Voltage/		AC input	1-phase 2	00 V	AC to 2	240 V AC), 50 Hz	/60 Hz					
	requency		DC input (Note 8)	283 V DC				,						•
	Rated curre			0.2			-					0.3		•
	Permissible		AC input		bhase 170 V AC to 264 V AC									•
1.	/oltage	ŀ	•											. 4
	luctuation		DC input (Note 8)	241 V DC	to 37	74 V DC	2							Notors
	Permissible Iuctuation	e freq	uency	±5 % max	imun	n								· 73
	Power cons	sump	tion [W]	30										
Interface po					- 10 °	% (reau	ired curr	ent capa	acity: 0.5 A	(including CN8	connector	signals))		•
Control met				Sine-wave								J //		NIOLOIS
Pormioniblo	rogonorat	ive p	ower of											
the built-in r	regenerativ	ve res	sistor (Note 2, 3) [W]	- 10	10 30 100 130 170						170	C.		
Dynamic br	ake (Note 4)			Built-in								I	I	•
-	ommunication function			Connect a	pers	sonal co	omputer	(MR Co	nfigurator2	compatible)				
Communica	ommunication function RS-422/RS-485			1:n comm	unica	ation (ur	p to 32 a	xes)		. ,				•
Encoder ou	ncoder output pulse			Compatibl			•	,						. 140
Analog mor				2 channels				- /						
			put pulse	4 Mpulses/s (when using differential receiver), 200 kpulses/s (when using open collector)										
		-	eedback pulse	Encoder re	esolu	ution: 26	3 bits							
Position control mod	Comma		ulse multiplying	Electronic	gear	r A/B m	ultiple, A	: 1 to 21	47483647,	B: 1 to 214748	33647, 1/10) < A/B < 64	000	Ednibilieur
0011110111100	~~ <u> </u>	tion ra	ange setting	0 pulse to	±167	777215	pulses (commar	nd pulse ur	nit)				
	Error ex				pulse to ±16777215 pulses (command pulse unit) 3 rotations								. =	
	Torque				Es totalions Set by servo parameters or external analog input (0 V DC to +10 V DC/maximum torque)									
	'		ol range						<u> </u>	command 1:500			-/	
Speed cont	Analog		ed command	01				,		is changeable		C12].)		
mode		fluctu	lation rate							%), 0 % (power 10 °C) only wh			command	•
	Torque	limit						•		(0 V DC to +10				•
Torque	Analog input		ue command							dance: 10 k Ω to				
control mod	Speed	limit		Set by ser	von	arametr	ers or ex	ternal ar	nalog innut	(0 V DC to ± 1	0 V DC/rate	ed speed)		1
Fully closed		R-J5-	A	Two-wire t						<u>,</u> .				•
control (Note 5			A-RJ	Two-wire/f					n method					•
Load-side e						ommunicati	ion				•			
interface			A-RJ							ion, A/B/Z-phas	e differenti	al innut sion	al	•
						-	-							•
Servo funct	Servo functions				Advanced vibration suppression control II, adaptive filter II, robust filter, quick tuning, auto tuning, one-touch tuning, tough drive function, drive recorder function, machine diagnosis function (including failure prediction), power monitoring function, lost motion compensation function, super trace control (Note 5)									
rotective functions			Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection, undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection Refer to "Safety Sub-Functions" in section 1 of this catalog.											

MR-J5-A_ (General-Purpose Interface) Specifications (200 V)

MR-J5-	A_ (General-Purpose I	nterf	ace) S	pecifi	icatio	ns (20	00 V)			Α	A-RJ	
Servo am	plifier model MR-J5(-RJ)	10A	20A	40A	60A	70A	100A	200A	350A	500A	700A	
Structure	Structure (IP rating)			Natural cooling, open (IP20)				Force cooling, open (IP20)				
Close	3-phase power supply input	Possib	le (Note 10)									
mounting	1-phase power supply input	Possib	le (Note 10)				Not possible	e	-			
Mass	[kg]	0.8			1.0	1.4		2.2		3.7	6.2	
	ated output and speed of a rotary servo						ust and maximu	m speed of a lir	ear servo motor	are applicable	when the	

servo amplifier is operated within the specified power supply voltage and frequency.

2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.

3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.

4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio and the permissible load to mass ratio.

5. For the servo amplifier firmware version supporting this function, refer to "MR-J5 User's Manual".
6. The values in brackets are the rated current for the 1-phase power supply input.
7. When the servo amplifier is used with a 1-phase power supply and combined with a servo motor of over 750 W, use the servo amplifiers at 75 % or less of the effective load ratio.

8. For a connection example of power supply circuit with DC input, refer to "MR-J5 User's Manual".

9. The connector part is excluded.


10. When the servo amplifiers are closely mounted, keep the ambient temperature within 0 °C to 45 °C, or use the servo amplifiers at 75 % or less of the effective load ratio.

Servo am	nplifie	r model MR	-J5(-RJ)	60A4	100A4	200A4	350A4	500A4	700A4	eci		
Output	Volt	tage		3-phase 0 V AC	to 480 V AC					ecificatio		
Output	_	ed current	[A]	1.6	2.8	5.5	8.6	14	17	Specifications		
		tage/ Juency ^(Note 1)	AC input	3-phase 380 V A	C to 480 V AC	, 50 Hz/60 Hz				S		
Main		ed current		1.4	2.5	5.1	7.9	10.8	14.4	-		
circuit	Per	missible			1	1	1			- Don		
power supply input		age tuation	AC input	3-phase 323 V A	AC to 528 V AC	;				Controllers		
input		missible fre tuation	quency	±5 % maximum								
		tage/ juency	AC input	1-phase 380 V A	AC to 480 V AC	, 50 Hz/60 Hz				Servo Amplifiers		
Control		ed current	[A]	0.1				0.2		- An		
circuit		missible		-						- plifi		
power	volt	age	AC input	1-phase 323 V A	AC to 528 V AC	;				iers		
supply	fluc	tuation								-		
input		missible fre tuation	quency	±5 % maximum						Motors		
	Pov	ver consum	ption [W]	30				45		Motors		
Interface	_				(required curred	ent capacity: 0	.5 A (including C	N8 connector sig	nals))	Suc		
Control m	netho	d		Sine-wave PWM	1 control/currer	nt control metho	od			- 2		
		enerative po enerative re	ower of sistor (Note 2, 3) [W]	15	15	100	120	130	170	- [
Dynamic				Built-in						Motors		
Commun	icotio	n function	USB	Connect a perso	onal computer (MR Configura	tor2 compatible)			Motors		
Commun	licatio	TTUTCION	RS-422/RS-485	1:n communicat	ion (up to 32 a	xes)				0		
Encoder	outpu	it pulse		Compatible (A/E	Z-phase pulse	e)						
Analog m	nonito	r		2 channels						-		
	Maximum input pulse frequency		4 Mpulses/s (wh	en using differ	ential receiver)	, 200 kpulses/s	(when using oper	n collector)	Motors			
		Positioning	feedback pulse	Encoder resolut	on: 26 bits					tors		
Position control m	frequency Positioning feedback puls		pulse multiplying	Electronic gear A/B multiple, A: 1 to 2147483647, B: 1 to 2147483647, 1/10 < A/B < 64000								
oona on m	1000		range setting	0 pulse to ±16777215 pulses (command pulse unit)								
		Error exces		±3 rotations								
		Torque limi	t	Set by servo parameters or external analog input (0 V DC to +10 V DC/maximum torque)								
		Speed con	trol range	Analog speed command 1:2000, internal speed command 1:5000								
Speed		Analog spe input	ed command	0 V DC to ±10 V DC/rated speed (Speed at 10 V is changeable with [Pr. PC12].)								
control m			tuation rate	±0.01 % maximu	um (load fluctua	ation: 0 % to 1	00 %), 0 % (pow	ver fluctuation: ±10	0 %)	-		
		Speed fluc	luation rate	±0.2 % maximur	m (ambient terr	nperature: 25 °	C ± 10 °C) only	when using analo	g speed command	\leq		
		Torque limi	t	Set by servo par	ameters or ext	ernal analog ir	nput (0 V DC to -	+10 V DC/maximu	um torque)	S/W		
Torque		Analog toro	que command	0 V DC to ±8 V	DC/maximum t	orque (input im	npedance: 10 kΩ	2 to 12 kΩ)		LVS/Wires		
control m	loue	Speed limit	t	Set by servo par	rameters or ext	ernal analog ir	nput (0 V DC to :	± 10 V DC/rated s	peed)			
Fully clos	sed lo	ор	MR-J5-A4	Two-wire type co	ommunication	method						
control			MR-J5-A4-RJ	Two-wire/four-w	ire type commu	unication metho	od			Proc		
Load-side	e enc	oder	MR-J5-A4	Mitsubishi Electi	ric high-speed	serial commun	ication			Product List		
interface			MR-J5-A4-RJ					nase differential ir		- 5		
Servo fur	nction	s		one-touch tuning	g, tough drive f	unction, drive r	ecorder function	, machine diagno	uning, auto tuning, sis function (including			
						-		•	n, super trace control	Precautions		
Protective	otoctivo functione			Overcurrent shut-off, regenerative overvoltage shut-off, overload shut-off (electronic thermal), servo motor overheat protection, encoder error protection, regenerative error protection,								
	otective functions		undervoltage protection, instantaneous power failure protection, overspeed protection, error excessive protection, magnetic pole detection protection, linear servo control fault protection									
Safety su	ıb-fun	ction, Safet	y performance	Refer to "Safety Sub-Functions" in section 1 of this catalog.								
Structure	(IP ra	ating)		Natural cooling,			ng, open (IP20)			-		
Close mo	ountin	g		Not possible						Support		
				1.6		2.2	2.3	5.2		5		

Notes: 1. Rated output and speed of a rotary servo motor are applicable when the servo amplifier is operated within the specified power supply voltage and frequency.
2. Select the most suitable regenerative option for your system with our drive system sizing software Motorizer.
3. Refer to "Regenerative Option" in this catalog for the permissible regenerative power [W] when a regenerative option is used.
4. When using the dynamic brake, refer to "MR-J5 User's Manual" for the permissible load to motor inertia ratio.

MR-J5-A_ Standard Wiring Diagram Example: Position Control Operation

Connecting to RD75D




A A-RJ

- Notes: 1. This connection is not necessary for RD75D Positioning module. Note that the connection between LG and the control common terminal is recommended for some Positioning modules to improve noise tolerance.
 - 2. This is for sink wiring. Source wiring is also possible.
 - 3. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.
 - 4. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
 - 5. Pulse train input is available with sink input and source input of open-collector type. When using the source input, use PP2 and NP2 terminals. Refer to "MR-J5 User's Manual" for details.
 - 6. The pins with the same signal name are connected in the servo amplifier.



Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.



2. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.

3. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.

4. The pins with the same signal name are connected in the servo amplifier.

Be sure to read through User's Manual for the actual wiring and use. Use the equipment after you have a full knowledge of the equipment, safety information and instructions.

List

Precautions


MR-J5-A_ Standard Wiring Diagram Example: Torque Control Operation

Servo amplifier MR-J5-A Servo motor connection CNP3 The connection differs according to each servo motor. Main circuit power supply Refer to "Servo Motor Connection Example" on pp. 3-18 to L1 Main/control circuit power supply connection U 3-21, 3-23, and 3-25 to 3-28 in this catalog. L2 The connection differs according to the input V L3 power supply. W Refer to "Main/Control Circuit Power Supply Control circuit ٢ Connection Example" on pp. 3-16 and 3-17 in power supply L11 ٢ this catalog.) L21 (Note 3) CN2 Main circuit CN3 (Note 1, 4) power supply FM2 42 Forced stop 2 Servo-on SON 15 Reset RES 19 I Speed selection 1 SP1 41 Servo motor Speed selection 2 SP2 16 Forward rotation start RS1 18 CN2L CN2L connector connection Reverse rotation start RS2 17 CN2L connector is available only on MR-J5-A(4)-RJ. DICOM 20 Refer to pp. 3-24 to 3-28 in this catalog for details. 24 V DC power DICOM 21 supply for interface 10 m or shorter 24 V DC power supply for interface CN3 (Note 1, 4) DOCOM 46 47 DOCOM Upper limit setting P15R 48 ALM Malfunction Analog torgue command TC 27 23 ZSP Zero speed detection ±8 V/maximum torque LG 28 25 VLC Limiting speed 49 RD Ready Upper limit setting 10 m or shorter Analog speed limit Encoder Z-phase pulse VLA 8 2 LZ 0 to ±10 V/rated speed LZR (differential line driver) SD Plate 9 LA Encoder A-phase pulse 4 LAR (differential line driver) 5 2 m or shorter 6 LB Encoder B-phase pulse Personal computer I BB (differential line driver) Control common CN5 * 34 IG 6 33 OP Encoder Z-phase pulse ÷., Plate SD (open collector) USB cable MR-J3USBCBL3M MR Configurator2 2 m or shorter CN6 Analog monitor output Personal computer 3 MO1 Output voltage: ±10 V Maximum output current: 1 mA CN1 1 LG Output voltage: ±10 V Maximum output current: 1 mA D Ì 2 MO2 Ethernet cable 2 m or shorter CN8 connector connection (Note 2) CN8 Refer to "Functional Safety I/O Signal Connector (CN8) Connection Example" on p. 3-15 in this catalog.


Notes: 1. This is for sink wiring. Source wiring is also possible.


2. Attach a short-circuit connector supplied with the servo amplifier when the functional safety (STO function) is not used.

- 3. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off.
- 4. The pins with the same signal name are connected in the servo amplifier.



A A-RJ





Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-A servo amplifiers.

Support

Options/Peripheral Equipment

LVS/Wires


Product List

[Unit: mm]

MR-J5-A_ Dimensions

•MR-J5-70A, MR-J5-70A-RJ


•MR-J5-100A, MR-J5-100A-RJ



A A-RJ

•MR-J5-200A, MR-J5-200A-RJ (Note 3)

•MR-J5-350A, MR-J5-350A-RJ (Note 3)



Notes: 1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier.


2. CN2L connector is not available for MR-J5-A servo amplifiers.

3. For the servo amplifiers manufactured in August 2022 or later, the fan unit is mounted with two screws. Refer to "Mitsubishi Electric AC Servo System Sales and Service No. 22-02E" for details.

A A-RJ



•MR-J5-500A, MR-J5-500A-RJ




[Unit: mm]

Notes: 1. CNP1A, CNP1B, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-A servo amplifiers.

MR-J5-A_ Dimensions

•MR-J5-60A4, MR-J5-60A4-RJ


•MR-J5-100A4, MR-J5-100A4-RJ



A A-RJ


MR-J5-200A4, MR-J5-200A4-RJ (Note 3)

•MR-J5-350A4, MR-J5-350A4-RJ (Note 3)



1. CNP1, CNP2, and CNP3 connectors are supplied with the servo amplifier. 2. CN2L connector is not available for MR-J5-A4 servo amplifiers. Notes:

3. For the servo amplifiers manufactured in August 2022 or later, the fan unit is mounted with two screws. Refer to "Mitsubishi Electric AC Servo System Sales and Service No. 22-02E" for details.



2. CN2L connector is not available for MR-J5-A4 servo amplifiers

Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Converter output

input

Overheat

detection


function

MR-CM3K Specifications (200 V)


G G-RJ WG B B-RJ WB A A-RJ Simple converter unit model MR-CM3K 270 V DC to 324 V DC Rated voltage Rated current [A] 20 3-phase 200 V AC to 240 V AC, 50 Hz/60 Hz Main circuit Voltage/frequency power supply Rated current [A] 16 Permissible voltage fluctuation 3-phase 170 V AC to 264 V AC The contact between TH1 and TH2 opens when the thermal sensor detects an overheat Thermal sensor condition. Maximum voltage 110 V AC/DC Maximum current 0.3 A at 20 V DC Contact specification 0.1 mA at 1 V DC Minimum current Maximum capacity 6 VA MR-J5-10G(-(RJ)(N1))/B(-RJ)/A(-RJ) to MR-J5-200G(-(RJ)(N1))/B(-RJ)/A(-RJ), Compatible servo amplifier MR-J5W2-22G(-N1)/B to MR-J5W2-1010G(-N1)/B, MR-J5W3-222G(-N1)/B, MR-J5W3-444G(-N1)/B Maximum number of connectable servo amplifiers 6 units Total capacity of servo amplifiers to be driven [kW] 3 Continuous rating [kW] 3 Instantaneous maximum rating [kW] 9 Structure (IP rating) IP20 Close mounting Possible

Environment		The operating environment is the same as that for the servo amplifiers. Refer to "1. Common Specifications" in this catalog.
Mass	[kg]	0.7
Wire cize	L1/L2/L3/PE	2 mm ² to 3.5 mm ² (AWG 14 to 12)
Wire size	P4/N-	2 mm ² to 3.5 mm ² (AWG 14 to 12)
•	ngth from P4/N- of er to P4/N- of servo amplifier	5 m or shorter

3-98



- Notes: 1. Use option daisy chain power connectors when using a simple converter.
 - 2. Connect P+ and D.
 - 3. The contact between TH1 and TH2 opens when the thermal sensor detects an overheat condition. 4. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of
 - contacts.
 - 5. To prevent an unexpected restart of the servo amplifier, create a circuit to turn off EM2 (Forced stop 2) when the main circuit power is turned off
 - 6. Stop the commands from the controller as soon as the main circuit power supply is turned off when an alarm occurs even in one servo amplifier. The following are example methods to turn off the main circuit power supply: Configure a circuit with an I/O module, or connect relays for alarm output corresponding to each servo amplifier to the coil-side of the magnetic contactor in series.
 - 7. Install an overcurrent protection device (molded-case circuit breaker, fuse, etc.) to protect the branch circuit.
 - 8. Twist or bundle the wires between the simple converter and the servo amplifier and between the servo amplifiers with cable ties to keep the two wires close to each
 - other. Keep the total wiring length between the simple converter and each servo amplifier 5 m or shorter. 9. When connecting a linear servo motor with a thermal protector, add a contact to shut off by being interlocked with the thermal protector output of the linear servo motor.
 - 10. Do not ground the servo amplifier between L11 and L21 even when the control circuit power supply is separated from the main circuit power supply using an uninterruptible power supply (UPS) or an isolation transformer.
 - 11. To turn on/off the main circuit power supply by a DC power supply, wire the circuit as follows. Do not use the 24 V DC interface power supply for the magnetic contactor. Provide a dedicated power supply to the magnetic contactor.






Options/Peripheral Equipment

LVS/Wires

MR-CM3K Dimensions

G G-RJ WG B B-RJ WB A A-RJ



MR-C	/_ Specifications	(NOLE -	³⁾ (400 V)						DG	<u>v</u>
Power rege	eneration converter unit model M	R-CV_	11K4	18K4	30K4	37K4	45K4	55K4	75K4	Common Specifications
Output	Rated voltage		513 V DC to 6	648 V DC			t	•		Commo becificati
Output	Rated current	[A]	21	38	72	82	99	119	150	tion
M	Voltage/frequency (Note 1))	3-phase 380 '	/ AC to 480	V AC, 50 Hz/6	60 Hz				S
Main circuit	Rated current	[A]	18	35	61	70	85	106	130	
power supply	Permissible voltage fluctuation		3-phase 323	/ AC to 528	VAC	·	·	·	·	Servo Cont
input	Permissible frequency fluctuation		±3 % maximu	m						ervo System Controllers
	Voltage/frequency		1-phase 380	/ AC to 480	V AC, 50 Hz/6	60 Hz				3
Control	Rated current	[A]	0.1							ပ္ရ
circuit power	Permissible voltage fluctuation		1-phase 323	/ AC to 528	V AC					Servo A
supply input	Permissible frequency fluctuation		±3 % maximu	m						Amplifiers
	Power consumption	[W]	30							ŝ
Interface	power supply		24 V DC ± 10	% (required	current capa	city: 0.35 A)				
Capacity	1	[kW]	11	18	30	37	45	55	75	Rotary Mot
Protectiv	ve functions		MC drive circ	uit error prote	ection, open-p	hase detection	i, inrush curren	overvoltage shu t suppression c		tary Servo Motors
			(electronic the		vice overneat		n, cooling fan e	inor protection,	overload shut-on	Ũ
Continuo	ous rating	[kW]	7.5	11	20	25		55		5
Instantar	neous maximum rating	[kW]	39	60	92	101	125	175	180	Linear Mot
Structure	e (IP rating)		Force cooling	, open (IP20) (Note 2)					ear Se Motors
Mass		[kg]	6.1		12.1			25.0		Servo tors
Notes: 1.	Rated output and speed of a ro	tary ser	rvo motor are appl	icable when the	e power regenera	tion converter unit	is operated within	the specified power	r supply voltage and	_ 0

MR-CV Specifications (Note 3) (400 V)

frequency. 2. Terminal blocks are excluded.

3. MR-CV_4 power regeneration converter units require a mounting attachment. Refer to "Mounting Attachment" in this catalog for details.

MR-CV_ Connection Example


For the connection example of power regeneration converter units, refer to "Main/Control Circuit Power Supply Connection Example For connecting MR-CV_ and MR-J5D_-G4(-N1)" in this catalog.

Direct Drive Motors

MR-CV_Dimensions

•MR-CV11K4

•MR-CV18K4




DG

•MR-CV30K4

•MR-CV37K4

•MR-CV45K4




DG

MR-CV_Dimensions

•MR-CV55K4

•MR-CV75K4



Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Selection of Converter Unit, Servo Amplifier, and Drive Unit

Combination of a simple converter and servo amplifiers

G G-RJ WG B B-RJ WB A A-RJ

Select a servo amplifier for connection that meets the following conditions. · Connectable servo amplifier models

MR-J5-10_ to MR-J5-200_, MR-J5W2-22_ to MR-J5W2-1010_, MR-J5W3-222 /MR-J5W3-444_

The sum of rated capacities [kW] of connected servo amplifiers ≤ 3 kW (MR-CM3K rated output)

For multi-axis servo amplifiers, the calculation uses the sum of the rated capacities of all axes as the rated capacity of one servo

amplifier.

• Number of connectable servo amplifiers to one MR-CM3K ≤ 6

A multi-axis servo amplifier is counted as one servo amplifier unit, rather than the number of axes.

	MR-CM3K (200 V)
Maximum number of connectable servo amplifiers	6
Total capacity of connectable servo amplifiers	3 kW
Continuous rating	3 kW
Instantaneous maximum rating	9 kW

Combination of a power regeneration converter unit and drive units

DG

Select a power regeneration converter unit which meets the following conditions. When all the conditions are satisfied, multiple MR-J5D_-G4(-N1) drive units can be connected to one power regeneration converter unit. When connecting the multiple MR-J5D_-G4(-N1) drive units, install the drive units in descending order of capacity per axis from the right side of the power regeneration converter unit.

Refer to "MR-J5D User's Manual" for details of the selection.

(1) Effective value [kW] of total output power of servo motors ≤ Continuous rating [kW] of MR-CV

(2) Maximum value [kW] of total output power of servo motors × 1.2 ≤ Instantaneous maximum rating [kW] of MR-CV_

(3) Total widths of MR-J5D_-G4(-N1) (one side) \leq 1500 mm

		MR-CV_ (400	V)					
		11K4	18K4	30K4	37K4	45K4	55K4	75K4
Continuous rating	[kW]	7.5	11	20	25	25	55	55
Instantaneous maximum rating	[kW]	39	60	92	101	125	175	180
Total widths of MR-J5D -G4(-N1))	1500 mm or sl	norter					

			MR-J5D1	(-N1)		-		MR-J5D2(-N1)					MR-J5D3(-N1)	
			100G4	200G4	350G4	500G4	700G4	100G4	200G4	350G4	500G4	700G4	100G4	200G4
U	Jnit width	[mm]	60					60			75		60	

Rotary Servo Motors


Model Designation	4-2
HK-KT Series	
Specifications	4-6
Torque Characteristics	
Dimensions	
Connector Dimensions	
Special Shaft Dimensions	
Geared Servo Motor Specifications	
Geared Servo Motor Dimensions	
Geared Servo Motor Special Shaft Dimensions	4-31
HK-MT Series	
Specifications	4-32
Torque Characteristics	4-34
Dimensions	
Connector Dimensions	
Special Shaft Dimensions	4-39
HK-ST Series	
Specifications	
Torque Characteristics	4-48
Dimensions	
Special Shaft Dimensions	4-56
Geared Servo Motor Specifications	4-57
Geared Servo Motor Dimensions	
Geared Servo Motor Special Shaft Dimensions	4-67
HK-RT Series	
Specifications	4-68
Torque Characteristics	4-70
Dimensions	4-72
Connector Dimensions	4-73
Special Shaft Dimensions	4-73
Power Supply Capacity	4-74

* Refer to p. 7-78 in this catalog for conversion of units.

* In this section, a term of servo amplifier includes a combination of a drive unit and a converter unit.

* The characteristics and numerical values without tolerances mentioned in this catalog are representative values.

•HK-KT series (low inertia, small capacity)




Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.

2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

3. A geared servo motor with an oil seal installed is not available.

4. The dimensions of the servo motors with functional safety are the same as those of the standard servo motors.


•HK-MT series (ultra-low inertia, small capacity)



Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.

- 2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.
- 3. The dimensions of the servo motors with functional safety are the same as those of the standard servo motors

•HK-ST series (medium inertia, medium capacity)



Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.


2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

3. The standard HK-ST G1/G1H servo motors have a keyed shaft (with a key).

4. A geared servo motor with an oil seal installed is not available.

5. The dimensions of the servo motors with functional safety are the same as those of the standard servo motors.

HK-RT series (ultra-low inertia, medium capacity)



Notes: 1. The dimensions are the same regardless of whether or not an oil seal is installed.

- 2. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.
- 3. The dimensions of the servo motors with functional safety are the same as those of the standard servo motors.

4-5

LVS/Wires

Product List

Precautions

HK-KT_W (Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size		[mm]	40 × 40			60 × 60					
Rotary servo m	notor model	HK-KT	053W	13W	1M3W	13UW	23W	43W	63W		
Continuous	Rated output	[kW]	0.05	0.1	0.15	0.1	0.2	0.4	0.6		
Rotary servo mo Rotary servo mo Continuous Funning duty Maximum torque Rated speed (Note Aaximum speed Aaximum speed Power rate at vontinuous ated torque VKW/s] Rated current Maximum current Aaximum current Aaximum current Aaximum current Aoment of vx 10-4 kg•m2] V Recommended I Speed/position d Toge Dil seal Electromagnetic Thermissible Libration rank Permissible Load for the Fehaft '2	Rated torque (Note 5)	[N•m]	0.16 (Note 6)	0.32	0.48	0.32	0.64	1.3	1.9		
Maximum torqu	Ue (Note 3)	[N•m]	0.56 (0.72)	1.1 (1.4)	1.7 (2.1)	1.1 (1.4)	2.2 (2.9)	4.5 (5.7)	6.7 (8.6)		
Rated speed (N	ote 4)	[r/min]	(· · /	(1.4)	(2.1)	(1.4)	(2.0)	(3.7)	(0.0)		
		[r/min]									
Power rate at continuous	Without electromagnet		6.4	14.8	23.3	8.4	19.4	39.5	61.0		
rated torque [kW/s]	With electromagnetic b	orake	5.8	14.0	22.4	6.6	16.0	36.7	58.0		
Rated current		[A]	1.3	1.2	1.2	1.1	1.4	2.6	4.5		
Maximum curre	ent ^(Note 3)	[A]	4.6 (6.2)	4.6 (6.0)	4.5 (6.0)	4.6 (6.0)	5.4 (7.1)	9.8 (14)	19 (25)		
Moment of	Without electromagnet	ic brake	0.0394	0.0686	0.0977	0.121	0.209	0.410	0.598		
nertia J	With electromagnetic b	rake	0.0434	0.0725	0.102	0.153	0.254	0.442	0.629		
	d load to motor inertia ra	atio (Note 1)	20 times or l	ess (Note 9)	20 times or less	10 times or less (Note 9)	23 times or less (Note 8)	23 times or less	25 times or less		
Speed/position	detector		Batteryless a	absolute/incre	emental 26-bit e	encoder (reso	ution: 67,108,	864 pulses/re	v)		
Туре			Permanent r	nagnet syncl	nronous motor						
Oil seal			None (Servo	motors with	an oil seal are	available.) (Note	6)				
Electromagnet	ic brake		None (Servo motors with an electromagnetic brake are available.)								
Thermistor			None								
Insulation class	S		155 (F)								
Structure			Totally enclo	sed, natural	cooling (IP ratir	ng: IP67) (Note 2,	7)				
Vibration resist	tance *1	[m/s ²]	X: 49, Y: 49								
Vibration rank			V10 [∗] 3								
Permissible	L	[mm]	25				30				
load for the	Radial	[N]	88				245				
shaft ^{*2}	Thrust	[N]	59				98				
	Without electromagnet	ic brake	0.27	0.37	0.47	0.57	0.77	1.2	1.5		
	With electromagnetic brake										

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. For HK-KT053W_J_ (with an oil seal), use the servo motor at a derating rate of 80 %.

7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

8. When the speed is 6000 r/min or less, the recommended load to motor inertia ratio is 28 times or less.

9. When the servo motor is combined with a 0.1 kW servo amplifier, this recommended load to motor inertia ratio is applicable for operating the servo motor at the rated speed. If operating speed exceeds the rated speed, check whether a regenerative option is required using drive sizing software Motorizer. A servo amplifier with a larger capacity can be combined.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	053WB	13WB	1M3WB	13UWB	23WB	43WB	63WB	
Туре	Spring actuated type safety brake									
Rated voltage			24 V DC (-10 % to 0 %)							
Power consumption [W] at 20 °C			6.4				7.9	7.9		
Electromagnetic brake static [N•m] friction torque			0.48 or higher			1.9 or high	1.9 or higher			
Permissible	Per braking	[J]	5.6				22			
braking work Per hour [J]		[J]	56				220			
Electromagnetic	Number of bra	king times	20000							
brake life (Note 2)	Work per brak	ing [J]	5.6				22			

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-KT_W (Low Inertia, Small Capacity)

·	ns when connected						fica		
Flange size			80 × 80				Specifications		
Rotary servo n			23UW	43UW	7M3W	103W	ns		
Continuous	Rated output	[kW]	0.2	0.4	0.75	1.0			
running duty (Note 4)	Rated torque (Note 5)	[N•m]	0.64	1.3	2.4	3.2	0		
Maximum torq		[N•m]	1.9 (2.5)	4.5 (5.7)	8.4 (10.7)	11.1 (14.3)	Controllers		
Rated speed (N							rs		
Maximum spee	ed (Note 4)	[r/min]	6700			6500			
Power rate at continuous	Without electromagne	etic brake	9.7	22.3	41.6	60.3	Servo		
rated torque [kW/s]	With electromagnetic	brake	7.3	18.8	37.7	56.0	Servo Amplifiers		
Rated current		[A]	1.5	2.1	4.7	5.0	ifier		
Maximum curr	ent (Note 3)	[A]	5.9	9.2	20	21	S.		
		6.0	(9.0)	(13)	(26)	(28)			
Moment of inertia J	Without electromagne	etic brake	0.419	0.726	1.37	1.68	Motors		
[× 10 ⁻⁴ kg•m ²]	With electromagnetic	brake	0.557	0.864	1.51	1.81	Motors		
Recommende	d load to motor inertia r	ratio (Note 1)	10 times or less		16 times or less	17 times or less			
Speed/position	n detector		Batteryless absolut	e/incremental 26-bit	encoder (resolution: 67,10	08,864 pulses/rev)			
Туре			-	t synchronous motor			Motors		
Oil seal			None (Servo motors with an oil seal are available.)						
Electromagnet	lic brake		None (Servo motors with an electromagnetic brake are available.)						
Thermistor			None						
Insulation class	S		155 (F)						
Structure			Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)						
Vibration resist		[m/s ²]	X: 49, Y: 49						
Vibration rank				V10 ⁻³					
Permissible	L	[mm]			40				
load for the	Radial		245			392			
shaft*2	Thrust		98		147				
Mass [kg]	Without electromagne		1.2	1.5	2.2	2.4			
	With electromagnetic		1.6	1.9	2.9	3.1			
2. The sha portion 3. The val	l.	ed. Refer to t	the asterisk 4 of "Annotat torque is increased by co	tions for Rotary Servo Mo	tor Specifications" on p. 4-79 in th y servo amplifier. Refer to "Comb	his catalog for the shaft-through inations of Rotary Servo Motors ar	Equipment		

The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-KT	23UWB	43UWB	7M3WB	103WB	
Туре		Spring actuated type safety brake				
Rated voltage		4 V DC (-10 % to 0 %)				
Power consumption	on [W] at 20 °C	8.2		10		
Electromagnetic b friction torque	rake static [N•m]	1.3 or higher		3.2 or higher		
Permissible	Per braking [J]	22		64		
braking work Per hour [J]		220		640		
Electromagnetic	Number of braking times	20000				
brake life (Note 2)	Work per braking [J]	22		64		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

LVS/Wires

HK-KT_W (Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	90 × 90							
Rotary servo m	notor model HK-KT	63UW	7M3UW	103UW	153W	203W	202W		
Continuous	Rated output [kW]	0.6	0.75	1.0	1.5	2.0	2.0		
running duty (Note 4)	Rated torque (Note 3, 5) [N•m]	1.9 (2.4)	2.4	3.2	4.8	6.4	9.5		
Maximum torqu	ue (Note 3) [N•m]	6.3 (10.3)	8.4 (10.7)	11.1 (14.3)	16.7 (21.5)	19.1 (25.5)	28.6 (38.2)		
Rated speed (No	ote 3, 4) [r/min]	3000 (2400)	3000		2000				
Maximum spee	ed (Note 3, 4) [r/min]	6000 (6700)	6700	6000	6700	6000	3000		
Power rate at continuous rated torque	Without electromagnetic brake	17.3 (27.0)	27.0	37.0	52.0	71.7	111		
(Note 3) [kW/s]	With electromagnetic brake	14.9 (23.3)	23.3	32.9	48.3	67.7	107		
Rated current (Note 3) [A]	3.2 (4.0)	4.0	4.9	8.7	11	9.0		
Maximum current (Note 3) [A]		12 (20)	16 (22)	21 (27)	34 (46)	34 (48)	30 (41)		
Moment of	Without electromagnetic brake	2.11 2.74 4.38 5.65				5.65	8.18		
inertia J [× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	2.45		3.08	4.72	5.99	8.53		
Recommended load to motor inertia ratio (Note 1)		10 times or less 15 times or less							
Speed/position	detector	Batteryless abs	olute/incremen	tal 26-bit encode	er (resolution: 67	,108,864 pulses/	′rev)		
Туре		Permanent magnet synchronous motor							
Oil seal		None (Servo motors with an oil seal are available.)							
Electromagnet	ic brake	None (Servo motors with an electromagnetic brake are available.)							
Thermistor		None							
Insulation class	3	155 (F)							
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)							
Vibration resist	ance ^{*1} [m/s ²]	X: 24.5, Y: 49 X: 24.5, Y: 24.5							
Vibration rank		V10 ^{·3}							
Permissible	L [mm]								
load for the	Radial [N]	392							
shaft*2	Thrust [N]	147							
Mass [kg]	Without electromagnetic brake	2.3		2.7	3.6	4.4	5.9		
Mass [kg]	With electromagnetic brake	2.9		3.3	4.7	5.5	7.0		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations. 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped. 5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	63UWB	7M3UWB	103UWB	153WB	203WB	202WB	
Туре			Spring actuated type safety brake						
Rated voltage			24 V DC (-10 % to 0 %)						
Power consumption [W] at 20 °C			9.0 13.8						
Electromagnetic brake static [N•m] friction torque		3.2 or higher			9.5 or higher				
Permissible	Per braking	[J]	66			64			
braking work	Per hour	[J]	660			640			
Electromagnetic	Number of bra	aking times	20000			5000			
brake life (Note 2)	Work per brak	king [J]	33			64			

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo

Linear Servo Motors

Motors

HK-KT 4 W (Low Inertia, Small Capacity)

HK-KI_4_	w (Low Inertia, Small	Capacity	/)						
Specification	ns when connected with	a 200 V se	rvo amplifi	er					
Flange size	[mn	n] 60 × 60		80 × 80		90 × 90			
Rotary servo n	notor model HK-K	T 434W	634W	7M34W	1034W	1534W	2034W	2024W	
Continuous	Rated output [kV	/] 0.2	0.3	0.375	0.5	0.75	1.0	1.0	
running duty (Note 4)	Rated torque (Note 5) [N•n	n] 1.3	1.9	2.4	3.2	4.8	6.4	9.5	
Maximum torq	ue ^(Note 3) [N•n	1] 4.5 (5.7)	6.7 (8.6)	8.4 (10.7)	11.1 (14.3)	19.1 (21.5)	22.3 (25.5)	38.2	
Rated speed (N	ote 4) [r/mii	1500 In	1500						
Maximum spee	ed (Note 4) [r/mil	n] 3500			3000				
Power rate at continuous	Without electromagnetic brake	39.5	61.0	41.6	60.3	52.0	71.7	111	
rated torque [kW/s]	With electromagnetic brake	36.7	58.0	37.7	56.0	48.3	67.7	107	
Rated current	[/	A] 1.3	2.3	2.4	2.5	4.4	5.3	4.5	
Maximum curr	ent (Note 3)	A] 4.9 (6.6)	9.1 (13)	9.7 (13)	11 (14)	20 (23)	21 (24)	21	
Moment of inertia J	Without electromagnetic brake	0.410	0.598	1.37	1.68	4.38	5.65	8.18	
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	0.442	0.629	1.51	1.81	4.72	5.99	8.53	
Recommended	l load to motor inertia ratio (Note	¹⁾ 25 times or	less	17 times or	r less	15 times o	or less		
Speed/position	detector	Batteryless	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)						
Туре		Permanent	Permanent magnet synchronous motor						
Oil seal		None (Serv	vo motors wit	h an oil seal ar	e available.)				
Electromagnet	ic brake	None (Serv	vo motors wit	h an electroma	gnetic brake	are available.)		
Thermistor		None							
Insulation class	S	155 (F)							
Structure		Totally enc	losed, natura	l cooling (IP ra	ting: IP67) (Not	e 2, 6)			
Vibration resist	tance ^{*1} [m/s	²] X: 49, Y: 49	9			X: 24.5, Y	: 24.5		

Direct Drive Motors Vibration rank V10*3 40 Permissible [mm] 30 load for the 392 Radial [N] 245 shaft *2 Thrust [N] 98 147 2.4 3.6 5.9 Without electromagnetic brake 1.2 1.5 2.2 4.4 Options/Peripheral Equipment Mass [kg] With electromagnetic brake 1.6 1.9 2.9 3.1 4.7 5.5 7.0

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	434WB	434WB 634WB 7M34WB 1034WB 1534WB 2034WB 2024WE						
Туре			Spring actua	Spring actuated type safety brake						
Rated voltage			24 V DC (-10 % to 0 %)							
Power consumptio	n	[W] at 20 °C	7.9		10 13.8					
Electromagnetic bi friction torque	lectromagnetic brake static [N·m] 1.9 or higher			r	3.2 or highe	r	9.5 or highe	r		
Permissible	Permissible Per braking [J		J] 22 64							
braking work Per hour		[J]	220		640					
Electromagnetic	Number of bra	aking times	20000				5000			
brake life (Note 2)	Work per brak	ing [J]	22		64					

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

LVS/Wires

HK-KT_W (Low Inertia, Small Capacity)

Specifications when connected with a 400 V servo amplifier

Flange size	[m	m] 40 × 40					
Rotary servo r	· · · · · · · · · · · · · · · · · · ·	T 053W	13W	1M3W			
Continuous	Rated output [k]	V] 0.05	0.1	0.15			
running duty (Note 4)	Rated torque (Note 5) [N•	m] 0.16 (Note 6)	0.32	0.48			
Maximum toro	ue (Note 3) [N•	n] 0.56 (0.72)	1.1 (1.4)	1.7 (2.1)			
Rated speed (*	Note 4)	n] 3000	(1.7)				
Maximum spe		n] 6700					
Power rate at continuous	Without electromagnetic brak		14.8	23.3			
rated torque [kW/s]	With electromagnetic brake	5.8	14.0	22.4			
Rated current		A] 1.3	1.2	1.2			
Maximum current (Note 3) [A]		4.6	4.6 (6.0)	4.5 (6.0)			
Moment of inertia J	Without electromagnetic brak	e 0.0394	0.0686	0.0977			
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	0.0434	0.0725	0.102			
Recommende	d load to MR-J5	20 times or less		·			
motor inertia r	atio (Note 1) MR-J5D	20 times or less					
Speed/position	n detector	Batteryless absolute/increm	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)				
Туре		Permanent magnet synchro	ermanent magnet synchronous motor				
Oil seal		None (Servo motors with a	n oil seal are available.) (Note 6)			
Electromagne	tic brake	None (Servo motors with a	None (Servo motors with an electromagnetic brake are available.)				
Thermistor		None					
Insulation clas	S	155 (F)	155 (F)				
Structure		Totally enclosed, natural co	Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 7)				
Vibration resis	tance*1 [m/	³²] X: 49, Y: 49					
Vibration rank		V10 ^{*3}	V10 ⁻³				
Permissible	L [m	m] 25					
load for the	Radial [N] 88					
shaft *2	Thrust [N] 59					
	Without electromagnetic brak	e 0.27	0.37	0.47			
Mass [kg]	With electromagnetic brake	0.53	0.63	0.73			

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. For HK-KT053W_J_ (with an oil seal), use the servo motor at a derating rate of 80 %.

7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	053WB	053WB 13WB 1M3WB				
Туре			Spring actuated type safety brake					
Rated voltage			24 V DC (-10 % to 0 %)					
Power consumptio	n	[W] at 20 °C	6.4					
Electromagnetic brake static [N•m]			0.48 or higher					
Permissible	Per braking	[J]	5.6					
braking work	Per hour	[J]	56					
Electromagnetic	Number of bra	king times	20000					
brake life (Note 2)	Work per brak	ing [J]	5.6					

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-KT_4_W (Low Inertia, Small Capacity)

Flange size			[mm]	60 × 60			80 × 80		all		
Rotary servo n	notor mode		HK-KT	434W	634W		7M34W	1034W	Specifications		
Continuous	Rated outp	out	[kW]	0.4	0.6		0.75	1.0			
running duty (Note 4)	Rated torq	Ue (Note 5)	[N•m]	1.3	1.9		2.4	3.2			
Maximum torq			[N•m]	4.5 (5.7)	6.7 (8.6)		8.4 (10.7)	11.1 (14.3)	Controllers		
Rated speed (N	lote 4)		[r/min]	3000	000						
Maximum spe	ed (Note 4)		[r/min]	6700				6500			
Power rate at continuous	Without ele	ectromagnetic	brake	39.5	61.0		41.6	60.3			
rated torque [kW/s]	With electr	romagnetic bra	ake	36.7	58.0		37.7	56.0			
Rated current	l current		[A]	1.3	2.3		2.4	2.5			
Maximum curr	ent (Note 3)		[A]	4.9	9.1		9.7 10				
			[, ,]	(6.6)	(13)		(13)	(14)	- 1		
Moment of inertia J	J		brake	0.410	0.598		1.37	1.68			
[x 10 ⁻⁴ kg•m ²]			ake	0.442	0.629		1.51	1.81			
Recommende	nended load to MR-J5			23 times or less	20 times	or less (Note 7)	s ^(Note 7) 9 times or less ^(Note 8) 7 times or less				
motor inertia r	otor inertia ratio (Note 1) MR-J5D			23 times or less	30 times	or less	20 times or less	30 times or less			
Speed/positior	n detector			Batteryless abso	lute/incremental	26-bit encode	r (resolution: 67,108,86	64 pulses/rev)	_		
Туре				Permanent magnet synchronous motor							
Oil seal				None (Servo motors with an oil seal are available.)							
Electromagnet	tic brake			None (Servo motors with an electromagnetic brake are available.)							
Thermistor				None					_		
Insulation clas	s			155 (F)					_		
Structure				Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 6)							
Vibration resis	tance *1		[m/s ²]	X: 49, Y: 49	X: 49, Y: 49						
Vibration rank				V10*3							
Permissible	L		[mm]	30			40		- 0		
load for the	Radial		[N]	245			392		_		
shaft ^{*2}	Thrust		[N]	98			147		_		
	Without ele	ectromagnetic	brake	1.2	1.5		2.2	2.4			
Mass [kg]	With electr	omagnetic bra	ake	1.6	1.9		2.9	3.1			

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations. 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp) 7. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 30 times or less.

8. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 20 times or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

						l ct		
Model	HK-KT	434WB	634WB	7M34WB	1034WB	t List		
Туре		Spring actuated type sa	ing actuated type safety brake					
Rated voltage		24 V DC (-10 % to 0 %)	V DC (-10 % to 0 %)					
Power consumption	on [W] at 20 °C	7.9		10		-		
Electromagnetic b friction torque	rake static [N•m]	1.9 or higher		3.2 or higher		^o recau		
Permissible	Per braking [J]	22		64		itions		
braking work	Per hour [J]	220		640		SI		
Electromagnetic	Number of braking times	20000		·				
brake life (Note 2)	Work per braking [J]	22		64				
Notoo: 1 The electron	magnatic brake is for holding. It conr	at he used for deceleration on	nliantiana			S		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

upport

LVS/Wires

Produ

HK-KT_4_W (Low Inertia, Small Capacity)

Specifications when connected with a 400 V servo amplifier

Continuous running duty (Note 4)Rated output[kW]0.61.0Rated torque (Note 3, 5)[N•m]1.9 (2.4)3.2Maximum torque (Note 3)[N•m]6.3 (11.1) (10.3)11.1 (14.3)Rated speed (Note 3, 4)[r/min]6.3 (2400)10.00 (2400)Maximum speed (Note 3, 4)[r/min]6000 (6700)6000 (6700)Power rate at continuous rated torque (Note 3)Without electromagnetic brake17.3 (27.0)37.0Power rate at continuous rated torque (Note 3)Without electromagnetic brake14.9 (23.3)32.9Rated current (Note 3)[A]1.6 (2.0)2.5Maximum current (Note 3)[A]5.6 (9.7)9.7 (14)Moment of inertia J [x 10-4 kg·m²]Without electromagnetic brake2.453.08Recommended load to motor inertia ratio (Note 1)MR-J5 MR-J510 times or less30.8Speed/position detectorMR-J5 MR-J5D10 times or less30.8Speed/position detectorPermanent magnet sync Oil sealNone (Servo motors with	2 .1 4.3) 000 000 7.0 2.9 5 7 4) 74	1534W 1.5 4.8 16.7 (21.5) 6700 52.0 48.3 4.4 17 (23) 4.38 4.72	2034W 2.0 6.4 19.1 (25.5) 6000 71.7 67.7 5.3 17 (24) 5.65 5.99	2024W 2.0 9.5 28.6 (38.2) 2000 3000 111 107 4.5 15 (21) 8.18 8.53		
Continuous running duty (Note 4)Rated output[kW]0.61.0Rated torque (Note 3, 5)[N•m]1.9 (2.4)3.2Maximum torque (Note 3)[N•m]6.3 (11.1) (10.3)11.1 (14.2)Rated speed (Note 3, 4)[r/min] 3000 (2400) 3000 (2400)Maximum speed (Note 3, 4)[r/min] 6000 (6700) 6000 (6700)Power rate at continuous rated torque (Note 3)Without electromagnetic brake 17.3 (27.0) 37.0 Power rate at continuous rated torque (Note 3)Without electromagnetic brake 14.9 (23.3) 32.9 Rated current (Note 3)[A] 1.6 (2.0) 2.5 Maximum current (Note 3)[A] 5.6 (9.7) 9.7 (14)Moment of inertia J [x 10-4 kg·m2]Without electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1)MR-J5 MR-J5D10 times or lessSpeed/position detectorBatteryless absolute/incTypePermanent magnet sync Oil sealNone (Servo motors with	0 2 .1 4.3) 000 000 7.0 2.9 5 7 4) 74	1.5 4.8 16.7 (21.5) 6700 52.0 48.3 4.4 17 (23) 4.38 4.72	2.0 6.4 19.1 (25.5) 6000 71.7 67.7 5.3 17 (24) 5.65	2.0 9.5 28.6 (38.2) 2000 3000 111 107 4.5 15 (21) 8.18		
$\begin{array}{c c c c c c c c c c c c c c c c c c c $	2 .1 4.3) 000 000 7.0 2.9 5 7 4) 74	4.8 16.7 (21.5) 6700 52.0 48.3 4.4 17 (23) 4.38 4.72	6.4 19.1 (25.5) 6000 71.7 67.7 5.3 17 (24) 5.65	9.5 28.6 (38.2) 2000 3000 111 107 4.5 15 (21) 8.18		
(Note 4) Rated torque (Note 3, 5) [N·m] 1.1.0 (2.4) 3.2 Maximum torque (Note 3) [N·m] 6.3 (10.3) 11.1 (10.3) (14.3) Rated speed (Note 3, 4) [r/min] 3000 (2400) 3000 3000 Maximum speed (Note 3, 4) [r/min] 6000 (6700) 6000 6000 Power rate at continuous rated torque (Note 3) Without electromagnetic brake 17.3 (27.0) 37.0 Rated current (Note 3) With electromagnetic brake 14.9 (2.3) 32.9 [kW/s] With electromagnetic brake 1.6 (2.0) 2.5 Maximum current (Note 3) [A] 1.6 (2.0) 2.5 Maximum current (Note 3) [A] 5.6 (9.7) 9.7 (9.7) 14) Moment of inertia J [x 10 ⁻⁴ kg·m ²] Without electromagnetic brake 2.11 2.74 Mth electromagnetic brake 1.0 times or less 3.08 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less 3.08 Speed/position detector Batteryless absolute/inc 7 7 MR-J5	.1 4.3) 000 000 7.0 2.9 5 7 4) 74	16.7 (21.5) 6700 52.0 48.3 4.4 17 (23) 4.38 4.72	19.1 (25.5) 6000 71.7 67.7 5.3 17 (24) 5.65	28.6 (38.2) 2000 3000 111 107 4.5 15 (21) 8.18		
Maximum torque (Note 3) [N·m] (10.3) (14.3) Rated speed (Note 3, 4) [r/min] 3000 (2400) 3000 Maximum speed (Note 3, 4) [r/min] 6000 (6700) 6000 Power rate at continuous rated torque (Note 3) Without electromagnetic brake 17.3 (27.0) 37.0 With electromagnetic brake 14.9 (23.3) 32.9 Rated current (Note 3) [A] 1.6 (2.0) 2.5 Maximum current (Note 3) [A] 1.6 (2.0) 2.5 Maximum current (Note 3) [A] 5.6 (9.7) 9.7 (14) Moment of inertia J [x 10 ⁻⁴ kg·m ²] Without electromagnetic brake 2.11 2.74 MR-J5 10 times or less 3.08 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less 3.08 Speed/position detector Batteryless absolute/inc Permanent magnet sync 3.08 Oil seal None (Servo motors with 3.08 3.08 3.08	4.3) 000 000 7.0 2.9 5 7 4) 74	 (21.5) 6700 52.0 48.3 4.4 17 (23) 4.38 4.72 	(25.5) 6000 71.7 67.7 5.3 17 (24) 5.65	(38.2) 2000 3000 111 107 4.5 15 (21) 8.18		
Hated speed (Note 3, 4) [r/min] (2400) 3000 Maximum speed (Note 3, 4) [r/min] 6000 (6700) 6000 Power rate at continuous rated torque (Note 3) Without electromagnetic brake 17.3 (27.0) 37.0 Maximum current (Note 3) With electromagnetic brake 14.9 (23.3) 32.9 Rated current (Note 3) [A] 1.6 (2.0) 2.5 Maximum current (Note 3) [A] 5.6 (9.7) 9.7 (14) Moment of inertia J [x 10 ⁻⁴ kg·m2] Without electromagnetic brake 2.11 2.74 (9.7) Moment of inertia J With electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with	000 7.0 2.9 5 7 4) 74	52.0 48.3 4.4 17 (23) 4.38 4.72	71.7 67.7 5.3 17 (24) 5.65	3000 111 107 4.5 15 (21) 8.18		
Maximum speed (Note 3, 4) [f/min] (6700) 6000 Power rate at continuous rated torque (Note 3) Without electromagnetic brake 17.3 (27.0) 37.0 Without electromagnetic brake 14.9 (23.3) 32.9 [kW/s] With electromagnetic brake 14.9 (20) 32.9 Rated current (Note 3) [A] 1.6 (2.0) 2.5 Maximum current (Note 3) [A] 5.6 (9.7) 9.7 (14) Moment of inertia J Without electromagnetic brake 2.11 2.74 (9.7) [x 10 ⁻⁴ kg·m2] With electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with	7.0 2.9 5 7 4) 74	52.0 48.3 4.4 17 (23) 4.38 4.72	71.7 67.7 5.3 17 (24) 5.65	111 107 4.5 15 (21) 8.18		
Continuous rated torque (Note 3)Without electromagnetic brakeInt.3 (27.0)37.0 (27.0)Rated torque (Note 3)With electromagnetic brake14.9 (23.3)32.9Rated current (Note 3)[A]1.6 (2.0)2.5Maximum current (Note 3)[A]5.6 (9.7)9.7 (14)Moment of inertia J [x 10-4 kg·m2]Without electromagnetic brake2.112.74With electromagnetic brake2.453.08Recommended load to motor inertia ratio (Note 1)MR-J5 MR-J5D10 times or lessSpeed/position detectorBatteryless absolute/incTypePermanent magnet sync None (Servo motors with	2.9 5 7 4) 74	48.3 4.4 17 (23) 4.38 4.72	67.7 5.3 17 (24) 5.65	107 4.5 15 (21) 8.18		
(Note 3) [kW/s] With electromagnetic brake 14.9 (23.3) 32.9 Rated current (Note 3) [A] (23.3) 32.9 Maximum current (Note 3) [A] 1.6 (2.0) 2.5 Maximum current (Note 3) [A] 5.6 (9.7) (14) 9.7 (14) Moment of inertia J [x 10 ⁻⁴ kg·m2] Without electromagnetic brake 2.11 2.74 With electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with	5 7 4) 74	4.4 17 (23) 4.38 4.72	5.3 17 (24) 5.65	4.5 15 (21) 8.18		
Hated current (Note 3) [A] (2.0) 2.5 Maximum current (Note 3) [A] (2.0) 2.5 Moment of inertia J [A] (9.7) (14) Moment of inertia J Without electromagnetic brake 2.11 2.74 [x 10 ⁻⁴ kg·m ²] With electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with	7 4) 74	17 (23) 4.38 4.72	17 (24) 5.65	15 (21) 8.18		
Maximum current (Note 3) [A] (9.7) (14) Moment of inertia J Without electromagnetic brake 2.11 2.74 [× 10 ⁻⁴ kg·m ²] With electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with	4) 74	(23) 4.38 4.72	(24) 5.65	(21) 8.18		
inertia J With out electromagnetic brake 2.11 2.14 [× 10 ⁻⁴ kg·m ²] With electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with		4.72				
[x 10 ⁻⁴ kg·m ²] With electromagnetic brake 2.45 3.08 Recommended load to motor inertia ratio (Note 1) MR-J5 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with	08		5.99	8 53		
motor inertia ratio (Note 1) MR-J5D 10 times or less Speed/position detector Type Permanent magnet sync Oil seal None (Servo motors with			1	0.00		
MR-J5D 10 times or less Speed/position detector Batteryless absolute/inc Type Permanent magnet sync Oil seal None (Servo motors with	10 times or less 11 times or less (Note 7) 10 times or less (Note 7)			15 times or less		
Type Permanent magnet synd Oil seal None (Servo motors with	10 times or less 10 times or less 9 times or less					
Oil seal None (Servo motors with	incremental 26-b	oit encoder (resolu	tion: 67,108,864 pul	ses/rev)		
	Permanent magnet synchronous motor					
Electromagnetic brake None (Servo motors with	None (Servo motors with an oil seal are available.)					
	None (Servo motors with an electromagnetic brake are available.)					
Thermistor None	None					
Insulation class 155 (F)						
Structure Totally enclosed, natura	Iral cooling (IP ra	ating: IP67) (Note 2, 6)				
Vibration resistance ^{*1} [m/s ²] X: 24.5, Y: 49		X: 24.5, Y: 24.5				
Vibration rank V10 ⁻³						
Permissible L [mm] 40						
load for the Radial [N] 392						
shaft ^{*2} Thrust [N] 147						
Without electromagnetic brake 2.3 2.7				5.9		
Mass [kg] With electromagnetic brake 2.9 3.3	7	3.6	4.4	1		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table. 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through

portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations. 4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

7. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 30 times or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-KT	634UWB	1034UWB	1534WB	2034WB	2024WB	
Туре			Spring actuated type safety brake					
Rated voltage 24 V DC (-10 % to 0 %)								
Power consumptio	n	[W] at 20 °C	9.0		13.8	13.8		
Electromagnetic brake static [N•m]		3.2 or higher		9.5 or higher				
Permissible	Permissible Per braking [J]		66		64	64		
braking work Per hour		[J]	660		640			
Electromagnetic	Number of bra	aking times	20000		5000			
brake life (Note 2)	Work per brak	ing [J]	33		64			

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires


HK-KT_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

E: For 3-phase 200 V AC - : For 1-phase 200 V AC




Standard torque




HK-KT053W


HK-KT1M3W




HK-KT1M3W Standard torque




Torque increased 2.5




HK-KT23W




HK-KT63W Standard torque




HK-KT23W Torque increased



HK-KT63W Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value.



HK-KT13UW

1.4

1.2

1.0

0.8

0.6

0.4

0.2

0.0 L

6.0

5.0

4.

3.

2.0

1.0

0.0

Torque [N•m]

HK-KT43W

Standard torque

Short-duration

running range

Continuous running range

2000

4000

Speed [r/min]

Torque [N•m]

Standard torque

Short-duration running range


Continuous

2000


4000


Speed [r/min]








HK-KT13UW Torque increased












HK-KT_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

6000 6700

4000

E: For 3-phase 200 V AC - : For 1-phase 200 V AC



running range

HK-KT23UW Torque increased 3.0 2 2 [orque [N•m] Short-duration running range 1.

0.

0.0L

12.0

10.

6.0

4.0

2.0

0.0 L 0

Torque [N•m]

Continuous running range

HK-KT7M3W

Torque increased

Short-duration

running range

Continuous running range

2000

4000

Speed [r/min]


6000 6700

2000

4000

Speed [r/min]

6000 6700



HK-KT103W (Note 2)

Standard torque

Short-duration

running range

Continuou running ra

2000

4000

Speed [r/min]

16.0

14.0

12.

[u•N] 8.0 10.0 Tordne


8.0

4.

2.0


0.0 L

HK-KT43UW Torque increased



HK-KT103W (Note 2) Torque increased

6000 6700




Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of the effective load ratio.

Continuous running range 0.0 L 2000 Speed [r/min]

1.0

0.5

HK-KT7M3W



Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires


HK-KT_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier

E: For 3-phase 200 V AC - : For 1-phase 200 V AC




Standard torque



Torque increased 12.0

HK-KT63UW



HK-KT103UW (Note 2)

Torgue increased

Short-duratio

16.0

14.0

12.0

Ē^{10.0}

orque

8.0


6.0


4.0

2.0

0.0

HK-KT103UW (Note 2) Standard torque





4000

Speed [r/min]

30.

25.

20.

10.0

5.

0.0

ż

Short-duration

running ra

Continuous running rang

HK-KT203W Torque increased

Continuous


2000

4000

Speed [r/min]

6000

5000






running range 6 4 2. Continuous running range 0.0 L 2000 4000 6000 6700 Speed [r/min]

HK-KT153W (Note 2)


HK-KT7M3UW Torque increased 12.0



HK-KT153W Torque increased

25.0

20.0



HK-KT202W (Note 2)

Standard torque

40. 35.0

30.

-25.

20.0


15 (

10.


5.

0.0


Ordine



HK-KT202W



Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of the effective load ratio.


HK-KT_4_W Torque Characteristics (Note 1)

When connected with a 200 V servo amplifier


: For 3-phase 200 V AC : For 1-phase 200 V AC

HK-KT434W







HK-KT7M34W Standard torque



HK-KT1534W Standard torque




HK-KT2024W (Note 2) Standard torque




HK-KT434W Torque increased


orque [N•m]




HK-KT7M34W Torgue increased




HK-KT1534W Torque increased




HK-KT634W Standard torque




HK-KT1034W Standard torque




HK-KT2034W (Note 2) Standard torque




HK-KT634W



HK-KT1034W Torque increased



HK-KT2034W (Note 2) Torque increased



Continuous

Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of

4-16 the effective load ratio.


HK-KT_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier


E: For 3-phase 400 V AC - : For 3-phase 380 V AC







HK-KT053W





2.5

2.0

1.1

0.

0.0 L

Torque [N•m]

Standard torque

Short-duration running range


Continuous running range

2000


4000

Speed [r/min]






Notes: 1. Torque drops when the power supply voltage is below the specified value.



HK-KT13W Torque increased



Common Specifications


Servo System Controllers

Product

HK-KT_4_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier

E: For 3-phase 400 V AC - : For 3-phase 380 V AC



1

6000 6700



Short-duration

running range

Continuous running range

2000

4000

Speed [r/min]

12.0

10.0

8

2.0

0.0L

Torque [N•m]







6000 6700


4000

HK-KT7M34W Torque increased









Short-duration running range

- Continuous running ran

2000

4000

Speed [r/min]

6000 6700

Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC


HK-KT_4_W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier


E: For 3-phase 400 V AC - : For 3-phase 380 V AC

HK-KT634UW







HK-KT634UW Torque increased



HK-KT1534W Standard torque



HK-KT1534W Torque increased





40. 35.0

30.

20.0

P H 15.0

10.0

5.0


0.0

running ra


HK-KT2024W Torque increased

2000

Speed [r/min]





Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC



Speed [r/min]


HK-KT2034W





HK-KT1034UW Torque increased 16.0 14.0 12.0 댣^{10.0} Torque [N-Short-duration 8.0 6.0 4 (2.0 Continuous running range 0.0 l 2000 4000







6000

Common Specifications

Servo System Controllers


Servo Amplifiers

Rotary Servo Motors

Product

Support

HK-KT Series Dimensions (Note 3, 4, 5)



Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

2. The electromagnetic brake terminals do not have polarity.

Connector

11.5

11.7

3. The dimensions are the same regardless of whether or not an oil seal is installed.

Å

(Note 6)

Κl

31.5

4. Use a friction coupling to fasten a load.

5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

08 -0.009

6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

Encoder

Pin No.

11

12

13

14

L 58.5

(82)

Signal

name

P5

MR

LG

Variable dimensions (Note 1)

KL

46.8

(70.3) [Unit: mm]

MRR

Power supply

Pin No.

2

3

4

Model

HK-KT13UW(B)

Signal

name

E

U

w

V

C

7. Use hexagonal cap head bolts when mounting the servo motor.

16.6

36

Common Specifications

Servo System Controllers


Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment



[Unit: mm]

(75.8)

62.8

(84.8)

HK-KT23UW(B)

HK-KT43UW(B)

(87.5)

74.5

(96.5)

LVS/Wires

1. The dimensions in brackets are for the models with an electromagnetic brake. 2. The electromagnetic brake terminals do not have polarity

3. The dimensions are the same regardless of whether or not an oil seal is installed.

4. Use a friction coupling to fasten a load.

Notes:


5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.


7. Use hexagonal cap head bolts when mounting the servo motor.

HK-KT Series Dimensions (Note 3, 4, 5)

HK-KT7M3W(B), HK-KT103W(B), HK-KT7M34W(B), HK-KT1034W(B)



HK-KT63UW(B), HK-KT7M3UW(B), HK-KT103UW(B), HK-KT153W(B), HK-KT203W(B), HK-KT202W(B), HK-KT634UW(B), HK-KT1034UW(B), HK-KT1534W(B), HK-KT2034W(B), HK-KT2024W(B)



[Unit: mm]

Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

2. The electromagnetic brake terminals do not have polarity.

3. The dimensions are the same regardless of whether or not an oil seal is installed.

4. Use a friction coupling to fasten a load.

5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

7. Use hexagonal cap head bolts when mounting the servo motor.

HK-KT Series Connector Dimensions

Cable direction: load side/opposite to load side

	Variable	dimensi	ons									
Model	Dual ca	ble type			Single c	able type	;					
	A	В	С	D	A	В	С	D				
HK-KT053W HK-KT13W HK-KT1M3W	36.8		12.7		39.6		12.7					
HK-KT13UW HK-KT23W HK-KT43(4)W HK-KT63(4)W	46.6				49.4							
HK-KT23UW HK-KT43UW HK-KT7M3(4)W HK-KT103(4)W	56.6	36	11.7	31.5	59.4	32	11.7	40				
HK-KT63(4)UW HK-KT7M3UW HK-KT103(4)UW HK-KT153(4)W HK-KT203(4)W HK-KT202(4)W	61.6				64.4							

Cable direction: load side

11.5

С



* The drawing shows a dual cable type as an example.

[Unit: mm]

Cable direction: vertical

	Variable dir	mensions							
Model	Dual cable	type		Single cabl	e type				
	A	В	С	A	В	С			
HK-KT053W									
HK-KT13W	63.4		12.7	71.9		12.7			
HK-KT1M3W				81.7 91.7					
HK-KT13UW	73.2								
HK-KT23W									
HK-KT43(4)W									
HK-KT63(4)W		-			-				
HK-KT23UW					32				
HK-KT43UW	83.2	36							
HK-KT7M3(4)W			11.7			11.7			
HK-KT103(4)W		-							
HK-KT63(4)UW									
HK-KT7M3UW									
HK-KT103(4)UW	88.2			96.7					
HK-KT153(4)W HK-KT203(4)W									
HK-KT203(4)W									
1111-11202(4)									

Connector

Luijan B

* The drawing shows a dual cable type as an example.

[Unit: mm]

Cable direction: opposite to load side

Servo Amplifiers

Common Specifications

Servo System Controllers

> ى ت

Rotary Servo Motors

Linear Servo Motors

LVS/Wires

Product List

Precautions

Support

HK-KT Series with Special Shaft Dimensions


Servo motors with the following specifications are also available.

D: D-cut shaft (Note 1)


Model	Variable dimensions				
Model	Q1	Q2			
HK-KT053WD					
HK-KT13WD	21.5	20.5			
HK-KT1M3WD					
HK-KT13UWD	21	20			

L: L-cut shaft (Note 1)

Model	Variable dimensions				
Model	Q1	Q2			
HK-KT053WL					
HK-KT13WL	21.5	20.5			
HK-KT1M3WL					
HK-KT13UWL	21	20			




[Unit: mm]




[Unit: mm]


K: Keyed shaft (with a double round-ended key) (Note 1)

Model	Variable	dimen	sions							
Model	S	LR	Q	W	QK	QL	U	R	Т	Υ
HK-KT053WK HK-KT13WK HK-KT1M3WK	8 ⁰ -0.009	25	21.5	3	14	5	6.2 ⁰ .0.085	1.5	3	M3×8
HK-KT13UWK			21							
HK-KT23WK HK-KT43(4)WK HK-KT63(4)WK HK-KT23UWK HK-KT43UWK	14.0.011	30	26	5	20	3	11 ⁰ .085	2.5	5	M4×15
HK-KT7M3(4)WK HK-KT103(4)WK HK-KT63(4)UWK HK-KT7M3UWK HK-KT103(4)UWK HK-KT103(4)WK HK-KT203(4)WK HK-KT202(4)WK	19 ⁰ -0.013	40	36	6	25	5	15.5 ⁰ .0.1	3	6	M5×20



[Unit: mm]





[Unit: mm]

Notes: 1. Do not use the servo motors with a D-cut shaft, an L-cut shaft, or a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft. 2. The servo motor is supplied without a key. The user needs to prepare a key.

HK-KT Series Geared Servo Motor Specifications

					•	fications nes, flange mou								Common Specifications	
			Actual	Moment c [× 10 ⁻⁴ kg·	of inertia J •m²] (Note 1)	Permissible load to motor inertia	Permi the sh	issible I ∩aft ^{*1}	oad for	Mass [kg]				mon cations	
Model HK-KT	Output [kW]	Reduction ratio	reduction	Without electro- magnetic brake	With electro- magnetic brake	ratio ^(Note 2) (when converted into the servo motor shaft)	Q [mm]			Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	Mounting direction	Servo	
		1/5	9/44	0.0764	0.0804			150	200	1.4	1.6			System trollers	
053G1	0.05	1/12	49/576	0.0984	0.102	5 times or less	12.5	240	320	1.8	2.0			:em rs	
		1/20	25/484	0.0804	0.0844	1		370	450	1.8	2.0				
		1/5	9/44	0.106	0.110		-	150	200	1.5	1.7			Servo	
13G1	0.1	1/12	49/576	0.128	0.132	5 times or less	12.5	240	320	1.9	2.1			VO /	
		1/20	25/484	0.110	0.114			370	450	1.9	2.1			Amplifiers	
		1/5	19/96	0.363	0.408	7 times or less		330	350	3.2	3.6	Grease	Any	olifie	
23G1	0.2	1/12	961/11664	0.494	0.539		7 times or less	17.5	710	720	3.8	4.2	(filled)	direction	Sle
		1/20	513/9984	0.375	0.420			780 780		3.8	4.2	Ì			
		1/5	19/96	0.564	0.596			330	350	3.5	3.9			Rotary Ser Motors	
43G1	0.4	1/12	961/11664	0.695	0.727	7 times or less	17.5	710	720	4.1	4.5			ary Mot	
		1/20	7/135	0.687	0.719			760	760	5.2	5.6			Servo tors	
		1/5	1/5	1.79	1.93			430	430	5.4	6.1			No	
7M3G1	0.75	1/12	7/87	1.85	1.99	5 times or less	25	620	620	6.5	7.2				
		1/20	625/12544	2.52	2.66			970	960	9.4	11				
														Linear Se Motors	
Item	em			Specificat	Specifications										
Mountin	lounting method		Flange m	ounting									Servo tors		
				Samo ac	the convol	motor output shaft o	diroctio	n							

		<u>o</u> =					
Item	Specifications	ar Se otors					
Mounting method Flange mounting							
Output shaft rotation direction Same as the servo motor output shaft direction							
Backlash (Note 4)	60 minutes or less at gear reducer output shaft						
Maximum torque (at servo motor shaft) (Note 5)	Three times of the rated torque (Refer to HK-KT series specifications in this catalog for the rated torque.)	Direct Dr Motors					
Maximum speed (at servo motor shaft) 4500 r/min							
IP rating (gear reducer part) Equivalent to IP44							
Gear reducer efficiency (Note 3)	40 % to 85 %						
 Contact your local sales office if the loc The gear reducer efficiency varies dep are not guaranteed as they are repress The backlash can be converted: 1 min 	the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake). ad to motor inertia ratio exceeds the value in the table. ending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table entative values at the rated torque and speed at a temperature of 20 °C. ute = 0.0167° s do not increase even when these servo motors are combined with larger capacity servo amplifiers.	Options/Peripheral Equipment					

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

LVS/Wires

Product List

Precautions

Support

HK-KT Series Geared Servo Motor Specifications

			Moment of [× 10 ⁻⁴ kg•		Permissible load to motor inertia	Permis the sha	sible loa aft ^{*1}	ad for	Mass [kg]			
Model HK-KT	Output [kW]	ratio (Note 3)	Without electro- magnetic brake	With electro- magnetic brake	ratio ^(Note 2) (when converted into the servo motor shaft)	L [mm]	Radial [N]	Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	direction
		1/5 (40 × 40)	0.0429	0.0469		17	93	431	0.48	0.66		
		1/5 (60 × 60)	0.107	0.111		23	177	706	1.1	1.3		
		1/9	0.0419	0.0459		17	111	514	0.49	0.67		
053G5	0.05	1/11	0.0994	0.103	10 times or less	23	224	895	1.2	1.4		
		1/21	0.0904	0.0944		23	272	1987	1.2	1.4		
		1/33	0.0844	0.0884		23	311	1244	1.2	1.4		
		1/45	0.0844	0.0884		23	342	1366	1.2	1.4		
		1/5 (40 × 40)	0.0721	0.0760		17	93	431	0.58	0.76		
		1/5 (60 × 60)	0.137	0.141		23	177	706	1.2	1.4		
13G5	0.1	1/11	0.129	0.133	10 times or less	23	224	895	1.3	1.5		
1505 0.	0.1	1/21	0.120	0.124		23	272	1087	1.3	1.5		
		1/33	0.131	0.135		32	733	2581	2.5	2.7	-	
		1/45	0.130	0.134		32	804	2833	2.5	2.7		
		1/5	0.410	0.455		23	177	706	1.7	2.1	Grease	Any
		1/11	0.412	0.457		23	224	895	1.8	2.2	(filled)	direction
23G5	0.2	1/21	0.707	0.752	14 times or less	32	640	2254	3.3	3.7		
		1/33	0.661	0.706		32	733	2581	3.3	3.7		
		1/45	0.660	0.705		32	804	2833	3.3	3.7		
		1/5	0.611	0.643		23	177	706	2.1	2.5		
		1/11	0.986	1.02		32	527	1856	3.7	4.1		
43G5	0.4	1/21	0.908	0.940	14 times or less	32	640	2254	3.7	4.1		
		1/33	0.960	0.992]	57	1252	4992	5.8	6.2		
		1/45	0.954	0.986]	57	1374	5478	5.8	6.2		
		1/5	2.02	2.16		32	416	1465	4.2	4.9]	
		1/11	1.93	2.07]	32	527	1856	4.5	5.2		
7M3G5	0.75	1/21	2.12	2.26	10 times or less	57	1094	4359	6.6	7.3		
		1/33	1.90	2.04]	57	1252	4992	6.6	7.3		
		1/45	1.90	2.04]	57	1374	5478	6.6	7.3]	

With a flange-output type gear reducer for high precision applications, flange mounting: G5

Item	Specifications
Mounting method	Flange mounting
Output shaft rotation direction	Same as the servo motor output shaft direction
Backlash (Note 5)	3 minutes or less at gear reducer output shaft
Maximum torque (at servo motor shaft)	Three times of the rated torque
(Note 6)	(Refer to HK-KT series specifications in this catalog for the rated torque.)
Maximum speed (at servo motor shaft)	6000 r/min
IP rating (gear reducer part)	Equivalent to IP44
	HK-KT053G5 1/5 (60 × 60): 12 %
Gear reducer efficiency (Note 4)	HK-KT053G5 1/11, 1/21, 1/33, and 1/45: 22 % to 34 %
	HK-KT053G5 1/5 (40 × 40) and 1/9, and HK-KT13G5 to HK-KT7M3G5: 48 % to 84 %

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).
2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.
3. The values in brackets represent the dimensions of the flange.

4. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.

5. The backlash can be converted: 1 minute = 0.0167°

6. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

HK-KT Series Geared Servo Motor Specifications

			Moment of [× 10 ⁻⁴ kg•		Permissible load to motor inertia		Permissible load for the shaft ^{*1}						Specifications
∕lodel ⊣K-KT	Output [kW]	Reduction ratio ^(Note 3)	Without electro- magnetic brake	With electro- magnetic brake	ratio ^(Note 2) (when converted into the servo motor shaft)	Q [mm]	[N]	[N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	Mounting direction	Controllers
		1/5 (40 × 40)	0.0456	0.0496		17	93	431	0.51	0.69			olle
		1/5 (60 × 60)	0.113	0.117		23	177	706	1.1	1.3			Sle
		1/9	0.0436	0.0476		17	111	514	0.51	0.69			_
53G7	0.05	1/11	0.100	0.104	10 times or less	23	224	895	1.2	1.4			S
		1/21	0.0904	0.0944		23	272	1987	1.2	1.4			DM6
		1/33	0.0844	0.0884		23	311	1244	1.2	1.4			Servo Amplifiers
		1/45	0.0844	0.0884		23	342	1366	1.2	1.4			nplii
		1/5 (40 × 40)	0.0748	0.0787		17	93	431	0.61	0.79			fiers
		1/5 (60 × 60)	0.143	0.147		23	177	706	1.2	1.4			0
007		1/11	0.130	0.134	10 times or less	23	224	895	1.3	1.5			л
3G7 0.1	0.1	1/21	0.120	0.124		23	272	1087	1.3	1.5]		M
		1/33	0.132	0.136		32	733	2581	2.8	3.0			Hotary Servo Motors
		1/45	0.130	0.134		32	804	2833	2.8	3.0	Grease (filled)		rs rs
		1/5	0.416	0.461		23	177	706	1.7	2.2		Any	Ő
		1/11	0.412	0.457		23	224	895	1.8	2.3		direction	
3G7	0.2	1/21	0.709	0.754	14 times or less	32	640	2254	3.7	4.1			Linear Servo Motors
		1/33	0.662	0.707		32	733	2581	3.7	4.1			Mo
		1/45	0.660	0.705		32	804	2833	3.7	4.1			tors
		1/5	0.617	0.649		23	177	706	2.2	2.6	-		Ň
		1/11	0.994	1.03		32	527	1856	4.1	4.5			
3G7	0.4	1/21	0.910	0.942	14 times or less	32	640	2254	4.1	4.5			
		1/33	0.966	0.998		57	1252	4992	7.2	7.6			
		1/45	0.957	0.989		57	1374	5478	7.2	7.6			Motors
		1/5	2.06	2.20		32	416	1465	4.6	5.3	-		ors
		1/11	1.94	2.08		32	527	1856	4.9	5.6	1		ē
//3G7	0.75	1/21	2.14	2.28	10 times or less	57	1094	4359	8.0	8.7	1		
		1/33	1.91	2.05		57	1252	4992	8.0	8.7	1		Options/Perip Equipmen
		1/45	1.90	2.04		57	1374	5478	8.0	8.7	1		Equ

Item	Specifications	ohera
Mounting method	Flange mounting	
Output shaft rotation direction	Same as the servo motor output shaft direction	_
Backlash (Note 5)	3 minutes or less at gear reducer output shaft	SN
Maximum torque (at servo motor shaft) (Note 6)	Three times of the rated torque (Refer to HK-KT series specifications in this catalog for the rated torque.)	Wires
Maximum speed (at servo motor shaft)	6000 r/min	0,
IP rating (gear reducer part)	Equivalent to IP44	
Gear reducer efficiency (Note 4)	HK-KT053G7 1/5 (60 × 60): 12 % HK-KT053G7 1/11, 1/21, 1/33, and 1/45: 22 % to 34 % HK-KT053G7 1/5 (40 × 40) and 1/9, and HK-KT13G7 to HK-KT7M3G7: 48 % to 84 %	Product
	e the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).	List

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake). 2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table. 3. The values in brackets represent the dimensions of the flange.

4. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.

5. The backlash can be converted: 1 minute = 0.0167°

6. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.


Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

Precautions

HK-KT Series Geared Servo Motor Dimensions (Note 1, 5)

With a gear reducer for general industrial machines, flange mounting HK-KT_G1 $^{(Note\;6)}$

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



[Unit: mm]

Model	Reduction ratio	Variable dir	nensions (No	ote 4)													
HK-KT	(Actual reduction ratio)	L	LA	LC	LD	LE	S	LH	LK	KL	LG	Q	LR	M	KA	LT	KC
	1/5	99.2								86.5							
	(9/44)	(134.2)								(121.5)							
053(B)G1	1/12																
053(B)G1	(49/576)	118			105.3												
	1/20	(153)								(140.3)							
	(25/484)		75	60.003	65	50	16.0.011	6.5			34.5	25	60.5	7	36.8	12.7	40
	1/5	111.7	/5	6U-0.03	65	50	10.0.011	0.5	8	99	34.5	25	60.5	l'	30.8	12.7	40
	(9/44)	(146.7)								(134)							
	1/12		1								1						
13(B)G1	(49/576)	130.5								117.8							
	1/20	(165.5)								(152.8)							
	(25/484)																
	1/5	120.7								109							
	(19/96)	(155.3)								(143.6)							
23(B)G1	1/12		1								1						
	(961/11664)	140.5								128.8							
	1/20	(175.1)	100	00.0			05.0			(163.4)	38						
	(513/9984)		100	82 .0.035	90	75	25 .0.013	8			38	35	74				
	1/5	138.7								127	1				46.6		60
	(19/96)	(173.3)								(161.6)							
	1/12	158.5							10	146.8	1			9			
l3(B)G1	(961/11664)	(193.1)								(181.4)						11.7	
	1/20	162.5							1	150.8				1			
	(7/135)	(197.1)								(185.4)							
	1/5	157.5		05.0						145.8	1					1	
	(1/5)	(193)	115	95.0035	100	83	32.0.016	9.5		(181.3)	39	50	90				
	1/12	179.5	1							167.8	1						
'M3(B)G1	(7/87)	(215)								(203.3)					56.6		80
	1/20	192.5					+ +			180.8			+		1		
	(625/12544)	(228)	140	115.0.035	120	98 4	40 .0.016	11.5	15	(216.3)	44.5	60	105.5	14			

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

2. The electromagnetic brake terminals do not have polarity.

3. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

4. The dimensions in brackets are for the models with an electromagnetic brake.

5. Use a friction coupling to fasten a load.

6. HK-KT_G1K, a geared servo motor with a keyed shaft (with a key), is also available. Refer to "HK-KT Series Geared Servo Motor Special Shaft Dimensions" in this catalog for details.


Rotary Servo Motors

Common Specifications

HK-KT Series Geared Servo Motor Dimensions (Note 1)

With a flange-output type gear reducer for high precision applications, flange mounting HK-KT_G5

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



Nodel	Reduction	Variable	dimension	ns (Note 4))																	Motors
Model HK-KT	ratio (Note 5)		LA	LB	LC	LD	LE	LF	LG	LH	LK	LM	KL	Т	N	Р	R	М	KA	LT	КС	ŝ
	1/5 (40 × 40)	95 (130)	46	18	40 .0.025	40	24	5 ^{+0.012}	15+0.25	2.5	5	34.5	82.3 (117.3)	3	3		6	3.4			1.0	
	1/5 (60 × 60)	119.5 (154.5)	70	30	56.0.03	60	40	14 ^{+0.018}	21 ^{+0.4}	3	8	56	106.8 (141.8)	5	6		7	5.5				
053(B)G5	1/9	95 (130)	46	18	40.0.025	40	24	5 +0.012	15+0.25	2.5	5	34.5	82.3 (117.3)	3	3		6	3.4	1			Motors
	1/11		T	T		T	T		T					Τ					7			oto
	1/21	119.5	70	30	56.0.03	60	40	14 ^{+0.018}	21 +0.4	3	8	56	106.8	5	6	M4	7	5.5				S.
	1/33	(154.5)			00.000			1		ľ	ĭ		(141.8)	Ĭ	ľ		l'	0.0	36.8	12.7	40	
	1/45	<u> </u>	ļ							ļ		_			_	_			4			
	1/5 (40 × 40)	107.5 (142.5)	46	18	40.000	40	24	5 +0.012	15+0.25	2.5	5	34.5	94.8 (129.8)	3	3		6	3.4				
	1/5 (60 × 60)	132											119.3									
13(B)G5	1/11	(167)	70	30	56.0.03	60	40	14 ^{+0.018}	21 +0.4	3	8	56	(154.3)				7	5.5				4
	1/21		<u> </u>	<u> </u>						-		_	` <i>`</i>	4					4			5
	1/33	134.5	105	45	85.0.035	90	59	24 +0.021	27 +0.4	8	10	56.5	121.8			M6	10	9				Ednibilieli
	1/45	(169.5)		+	-	-	-	-	-	-			(156.8)	-			-		-	-		-
	1/5	(166.1)	70	30	56.0.03	60	40	14 +0.018	21 +0.4	3	8	56	(154.4)			M4	7	5.5				
23(B)G5	1/21			+	-		1	-	-	-		-		-			-		-			
20(0)00	1/33	138.5	105	45	85.0.035	90	59	24 +0.021	27 +0.4	8	10	61	126.8			M6	10	9	1			
	1/45	(173.1)			0.035	01			20.5			-	(161.4)					-				
	1/5	149.5 (184.1)	70	30	56 ^{.0} .03	60	40	14 ^{+0.018}	21 ^{+0.4}	3	8	56	137.8 (172.4)	5	6	M4	7	5.5	46.6		60	
12/01/05	1/11	156.5	105	45	05.0			24 +0.021	07+04		10	-	144.8	1			1.0	9	1	11.7		
43(B)G5	1/21	(191.1)	105	45	85.0.035	90	59	24	27 +0.4	8	10	61	(179.4)			M6	10	9		111.7		
	1/33	168.5	135	60	115.0.035	120	84	32 +0.025	35+0.4	13	13	70	156.8	1		M8	12	11	1			
	1/45	(203.1)	133	00	110.035	120	04	02 0	35.05	10	10	10	(191.4)			INIO	12					
	1/5	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	10	68	158.8]		M6	10	9	T											
	1/11		Ľ.	10	00	(194.3)			NIO .	10	~											
7M3(B)G5	1/21	180.5											168.8						56.6		80	
	1/33	(216)	135	60	115.0.035	120	84	32 +0.025	35 +0.4	13	13	75	(204.3)			M8	12	11				

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space

2. The electromagnetic brake terminals do not have polarity.

3. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

4. The dimensions in brackets are for the models with an electromagnetic brake.


5. The values in brackets represent the dimensions of the flange

Precautions

HK-KT Series Geared Servo Motor Dimensions (Note 1, 5)

With a shaft-output type gear reducer for high precision applications, flange mounting HK-KT_G7 $^{(Note\ 7)}$

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



Variable dimensions (Note 4) Reduction Mode HK-KT ratio (Note 6) LA LC LD LE S LG LH Q LR IК LM KL М KA KC 82.3 42 1/5 (40 × 40) 40.002 10.0015 15 34.5 46 40 29 2.5 20 3.4 (130) (117.3) 119.5 106.8 1/5 (60 × 60) 70 56.°a 60 40 16.0 21 3 28 58 56 5.5 (154.5) (141.8) 82.3 15 2.5 42 053(B)G7 1/9 46 40.0.02 40 29 10.0015 20 34.5 3.4 (130) (117.3) 1/21 119.5 106.8 70 56.0.03 60 40 16.0.018 21 3 28 58 56 5.5 (154.5) (141.8) 12.7 1/33 36.8 40 1/45 107.5 94.8 1/5 (40 × 40) 46 40.0.02 40 29 10.0015 15 2.5 20 42 34.5 3.4 (129.8) (142.5) 1/5 (60 × 60) 132 119.3 13(B)G7 70 56.0.03 60 40 16.0.018 21 28 58 56 5.5 3 (167) (154.3) 1/21 1/33 134.5 121.8 105 85.0.035 25.0.021 27 8 80 10 56.5 90 59 42 1/45 (169.5) (156.8) 1/5 131.5 119.8 70 56.0 60 40 16.0 21 3 28 58 56 5.5 1/11 (166.1) (154.4) 23(B)G7 1/21 138.5 126.8 105 27 42 80 10 1/33 85.0035 90 59 25.0021 8 61 (173.1) (161.4) 1/45 149.5 137.8 46.6 60 1/5 70 56.0 60 40 16.0 21 3 28 58 56 5.5 (184.1) (172.4) 1/11 156.5 144.8 11.7 43(B)G7 105 85.0035 90 59 25.0021 27 8 42 80 10 61 (191.1) (179.4) 1/33 168.5 156.8 135 115.003 120 84 40.0.025 35 13 82 133 13 70 11 (191.4) 1/45 (203.1) 1/5 170.5 158.8 27 80 105 85.0.035 59 25.0.02 8 42 10 68 90 (206) (194.3) 7M3(B)G7 56.6 80 1/21 180.5 168.8 135 115.0.035 35 13 133 75 1/33 120 84 40 .0.025 82 13 11 (216) (204.3) 1/45

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

2. The electromagnetic brake terminals do not have polarity.

3. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-KT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

4. The dimensions in brackets are for the models with an electromagnetic brake.

5. Use a friction coupling to fasten a load.

6. The values in brackets represent the dimensions of the flange.

7. HK-KT_G7K, a geared servo motor with a keyed shaft (with a key), is also available. Refer to "HK-KT Series Geared Servo Motor Special Shaft Dimensions" in this catalog for details.

[Unit: mm]

HK-KT Series Geared Servo Motor Special Shaft Dimensions

The standard HK-KT_G1 (with a gear reducer for general industrial machines) and HK-KT_G7 (with a shaft-output type gear reducer for high precision applications, flange mounting) have a straight shaft. Note that these motors are also available with a keyed shaft (with a key) as HK-KT_G1K and HK-KT_G7K.

[Unit: mm]

Model

HK-KT053(B)G7K

HK-KT13(B)G7K

HK-KT23(B)G7K

HK-KT43(B)G7K

HK-KT7M3(B)G7K

2. Dimensions not shown in the tables are respectively the same as those of HK-KT_G1 and HK-KT_G7 with a straight shaft. Refer to "HK-KT_G1" and "HK-KT_G7" of

HK-KT G1K (Note 1, 2)

Model

HK-KT053(B)G1K

HK-KT13(B)G1K


HK-KT23(B)G1K

HK-KT43(B)G1K

HK-KT7M3(B)G1K

Notes:

Keyed shaft (with a double square-ended key)



S

16^{.0}

25⁰.013

32.0.016

40 .0.016

35 8 30 21

50 10 40 27

60 12 50 35

Variable dimensions

O

25 5

w

QK U

20 13 5

Т

7

8

1. Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft.

Y

M4×8

M6×12

M8×16

M10×20

Reduction ratio

reduction ratio)

(Actual

1/5 (9/44)

1/12

1/20

1/5

(9/44)

1/12

1/20

1/5

1/12

1/20

1/5

1/12

1/20

1/5

(1/5)

1/12

(7/87)

1/20

(625/12544)

(7/135)

(19/96)

(49/576)

(25/484)

(49/576)

(25/484)

(19/96)

(961/11664)

(513/9984)

(961/11664)

HK-KT G7K (Note 1, 2)

Keyed shaft (with a single pointed key)

Reduction

ratio (Note 3)

(40 × 40)

(60 × 60)

1/5

1/5

1/9

1/11

1/21

1/33

1/45

1/5

1/5

1/11

1/21

1/33

1/45

1/5

1/11

1/21

1/33

1/45

1/5

1/11

1/21

1/33

1/45

1/5

1/11

1/21 1/33

1/45

(40 × 40)

(60 × 60)

S Q W

10 20 4

16 28 5

10 20 4

16 28 5 25

10 20 4

16 28 5

25 42 8

16 28 5

25 42 8


16 28

25 42 8

40 82 12 70 35 8

25 42 8

40 82 12 70 35 8



Variable dimensions

QK U

15 7.5 4

25 13 5

15 7.5 4

15 7.5 4

25 13 5

36 21 7

25 13 5

36

25

36 21 7

36 21 7

5

21 7

13 5 Servo System Controllers

Common Specifications

Servo Amplifier

[Unit: mm]

Y

M3×6

M4×8

M3×6

M4×8

M3×6

M4×8

M6×12

M4×8

M6×12

M4×8

M6×12

M10×20

M6×12

M10×20

5 13

0,
R

Ì0	٦ry
SIC	Se
	S

δ	

Linear Servo Motors

ш	ť
9	su
Ē	P
лe	₽ï.
Ľ	D

g

LVS/Wires

Ieral

Product

List

"HK-KT Series Geared Servo Motor Dimensions" in this catalog. 3. The values in brackets represent the dimensions of the flange

HK-MT_W (Ultra-Low Inertia, Small Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size		[mm]	40 × 40			60×60		80 × 80	80 × 80	
Rotary servo r	notor model	HK-MT	053W	13W	1M3W	23W	43W	63W	7M3W	103W
Continuous	Rated output	[kW]	0.05	0.1	0.15	0.2	0.4	0.6	0.75	1.0
running duty (Note 4)	Rated torque (Note 5)	[N•m]	0.16 (Note 6)	0.32	0.48	0.64	1.3	1.9	2.4	3.2
Maximum torc	UE (Note 3)	[N•m]	0.48 (0.64)	0.95 (1.3)	1.4 (1.9)	1.9 (2.3)	3.8 (4.5)	5.7 (7.1)	7.2 (8.8)	9.5 (12.4)
Rated speed (Note 4)	[r/min]	3000	,						
Maximum spe	ed (Note 4)	[r/min]	6700							
Power rate at continuous	Without electromagne	tic brake	12.5	31.7	52.2	41.5	101.3	155.9	104.6	142.5
rated torque [kW/s]	With electromagnetic I	orake	10.4	28.1	47.8	31.2	84.4	137.1	83.4	119.3
Rated current		[A]	1.2	1.2	1.2	1.6	2.5	5.3	5.8	5.4
Maximum curi	rent (Note 3)	[A]	4.3 (6.3)	4.6 (5.9)	4.6 (6.5)	6.3 (9.8)	9.7 (13)	21 (28)	21 (31)	20 (31)
Moment of	Without electromagne	tic brake	0.0203	0.0320	0.0437	0.0976	0.160	0.234	0.545	0.711
inertia J [× 10 ⁻⁴ kg•m ²]	With electromagnetic b	orake	0.0243	0.0360	0.0477	0.130	0.192	0.266	0.683	0.849
	d load to motor inertia ra	atio (Note 1)	35 times or less (Note 8) 35 times or less							
Speed/positio	n detector		Batteryless	absolute/i	ncremental	26-bit encod	er (resolutio	on: 67,108,8	64 pulses/re	V)
Туре			Permanent	magnet sy	nchronous	motor				
Oil seal			None (Serv	o motors v	vith an oil se	al are availa	able.) (Note 6)			
Electromagne	tic brake		None (Serv	vo motors v	vith an elect	romagnetic l	brake are av	vailable.)		
Thermistor			None							
Insulation clas	S		155 (F)							
Structure			Totally encl	osed, natu	ral cooling (IP rating: IP	67) (Note 2, 7)			
Vibration resis	tance *1	[m/s ²]	X: 49, Y: 49	9						
Vibration rank			V10 [∗] 3							
Permissible	L	[mm]	25			30			40	
load for the	Radial	[N]	88			245	245			
shaft [∗] 2	Thrust	[N]	59			98			147	
	Without electromagne	tic brake	0.31	0.43	0.54	0.92	1.4	1.8	2.8	3.3
Mass [kg]	With electromagnetic l	orake	0.59	0.74	0.82	1.4	1.8	2.2	3.5	3.9

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. For HK-MT053W_J_ (with an oil seal), use the servo motor at a derating rate of 80 %.

7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp) 8. When the servo motor is combined with a 0.1 kW servo amplifier, this recommended load to motor inertia ratio is applicable for operating the servo motor at the rated speed. If operating speed exceeds the rated speed, check whether a regenerative option is required using drive sizing software Motorizer. A servo amplifier with a larger capacity can be combined.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-MT	053WB	13WB	1M3WB	23WB	43WB	63WB	7M3WB	103WB	
Туре		Spring actuated type safety brake									
Rated voltage 24 V DC (-10 % to 0 %)											
Power consumptio											
Electromagnetic bi friction torque	[N•m]	0.48 or higher			1.9 or high	1.9 or higher			3.2 or higher		
Permissible	Per braking	[J]	5.6			22		64	64		
braking work	Per hour	[J]	56			220			640		
Electromagnetic	Number of bra	aking times	20000								
brake life (Note 2)	Work per brak	ing [J]	5.6			22			64		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-MT_VW (Ultra-Low Inertia, Small Capacity)

			a 200 V servo amplifier			00 00			00 00	ecificatio	
Flange size				101/14/	41401/14/	60 × 60	401/14/	001/14/	80 × 80	1001/04/	Specifications
Rotary servo m			053VW	13VW	1M3VW	23VW	43VW	63VW	7M3VW	103VW	ns
Continuous running duty	Rated output	[kW]	0.05	0.1	0.15	0.2	0.4	0.6	0.75	1.0	_
(Note 4)	Rated torque (Note 5)	[N•m]	0.16 (Note 6)	0.32	0.48	0.64	1.3	1.9	2.4	3.2	Q
Maximum torqu		[N•m]	0.48 (0.64)	0.95 (1.3)	1.4 (1.9)	1.9 (2.3)	3.8 (4.5)	5.7 (7.1)	7.2 (8.8)	9.5 (11.5)	Controllers
Rated speed (No		[r/min]	3000								SJ6
Maximum spee	ed (Note 4)	[r/min]	10000								_
continuous	Without electromagnet	tic brake	12.5	31.7	52.2	41.5	101.3	155.9	104.6	142.5	CEIVE
rated torque [kW/s]	With electromagnetic b		10.4	28.1	47.8	31.2	84.4	137.2	83.4	119.3	
Rated current		[A]	1.2	1.2	1.2	1.6	3.0	5.3	5.8	8.1	
Maximum curre	ent (Note 3)	[A]	4.3	4.6	4.6	6.3	12	21	21	30	U
	1		(6.3)	(5.9)	(6.5)	(9.8)	(15)	(28)	(31)	(37)	_
Moment of inertia J	Without electromagnet	tic brake	0.0203	0.0320	0.0437	0.0976	0.160	0.234	0.545	0.711	
	With electromagnetic t	orake	0.0243	0.0360	0.0477	0.130	0.192	0.266	0.683	0.849	Motors
Recommended	d load to motor inertia r	atio (Note 1)	24 times or less (Note 8) 24 times or less 30 times or less								- v
Speed/position	l detector		Incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)								
Туре			Permanent	magnet sy	agnet synchronous motor						
Oil seal			None (Serv	o motors w	ith an oil se	al are availa	able.) (Note 6)				Motors
Electromagneti	ic brake		None (Serv	o motors w	ith an electr	romagnetic	brake are av	/ailable.)			Motors
Thermistor			None								SJC
Insulation class	S		155 (F)	155 (F)							
Structure			Totally enclosed, natural cooling (IP rating: IP67) (Note 2, 7)								_
Vibration resist	ance *1	[m/s ²]	X: 49, Y: 49)							_
Vibration rank			V10 ^{*3}						1		_ <
Permissible	L	[mm]				30			40		Motors
load for the	Radial	[N]				245			392		
shaft*2						98			147		_
Mass [kg]	Without electromagnet		0.31	0.43	0.54	0.92	1.4	1.8	2.8	3.3	Equipment
	With electromagnetic b	orake	0.59	0.74	0.82	1.4	1.8	2.2	3.5	3.9	m

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. For HK-MT053VW_J_ (with an oil seal), use the servo motor at a derating rate of 80 %.

7. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp) 8. When the servo motor is combined with a 0.1 kW servo amplifier, this recommended load to motor inertia ratio is applicable for operating the servo motor at the rated speed. If operating speed exceeds the rated speed, check whether a regenerative option is required using drive sizing software Motorizer. A servo amplifier with a larger capacity can be combined.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-MT	053VWB	13VWB	1M3VWB	23VWB	43VWB	63VWB	7M3VWB	103VWB			
Type Spring actuated type sa													
Rated voltage 24 V DC (-10 % to 0 %)													
Power consumption [W] at 20 °C 6.4 7.9 10													
Electromagnetic bi friction torque	[N•m]	0.48 or higher			1.9 or higher			3.2 or higher					
Permissible	Per braking	[J]	5.6			22		64					
braking work	Per hour	[J]	56	56			220						
Electromagnetic	Electromagnetic Number of braking times				20000								
brake life (Note 2)	Work per braking	[J]	5.6			22			64				

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

LVS/Wires


HK-MT_W Torque Characteristics (Note 1)

Specifications when connected with a 200 V servo amplifier

E: For 3-phase 200 V AC - : For 1-phase 200 V AC

HK-MT053W





HK-MT053W

HK-MT1M3W

2.5

2.0

1.0

0.

0.0

Ē

Forgue


Torque increased

Short-du


running range

Continuous


runn ing ra




HK-MT1M3W Standard torque








HK-MT7M3W Standard torque




Torque increased 5.0




HK-MT7M3W


[m·N]

orque |







HK-MT23W Standard torque




HK-MT13W Torque increased



HK-MT23W Torque increased



HK-MT63W Torque increased




Standard torque

2000


4000

Speed [r/min]

6000 6700




HK-MT103W (Note 2) Torque increased



1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC Notes: 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of 4-34 the effective load ratio.

HK-MT43W




2000


4000

Speed [r/min]

6000 6700



Torque increased



0.0

HK-MT63W

8.0

7.0

6.0

5.0

Standard torque

Short-duration

HK-MT103W (Note 2)


HK-MT_VW Torque Characteristics (Note 1)

Specifications when connected with a 200 V servo amplifier

E: For 3-phase 200 V AC - : For 1-phase 200 V AC


HK-MT053VW

Standard torque




HK-MT053VW Torque increased


HK-MT1M3VW




HK-MT1M3VW Standard torque




Torque increased




HK-MT43VW Standard torque




HK-MT7M3VW Standard torque



HK-MT43VW Torque increased



HK-MT7M3VW Torque increased



HK-MT13VW Standard torque

HK-MT23VW

2.5

2.0

1.0

0.5

0.0

8.0

6.0

5.0

2.0

14.0

12.0

10.0

8.0

6.0

4.0

2.0

0.01

[M-m]

Torque

[m·N]

Torque |

[M•N]

Torque

Standard torque

Short-du

Continu running

HK-MT63VW

Standard torque

ng ra

3000

HK-MT103VW (Note 2)

Standard torque

Short-du

Continu

running ra

3000

6000


Speed [r/min]


6000

Speed [r/min]

9000 10000


running range






02 Continuous running range 0.0L 3000 6000

HK-MT23VW Torque increased



HK-MT63VW Torque increased 8.0


7.0



6.0 5.0


Im-N Short-duratio 4.0 3.0 2.0 Continuous 1.0 running range 0.0 L 9000 10000 3000 6000 Speed [r/min]


HK-MT103VW Torque increased




Common Specifications

Servo System Controllers










HK-MT Series Dimensions (Note 3, 4, 5)

HK-MT053W(B), HK-MT13W(B), HK-MT1M3W(B) HK-MT053VW(B), HK-MT13VW(B), HK-MT1M3VW(B)



[Unit: mm]

Electromagnetic

Signal

name

Signal

name

P5

MR

LG

MRR

Variable dimensions (Note 1)

KL

48.6

(83.6)

62.1

(97.1)

75.6

(110.6)

B1

B2

brake (Note

Pin No.

Encoder

Pin No

11

12

13

14

61.3

(96.3)

74.8

88.3

(109.8)

(123.3)


5

6

6

4

HK-MT23W(B), HK-MT43W(B), HK-MT63W(B), HK-MT23VW(B), HK-MT43VW(B), HK-MT63VW(B)



Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

The electromagnetic brake terminals do not have polarity.

3. The dimensions are the same regardless of whether or not an oil seal is installed.

4. Use a friction coupling to fasten a load.


5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-MT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

7. Use hexagonal cap head bolts when mounting the servo motor.

HK-MT Series Dimensions (Note 3, 4, 5)

HK-MT7M3W(B), HK-MT103W(B) HK-MT7M3VW(B), HK-MT103VW(B) 40 8 3 12 11 45 4× ø6.6 8 6 (Note 7) 00 0 Con octo D Power supply 070 Signal Pin No. name 56.6 1 2 U Ø19-0.013 (Note 6) 3 W Connector 4 V 31.5 11.5 11.7 Model HK-MT7M3W(B) Å HK-MT7M3VW(B)



Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are the same regardless of whether or not an oil seal is installed.
- 4. Use a friction coupling to fasten a load.
- 5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
- 6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-MT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.
- 7. Use hexagonal cap head bolts when mounting the servo motor.

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Support

HK-MT Series Connector Dimensions

Cable direction: load side/opposite to load side

	Variable dimensions									
Model	Dual cal	ble type			Single c	able type	•			
	A	В	С	D	A	В	С	D		
HK-MT053(V)W										
HK-MT13(V)W	36.8		12.7		39.6		12.7			
HK-MT1M3(V)W										
HK-MT23(V)W		36				32		10		
HK-MT43(V)W	46.6	30		31.5	49.4			40		
HK-MT63(V)W			11.7				11.7			
HK-MT7M3(V)W	50.0				50.4					
HK-MT103(V)W	56.6				59.4					



Cable direction: load side

Connector

С

Cable direction: opposite to load side




* The drawing shows a dual cable type as an example.

[Unit: mm]

Cable direction: vertical

	Variable dir	nensions					
Model	Dual cable	type		Single cable type			
	A	В	С	A	В	С	
HK-MT053(V)W							
HK-MT13(V)W	63.4		12.7	71.9		12.7	
HK-MT1M3(V)W					32		
HK-MT23(V)W		36					
HK-MT43(V)W	73.2	30		81.7			
HK-MT63(V)W		-	11.7			11.7	
HK-MT7M3(V)W	83.2			91.7			
HK-MT103(V)W	00.2			51.7			



* The drawing shows a dual cable type as an example.

[Unit: mm]

HK-MT Series with Special Shaft Dimensions


Servo motors with the following specifications are also available.


D: D-cut shaft (Note 1)

Model	Variable dimensions						
Woder	Q1	Q2					
HK-MT053(V)WD							
HK-MT13(V)WD	21.5	20.5					
HK-MT1M3(V)WD							

L: L-cut shaft (Note 1)

Model	Variable dimensions						
Model	Q1	Q2					
HK-MT053(V)WL							
HK-MT13(V)WL	21.5	20.5					
HK-MT1M3(V)WL							





LR Q

QK

D

QL

A-A

[Unit: mm]

[Unit: mm]

[Unit: mm]

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product List

Precautions


Support

K: Keyed shaft (with a double round-ended key) (Note 1)

Model	Variable	Variable dimensions									
Woder	S	LR	Q	W	QK	QL	U	R	Т	Y	
HK-MT053(V)WK											
HK-MT13(V)WK	8.0.009	25	21.5	3	14	5	6.2 + 0.085	1.5	3	M3×8	
HK-MT1M3(V)WK											
HK-MT23(V)WK											
HK-MT43(V)WK	14.0.011	30	26	5	20	3	11 ⁰ _{-0.085}	2.5	5	M4×15	
HK-MT63(V)WK											
HK-MT7M3(V)WK	19 ⁰ -0.013	40	36	6	25	5	15.5.01	3	6	M5×20	
HK-MT103(V)WK	19.0.013	40	30	0	25	5	15.5.0.1	3	0	IVI5×20	

N: Keyed shaft (without a key) (Note 1, 2)

Model	Variable dimensions									
WOUEI	S	LR	Q	W	QK	QL	U	R	Y	
HK-MT053(V)WN										
HK-MT13(V)WN	8 .0.009	25	21.5	3 -0.004 -0.029	14	5	6.2 ⁰ -0.085	1.5	M3×8	
HK-MT1M3(V)WN										
HK-MT23(V)WN										
HK-MT43(V)WN	14 ^{.0}	30	26	5 ⁰ -0.03	20	3	11 ⁰ _{-0.085}	2.5	M4×15	
HK-MT63(V)WN										
HK-MT7M3(V)WN	19.0013	40	36	6.003	25	5	15.5.01	3	M5×20	
HK-MT103(V)WN	19.0.013	40	30	U -0.03	20	5	10.0.0.1	3	IVIJX20	



Notes: 1. Do not use the servo motors with a D-cut shaft, an L-cut shaft, or a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft. 2. The servo motor is supplied without a key. The user needs to prepare a key.

HK-ST_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

			-					
Flange size		130 × 130						
Rotary servo m	otor model HK-ST	52W	102W	172W	202AW	302W		
Continuous	Rated output [kW]	0.5	1.0	1.75	2.0	3.0		
running duty (Note 4)	Rated torque (Note 3, 5) [N•m]	2.4 (3.2)	4.8 (6.4)	8.4	9.5 (11.6)	14.3		
Maximum torqu	e (Note 3) [N•m]	7.2 (12.7)	14.3 (19.1)	25.1	28.6 (34.7)	43.0 (50.1)		
Rated speed (Not	(r/min	2000 (1500)	2000 (1500)	2000	2000 (1650)	2000		
Maximum spee	d ^(Note 4) [r/min]	4000				2500		
Power rate at continuous	Without electromagnetic brake	9.7 (17.2)	26.3 (46.8)	61.2	53.9 (79.2)	91.5		
rated torque (Note 3) [kW/s]	With electromagnetic brake	7.0 (12.4)	20.9 (37.2)	51.1	47.8 (70.3)	83.6		
Rated current (N	ote 3) [A]	3.0 (4.0)	5.3 (7.0)	9.3	11 (13)	11		
Maximum current (Note 3) [A]		11 (19)	18 (24)	32	34 (42)	34 (40)		
Moment of inertia J	Without electromagnetic brake	5.90	8.65	11.4	16.9	22.4		
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	8.15	10.9	13.7	19.1	24.5		
Recommended	load to motor inertia ratio (Note 1)	15 times or less (Note 6) 23 times or less 24 times or less						
Speed/position	detector	Batteryless absolu	te/incremental 26-b	oit encoder (resoluti	on: 67,108,864 puls	ses/rev)		
Туре		Permanent magne	et synchronous mot	or				
Oil seal		None (Servo moto	rs with an oil seal a	are available.)				
Electromagnetic	c brake	None (Servo motors with an electromagnetic brake are available.)						
Thermistor		None						
Insulation class		155 (F)						
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2)						
Vibration resista	ance ^{*1} [m/s ²]	X: 24.5, Y: 49						
Vibration rank		V10 ^{∗3}						
Permissible	L [mm]							
load for the		980						
shaft*2		490						
Mass [kg]	Without electromagnetic brake	5.0	6.0	7.1	9.1	11		
iviass [ky]	With electromagnetic brake	6.8	7.8	8.8	11	13		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

 The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
 When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 19 times or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-ST	52WB	102WB	172WB	202AWB	302WB	
Туре			Spring actuated typ	pring actuated type safety brake				
Rated voltage			24 V DC (-10 % to	24 V DC (-10 % to 0 %)				
Power consumption [W] at 20 °C			20			23		
Electromagnetic brake static [N·m] friction torque			8.5 or higher			16 or higher		
Permissible	Per braking	[J]	400					
braking work	Per hour	[J]	4000					
Electromagnetic Number of braking times		20000			5000			
brake life (Note 2)	Work per braking	[J]	200			400		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-ST_W (Medium Inertia, Medium Capacity)

		[]	170 170						. 0	
			176 × 176					70014/	Specifications	
Rotary servo m		-	7M2UW	172UW	202W	352W	502W	702W		
Continuous	Rated output	[kW]	0.75	1.75	2.0	3.5	5.0	7.0		
running duty (Note 4)	Rated torque (Note 3, 5)	[N•m]	3.6	8.4	9.5 (12.7)	16.7 (20.3)	23.9 (28.9)	33.4		
Maximum torq	Je (Note 3)	[N•m]	10.7 (12.5)	25.1 (29.2)	28.6 (38.2)	50.1 (60.8)	71.6 (86.8)	100		
Rated speed (N	ote 3, 4)	[r/min]	2000		2000 (1500)	2000 (1650)	2000 (1650)	2000		
Maximum spee	ed (Note 4)	[r/min]	3000		4000	3500	4000	3000		
Power rate at continuous	Without electromagne	tic brake	12.2	36.6	25.1 (44.6)	52.1 (76.5)	80.4 (118)	106	-	
rated torque (Note 3) [kW/s]	With electromagnetic b	orake	10.4	33.4	22.0 (39.2)	47.7 (70.0)	75.2 (110)	101		
Rated current (Note 3) [A]			4.6	9.0	10 (14)	16 (19)	27 (32)	28		
Maximum current (Note 3) [A]		18 (24)	34 (40)	32 (45)	52 (66)	90 (110)	102			
Moment of inertia J	Without electromagne	tic brake	10.5	19.1	36.4	53.6	70.8	105		
[× 10 ⁻⁴ kg•m ²]	With electromagnetic b	orake	12.3	20.9	41.4	58.6	75.8	110		
Recommended	d load to motor inertia ra	atio (Note 1)	19 times or	19 times or less 15 times or less (Note 6) 12 times or less (Note 7) 10 times or less (Note 8) 8 times or less (Note 8)						
Speed/position	detector		Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)							
Туре			Permanent magnet synchronous motor							
Oil seal			None (Servo	None (Servo motors with an oil seal are available.)						
Electromagnet	ic brake		None (Servo motors with an electromagnetic brake are available.)							
Thermistor			None							
Insulation class	3		155 (F)						- 00	
Structure					oling (IP rating: IP				_ `	
Vibration resistance ^{*1} [m/s ²]			X:24.5, Y:24	.5	X: 24.5, Y: 49)	X: 24.5, Y: 29	.4		
Vibration rank			V10 ^{*3}							
Permissible	L	[mm]			79				Equipment	
load for the	Radial		980			2058				
shaft*2	Thrust		490		980				-	
Mass [kg]	Without electromagne		7.5	9.2	13	16	20	27		
11000 [109]	With electromagnetic b	orake	9.5	11	18	21	25	31		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 20 times or less.

7. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 22 times or less.

8. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 22 times or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-ST	7M2UWB	172UWB	202WB	352WB	502WB	702WB	_
Туре	Spring actuated type safety brake								
Rated voltage			24 V DC (-10 %	V DC (-10 % to 0 %)					
Power consumption	on	[W] at 20 °C	20		34				
Electromagnetic b friction torque	Electromagnetic brake static [N•m]			8.5 or higher 44 c		44 or higher			- <i>0</i> .
Permissible	Per braking	[J]	400		4500				
braking work	Per hour	[J]	4000		45000				U U
Electromagnetic	Number of brak	king times	20000		20000				
brake life (Note 2)	Work per brakir	ng [J]	200		1000				

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

4-41

LVS/Wires

Product List

HK-ST_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	130 × 130				
Rotary servo m	otor model HK-ST	353W	503W			
Continuous running duty	Rated output (Note 3) [kW]	2.6 (3.5)	5.0			
(Note 4)	Rated torque (Note 3, 5) [N•m]	8.3 (11.1)	15.9			
Maximum torqu	Ie (Note 3) [N•m]	24.8 (44.6)	47.8 (63.7)			
Rated speed (No	(r/min]	3000				
Maximum spee	d (Note 4) [r/min]	6700	6000			
Power rate at continuous rated torque	Without electromagnetic brake	40.5 (73.4)	91.5			
(Note 3) [kW/s]	With electromagnetic brake	35.9 (65.0)	84.7			
Rated current (N	lote 3) [A]	14 (19)	23			
Maximum current (Note 3) [A]		43 (83)	73 (100)			
Moment of	Without electromagnetic brake	16.9	27.7			
inertia J [× 10 ⁻⁴ kg•m²]	With electromagnetic brake	19.1	29.9			
Recommended	load to motor inertia ratio (Note 1)	10 times or less				
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)				
Туре		Permanent magnet synchronous motor				
Oil seal		None (Servo motors with an oil seal are available.)				
Electromagneti	c brake	None (Servo motors with an electromagnetic br	ake are available.)			
Thermistor		None				
Insulation class	5	155 (F)				
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2)				
Vibration resista	ance ^{*1} [m/s ²]	X: 24.5, Y: 49				
Vibration rank		V10 ⁻³				
Permissible	L [mm]	55				
load for the	Radial [N]	980				
shaft*2	Thrust [N]	490				
Maga [kg]	Without electromagnetic brake	9.1	13			
Mass [kg]	With electromagnetic brake	11	15			

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table. 2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through

portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-ST	353WB	503WB		
Туре		Spring actuated type safety brake	·		
Rated voltage		24 V DC (-10 % to 0 %)	24 V DC (-10 % to 0 %)		
Power consumption	on [W] at 20 °C	23			
Electromagnetic b friction torque	rake static [N•m]	16 or higher			
Permissible	Per braking [J]	400			
braking work	Per hour [J]	4000			
Electromagnetic Number of braking times		5000			
brake life (Note 2)	Work per braking [J]	400			

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

ပ္သ

HK-ST_4_W (Medium Inertia, Medium Capacity)

Flange size	[mm]] 130 × 130					Common ecificatio	
Rotary servo m	lotor model HK-ST	524W	1024W	1724W	2024AW	3024W	Common	
Continuous	Rated output [kW]	0.3	0.6	0.85	1.0	1.5		
running duty (Note 4)	Rated torque (Note 5) [N•m]	2.9	5.7	8.1	9.5	14.3	Sen	
Maximum torqu	ue (Note 3) [N•m]	11.5	17.2 (20.1)	24.4	33.4	43.0	Servo System Controllers	
Rated speed (No	ote 4) [r/min]] 1000					irs	
Maximum spee	d (Note 4) [r/min]	2000				1200		
Power rate at continuous	Without electromagnetic brake	13.9	37.9	57.8	53.9	91.5	Servo	
rated torque [kW/s]	With electromagnetic brake	10.1	30.1	48.3	47.8	83.6	Servo Amplifiers	
Rated current	[A ¹] 1.8	3.2	4.5	5.2	5.1	ifier	
Maximum curre	ent (Note 3) [A]] 8.3	11 (13)	17	20	17		
Moment of inertia J	Without electromagnetic brake	5.90	8.65	11.4	16.9	22.4	Rotary Servo Motors	
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	8.15	10.9	13.7	19.1	24.5	Motors	
	d load to motor inertia ratio (Note 1)	15 times or less	24 times or less		20 times or less	24 times or less	e vo	
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)						
Туре		Permanent magne	et synchronous mot	or				
Oil seal		None (Servo moto	ors with an oil seal a	are available.)			Motors	
Electromagneti	c brake	None (Servo motors with an electromagnetic brake are available.)						
Thermistor		None						
Insulation class	\$	155 (F)						
Structure			natural cooling (IP ra	ating: IP67) (Note 2)				
Vibration resista	ance ^{*1} [m/s ²]	X: 24.5, Y: 49						
Vibration rank		V10*3					Mo	
Permissible	L [mm]						Motors	
load for the		980					, a	
shaft*2		490	T	1	1	1		
Mass [kg]	Without electromagnetic brake		6.0	7.1	9.1	11		
	With electromagnetic brake	6.8	7.8	8.8	11	13	Eq	
2. The sha portion. 3. The valu	t your local sales office if the load to moto aft-through portion is excluded. Refer to t ues in brackets are applicable when the ymplifiers" in this catalog for the available	the asterisk 4 of "Annota torque is increased by co	tions for Rotary Servo N		-	-	Equipment	

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-ST	524WB	1024WB	1724WB	2024AWB	3024WB		
Туре			Spring actuate	Spring actuated type safety brake					
Rated voltage			24 V DC (-10	% to 0 %)					
Power consumpti	on	[W] at 20 °C	20			23			
Electromagnetic brake static [N•m]			8.5 or higher	3.5 or higher 16 or higher					
Permissible	Per braking	[J]	400			·			
braking work	Per hour	[J]	4000						
Electromagnetic Number of braking times			20000			5000			
brake life (Note 2)	Work per brakir	ng [J]	200			400			

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

Support

LVS/Wires

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	176 × 176					
Rotary servo m	notor model HK-ST	2024W	3524W	5024W	7024W		
Continuous	Rated output [kW]	1.2	2.0	3.0	4.2		
running duty	Rated torque (Note 5) [N•m]	11.5	19.1	28.6	40.1		
Maximum torq	ue (Note 3) [N•m]	40.1	57.3 (66.8)	85.9	120		
Rated speed (N	ote 4) [r/min]	1000			·		
Maximum spee	ed (Note 4) [r/min]	2000	1500	2000	1500		
Power rate at continuous	Without electromagnetic brake	36.1	68.0	116	153		
rated torque [kW/s]	With electromagnetic brake	31.7	62.3	108	146		
Rated current	[A]	6.0	9.0	16	17		
Maximum curre	ent (Note 3) [A]	24	32 (37)	52	60		
Moment of	Without electromagnetic brake	36.4	53.6	70.8	105		
inertia J [× 10 ⁻⁴ kg•m²]	With electromagnetic brake	41.4	58.6	75.8	110		
Recommended	d load to motor inertia ratio (Note 1)	23 times or less 22 times or less					
Speed/position	detector	Batteryless absolute/incremental 26-bit encoder (resolution: 67,108,864 pulses/rev)					
Туре		Permanent magnet synchronous motor					
Oil seal		None (Servo motors with an oil seal are available.)					
Electromagnet	ic brake	None (Servo motors with an electromagnetic brake are available.)					
Thermistor		None					
nsulation class	8	155 (F)					
Structure		Totally enclosed, natural cooling (IP rating: IP67) (Note 2)					
Vibration resist	tance ^{*1} [m/s ²]	X: 24.5, Y: 49 X: 24.5, Y: 29.4					
Vibration rank		V10*3					
Permissible	L [mm]						
oad for the		2058					
shaft*2		980					
Mass [kg]	Without electromagnetic brake		16	20	27		
hadd [hg]	With electromagnetic brake	18	21	25	31		

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-ST	2024WB	3524WB	5024WB	7024WB		
Туре			Spring actuated ty	Spring actuated type safety brake				
Rated voltage			24 V DC (-10 % to	24 V DC (-10 % to 0 %)				
Power consumption [W] at 20 °C			34					
Electromagnetic brake static [N•m] friction torque			44 or higher					
Permissible	Per braking	[J]	4500					
braking work	Per hour	[J]	45000					
Electromagnetic Number of braking times		20000						
brake life (Note 2)	Work per braking	g [J]	1000					

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications	when	connected	with a	a 400	V	servo amplifier
----------------	------	-----------	--------	-------	---	-----------------

								- 0.1
Flange size		L 3	130 × 130		1	1		Common Specifications
		HK-ST		1024W	1724W	2024AW	3024W	ns
Continuous	Rated output	ıt [kW]	0.5	1.0		2.0	3.0	_
(Note 4)	Rated torque	e ^(Note 3, 5) [N•m]	2.4 (3.2)	4.8 (6.4)	8.4	9.5 (11.6)	14.3	Con
Maximum torq	Je (Note 3)	[N•m]	7.2 (12.7)	14.3 (19.1)	25.1	28.6 (34.7)	43.0 (50.1)	Servo System Controllers
		[r/min]	2000 (1500)	2000 (1500)	2000	2000 (1650)	2000	
Maximum spee	(Note 3, 4) [r/n eed (Note 4) [r/n Without electromagnetic brake With electromagnetic brake (Note 3) rent (Note 3) Without electromagnetic brake Without electromagnetic brake Without electromagnetic brake With electromagnetic brake ed load to MR-J5 ratio (Note 1) MR-J5D in detector estic brake sss stance *1 [m		4000				2500	Ser
Power rate at continuous	Without elect	tromagnetic brake	9.7 (17.2)	26.3 (46.8)	61.2	53.9 (79.2)	91.5	Servo Amplifiers
(Note 3) [kW/s]	y servo motor model HK nuous g duty Rated output [Rated torque (Note 3, 5) [N num torque (Note 3, 4) [N speed (Note 3, 4) [r/n num speed (Note 4) [r/n num speed (Note 4) [r/n r rate at uous torque Without electromagnetic brake U urrent (Note 3) Num current (No	magnetic brake	(12.4)	20.9 (37.2)	51.1	47.8 (70.3)	83.6	lifiers
Rated current (Datary servo motor model HK- potary servo motor model HK- potary servo motor model Rated output [k potary servo motor model Rated output [k potary servo motor model Rated output [k Pated output [k Rated output [k Pated speed (Note 3, 4) [r/m [r/m aximum speed (Note 4) [r/m power rate at ntinuous Without electromagnetic brake W/s] Without electromagnetic brake M/s] Without electromagnetic brake M/s] Without electromagnetic brake poment of ertia J Without electromagnetic brake poment of position detector MR-J5 poment of position detector MR-J5 peed/position detector MR-J5 peed/position detector Image: seal seal sectomagnetic brake portation resistance *1 [m/minimiter seal seal sector seal sector seal seal seal sector seal seal seal seal seal seal seal seal	[A]	(2.0)	2.7 (3.5)	4.7	5.2 (6.3)	5.1	Rota N
Maximum curre	ent (Note 3)	[A]	5.1 (9.3)	8.8 (12)	16	17 (21)	17 (20)	Rotary Servo Motors
Moment of inertia J	With electromagnetic brake /s] With electromagnetic brake ed current (Note 3)	t electromagnetic brake 5.90 8.65 11.4 16.9					22.4	ò
[× 10 ⁻⁴ kg•m ²]	With electron		8.15	10.9	13.7	19.1	24.5	
				4 times or less (Note 7)	⁾ 4 times or less ^(Note 8)			Linear Servo Motors
motor inertia ra	atio (Note 1)		19 times or less	16 times or less	11 times or less	7 times or less (Note 8)		Motors
· ·	t of J Vithout electromagnetic brack (g•m²] With electromagnetic brack mended load to MR-J5 position detector				oit encoder (resolutio	on: 67,108,864 puls	es/rev)	- S
Туре	num speed (Note 4) [r/i r rate at uous torque Without electromagnetic bracked with electromagnetic bracked With electromagnetic bracked current (Note 3) Without electromagnetic bracked num current (Note 3) Without electromagnetic bracked num current (Note 3) Without electromagnetic bracked num current (Note 3) With electromagnetic bracked num current (Note 1) MR-J5 nmended load to inertia ratio (Note 1) MR-J5 l/position detector MR-J5 al D comagnetic brake Inton class ure Inton rank ssible L [r]		°	et synchronous moto				_
Oil seal	ended load to MR-J5 tia ratio (Note 1) MR-J5D sition detector			rs with an oil seal a	,			-
	ic brake			rs with an electroma	agnetic brake are av	vailable.)		
Thermistor			None					Motors
	<u>}</u>		155 (F)	turnel acceling (ID w	(Note 2)			- SIC
	tanaa *1	[m/s²]	X: 24.5, Y: 49	natural cooling (IP ra				- 0
			V10 ^{*3}					-
	1	[mm]						- С
load for the			980					Equipment
shaft*2	e resistance 1 n rank ible L Radial Thrust		490					- mer
	Without elec			6.0	7.1	9.1	11	- It
Mass [kg]			6.8	7.8	8.8	11	13	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through

portion. 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 19 times or less.

7. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 23 times or less. 8. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 24 times or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-ST	524WB	1024WB	1724WB	2024AWB	3024WB	
Туре			Spring actuated ty	pe safety brake				rec
Rated voltage			24 V DC (-10 % to	0 %)				aut
Power consumption	on	[W] at 20 °C	20			23		ions
Electromagnetic b friction torque	rake static	[N•m]	8.5 or higher			16 or higher		- 07
Permissible	Per braking	[J]	400					-
braking work	Per hour	[J]	4000					Sup
Electromagnetic	Number of braki	ng times	20000			5000		ppo
brake life (Note 2)	Work per braking	g [J]	200			400		ㅋ

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

LVS/Wires

Product List

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specifications when connected with a 400 V servo amplifier

Flange size		[mm]	176 × 176			
Rotary servo m	otor model	HK-ST	2024W	3524W	5024W	7024W
Continuous	tary servo motor model ntinuous Rated output ning duty Rated torque (Note 3) ted speed (Note 3, 4) ted speed (Note 3, 4) tximum speed (Note 4) wer rate at ottinuous ed torque 33 V/s] ted current (Note 3) ted current (Note 3) with electromagne attag With electromagne with electromagne ted current (Note 3) with electromagne comment of tria J 10-4 kg·m2] With electromagne commended load to no inertia ratio (Note 1) MR-actor inertia ratio (Note 1) MR-actor inertia ratio (Note 1) weak seal ectromagnetic brake ermistor ulation class ucture rration rank rrmissible L d for the aft *2 Thrust without electromagne	[kW]	2.0	3.5	5.0	7.0
running duty (Note 4)		(Note 3, 5) [N•m]	9.5 (12.7)	16.7 (20.3)	23.9 (28.9)	33.4
Maximum torqu	e (Note 3)	[N•m]	28.6 (38.2)	50.1 (60.8)	71.6 (86.8)	100
Rated speed (No	Rated output Rated output Rated output Rated output Rated torque (Note 3, 4) ximum torque (Note 3, 4) ximum speed (Note 4) wer rate at thinuous ed torque (Note 3) Without electromage (Note 3) With electromage (Note 3) wer rate at thinuous ed torque (Note 3) With electromage (Note 3) wer rate at thinuous ed torque (Note 3) With electromagne (Note 3) ximum current (Note 3) ximum current (Note 3) with electromagne (Note 1) With electromagne (Note 1) Of 4 kg•m2] Without electromagne (Note 1) Commended load to tor inertia ratio (Note 1) MR-J eed/position detector Peeseal ctromagnetic brake ermistor Permistor ulation class Permistance 1	[r/min]	2000 (1500)	2000 (1650)	2000 (1650)	2000
Maximum spee	4) Rated torque (Note 3, 4) kimum torque (Note 3, 4) ed speed (Note 3, 4) kimum speed (Note 4) ver rate at tinuous do torque (Note 3) ver rate at tinuous do torque (Note 3) with electromagne (Note 3) ed current (Note 3) ed current (Note 3) ment of tia J 0 ⁻⁴ kg•m ²] With electromagne commended load to or inertia ratio (Note 1) MR-J ed/position detector e seal ctromagnetic brake rmistor ulation class ucture ration resistance ^{*1} ration rank missible L d for the Radial	[r/min]	4000	3500	4000	3000
Power rate at continuous	Without elect	romagnetic brake	25.1 (44.6)	52.1 (76.5)	80.4 (118)	106
(Note 3) [kW/s]	ximum torque (Note 3) ted speed (Note 3, 4) ximum speed (Note 4) wer rate at titinuous ed torque 3) Without electromagne With electromagne With electromagne ted current (Note 3) ximum cur	nagnetic brake	22.0 (39.2)	47.7 (70.0)	75.2 (110)	101
Rated current (N	lote 3)	[A]	5.0 (6.7)	7.9 (9.5)	14 (16)	14
Maximum curre	ent (Note 3)	[A]	16 (23)	26 (33)	45 (55)	59
Moment of	Without elect	romagnetic brake	36.4	53.6	70.8	105
inertia J [× 10 ⁻⁴ kg•m ²]	With electron	nagnetic brake	41.4	58.6	75.8	110
Recommended	load to	MR-J5	4 times or less (Note 6)	5 times or less (Note 7)	4 times or less (Note 7)	8 times or less (Note 7)
motor inertia ra	tio (Note 1)	MR-J5D	2 times or less (Note 8)	4 times or less (Note 9)	2 times or less (Note 10)	2 times or less (Note 11)
Speed/position	detector		Batteryless absolute/ir	ncremental 26-bit encode	er (resolution: 67,108,86	1 pulses/rev)
Туре			Permanent magnet sy	nchronous motor		
Oil seal			None (Servo motors w	rith an oil seal are availa	ole.)	
Electromagneti	c brake		None (Servo motors w	ith an electromagnetic b	rake are available.)	
Thermistor			None			
Insulation class	i		155 (F)			
Structure	Mathematical Action Without electromagnetic ia J With electromagnetic ia J With electromagnetic por inertia ratio (Note 1) MR- por inerti		Totally enclosed, natur	al cooling (IP rating: IP6	7) (Note 2)	
Vibration resista	ance *1	[m/s ²]	X: 24.5, Y: 49		X: 24.5, Y: 29.4	
Vibration rank			V10 *3			
Permissible	L	[mm]	79			
load for the	ormended load to MR- cor inertia ratio (Note 1) MR- ed/position detector	[N]	2058			
shaft ^{⁺2}	tromagnetic brake mistor ation class cture ation resistance ^{*1} ation rank nissible for the t ^{*2} Radial Thrust	[N]	980			
Maga [kg]	IO-4 kg•m2] With electromagne commended load to tor inertia ratio (Note 1) MR-J MR-J eed/position detector MR-J beed/position class MR-J ucture MR-J ration resistance '1 MR-J ration rank MR-J missible L d for the Radial	romagnetic brake	13	16	20	27
wass [ky]	With electron	nagnetic brake	18	21	25	31

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion. 3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 20 times or less.

7. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 22 times or less.

8. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 12 times or less.

9. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 14 times or less. 10. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 10 times or less.

11. When the speed is 2000 r/min or less, the recommended load to motor inertia ratio is 7 times or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-S	C 2024WB	3524WB	5024WB	7024WB
Туре		Spring actuated type s	afety brake		
Rated voltage		24 V DC (-10 % to 0 %)		
Power consumption	on [W] at 20 °C	34			
Electromagnetic b friction torque	orake static [N•m] 44 or higher			
Permissible	Per braking [.] 4500			
braking work	Per hour [J] 45000			
Electromagnetic	Number of braking times	20000			
brake life (Note 2)	Work per braking [J] 1000			

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed. 4-46

g

HK-ST_4_W (Medium Inertia, Medium Capacity)

Specification	is when coi	nnected with a	400 V servo amplifier		Common Specifications
Flange size	-	[mm]	130 × 130		Imo
Rotary servo m	otor model	HK-ST	3534W	5034W	n
Continuous	Rated output	(Note 3) [kW]	2.6 (3.5)	5.0	
(Note 4)	Rated torque	(Note 3, 5) [N•m]	8.3 (11.1)	15.9	Servo Syste Controllers
Maximum torqu	Ie (Note 3)	[N•m]	24.8 (44.6)	47.8 (63.7)	System trollers
Rated speed (No	ote 4)	[r/min]	3000		
Maximum spee	d (Note 4)	[r/min]	6700	6000	S
Power rate at continuous	Without elect	tromagnetic brake	40.5 (73.4)	91.5	Servo Amplifiers
rated torque (Note 3) [kW/s]	With electron	nagnetic brake	35.9 (65.0)	84.7	plifiers
Rated current (*	lote 3)	[A]	6.9 (9.2)	12	Ro
Maximum curre	ent (Note 3)	[A]	22 (42)	37 (52)	Rotary Servo Motors
Moment of	Without elect	tromagnetic brake	16.9	27.7	ovre
inertia J [× 10 ⁻⁴ kg•m ²]	With electron	nagnetic brake	19.1	29.9	-
Recommended	load to	MR-J5	10 times or less	7 times or less	Lin
motor inertia ra	tio (Note 1)	MR-J5D	3 times or less (Note 6)	2 times or less (Note 7)	Linear Servo Motors
Speed/position	detector		Batteryless absolute/incremental 26-bit encod	er (resolution: 67,108,864 pulses/rev)	ors
Туре			Permanent magnet synchronous motor		0
Oil seal			None (Servo motors with an oil seal are availa		-
Electromagneti	c brake		None (Servo motors with an electromagnetic b	orake are available.)	
Thermistor			None		Direct Drive Motors
Insulation class	;		155 (F)		rect Dri Motors
Structure			Totally enclosed, natural cooling (IP rating: IP6	57) (Note 2)	S
Vibration resist	ance *1	[m/s ²]	X: 24.5, Y: 49		-
Vibration rank	1		V10 ⁻³		- 0
Permissible	L	[mm]			- E
load for the	Radial		980		ions/Periph Equipment
shaft*2	Thrust		490		Perip
Mass [kg]		tromagnetic brake		13	Options/Peripheral Equipment
		nagnetic brake	11 or inertia ratio exceeds the value in the table.	15	

1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table. Notes:

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 20 times or less.

7. When the speed is 3000 r/min or less, the recommended load to motor inertia ratio is 12 times or less.

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model	HK-ST	3534WB	5034WB	
Туре		Spring actuated type safety brake		
Rated voltage		24 V DC (-10 % to 0 %)		Pre
Power consumption	on [W] at 20 °C	23		recau
Electromagnetic b friction torque	orake static [N•m]	16 or higher		itions
Permissible	Per braking [J]	400		
braking work	Per hour [J]	4000		
Electromagnetic	Number of braking times	5000		S
brake life (Note 2)	Work per braking [J]	400		Suppo

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

LVS/Wires


Product List

When connected with a 200 V servo amplifier

E: For 3-phase 200 V AC - : For 1-phase 200 V AC


HK-ST52W






Torque increased 14 (

HK-ST52W



HK-ST102W (Note 2) Standard torque



HK-ST202AW (Note 2)

Standard torque

Short-duration running range

Continuous running range

1000 2000 3000

Speed [r/min]

4000

40.0

35.

30.

E^{25.}

Forque

20.


15.0

10.0


5.0


0.0

HK-ST102W (Note 2) Torque increased



HK-ST202AW Torque increased






HK-ST172W (Note 2)


Standard torgue

HK-ST302W Standard torque

HK-ST302W



Torque increased



1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of Notes: the effective load ratio.

0.0 L

60. 50.0

40.0

20.0

10.0

0.0

[N•m] 30. running range

1000

2000

Speed [r/min]

3000


4000

When connected with a 200 V servo amplifier


E: For 3-phase 200 V AC - : For 1-phase 200 V AC

HK-ST7M2UW


Standard torque




HK-ST202W (Note 2) Standard torque




HK-ST502W Standard torque




HK-ST353W Standard torque




HK-ST7M2UW



HK-ST202W Torque increased




HK-ST502W Torque increased




HK-ST353W Torque increased









HK-ST352W




HK-ST172UW Torque increased



HK-ST352W Torque increased







1000




Speed [r/min]


2000

3000

HK-ST503W Standard torque



HK-ST503W



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of the effective load ratio.

Linear Servo Motors

Common Specifications

Servo System Controllers

Servo Amplifiers


Rotary Servo Motors

Product

When connected with a 200 V servo amplifier

E : For 3-phase 200 V AC - : For 1-phase 200 V AC


HK-ST524W




4. 20 - Continuous running range 0.0 L 1000 1500 2000 Speed [r/min]

HK-ST1724W (Note 2)






HK-ST3024W (Note 2) Standard torque




HK-ST1024W


Standard torque




HK-ST1024W



HK-ST2024AW (Note 2) Standard torque



HK-ST2024W (Note 2) Standard torque




Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of the effective load ratio.

When connected with a 200 V servo amplifier


: For 3-phase 200 V AC : For 1-phase 200 V AC


HK-ST3524W (Note 2)

Standard targue




HK-ST3524W Torque increased





Speed [r/min]

HK-ST7024W



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of the effective load ratio.


Support

When connected with a 400 V servo amplifier


: For 3-phase 400 V AC : For 3-phase 380 V AC

HK-ST524W


Standard torque



HK-ST524W Torque increased



HK-ST1024W Standard torque



HK-ST2024AW

Standard torque

Short-duration running range

Continuous

running range

1000 2000

Speed [r/min]

3000

4000

40.0

35.0

30

Έ^{25.0}

20.

15.0


10.0

5.0


0.0 L

Torque

HK-ST1024W Torque increased




HK-ST2024AW Torque increased




HK-ST1724W






HK-ST3024W Standard torque



HK-ST3024W Torque increased




Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC

When connected with a 400 V servo amplifier


E: For 3-phase 400 V AC - : For 3-phase 380 V AC




Standard torque



HK-ST2024W Torque increased



HK-ST5024W





Standard torque

Short-duration running range

- Continuous running range

2000

4000

Speed [r/min]

50.0

45.0

40.0

35.0

25.0

15.0

10.0

5.0

0.0

둔 30.0 之

20.0

HK-ST3534W Torque increased

Continuous running rang

1000

2000

Speed [r/min]

3000

4000

HK-ST5024W

100.0

90.0

80.0

70.0

50.0 en 50.0

30.0

20.0


10.0


0.0 L

臣 60.0


Torque increased

Short-duration running range






HK-ST3524W Standard torque 70.0 60.0 50.0





HK-ST3524W Torque increased 70 0




Speed [r/min]

HK-ST7024W Standard torque






HK-ST5034W Standard torque



HK-ST5034W Torque increased



Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC

LVS/Wires

Support

Servo Amplifiers


Rotary Servo Motors

Linear Servo Motors


Direct Drive Motors

HK-ST Series Dimensions (Note 3, 4, 6)

HK-ST52W(B), HK-ST102W(B), HK-ST172W(B), HK-ST202AW(B), HK-ST302W(B), HK-ST524W(B), HK-ST1024W(B), HK-ST1724W(B), HK-ST2024AW(B), HK-ST3024W(B)



HK-ST7M2UW(B), HK-ST172UW(B)




Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are the same regardless of whether or not an oil seal is installed.
- 4. Use a friction coupling to fasten a load.
- 5. Only for the models with an electromagnetic brake.
- 6. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.
- 7. Use hexagonal cap head bolts when mounting the servo motor.

HK-ST Series Dimensions (Note 3, 4, 7)

HK-ST202W(B), HK-ST352W(B), HK-ST502W(B), HK-ST702W(B), HK-ST2024W(B), HK-ST3524W(B), HK-ST5024W(B), HK-ST7024W(B)



50.9 õ 0165 Ø t 13 024_{-0.013} 56.5 (Note 5 108. Encoder connector CMV1-R10P (Note 5) Electromagnetic brake connecto CMV1-R2P (Note 5) 29 (Note 18.8 13.5 35.5 5) 80 Power connector JL10-2E18-10PCE (MS3102A18-10P) Main key position marl Main key position mark Signal name P5 (Note 2) Encoder connector Electromagnetic brake connector C B Power connecto Variable dimensions (Note 1) Model В SHD HK-ST353W(B) 159.5 HK-ST3534W(B) (194) HK-ST503W(B) 203.5 HK-ST5034W(B) (238)

ΚL

103.8

147.8

[Unit: mm]

Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

- 2. The electromagnetic brake terminals do not have polarity.
- 3. The dimensions are the same regardless of whether or not an oil seal is installed.
- 4. Use a friction coupling to fasten a load.

(Note 5) 0.

Encode

Pin No.

1

2

3

4

5

(Note 5)

Signal

name

MRR

MR

LG

Pin No.

6

8

9

10

5. Only for the models with an electromagnetic brake.

6. HK-ST352W(B), HK-ST3524W(B), HK-ST502W(B), HK-ST5024W(B), HK-ST702W(B), and HK-ST7024W(B) have screw holes (M8) for eyebolts

7. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space


8. Use hexagonal cap head bolts when mounting the servo motor.

HK-ST Series with Special Shaft Dimensions

Servo motors with the following specifications are also available.

K: Keyed shaft (with a double round-ended key) (Note 1)


Madal	Variable	dimen	sions							
Model HK-ST52(4)WK HK-ST102(4)WK HK-ST172(4)WK HK-ST302(4)WK HK-ST302(4)WK HK-ST353(4)WK HK-ST353(4)WK HK-ST7M2UWK HK-ST172UWK HK-ST352(4)WK HK-ST502(4)WK	S	LR	Q	W	QK	QL	U	R	Т	Y
HK-ST52(4)WK										
HK-ST102(4)WK										
HK-ST172(4)WK										
HK-ST202(4)AWK										
HK-ST302(4)WK	24 .0.013	55	50	8	36	5	20.0	4	7	M8×20
HK-ST353(4)WK										
HK-ST503(4)WK										
HK-ST7M2UWK										
HK-ST172UWK										
HK-ST202(4)WK										
HK-ST352(4)WK	35 +0.010	79	75	10	55	5	30.0 12	5	8	M8×20
HK-ST502(4)WK	35 0	/9	/5	10	55	5	30 -0.12	5	°	IVIOX20
HK-ST702(4)WK										



[Unit: mm]

N: Keyed shaft (without a key) (Note 1, 2)

Model	Variable	dimer	isions						
Model	S	LR	Q	W	QK	QL	U	R	Υ
HK-ST52(4)WN HK-ST102(4)WN HK-ST172(4)WN HK-ST202(4)AWN HK-ST302(4)WN HK-ST353(4)WN HK-ST503(4)WN HK-ST702UWN HK-ST172UWN	24 ⁰ -0.013	55	50	8 ⁰ .036	36	5	20 .0.1	4	M8×20
HK-ST202(4)WN HK-ST352(4)WN HK-ST502(4)WN HK-ST702(4)WN	35 ^{+0.010}	79	75	10 ⁰ -0.036	55	5	30 ⁰ _{-0.12}	5	M8×20



[Unit: mm]

Notes: 1. Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft. 2. The servo motor is supplied without a key. The user needs to prepare a key.

			Moment of [× 10 ⁻⁴ kg•l		Permissible load to	Permis the sha	sible loa aft ^{*1}	d for	Mass [kg]		Lubrication	
Model HK-ST	Output [kW]	Reduction ratio	Without electro- magnetic brake	With electro- magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	Q [mm]	Radial [N]	Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method (Note 5)	Mounting direction
		1/6	6.72	8.97	_	35	2058	1470	17	19		
		1/11	6.29	8.54	_	35	2391	1470	17	19		
52G1		1/17	6.17	8.42	-	35	2832	1470	17	19	Grease	Any
24G1	0.5	1/29	6.11	8.36	4 times or less	35	3273	1470	17	19	(filled)	direction
		1/35	6.90	9.15	_	55	5253	2940	27	29	-	
		1/43	6.86	9.11	_	55 55	5253	2940	27	29		
		1/59 1/6	6.82 11.9	9.07		55	5880 2842	2940 2352	27 29	29 31		
		1/0	10.4	14.1	-	55 55	3273	2352	29	31	-	
		1/17	9.95	12.0	-	55	3646	2940	29	31	Grease	Any
02G1		1/29	9.65	11.9	-	55	4410	2940	29	31	(filled)	direction
024G1	1.0	1/35	9.65	11.9	4 times or less	55	5253	2940	29	31	-	
		1/43	10.9	13.1		70	6047	3920	48	50	Oil (Note 3)	Shaft
		1/59	16.2	18.4	-	90	9741	6860	80	82		horizontal (Note 4)
		1/6	14.6	16.9		55	2842	2352	30	32		
		1/11	13.1	15.4	-	55	3273	2764	30	32	Grease	Any
52G1		1/17	12.7	15.0	-	55	3646	2940	30	32	(filled)	direction
524G1	1.5	1/29	13.8	16.1	6.0 70 6047 3920 49 51 91.3 90 8555 6860 81 83 91.2 90 9741 6860 81 83	70	5135	3920	49	51		
ote 6)		1/35	13.7	16.0		70	6047	3920	49	51	Oil (Note 3)	
		1/43	19.0	21.3								
		1/59	18.9	21.2								
		1/6	39.6	44.6	_	55	2842	2352	37	42	Grease Any (filled) direction	
		1/11	38.0	43.0	-	55	3273	2764	37	42		
02G1		1/17	37.7	43.0 55 3273 2764 37 42 Grease (filled) 42.7 55 3646 2940 37 42 (filled)								
024G1	2.0	1/29	44.4	49.4	4 times or less	90	7291	6860	88	93	— Oil (Note 3)	Shaft
		1/35	44.1	49.1	-	90	8555	6860	88	93		horizontal (Note 4)
		1/43	43.9	48.9	-	90	8555	6860	88	93		
		1/59	43.8	48.8		90	9741	6860	88	93		
		1/6 1/11	62.1 57.8	67.1 62.8	-	70 70	3332 3871	3920 3920	59 59	63 63		
		1/17	56.5	61.5	-	70	4420	3920	59	63	Oil (Note 3)	
52G1	3.5	1/29	61.6	66.6	4 times or less	90	7291	6860	91	96		Shaft horizontal
524G1		1/35	61.3	66.3			8555	6860	91	96	-	(Note 4)
		1/43	80.0	85.0	-		11662	9800	135	140		
		1/59	79.0	84.0	90 90 90 90 90 90 90 90 90 90 90 90 110 110 110 90 90 90 90 90 90 90 90 90 90 90 90 90 90 90 90 90 91 110 110 110		13132	9800	135	140	Oil	
		1/6	97.1	102		90	5448	5000	94	99	Oil	
		1/11	85.1	90.1		90	5488	6292	94	99	Oil (Note 2)	1
		1/17	81.1	86.1		90	6468	6860	94	99	Oil (Note 3)	Shaft
02G1 024G1	5.0	1/29	112	117		110	13426	13720	165	170		horizontal
		1/35	111	116		110	16072	13720	165	170	Oil	(Note 4)
		1/43	110	115		110	16072	13720	165	170		
		1/59	109	114			16072	13720	165	170		
		1/6	131	136		-	7526	5000	100	105	1	
		1/11	144	149		7526	8085	145	150	-		
02G1		1/17	136	141		8683	9673	145	150		Shaft	
024G1	7.0	1/29	146	151		13426	13720	170	175	Oil	horizontal (Note 4)	
		1/35										
		1/43	146 221	151 226		16072 22540	13720 19600	170 240	175 245			

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

3. The oil lubricated servo motor cannot be used for applications where the servo motor moves. In that case, order a grease lubricated servo motor (special specification). The maximum speed of the grease lubricated servo motor is the same as that of the oil lubricated.

4. Do not mount the servo motor in a way that the servo motor is tilted to the shaft direction or to the shaft rotation direction. Refer to the asterisk 2 of "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog. Servo motors with special specifications may be available to be mounted with other than the shaft horizontal. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for the available models.

5. The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.

6. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N•m.) Refer to p. 4-58 in this catalog for the torque characteristics. The moment of inertia and electromagnetic brake specifications of HK-ST152(4) are the same as those of HK-ST172(4)W.

Support

general general general	
Item	Specifications
Mounting method	Flange mounting
Output shaft rotation direction	Opposite from the servo motor output shaft direction
Backlash (Note 3)	40 minutes to 2° at gear reducer output shaft (Note 2)
Maximum torque (at servo motor shaft)	Three times of the rated torque
(Note 4)	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 5)
Maximum speed (at servo motor shaft)	Grease lubricated: 3000 r/min
waximum speed (at serve motor shart)	Oil lubricated: 2000 r/min
IP rating (gear reducer part)	Equivalent to IP44
Gear reducer efficiency (Note 1)	85 % to 94 %

With a gear reducer for general industrial machines, flange mounting: G1

Notes: 1. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.

2. This is a designed value, not guaranteed value.


3. The backlash can be converted: 1 minute = 0.0167°

4. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) Refer to the torque characteristics on this page. The moment of inertia and electromagnetic brake specifications of HK-ST152(4) are the same as those of HK-ST172(4)W.


HK-ST152/HK-ST1524 Torque Characteristics (Note 1)

HK-ST152 (Note 2)



: For 3-phase 400 V AC : For 3-phase 380 V AC **HK-ST1524**

Standard torque



Notes: 1. Torque drops when the power supply voltage is below the specified value.

2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of the effective load ratio.

			Moment of [× 10 ⁻⁴ kg•		Permissible load to	Permis the sha	ssible loa aft ^{*1}	d for	Mass [kg]		Lutrication		Specifications
Model HK-ST	Output [kW]	Reduction ratio	Without electro-	With electro- magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	Q [mm]	Radial [N]	Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method (Note 5)	Mounting direction	s Controllers
		1/6	6.72	8.97		35	2058	1470	20	22			Circ
		1/11	6.29	8.54	1	35	2391	1470	20	22	1		0
		1/17	6.17	8.42	1	35	2832	1470	20	22	1		
52G1H 524G1H	0.5	1/29	6.11	8.36	4 times or less	35	3273	1470	20	22	Grease (filled)	Any direction	
02.0		1/35	6.90	9.15		55	5253	2940	28	30	(1	unoonen	
		1/43	6.86	9.11		55	5253	2940	28	30			
		1/59	6.82	9.07	<u>] </u>	55	5880	2940	28	30			
		1/6	11.9	14.1		55	2842	2352	30	32			
		1/11	10.4	12.6]	55	3273	2764	30	32			
		1/17	9.95	12.2	1	55	3646	2940	30	32	Grease (filled)	Any direction	
102G1H	1.0	1/29	9.65	11.9	4 times or less	55	4410	2940	30	32		uncouori	
1024G1H	1.0	1/35	9.65	11.9	4 times or less	55	5253	2940	30	32	1		
		1/43	10.9	13.1		70	6047	3920	49	51	Oil (Note 3)	Shaft horizontal	
		1/59	16.2 18.4 14.6 16.9 13.1 15.4 12.7 15.0 13.8 16.1		90	9741	6860	85	87	0	(Note 4)		
	1/6 14.6 10 1/11 13.1 19 1/17 12.7 19 1.5 1/29 13.8 10 1/35 13.7 10	16.9		55	2842	2352	31	33					
		1/11		+	1	55	3273	2764	31	33	Grease	Any	
152G1H			-	-	-	55	3646	2940	31	33	(filled)	direction	-
1524G1H	1.5				4 times or less	70	5135	3920	50	52	2 32 38 Oil (Note 3) Shaft horizontal (Note 4)		
(Note 6)				16.0		70	6047	3920	50	52	-	horizontal (Note 4)	0
		1/43	19.0	21.3	1	90	8555	6860	86	88	- Oil (Note 3)		
		1/59	18.9	21.2	1	90	9741	6860	86	88	-		
	<u> </u>	1/6	39.6	44.6		55	2842	2352	38	43	+		
		1/11	38.0	43.0	1	55	3273	2764	38	43	Grease		
		1/17	37.7	42.7	1	55	3646	2940	38	43	(filled)		-
202G1H	2.0	1/29	44.4	49.4	4 times or less	90	7291	6860	93	98	-		C
2024G1H		1/35	44.1	49.1	1	90	8555	6860	93	98	-	Shaft	
		1/43	43.9	48.9	1	90	8555	6860	93	98	Oil (Note 3)	horizontal (Note 4)	
		1/59	43.8	48.8	-	90	9741	6860	93	98	-	(((),	
		1/6	62.1	67.1		70	3332	3920	60	64			-
		1/11	57.8	62.8	-	70	3871	3920	60	64	1		
		1/17	56.5	61.5	1	70	4420	3920	60	64	Oil (Note 3)	Shaft	
352G1H 3524G1H	3.5	1/29	61.6	66.6	4 times or less	90	7291	6860	96	105	-	horizontal	
3524G I Π		1/35	61.3	66.3	1	90	8555	6860	96	105	1	(Note 4)	
		1/43	80.0	66.3	90	11662	9800	140	145	01	1		
	1/43 1/59 1/6 1/11	1/59	79.0	84.0	1	90	13132	9800	140	145	Oil		
		1/6	97.1	102		90	5448	5000	99	105	Oil		
		1/11	85.1	90.1	1	90	5488	6292	99	105			
		1/17	81.1	86.1	1	90	6468	6860	99	105	Oil (Note 3)	Note 3) Shaft horizontal (Note 4)	
502G1H 5024G1H	5.0	1/29	112	117	4 times or less	110	13426	13720	180	185			
5024GTH		1/35	111	116	1	110 16072 13720 180 185 110 16072 13720 180 185 110 16072 13720 180 185 110 16072 13720 180 185	(Note 4)						
		1/43	110	115									
		1/59	109	114									
		1/6	144 149 90 7526 8085 145 150 100 111 100 111 111 110 111 110										
		1/11											
		1/17											
702G1H	7.0	1/17 136 141 90 8683 9673 145 150 Shaft	horizontal										
7024G1H		1/35	146	151	1	110	16072	13720	185	190	1	(Note 4)	
		1/43	221	226	1	135	22540	19600	255	260	1		
	al.		+	+	-	135	+	+	255	260	4	1	

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

3. The oil lubricated servo motor cannot be used for applications where the servo motor moves. In that case, order a grease lubricated servo motor (special specification). The maximum speed of the grease lubricated servo motor is the same as that of the oil lubricated.

4. Do not mount the servo motor in a way that the servo motor is tilted to the shaft direction or to the shaft rotation direction. Refer to the asterisk 2 of "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog. Servo motors with special specifications may be available to be mounted with other than the shaft horizontal. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for the available models.

5. The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.

6. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N•m.) Refer to p. 4-58 in this catalog for the torque characteristics. The moment of inertia and electromagnetic brake specifications of HK-ST152(4) are the same as those of HK-ST172(4)W.

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

Support

With a gear reducer for general industrial machines, foot mounting: G1H

Item	Specifications
Mounting method	Foot mounting
Output shaft rotation direction	Opposite from the servo motor output shaft direction
Backlash (Note 3)	40 minutes to 2° at gear reducer output shaft (Note 2)
Maximum torque (at servo motor shaft)	Three times of the rated torque
(Note 4)	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 5)
Maximum speed (at servo motor shaft)	Grease lubricated: 3000 r/min
Maximum speed (at serve motor shart)	Oil lubricated: 2000 r/min
IP rating (gear reducer part)	Equivalent to IP44
Gear reducer efficiency (Note 1)	85 % to 94 %

Notes: 1. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.

This is a designed value, not guaranteed value.
 The backlash can be converted: 1 minute = 0.0167^e

4. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

5. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) Refer to p. 4-58 in this catalog for the torque characteristics. The moment of inertia and electromagnetic brake specifications of HK-ST152(4) are the same as those of HK-ST172(4)W.

					r Specifications for high precision ap	oplicati	ons, fla	ange m	ounting:	G5			Common Specifications
			Moment of [× 10 ⁻⁴ kg•		Permissible load to	Permis the sha	sible loa aft ^{*1}	d for	Mass [kg]				Common
Model HK-ST		Reduction ratio	Without electro- magnetic brake	With electro- magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	L [mm]		Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	Mounting direction	s Controllers
		1/5	6.55	8.80		32	416	1465	7.1	8.8			Sys
5005	1	1/11	6.46	8.71		32	527	1856	7.5	9.2			ers
52G5 524G5	0.5	1/21	8.80	11.1	10 times or less	57	1094	4359	11	13]		
02100	1	1/33	8.60	10.9		57	1252	4992	11	13]		S
		1/45	8.60	10.9		57	1374	5478	11	13			erv
		1/5	9.30	11.6		32	416	1465	8.0	9.7	1		οA
		1/11	12.0	14.2		57	901	3590	12	14	1		mp
102G5 1024G5	1.0	1/21	11.6	13.8	10 times or less	57	1094	4359	12	14	1		lifie
102-400		1/33	13.4	15.6		62	2929	10130	22	23	1	Servo Amplifiers Mo	
	1	1/45	13.3	15.5	1	62	3215	11117	22	23	Grease Any direction direction		
		1/5	12.1	14.4		32	416	1465	9.0	11	1		Rot
152G5		1/11	14.7	17.0		57	901	3590	13	15]		ary Mot
1524G5	1.5	1/21	17.1	19.4	10 times or less	62	2558	8845	23	24	Grease	Any	lors
(Note 3)		1/33	16.1	18.4		62	2929	10130	23	24	(filled)	direction	Š
	1	1/45	16.0	18.3	1	62	3215	11117	23	24	1`´		
		1/5	41.0	46.0		57	711	2834	20	25	1		
	1	1/11	40.8	45.8	-	57	901	3590	20	25	1		Linear Servo Motors
202G5 2024G5	2.0	1/21	42.8	47.8	10 times or less	62	2558	8845	30	35	1		ear Se Motors
202403	1	1/33	41.8	46.8		62	2929	10130	30	35	1		Se
		1/45	41.8	46.8	1	62	3215	11117	30	35	1		NO
		1/5	58.2	63.2		57	711	2834	23	28	1		
352G5 3524G5	3.5	1/11	61.7	66.7	10 times or less	62	2107	7285	33	38	1		
352403	1	1/21	60.0	65.0		62	2558	8845	33	38	1		Dir
502G5	- 0	1/5	80.9	85.9		62	1663	5751	34	39	1		rect Dri Motors
5024G5	5.0	1/11	78.9	83.9	10 times or less	62	2107	7285	36	41	1		Direct Drive Motors
702G5 7024G5	7.0	1/5	115	120	10 times or less	62	1663	5751	40	45			ve

		Opt
Item	Specifications	Options/Periph Equipment
Mounting method	Flange mounting	;/Pe
Output shaft rotation direction	Same as the servo motor output shaft direction	eriph ment
Backlash (Note 5)	3 minutes or less at gear reducer output shaft	iera
Maximum torque (at servo motor shaft)	Three times of the rated torque	
(Note 6)	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 3)	_
Maximum speed (at servo motor shaft)	3000 r/min	~~~~
IP rating (gear reducer part)	Equivalent to IP44	Š
Gear reducer efficiency (Note 4)	77 % to 92 %	ires

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

3. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) Refer to p. 4-58 in this catalog for the torque characteristics. The moment of inertia and electromagnetic brake specifications of HK-ST152(4) are the same as those of HK-ST172(4)W.

4. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.
5. The backlash can be converted: 1 minute = 0.0167°

6. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.

Precautions

Product List

			Moment of [× 10 ⁻⁴ kg•	m ²] (Note 1)	Permissible load to	the sha	sible loa aft ^{*1}	d for	Mass [kg]			
Model HK-ST		Reduction ratio	brake	With electro- magnetic brake	motor inertia ratio (Note 2) (when converted into the servo motor shaft)	Q [mm]		Thrust [N]	Without electro- magnetic brake	With electro- magnetic brake	Lubrication method	Mounting direction
		1/5	6.59	8.84		32	416	1465	7.5	9.2		
52G7		1/11	6.46	8.71		32	527	1856	7.7	9.4		
52G7 524G7	0.5	1/21	8.80	11.1	10 times or less	57	1094	4359	13	14		
		1/33	8.60	10.9		57	1252	4992	13	14		
		1/45	8.60	10.9		57	1374	5478	13	14		
		1/5	9.34	11.6		32	416	1465	8.4	11		
		1/11	12.1	14.3		57	901	3590	14	15		
102G7 1024G7	1.0	1/21	11.6	13.8	10 times or less	57	1094	4359	14	15		
102107		1/33	13.4 15.6			62	2929	10130	25	26		
		1/45	13.4	15.6		62	3215	11117	25	26		
		1/5	12.1	14.4		32	416	1465	9.4	11		
152G7		1/11	14.8	17.1		57	901	3590	15	16		
	1.5	1/21	17.1	19.4	10 times or less	62	2558	8845	26	27	Grease	Any
(Note 3)		1/33	16.1	18.4		62	2929	10130	26	27	(filled)	direction
		1/45	16.1	18.4		62	3215	11117	26	27		
		1/5	41.3	46.3		57	711	2834	21	26		
		1/11	40.9	45.9		57	901	3590	22	27	1	
202G7 2024G7	2.0	1/21	42.9	47.9	10 times or less	62	2558	8845	33	38		
202407		1/33	41.8	46.8	1	62	2929	10130	33	38		
		1/45	41.8	46.8		62	3215	11117	33	38		
		1/5	58.5	63.5		57	711	2834	24	29		
352G7 3524G7	3.5	1/11	62.0	67.0	10 times or less	62	2107	7285	36	41	1	
002407		1/21	60.1	65.1	1	62	2558	8845	36	41	1	
502G7		1/5	82.3	87.3	10 1/2010	62	1663	5751	37	42	1	
5024G7	5.0	1/11	79.2	84.2	10 times or less	62	2107	7285	39	44	1	
702G7 7024G7	7.0	1/5	117	122	10 times or less	62	1663	5751	43	48	1	

With a shaft-output type gear reducer for high precision applications, flange mounting: G7

Item	Specifications
Mounting method	Flange mounting
Output shaft rotation direction	Same as the servo motor output shaft direction
Backlash (Note 5)	3 minutes or less at gear reducer output shaft
Maximum torque (at servo motor shaft)	Three times of the rated torque
(Note 6)	(Refer to HK-ST series specifications in this catalog for the rated torque.) (Note 3)
Maximum speed (at servo motor shaft)	3000 r/min
IP rating (gear reducer part)	Equivalent to IP44
Gear reducer efficiency (Note 4)	77 % to 92 %

Notes: 1. The moments of inertia in the table are the values that are converted into the shaft of the servo motor with a gear reducer (and with an electromagnetic brake).

2. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table. 3. The torque characteristics of HK-ST152(4) are equivalent to those of HK-ST172(4)W that are derated by the output ratio of HK-ST172(4)W (1.75 kW) to HK-ST152(4) (1.5 kW). (The rated torque of HK-ST152(4) is 7.2 N·m.) Refer to p. 4-58 in this catalog for the torque characteristics. The moment of inertia and electromagnetic brake specifications of HK-ST152(4) are the same as those of HK-ST172(4)W.

4. The gear reducer efficiency varies depending on the reduction ratio and the conditions of use such as an output torque, speed, and temperature. The values in the table are not guaranteed as they are representative values at the rated torque and speed at a temperature of 20 °C.
5. The backlash can be converted: 1 minute = 0.0167°

6. The torques of the geared servo motors do not increase even when these servo motors are combined with larger capacity servo amplifiers.

Refer to "Annotations for Geared Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1.


Common Specifications

HK-ST Series Geared Servo Motor Dimensions (Note 1, 5)

With a gear reducer for general industrial machines, flange mounting

HK-ST_G1 (Note 6)

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws and the oil cap may differ from the drawing.



Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

2. The electromagnetic brake terminals do not have polarity.

3. Only for the models with an electromagnetic brake.

4. The dimensions in brackets are for the models with an electromagnetic brake.

5. The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.


6. This geared servo motor has a keyed shaft (with a key).

Support

HK-ST Series Geared Servo Motor Dimensions (Note 1, 5)

With a gear reducer for general industrial machines, foot mounting HK-ST_G1H $^{(Note\;6)}$

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws and the oil cap may differ from the drawing.



Model	Reduc-	Variable	dimens	sions (I	Note 4))																							_			
HK-ST	tion ratio	L	LA	LB	LK	LS	LT	LP	LW	н	KL	KA	KB	KD	KC	KE	Z	FA	FB	FC	FD	FE	FF	FG	FH	Q	QK	S	Т	U	W	Y
52(B)G1H 524(B)G1H	1/6 1/11 1/17 1/29	320.5 (355)	100	219	150	(29)	35.5 (39.5)	(56.5)	13.5	121	55.7 (90.2)	18.8	108.8	(79.9)	130	80	11	90	135	60	15	12	40	150	180	35	32	28 .0.013	7	24	8	M8×20
324(b)0111	1/35 1/43 1/59	334 (368.5)	120	252	204	(29)	35.5 (39.5)	(56.5)	13.5	131	55.7 (90.2)	18.8	108.8	(79.9)	130	80	14	115	155	82	20	15	55	190	230	55	50	38 ⁰ -0.016	8	33	10	
102(B)G1H 1024(B)G1H	1/6 1/11 1/17 1/29 1/35	345 (379.5)	120	252	204	(29)	35.5 (39.5)	(56.5)	13.5	131	55.7 (90.2)	18.8	108.8	(79.9)	130	80	14	115	155	82	20	15	55	190	230	55	50	38 ⁰ .0.016	8	33	10	M8×20
1024(B)GTH	1/43	397.5 (432)	150	295	230	(29)	35.5 (39.5)	(56.5)	13.5	170	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	145	195	100	25	22	65	290	330	70	56	50 ⁰ -0.016	9	44.5	14	M10×18
	1/59	468 (502.5)	160	352	300	(29)	35.5 (39.5)	(56.5)	13.5	218	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	150	238	139	44	25	75	370	410	90	80	60 ⁰ -0.019	11	53	18	WITUX 18
152(B)G1H	1/6 1/11 1/17	356 (390.5)	120	252	204	(29)	35.5 (39.5)	(56.5)	13.5	131	55.7 (90.2)	18.8	108.8	(79.9)	130	80	14	115	155	82	20	15	55	190	230	55	50	38 .0.016	8	33	10	M8×20
152(B)G1H	1/29 1/35	408.5 (443)	150	295	230	(29)	35.5 (39.5)	(56.5)	13.5	170	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	145	195	100	25	22	65	290	330	70	56	50 ⁰ -0.016	9	44.5	14	
	1/43 1/59	479 (513.5)	160	352	300	(29)	35.5 (39.5)	(56.5)	13.5	218	55.7 (90.2)	18.8	108.8	(79.9)	130	80	18	150	238	139	44	25	75	370	410	90	80	60 ⁰ -0.019	11	53	18	M10×18
202(B)G1H	1/6 1/11 1/17	375 (424.5)	120	262	204	(44)	35.5 (42.5)	(62.5)	0	131	57.8 (107.3)	22.6	140.8	(96.9)	176	80	14	115	155	82	20	15	55	190	230	55	50	38 ⁰ -0.016	8	33	10	M8×20
2024(B)G1H	1/29 1/35 1/43 1/59	492 (541.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60 ⁰ _{-0.019}	11	53	18	M10×18
352(B)G1H	1/6 1/11 1/17	444.5 (494)	150	295	230	(44)	35.5 (42.5)	(62.5)	0	170	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	145	195	100	25	22	65	290	330	70	56	50 ⁰ -0.016	9	44.5	14	M10×18
3524(B)G1H	1/29 1/35	512 (561.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60 ⁰ -0.019	11	53	18	
	1/43 1/59	556.5 (606)	200	381	340	(44)	35.5 (42.5)	(62.5)	0	262	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	275	335	125	30	30	80	380	430	90	80	70 .0.019	12	62.5	20	M12×24
502(B)G1H	1/6 1/11 1/17	532 (581.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60 ⁰ -0.019	11	53	18	M10×18
5024(B)G1H	1/29 1/35 1/43 1/59	616.5 (666)	220	405	370	(44)	35.5 (42.5)	(62.5)	0	279	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	320	380	145	30	30	85	420	470	110	100	80 .0.019	14	71	22	M12×24
	1/6	572 (621.5)	160	341	300	(44)	35.5 (42.5)	(62.5)	0	218	57.8 (107.3)	22.6	140.8	(96.9)	176	80	18	150	238	139	44	25	75	370	410	90	80	60 ⁰ -0.019	11	53	18	M10×18
702(B)G1H	1/11 1/17	616.5 (666)	200	381	340	(44)	35.5 (42.5)	(62.5)	0	262	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	275	335	125	30	30	80	380	430	90	80	70.0.019	12	62.5	20	M12×24
7024(B)G1H	1/29 1/35	656.5 (706)	220	405	370	(44)	35.5 (42.5)	(62.5)	0	279	57.8 (107.3)	22.6	140.8	(96.9)	176	80	22	320	380	145	30	30	85	420	470	110	100	80 .0.019	14	71	22	
	1/43 1/59	747.5 (797)	250	465	430	(44)	35.5 (42.5)	(62.5)	0	330	57.8 (107.3)	22.6	140.8	(96.9)	176	80	26	380	440	170	30	35	90	480	530	135	125	95 ⁰ _{-0.022}	14	86	25	M20×34

[Unit: mm]

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

2. The electromagnetic brake terminals do not have polarity.

Only for the models with an electromagnetic brake.
 The dimensions in brackets are for the models with an electromagnetic brake.

5. The lubricant oil is removed from the gear reducer before shipment, and thus please purchase the required lubricant oil and fill the oil into the gear reducer.

6. This geared servo motor has a keyed shaft (with a key).


Model

Reduc- Variable dimensions (Note 4)

HK-ST Series Geared Servo Motor Dimensions (Note 1)

With a flange-output type gear reducer for high precision applications, flange mounting HK-ST_G5

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.



Model	Reduc-	Variabl	e dimen	sions (N	ote 4)																							
HK-ST	tion ratio	L	LA	LB	LC	LD	LE	LF	LG	LH	LK	LM	LT	KL	LP	LW	LS	т	N	Р	R	м	КВ	KD	кс	KE	Front view	
52(B)G5	1/5	210.5 (245)	105	45	85.0	90	59	24 ^{+0.021}	27 +0.4	8	10	85	35.5 (39.5)	154.8	(56.5)	13.5	(29)	5	6	M6	10	9	108.8	(79.9)	130	80	A	
524(B)G5	1/21 1/33 1/45	222.5 (257)	135	60	115.0000	120	84	32 +0.025	35 +0.4	13	13	94	35.5 (39.5)	166.8	(56.5)	13.5	(29)	5	6	M8	12	11	108.8	(79.9)	130	80	A	Motors
	1/5	221.5 (256)	105	45	85.0.035	90	59	24 ^{+0.021}	27 ^{+0.4} •0.5	8	10	85	35.5 (39.5)	165.8	(56.5)	13.5	(29)	5	6	M6	10	9	108.8	(79.9)	130	80	A	SJC
102(B)G5 1024(B)G5	1/11 1/21	233.5 (268)	135	60	115.0.035	120	84	32 +0.025	35 +0.4	13	13	94	35.5 (39.5)	177.8	(56.5)	13.5	(29)	5	6	M8	12	11	108.8	(79.9)	130	80	A	
	1/33	249.5 (284)	190	100	165.0	170	122	47 +0.025	53 ^{+0.5}	13	16	107	35.5 (39.5)	193.8	(56.5)	13.5	(29)	7	14	M8	12	14	108.8	(79.9)	130	80	в	
	1/5	232.5 (267)	105	45	85.0.035	90	59	24 ^{+0.021}	27 ^{+0.4}	8	10	85	35.5 (39.5)	176.8	(56.5)	13.5	(29)	5	6	M6	10	9	108.8	(79.9)	130	80	A	
152(B)G5	1/11	244.5 (279)	135	60	115.0	120	84	32 +0.025	35 +0.4	13	13	94	35.5 (39.5)	188.8	(56.5)	13.5	(29)	5	6	M8	12	11	108.8	(79.9)	130	80	A	quip
1524(B)G5	1/21 1/33 1/45	260.5 (295)	190	100	165.0003	170	122	47 ^{+0.025}	53 ^{+0.5}	13	16	107	35.5 (39.5)	204.8	(56.5)	13.5	(29)	7	14	M8	12	14	108.8	(79.9)	130	80	в	Equipment
202(B)G5	1/5 1/11	267.5 (317)	135	60	115.0	120	84	32 +0.025	35+0.4	13	13	116	35.5 (42.5)	209.7	(62.5)	0	(44)	5	6	M8	12	11	140.8	(96.9)	176	80	A	
202(B)G5	1/21 1/33 1/45	287.5 (337)	190	100	165.0	170	122	47 +0.025	53 ^{+0.5}	13	16	133	35.5 (42.5)	229.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	в	
352(B)G5	1/5	287.5 (337)	135	60	115 ⁰ -0.035	120	84	32 +0.025	35 +0.4	13	13	116	35.5 (42.5)	229.7	(62.5)	0	(44)	5	6	M8	12	11	140.8	(96.9)	176	80	A	
3524(B)G5	1/11 1/21	307.5 (357)	190	100	165.0	170	122	47 +0.025	53 ^{+0.5}	13	16	133	35.5 (42.5)	249.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	в	S/WIres
502(B)G5 5024(B)G5	1/5 1/11	327.5 (377)	190	100	165.0003	170	122	47 ^{+0.025}	53 ^{+0.5}	13	16	133	35.5 (42.5)	269.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	в	Ires
702(B)G5 7024(B)G5	1/5	367.5 (417)	190	100	165.0	170	122	47 ^{+0.025}	53 ^{+0.5}	13	16	133	35.5 (42.5)	309.7	(62.5)	0	(44)	7	14	M8	12	14	140.8	(96.9)	176	80	в	

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

2. The electromagnetic brake terminals do not have polarity.

3. Only for the models with an electromagnetic brake.

4. The dimensions in brackets are for the models with an electromagnetic brake.

5. HK-ST202(B)G5 to HK-ST702(B)G5 and HK-ST2024(B)G5 to HK-ST7024(B)G5 have the maximum dimensions of 180 mm x 180 mm in this part.

6. For the front view B, the screws are not placed at equal intervals.

[Unit: mm]


Common Specifications


Servo Amplifiers

HK-ST Series Geared Servo Motor Dimensions (Note 1, 5)

With a shaft-output type gear reducer for high precision applications, flange mounting HK-ST G7 $^{(Note 7)}$

The drawing is schematic only. The actual shapes of the servo motors and the location of the mounting screws may differ from the drawing.





[Unit: mm]

Model	Reduc-	Variable o	dimension	s (Note 4)																			
HK-ST	tion ratio	L	LA	LC	LD	LE	S	LG	LH	Q	LR	LK	LM	LT	KL	LP	LW	LS	M	KB	KD	KC	KE
52(B)G7	1/5 1/11	210.5 (245)	105	85 ⁰ .035	90	59	25 .0.021	27	8	42	80	10	85	35.5 (39.5)	154.8	(56.5)	13.5	(29)	9	108.8	(79.9)	130	80
524(B)G7	1/21 1/33 1/45	222.5 (257)	135	115.0.035	120	84	40 .0.025	35	13	82	133	13	94	35.5 (39.5)	166.8	(56.5)	13.5	(29)	11	108.8	(79.9)	130	80
	1/5	221.5 (256)	105	85 .0.035	90	59	25 .0.021	27	8	42	80	10	85	35.5 (39.5)	165.8	(56.5)	13.5	(29)	9	108.8	(79.9)	130	80
102(B)G7 1024(B)G7	1/11 1/21	233.5 (268)	135	115.0.035	120	84	40 .0.025	35	13	82	133	13	94	35.5 (39.5)	177.8	(56.5)	13.5	(29)	11	108.8	(79.9)	130	80
	1/33 1/45	249.5 (284)	190	165.0.063	170	122	50 .0.025	53	13	82	156	16	107	35.5 (39.5)	193.8	(56.5)	13.5	(29)	14	108.8	(79.9)	130	80
	1/5	232.5 (267)	105	85 .0.035	90	59	25 .0.021	27	8	42	80	10	85	35.5 (39.5)	176.8	(56.5)	13.5	(29)	9	108.8	(79.9)	130	80
152(B)G7	1/11	244.5 (279)	135	115.0.035	120	84	40 .0.025	35	13	82	133	13	94	35.5 (39.5)	188.8	(56.5)	13.5	(29)	11	108.8	(79.9)	130	80
1524(B)G7	1/21 1/33 1/45	260.5 (295)	190	165.0000	170	122	50 .0.025	53	13	82	156	16	107	35.5 (39.5)	204.8	(56.5)	13.5	(29)	14	108.8	(79.9)	130	80
202(B)G7	1/5 1/11	267.5 (317)	135	115.0.035	120	84	40 .0.025	35	13	82	133	13	116	35.5 (42.5)	209.7	(62.5)	0	(44)	11	140.8	(96.9)	176	80
2024(B)G7	1/21 1/33 1/45	287.5 (337)	190	165.0000	170	122	50 .0.025	53	13	82	156	16	133	35.5 (42.5)	229.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80
352(B)G7	1/5	287.5 (337)	135	115.0.035	120	84	40 .0.025	35	13	82	133	13	116	35.5 (42.5)	229.7	(62.5)	0	(44)	11	140.8	(96.9)	176	80
3524(B)G7	1/11 1/21	307.5 (357)	190	165.0	170	122	50 .0.025	53	13	82	156	16	133	35.5 (42.5)	249.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80
502(B)G7 5024(B)G7	1/5 1/11	327.5 (377)	190	165.0	170	122	50 ⁰ _{-0.025}	53	13	82	156	16	133	35.5 (42.5)	269.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80
702(B)G7 7024(B)G7	1/5	367.5 (417)	190	165.00063	170	122	50 .0.025	53	13	82	156	16	133	35.5 (42.5)	309.7	(62.5)	0	(44)	14	140.8	(96.9)	176	80

Notes: 1. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

2. The electromagnetic brake terminals do not have polarity.

3. Only for the models with an electromagnetic brake.

4. The dimensions in brackets are for the models with an electromagnetic brake.

5. Use a friction coupling to fasten a load.

6. HK-ST202(B)G7 to HK-ST702(B)G7 and HK-ST2024(B)G7 to HK-ST7024(B)G7 have the maximum dimensions of 180 mm × 180 mm in this part.

7. HK-ST_G7K, a geared servo motor with a keyed shaft (with a key), is also available. Refer to "HK-ST Series Geared Servo Motor Special Shaft Dimensions" in this catalog for details.

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment


HK-ST Series Geared Servo Motor Special Shaft Dimensions

The standard HK-ST_G7 (with a shaft-output type gear reducer for high precision applications, flange mounting) has a straight shaft. Note that this motor is also available with a keyed shaft (with a key) as HK-ST_G7K.

HK-ST_G7K (Note 1, 2)

Keyed shaft (with a single pointed key)

Model	Reduction ratio	Variat	ole dim	ensions	6			
woder	neulon ralio	S	Q	W	QK	U	Т	Y
	1/5	25	42	8	36	21	7	M6×12
	1/11	25	42	°	30	21	ľ	IVIOX 12
HK-ST52(B)G7K HK-ST524(B)G7K	1/21							
TIK OTSZ4(D)G/TK	1/33	40	82	12	70	35	8	M10×20
	1/45							
	1/5	25	42	8	36	21	7	M6×12
HK-ST102(B)G7K	1/11	40	82	12	70	35	8	M10×20
HK-ST102(B)G7K	1/21	40	02	12	10	00	0	1011020
111C-011024(D)0/1C	1/33	50	82	14	70	44.5	9	M10×20
	1/45	50	02	14	10	44.5	9	10110220
	1/5	25	42	8	36	21	7	M6×12
HK-ST152(B)G7K	1/11	40	82	12	70	35	8	M10×20
HK-ST1524(B)G7K	1/21							
	1/33	50	82	14	70	44.5	9	M10×20
	1/45							
	1/5	40	82	12	70	35	8	M10×20
HK-ST202(B)G7K	1/11	40	02	12	10	35	0	10110220
HK-ST202(B)G7K HK-ST2024(B)G7K	1/21							
TIK-312024(D)G/K	1/33	50	82	14	70	44.5	9	M10×20
	1/45							
	1/5	40	82	12	70	35	8	M10×20
HK-ST352(B)G7K	1/11							
HK-ST3524(B)G7K	1/21							
HK-ST502(B)G7K	1/5	50	82	14	70	44.5	9	M10×20
HK-ST5024(B)G7K	1/11		02	'-	10			10110220
HK-ST702(B)G7K HK-ST7024(B)G7K	1/5							



[Unit: mm]

1. Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft.

Notes: 2. Dimensions not shown in the tables are the same as those of HK-ST_G7 with a straight shaft. Refer to "HK-ST_G7" of "HK-ST Series Geared Servo Motor Dimensions" in this catalog.

Support

HK-RT_W (Ultra-Low Inertia, Medium Capacity)

Specifications when connected with a 200 V servo amplifier

Flange size	[mm]	90 × 90			130 × 130		
Rotary servo n	notor model HK-RT	103W	153W	203W	353W	503W	703W
Continuous	Rated output [kW]	1.0	1.5	2.0	3.5	5.0	7.0
running duty (Note 4)	Rated torque (Note 5) [N•m]	3.2	4.8	6.4	11.1	15.9	22.3
Maximum torq	ue (Note 3) [N•m]	8.0 (9.5)	11.9 (12.9)	15.9 (19.1)	27.9 (33.4)	47.7 (55.7)	66.8
Rated speed (N	lote 4) [r/min]	3000					
Maximum spee	ed (Note 4) [r/min]	6700			6000		5000
Power rate at continuous	Without electromagnetic brake	141	251	317	280	403	655
rated torque [kW/s]	With electromagnetic brake	95.6	182	249	189	301	512
Rated current	[A]	5.2	11	9.5	16	25	28
Maximum curr		17 (21)	34 (42)	30 (37)	51 (62)	90 (110)	102
Moment of inertia J	Without electromagnetic brake	0.721	0.909	1.28	4.44	6.29	7.58
[× 10 ⁻⁴ kg•m ²]	With electromagnetic brake	1.06	1.25	1.63	353W 503W 3.5 5.0 11.1 15.9 27.9 47.7 (33.4) (55.7) 6000 6000 280 403 189 301 16 25 51 90 (62) (110) 4.44 6.29 6.57 8.41 10 times or less coder (resolution: 67,108,864 pulses/reference) railable.) tic brake are available.) Totally enclosed, natural cooling (IP rating: IP67) (Note 2) X: 24.5, Y: 24.5 55 980 490 13 17	9.70	
Recommende	l load to motor inertia ratio (Note 1)	11 times or les	S		10 times o	r less	
Speed/positior	n detector	Batteryless ab	solute/incren	nental 26-bit enc	oder (resolution	: 67,108,864 pul	ses/rev)
Туре		Permanent ma	,				
Oil seal		None (Servo n	notors with a	n oil seal are ava	ailable.)		
Electromagnet	ic brake	None (Servo n	notors with a	n electromagnet	ic brake are ava	ilable.)	
Thermistor		None					
Insulation clas	S	155 (F)					
Structure		Totally enclose (IP rating: IP67	,	oling		,	oling
Vibration resis	tance ^{*1} [m/s ²]	X: 24.5, Y: 49			X: 24.5, Y:	24.5	
Vibration rank		V10*3					
Permissible	L [mm]	40			55		
load for the	Radial [N	686			980		
shaft*2	Thrust [N	196			490		
	Without electromagnetic brake	3.6	4.4	5.9	13	17	20
Mass [kg]	With electromagnetic brake	4.7	5.5	7.0	15	19	23

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.
 When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque.

6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

Model		HK-RT	103WB	153WB	203WB	353WB	503WB	703WB
Туре			Spring actuated	type safety	brake			
Rated voltage			24 V DC (-10 %	s to 0 %)				
Power consumptio	n	[W] at 20 °C	13.8			23		
Electromagnetic bi friction torque	rake static	[N•m]	9.5 or higher			16 or higher		
Permissible	Per braking	[J]	64			400		
braking work	Per hour	[J]	640			4000		
Electromagnetic	Number of bra	aking times	5000					
brake life (Note 2)	Work per brak	ting [J]	64			400		

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.

2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

HK-RT_4W (Ultra-Low Inertia, Medium Capacity)

Flange size		[mm]	90 × 90			130 × 130			
Rotary servo i	motor model		1034W	1534W	2034W	3534W	5034W	7034W	
Continuous	Rated output			1.5	2.0	3.5	5.0	7.0	0
running duty	Rated torque	(Note 5) [N•m]	3.2	4.8	6.4	11.1	15.9	22.3	6
Maximum toro	ue (Note 3)	[N•m]	8.0 (9.5)	11.9 (12.9)	15.9 (19.1)	27.9 (33.4)	47.7 (55.7)	66.8	
Rated speed (Note 4)	[r/min]	3000	·					Ű
Maximum spe	ed (Note 4)	[r/min]	6700			6000		5000	
Power rate at continuous	Without electr	romagnetic brake	141	251	317	280	403	655	
rated torque [kW/s]	With electrom	nagnetic brake	95.6	182	249	189	301	512	
Rated current		[A]	2.6	5.3	4.7	7.8	13	14	
Maximum cur	rent (Note 3)	[A]	8.5 (11)	18 (20)	15 (19)	26 (31)	45 (55)	51	
Moment of	Without elect	romagnetic brake	0.721	0.909	1.28	4.44	6.29	7.58	
inertia J [× 10 ⁻⁴ kg•m ²]	With electrom	nagnetic brake	1.06	1.25	1.63	6.57	8.41	9.70	
Recommende	d load to	MR-J5	11 times or	less		10 times or	less		
motor inertia r	atio (Note 1)	MR-J5D	11 times or	less		10 times or	less		
Speed/positio	n detector					oder (resolution:	67,108,864 puls	ses/rev)	
Туре				magnet synchro					
Oil seal				o motors with ar		,			_
Electromagne	tic brake			o motors with ar	n electromagnet	c brake are avai	lable.)		
Thermistor			None						_
Insulation clas	S		155 (F)						
Structure			Iotally encl (IP rating: II	osed, natural co	oling	(IP rating: II	osed, natural co	oling	
Vibration resis	stance *1	[m/e2]	X: 24.5, Y: 4	,		X: 24.5, Y: 2			
Vibration rank		[11/5-]	X. 24.3, 1.4 V10*3	49		A. 24.5, 1.7	24.5		=
Permissible	<u> </u>	[mm]				55			
load for the	Radial		686			980			- 1
shaft*2	Thrust		196			490			_
			3.6	4.4	5.9	13	17	20	
Mass [kg]		nagnetic brake	4.7	5.5	7.0	15	19	23	:

2. The shaft-through portion is excluded. Refer to the asterisk 4 of "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for the shaft-through portion.

3. The values in brackets are applicable when the torque is increased by combining a larger-capacity servo amplifier. Refer to "Combinations of Rotary Servo Motors and Servo Amplifiers" in this catalog for the available combinations.

4. The continuous running duty and the speed are not guaranteed when the power supply voltage is dropped.

5. When unbalanced torque is generated, such as in a vertical lift machine, keep the unbalanced torque of the machine under 70 % of the servo motor rated torque. 6. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Refer to "Annotations for Rotary Servo Motor Specifications" on p. 4-79 in this catalog for details about asterisks 1 to 3.

Electromagnetic brake specifications (Note 1)

									. ă
Model		HK-RT	1034WB	034WB 1534WB 2034WB 3534WB 5034WB 7034WB				oduct	
Туре			Spring actuated	pring actuated type safety brake					List
Rated voltage			24 V DC (-10 %	V DC (-10 % to 0 %)					it
Power consumption	on [V	N] at 20 °C	13.8			23			
Electromagnetic b friction torque	rake static	[N•m]	9.5 or higher			16 or higher			Prec
Permissible	Per braking	[J]	64			400			auti
braking work	Per hour	[J]	640			4000			utions
Electromagnetic	Number of brakin	ng times	5000						
brake life (Note 2)	Work per braking	g [J]	64			400			

Notes: 1. The electromagnetic brake is for holding. It cannot be used for deceleration applications.


2. Brake gap is not adjustable. Electromagnetic brake life is defined as the time period until readjustment is needed.

LVS/Wires


Pro

When connected with a 200 V servo amplifier


E: For 3-phase 200 V AC - : For 1-phase 200 V AC




HK-RT103W (Note 2) Torque increased



HK-RT203W (Note 2) Standard torque



HK-RT503W Standard torque



HK-RT503W Torque increased

HK-RT203W

15.0

5.0

0.0

Forgue [N•m]

Torque increased

ı Short-duratior

ining nge

Continuo


running range

2000


4000

Speed [r/min]

6000 6700




HK-RT153W (Note 2) Standard torque




HK-RT353W


Standard torque




HK-RT153W



HK-RT353W Torque increased







Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 170 V AC 2. When using a combination of the servo motors of over 750 W and MR-J5-100_ or MR-J5-200_ with a 1-phase power supply, use the servo amplifiers at 75 % or less of the effective load ratio.

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires


HK-RT_4W Torque Characteristics (Note 1)

When connected with a 400 V servo amplifier


E: For 3-phase 400 V AC - : For 3-phase 380 V AC




Standard torque




HK-RT1034W Torque increased




HK-RT2034W Standard torque




HK-RT2034W Torgue increased 25.0




HK-RT5034W Standard torque



HK-RT5034W Torque increased





6000 6700

0.0

40.0

35.0

30.0

F25.0

i] 20.0 Lordne

10.0

5.0

0.0 L

2000

HK-RT3534W

Standard torque

Short-durat unning

Continuou running ra

2000

4000


Speed [r/min]

6000


4000

Speed [r/min]


HK-RT1534W Torque increased




HK-RT3534W Torque increased










Notes: 1. Torque drops when the power supply voltage is below the specified value. ----: A rough indication of the possible continuous running range for 3-phase 323 V AC

Product


HK-RT Series Dimensions (Note 3, 4, 5)

HK-RT103W(B), HK-RT153W(B), HK-RT203W(B) HK-RT1034W(B), HK-RT1534W(B), HK-RT2034W(B)



[Unit: mm]

HK-RT353W(B), HK-RT503W(B), HK-RT703W(B) HK-RT3534W(B), HK-RT5034W(B), HK-RT7034W(B)



Notes: 1. The dimensions in brackets are for the models with an electromagnetic brake.

2. The electromagnetic brake terminals do not have polarity.

3. The dimensions are the same regardless of whether or not an oil seal is installed.

4. Use a friction coupling to fasten a load.

5. The actual dimensions may be up to 3 mm larger than those shown in the drawing because of shifting and variance of parts that occur during the assembly and manufacture of the rotary servo motors. The dimensions and tolerances shown are applicable at a temperature of 20 °C and may vary depending on the ambient temperature. Design the machine to allow for sufficient space.

6. The dimensions are applicable when a dual type motor cable is led to the load side. Refer to "HK-RT Series Connector Dimensions" in this catalog for the dimensions when leading the cable to the opposite to the load side or leading vertically and when using a single type motor cable.

Only for the models with an electromagnetic brake.
 HK-BT703W(B) and HK-BT7034W(B) have screw holes (M6x10.5) for evenates. When using evena

8. HK-RT703W(B) and HK-RT7034W(B) have screw holes (M6×10.5) for eyebolts. When using eyebolts, use a washer of ø14 mm or larger. Tighten the bolt until the washer is closely attached to the servo motor's surface.

9. Use hexagonal cap head bolts when mounting the servo motor

HK-RT Series Connector Dimensions

Cable direction: load side/opposite to load side

	Variable dimensions							
Model	Dual cable type			Single cable type				
	A	В	С	D	A	В	С	D
HK-RT103(4)W								
HK-RT153(4)W	61.6	36	11.7	31.5	64.4	32	11.7	40
HK-RT203(4)W								

Cable direction: vertical

Model

Model

HK-RT103(4)WK HK-RT153(4)WK

HK-RT203(4)WK HK-RT353(4)WK HK-RT503(4)WK

HK-RT703(4)WK

HK-RT103(4)WN

HK-RT153(4)WN

HK-RT203(4)WN HK-RT353(4)WN HK-RT503(4)WN

HK-RT703(4)WN

	Variable dimensions						
Model	Dual cable type			Single cable type			
	A	В	С	A	В	С	
HK-RT103(4)W HK-RT153(4)W	88.2	36	11.7	96.7	32	11.7	
HK-RT203(4)W	00.2	50	11.7	30.7	52		

HK-RT Series with Special Shaft Dimensions Servo motors with the following specifications are also available.

K: Keyed shaft (with a double round-ended key) (Note 1)

Q

50 8

36

W

QK QL

25 5

36 5

QK QL

25 5

36

U

15.5.0 3 6

20.0 4

U

15.5.0 3

20.0

R Т

R

4

7

M5×20

M8×20

V

M5×20

M8×20

Variable dimensions

LR

S

19^{.0}.013 40 36 6

24 ⁰-0.013 55

N: Keyed shaft (without a key) (Note 1, 2)


19.0013 40

24 ⁰-0.013

Variable dimensions

LR Q

55 50



Cable direction: load side

ŁĽ

* The drawing shows a dual cable type as an example

* The drawing shows a dual cable type as an example [Unit: mm]

<u>H</u> H

Direct Drive Motors

LVS/Wires

[Unit: mm]

[Unit: mm]







Do not use the servo motors with a keyed shaft for frequent start/stop applications as this may cause the damage to the shaft. Notes:

5

Notoo	1. Do not use the serve maters with a knowledge of far fragment start/star applications as this may source

2. The servo motor is supplied without a key. The user needs to prepare a key.

W

6.0.03

8.0.036

LR Q QK QL A-A

LR Q OK QL D ဖွ



Cable direction: opposite to load side

11.5

3





Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo

1-axis servo amplifiers (200 V)

Rotary servo motor		Servo amplifier	Power supply capacity [kVA] (Note 1)	Rotary servo	motor	Servo amplifier	Power supply capacity [kVA] (Note
		MR-J5-10G/B/A	0.3			MR-J5-20G/B/A	0.6
	HK-KT053W	MR-J5-20G/B/A	0.3		HK-KT434W	MR-J5-40G/B/A	0.6
		MR-J5-40G/B/A	0.3			MR-J5-60G/B/A	0.6
		MR-J5-10G/B/A	0.3			MR-J5-40G/B/A	0.8
	HK-KT13W	MR-J5-20G/B/A	0.3		HK-KT634W	MR-J5-60G/B/A	0.8
		MR-J5-40G/B/A	0.3			MR-J5-70G/B/A	0.8
		MR-J5-20G/B/A	0.5			MR-J5-40G/B/A	0.9
	HK-KT1M3W	MR-J5-40G/B/A	0.5		HK-KT7M34W	MR-J5-60G/B/A	0.9
		MR-J5-60G/B/A	0.5			MR-J5-70G/B/A	0.9
		MR-J5-10G/B/A	0.3			MR-J5-60G/B/A	1.1
	HK-KT13UW	MR-J5-20G/B/A	0.3	нк-кт 4 W	HK-KT1034W	MR-J5-70G/B/A	1.1
		MR-J5-40G/B/A	0.3			MR-J5-100G/B/A	1.1
		MR-J5-20G/B/A	0.5			MR-J5-70G/B/A	1.5
	HK-KT23W	MR-J5-40G/B/A	0.5		HK-KT1534W	MR-J5-100G/B/A	1.5
		MR-J5-60G/B/A	0.5		111(1(11)0400	MR-J5-200G/B/A	1.5
		MR-J5-40G/B/A	0.9			MR-J5-100G/B/A	1.9
	HK-KT43W	MR-J5-60G/B/A	0.9		HK-KT2034W	MR-J5-200G/B/A	1.9
	1111-114300	MR-J5-70G/B/A	0.9		1111-11203400	MR-J5-350G/B/A	2.0
		MR-J5-70G/B/A	1.3			MR-J5-100G/B/A	1.9
	HK-KT63W	MR-J5-100G/B/A	1.3		HK-KT2024W	MR-J5-200G/B/A	1.9
		MR-J5-200G/B/A	1.3			MR-J5-350G/B/A	2.1
		MR-J5-20G/B/A	0.5		HK-MT053W	MR-J5-10G/B/A	0.3
	HK-KT23UW	MR-J5-40G/B/A	0.5			MR-J5-20G/B/A	0.3
нк-кт_w нк-кт4зuw нк-кт7мзw	MR-J5-60G/B/A	0.5			MR-J5-40G/B/A	0.3	
	MR-J5-40G/B/A	0.8			MR-J5-10G/B/A	0.3	
	MR-J5-60G/B/A	0.8		HK-MT13W	MR-J5-20G/B/A	0.4	
	MR-J5-70G/B/A	0.8			MR-J5-40G/B/A	0.4	
	MR-J5-70G/B/A	1.3		HK-MT1M3W	MR-J5-20G/B/A	0.5	
	MR-J5-100G/B/A	1.3			MR-J5-40G/B/A	0.5	
		MR-J5-200G/B/A	1.3	HK-MT_W	HK-MT23W	MR-J5-20G/B/A	0.5
		MR-J5-100G/B/A	1.9		1111-10112500	MR-J5-40G/B/A	0.6
	HK-KT103W	MR-J5-200G/B/A	1.9		HK-MT43W	MR-J5-40G/B/A	0.9
		MR-J5-350G/B/A	2.0			MR-J5-70G/B/A	0.9
		MR-J5-60G/B/A	1.3			MR-J5-70G/B/A	1.2
	HK-KT63UW	MR-J5-70G/B/A	1.3		HK-MT63W	MR-J5-200G/B/A	1.2
		MR-J5-100G/B/A	1.1			MR-J5-70G/B/A	1.3
		MR-J5-70G/B/A	1.3		HK-MT7M3W	MR-J5-200G/B/A	1.6
	HK-KT7M3UW	MR-J5-100G/B/A	1.3			MR-J5-100G/B/A	1.8
		MR-J5-200G/B/A	1.3		HK-MT103W	MR-J5-200G/B/A	2.0
		MR-J5-100G/B/A	1.8			MR-J5-10G/B/A	0.3
	HK-KT103UW	MR-J5-200G/B/A	1.8		HK-MT053VW	MR-J5-20G/B/A	0.3
		MR-J5-350G/B/A	1.8			MR-J5-40G/B/A	0.3
		MR-J5-200G/B/A	2.6			MR-J5-10G/B/A	0.3
	HK-KT153W	MR-J5-350G/B/A	2.8		HK-MT13VW	MR-J5-20G/B/A	0.4
HK-KT203W		MR-J5-200G/B/A	3.2			MR-J5-40G/B/A	0.4
	MR-J5-350G/B/A	3.6			MR-J5-20G/B/A	0.5	
	MR-J5-200G/B/A	3.3		HK-MT1M3VW	MR-J5-40G/B/A	0.5	
	HK-KT202W	MR-J5-350G/B/A	3.6			MR-J5-20G/B/A	0.5
		INIT 1-03-03000/D/A	0.0	HK-MT_VW	HK-MT23VW	MR-J5-40G/B/A	
							0.6
					HK-MT43VW	MR-J5-60G/B/A	0.9
						MR-J5-70G/B/A	0.9
					HK-MT63VW	MR-J5-70G/B/A	1.2
						MR-J5-200G/B/A	1.2
					HK-MT7M3VW	MR-J5-70G/B/A	1.3
						MR-J5-200G/B/A	1.6

Notes: 1. The power supply capacity varies depending on the power supply impedance. 2. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

MR-J5-200G/B/A

MR-J5-350G/B/A

HK-MT103VW

2.0

2.0

LVS/Wires

Options/Peripheral Equipment

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Support

Rotary Servo Motors

Power Supply Capacity

1-axis servo amplifiers (200 V)

Rotary servo motor		Servo amplifier	Power supply capacity [kVA] (Note 1)
		MR-J5-60G/B/A	1.0
	HK-ST52W	MR-J5-70G/B/A	1.0
		MR-J5-100G/B/A	1.0
		MR-J5-100G/B/A	1.7
	HK-ST102W	MR-J5-200G/B/A	1.7
		MR-J5-350G/B/A	1.8
		MR-J5-200G/B/A	3.0
	HK-ST172W	MR-J5-350G/B/A	3.2
		MR-J5-200G/B/A	3.5
	HK-ST202AW	MR-J5-350G/B/A	3.5
		MR-J5-350G/B/A	4.9
	HK-ST302W	MR-J5-500G/B/A	4.9
		MR-J5-350G/B/A	5.5
HK-ST W	HK-ST353W	MR-J5-500G/B/A	7.4
Note 3)		MR-J5-500G/B/A	7.5
	HK-ST503W	MR-J5-700G/B/A	10
		MR-J5-70G/B/A	1.3
	HK-ST7M2UW	MR-J5-100G/B/A	1.3
		MR-J5-200G/B/A	1.3
	HK-ST172UW	MR-J5-200G/B/A	
			3.0
		MR-J5-350G/B/A	3.2
	HK-ST202W	MR-J5-200G/B/A	3.5
		MR-J5-350G/B/A	3.5
	HK-ST352W	MR-J5-350G/B/A	5.5
		MR-J5-500G/B/A	5.5
	HK-ST502W	MR-J5-500G/B/A	7.5
		MR-J5-700G/B/A	7.8
	HK-ST702W	MR-J5-700G/B/A	10
	HK-ST524W	MR-J5-40G/B/A	0.7
		MR-J5-60G/B/A	0.7
		MR-J5-70G/B/A	0.7
		MR-J5-60G/B/A	1.3
	HK-ST1024W	MR-J5-70G/B/A	1.3
		MR-J5-100G/B/A	1.3
		MR-J5-100G/B/A	1.7
	HK-ST1724W	MR-J5-200G/B/A	1.7
		MR-J5-350G/B/A	1.8
		MR-J5-100G/B/A	1.9
	HK-ST2024AW	MR-J5-200G/B/A	1.9
HK-ST_4_W		MR-J5-350G/B/A	2.0
		MR-J5-200G/B/A	2.6
	HK-ST3024W	MR-J5-350G/B/A	2.8
		MR-J5-200G/B/A	2.1
	HK-ST2024W	MR-J5-350G/B/A	2.2
		MR-J5-200G/B/A	3.2
			1
	HK-ST3524W		3.5
	HK-ST3524W	MR-J5-350G/B/A	3.5 4.9
	HK-ST3524W HK-ST5024W	MR-J5-350G/B/A MR-J5-350G/B/A	4.9
		MR-J5-350G/B/A	

				Common Specifications
Rotary servo motor		Servo amplifier	Power supply capacity [kVA] (Note 1)	mon cations
HK-RT103W		MR-J5-100G/B/A	1.7	0,
	HK-H1103W	MR-J5-200G/B/A	1.7	(0)
	HK-RT153W	MR-J5-200G/B/A	2.5	Servo Cont
	HK-H1155W	MR-J5-500G/B/A	3.1	/o S
	HK-RT203W	MR-J5-200G/B/A	3.5	ervo System Controllers
HK-RT_W		MR-J5-350G/B/A	3.5	tem
		MR-J5-350G/B/A	5.5	
	HK-RT353W	MR-J5-500G/B/A	6.4	S
	HK-RT503W	MR-J5-500G/B/A	7.5	DANK
	HK-H1503W	MR-J5-700G/B/A	8.8	An
	HK-RT703W	MR-J5-700G/B/A	13	npli
				Servo Amplifiers

Notes: 1. The power supply capacity varies depending on the power supply impedance. 2. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output. 3. A power supply capacity for HK-ST152G_ is 2.5 kVA.

1-axis servo amplifiers (400 V)

Rotary servo	motor	Servo amplifier	Power supply capacity [kVA] (Note 1)	Rotary servo	motor	Servo amplifier	Power supply capacity [kVA] (Note 1)
		MR-J5-60G4/B4/A4	0.3			MR-J5-60G4/B4/A4	1.0
	HK-KT053W	MR-J5-100G4/B4/A4	0.3		HK-ST524W	MR-J5-100G4/B4/A4	1.0
		MR-J5-60G4/B4/A4	0.5			MR-J5-200G4/B4/A4	
IK-KT_W	HK-KT13W	MR-J5-100G4/B4/A4	0.4			MR-J5-100G4/B4/A4	1.7
		MR-J5-60G4/B4/A4	0.6		HK-ST1024W	MR-J5-200G4/B4/A4	1.7
	HK-KT1M3W	MR-J5-100G4/B4/A4	0.6			MR-J5-350G4/B4/A4	1.7
			1.2			MR-J5-200G4/B4/A4	3.2
	HK-KT434W	MR-J5-100G4/B4/A4	1.1		HK-ST1724W	MR-J5-350G4/B4/A4	3.2
		MR-J5-200G4/B4/A4	1.1			MR-J5-500G4/B4/A4	3.2
		MR-J5-100G4/B4/A4	1.5			MR-J5-200G4/B4/A4	3.5
	HK-KT634W	MR-J5-200G4/B4/A4	1.6		HK-ST2024AW	MR-J5-350G4/B4/A4	3.5
		MR-J5-350G4/B4/A4	1.6			MR-J5-500G4/B4/A4	3.5
		MR-J5-100G4/B4/A4	1.8		HK-ST3024W	MR-J5-350G4/B4/A4	4.9
	HK-KT7M34W	MR-J5-200G4/B4/A4	1.8	HK-ST_4_W		MR-J5-500G4/B4/A4	4.9
	MR-J5-350G4/B4/A4		(Note 3)		MR-J5-700G4/B4/A4		
		MR-J5-100G4/B4/A4			HK-ST3534W	MR-J5-350G4/B4/A4	
	HK-KT1034W	MR-J5-200G4/B4/A4				MR-J5-500G4/B4/A4	
HK-KT_4_W	MR-J5-350G4/B4/A4				MR-J5-500G4/B4/A4		
		1.3		HK-ST5034W	MR-J5-700G4/B4/A4		
	MR-J5-100G4/B4/A4	1.3			MR-J5-200G4/B4/A4		
		MR-J5-200G4/B4/A4			HK-ST2024W	MR-J5-350G4/B4/A4	
		MR-J5-100G4/B4/A4	1.7			MR-J5-500G4/B4/A4	
	HK-KT1034UW	MR-J5-200G4/B4/A4			HK-ST3524W	MR-J5-350G4/B4/A4	
		MR-J5-350G4/B4/A4				MR-J5-500G4/B4/A4	
		MR-J5-200G4/B4/A4				MR-J5-700G4/B4/A4	
	HK-KT1534W	MR-J5-350G4/B4/A4				MR-J5-500G4/B4/A4	
		MR-J5-200G4/B4/A4			HK-ST5024W	MR-J5-700G4/B4/A4	
	HK-KT2034W	MR-J5-350G4/B4/A4			HK-ST7024W	MR-J5-700G4/B4/A4	
		MR-J5-200G4/B4/A4				MR-J5-100G4/B4/A4	
	HK-KT2024W	MR-J5-350G4/B4/A4			HK-RT1034W	MR-J5-200G4/B4/A4	
						MR-J5-200G4/B4/A4	
					HK-RT1534W	MR-J5-500G4/B4/A4	
						MR-J5-200G4/B4/A4	
				HK-RT 4W	HK-RT2034W	MR-J5-350G4/B4/A4	
						MR-J5-350G4/B4/A4	
					HK-RT3534W	MR-J5-500G4/B4/A4	
						MR-J5-500G4/B4/A4	
					HK-RT5034W	MR-J5-700G4/B4/A4	
							1.0

Notes: 1. The power supply capacity varies depending on the power supply impedance. 2. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

HK-RT7034W MR-J5-700G4/B4/A4 10

3. A power supply capacity for HK-ST1524G_ is 2.5 kVA.

Multi-axis servo amplifiers (200 V)

Rotary servo	motor	Servo amplifier (Note 3)	Power supply capacity [kVA] (Note 1, 2)	
		MR-J5W2-22G/B	0.3	
		MR-J5W2-44G/B	0.3	
	HK-KT053W	MR-J5W3-222G/B	0.3	
		MR-J5W3-444G/B	0.3	
		MR-J5W2-22G/B	0.3	
		MR-J5W2-44G/B	0.3	
	HK-KT13W			
		MR-J5W3-222G/B	0.3	
		MR-J5W3-444G/B	0.3	
		MR-J5W2-22G/B	0.5	
	HK-KT1M3W	MR-J5W2-44G/B	0.5	
		MR-J5W3-222G/B	0.5	
		MR-J5W3-444G/B	0.5	
		MR-J5W2-22G/B	0.3	
		MR-J5W2-44G/B	0.3	
	HK-KT13UW	MR-J5W3-222G/B	0.3	
		MR-J5W3-444G/B	0.3	
		MR-J5W2-22G/B	0.5	
		MR-J5W2-44G/B	0.5	
	HK-KT23W	MR-J5W3-222G/B	0.5	
		MR-J5W3-444G/B	0.5	
-IK-KT W		MR-J5W2-44G/B	0.9	
	HK-KT43W	MR-J5W2-77G/B	0.9	
		MR-J5W2-1010G/B	0.9	
		MR-J5W3-444G/B	0.9	
		MR-J5W2-77G/B	1.3	
	HK-KT63W	MR-J5W2-1010G/B	1.3	
		MR-J5W2-22G/B	0.5	
	HK-KT23UW	MR-J5W2-44G/B	0.5	
		MR-J5W3-222G/B	0.5	
		MR-J5W3-444G/B	0.5	
	HK-KT43UW	MR-J5W2-44G/B	0.8	
		MR-J5W2-77G/B	0.8	
		MR-J5W2-1010G/B	0.8	
		MR-J5W3-444G/B	0.8	
	НК-КТ7МЗW	MR-J5W2-77G/B	1.3	
		MR-J5W2-1010G/B	1.3	
	HK-KT103W	MR-J5W2-1010G/B	1.9	
		MR-J5W2-77G/B	1.3	
	HK-KT63UW	MR-J5W2-1010G/B	1.3	
		MR-J5W2-77G/B	1.3	
	HK-KT7M3UW	MR-J5W2-1010G/B	1.3	
	HK-KT103UW	MR-J5W2-1010G/B	1.3	
	111-1110304			
		MR-J5W2-22G/B	0.6	
	HK-KT434W	MR-J5W2-44G/B	0.6	
		MR-J5W3-222G/B	0.6	
		MR-J5W3-444G/B	0.6	
		MR-J5W2-44G/B	0.8	
		MR-J5W2-77G/B	0.8	
	HK-KT634W	MR-J5W2-1010G/B	0.8	
		MR-J5W3-444G/B	0.8	
		MR-J5W2-44G/B	0.9	
HK-KT_4_W		MR-J5W2-77G/B	0.9	
	HK-KT7M34W	MR-J5W2-1010G/B	0.9	
		MR-J5W3-444G/B	0.9	
	HK-KT1034W	MR-J5W2-77G/B	1.1	
		MR-J5W2-1010G/B	1.1	
	HK-KT1534W	MR-J5W2-77G/B	1.5	
	11111100411	MR-J5W2-1010G/B	1.5	
	HK-KT2034W	MR-J5W2-1010G/B	1.9	

				Con Specif	
Rotary servo	motor	Servo amplifier (Note 3)	Power supply capacity [kVA] (Note 1, 2)	Common Specifications	
		MR-J5W2-22G/B	0.3	-	
		MR-J5W2-44G/B	0.3	Servo System Controllers	
	HK-MT053W	MR-J5W3-222G/B	0.3		
		MR-J5W3-444G/B	0.3	o Syst htrolle	
		MR-J5W2-22G/B	0.4	ster	
		MR-J5W2-44G/B	0.4	m	
	HK-MT13W	MR-J5W3-222G/B	0.4	v	
		MR-J5W3-444G/B	0.4	Servo Amplifiers	
		MR-J5W2-22G/B	0.5	° A	
		MR-J5W2-44G/B	0.5	mp	
	HK-MT1M3W	MR-J5W3-222G/B	0.5	olifie	
		MR-J5W3-444G/B	0.5	Sle	
HK-MT_W		MR-J5W2-22G/B	0.5		
	HK-MT23W	MR-J5W2-44G/B	0.5	Ro	
		MR-J5W3-222G/B	0.5	Rotary Servo Motors	
		MR-J5W3-444G/B	0.5	ary Sei Motors	
		MR-J5W2-44G/B	0.9	s	
	HK-MT43W	MR-J5W2-77G/B	0.9	- 0	
	HK-MT63W	MR-J5W2-1010G/B	0.9		
		MR-J5W3-444G/B	0.9	:	
		MR-J5W2-77G/B	1.2	nea Mc	
		MR-J5W2-1010G/B	1.2	lear Ser Motors	
		MR-J5W2-77G/B	1.3	Linear Servo Motors	
		MR-J5W2-1010G/B	1.3		
	HK-MT103W	MR-J5W2-1010G/B	1.8		
		MR-J5W2-22G/B	0.3		
	HK-MT053VW	MR-J5W2-44G/B	0.3	Mo	
		MR-J5W3-222G/B	0.3	rect Driv Motors	
		MR-J5W3-444G/B	0.3	Direct Drive Motors	
	HK-MT13VW	MR-J5W2-22G/B	0.4	_	
		MR-J5W2-44G/B	0.4	0	
		MR-J5W3-222G/B	0.4	Options/Peripheral Equipment	
		MR-J5W3-444G/B	0.4	ions/Periph Equipment	
		MR-J5W2-22G/B	0.5	Peri	
	HK-MT1M3VW	MR-J5W2-44G/B	0.5	phe	
HK-MT VW		MR-J5W3-222G/B	0.5	ral	
		MR-J5W3-444G/B	0.5	-	
		MR-J5W2-22G/B	0.5		
		MR-J5W2-44G/B	0.5	/S/	
	-	MR-J5W3-222G/B	0.5	LVS/Wires	
		MR-J5W3-444G/B	0.5	es	
	HK-MT43VW	MR-J5W2-77G/B	0.9	-	
		MR-J5W2-1010G/B	0.9	-	
	HK-MT63VW	MR-J5W2-77G/B	1.2	Pro	
		MR-J5W2-1010G/B	1.2	Product List	
	HK-MT7M3VW	MR-J5W2-77G/B	1.3	- ct L	
		MR-J5W2-1010G/B	1.3	- ist	
	HK-ST52W	MR-J5W2-77G/B	1.0	-	
LIK OT M		MR-J5W2-1010G/B	1.0	-	
HK-ST_W	HK-ST102W	MR-J5W2-1010G/B	1.7	Pre	
	HK-ST7M2UW	MR-J5W2-77G/B	1.3	эса	
		MR-J5W2-1010G/B	1.3	Precautions	
		MR-J5W2-44G/B	0.7	ns	
	HK-ST524W	MR-J5W2-77G/B	0.7	-	
		MR-J5W3-444G/B	0.7	-	
HK-ST_4_W	HK-ST1024W	MR-J5W2-77G/B	1.3	(0	
		MR-J5W2-1010G/B	1.3	gup	
	HK-ST1724W	MR-J5W2-1010G/B	1.7	Support	
	HK-ST2024AW	MR-J5W2-1010G/B	1.9	- 4	
HK-RT_W	HK-RT103W	MR-J5W2-1010G/B	1.7	-	

 Notes:
 1. The power supply capacity varies depending on the power supply impedance.

 2. The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below: Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors

 3. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.
 4.

Drive unit (400 V)

Select power supply capacity on the basis of the capacity of the power regeneration converter unit.

Power regeneration converter unit	Power supply capacity [kVA] (Note 1, 2)
MR-CV11K4	16
MR-CV18K4	27
MR-CV30K4	43
MR-CV37K4	53
MR-CV45K4	64
MR-CV55K4	78
MR-CV75K4	107

Notes: 1. Select power supply capacity on the basis of the capacity of the power regeneration converter unit even when multiple drive units are connected to the converter unit. Calculate the total output wattage of the servo motors driven by the drive units which are connected to the power regeneration converter unit. If this wattage is smaller than the capacity of the converter unit, the power supply capacity can be lower than the value in the table.


2. An acceleration of the servo motor requires a current of 2 to 2.5 times the rated current. Secure the voltage of the main circuit power supply terminals (L1/L2/L3) of the power regeneration converter unit within the permissible voltage fluctuation. The power supply capacity varies depending on the power supply impedance.

Rotary Servo Motors


Annotations for Rotary Servo Motor Specifications

*1. The vibration direction is shown in the diagram below. The numerical value indicates the maximum value of the component (commonly the bracket in the opposite direction of the load side).

Fretting tends to occur on the bearing when the servo motor stops. Thus, maintain vibration level at approximately one-half of the allowable value.




*2. Refer to the diagram below for the permissible load for the shaft. Ensure that loads applied on the shaft do not exceed the values specified in the table. The values in the table are applicable when each load is applied singly.




L: Distance between the flange mounting surface and the center of load

*3. V10 indicates that the amplitude of the servo motor itself is 10 μm or less. The following shows mounting orientation and measuring position of the servo motor during the measurement:



*4. Refer to the diagram below for the shaft-through portion.





Annotations for Geared Servo Motor Specifications

With a gear reducer for general industrial machines (G1/G1H)

With a shaft-output type gear reducer for high precision applications,

*1. Refer to the diagram below for the permissible load for the shaft. Ensure that loads applied on the shaft do not exceed the values specified in the table. The values in the table are applicable when each load is applied singly.






L: Distance between the gear reducer end and the center of load


With a flange-output type gear reducer for high precision applications, flange mounting (G5)

- *2. Do not mount the following servo motor in a way that the servo motor is tilted to the shaft direction or to the shaft rotation direction.
 - HK-ST102(4)G1/G1H 1/43, 1/59

flange mounting (G7)

- HK-ST152(4)G1/G1H 1/29, 1/35, 1/43, 1/59
- HK-ST202(4)G1/G1H 1/29, 1/35, 1/43, 1/59
- HK-ST352(4)G1/G1H all reduction ratios
- HK-ST502(4)G1/G1H all reduction ratios
- HK-ST702(4)G1/G1H all reduction ratios





MEMO


5 Linear Servo Motors

Model Designation	5-2
Specifications	
LM-H3 series	5-8
LM-AJ series	5-10
LM-F series	5-12
LM-K2 series	5-14
LM-U2 series	5-16
LM-AU series	5-18
Power Supply Capacity	5-20
Dimensions	
LM-H3 series	5-22
LM-AJ series	5-24
LM-F series	5-28
LM-K2 series	5-30
LM-U2 series	5-32
LM-AU series	5-34
List of Linear Encoders	5-39
Determining the Number of the Secondary-Side (Magnet) Blocks	5-41

* Refer to p. 7-78 in this catalog for conversion of units.
 * The characteristics and numerical values without tolerances mentioned in this catalog are representative values.


Model Designation (Note 1)

●LM-H3 series



L M - H 3 <u>S 2</u> 0 - <u>2 8 8</u> - ___ (Secondary side: magnet) Symbol Linear servo motor model LM-H3S20-288 LM-H3S20-384 BSS0 LM-H3S20-480 LM-H3S20-768 LM-H3S30-288 Symbol Length (nominal) [mm] LM-H3S30-384 288 288 CSS0 LM-H3S30-480 384 384 LM-H3S30-768 480 480 Width (nominal) [mm] Symbol LM-H3S70-288 768 768 2 42 LM-H3S70-384 3 60 ASS0 LM-H3S70-480 7 95 LM-H3S70-768 Secondary side (magnet)

Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.




Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.


Precautions

Model Designation (Note 1)

●LM-F series




L M - F S 2 0 - 4 8 0 - (Secondary side: magnet)



Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

Model Designation (Note 1) Common Specifications ●LM-K2 series LM-K2P1A-01M- (Primary side: coil) Servo System Controllers Symbol Linear servo motor model LM-K2P1A-01M 2SS1 LM-K2P1C-03M Symbol Maximum speed [m/s] LM-K2P2A-02M Μ 2.0 LM-K2P2C-07M LM-K2P2E-12M 1SS1 Symbol Continuous thrust [N] Servo Amplifiers LM-K2P3C-14M 01 120 LM-K2P3E-24M 02 240 03 360 Symbol Length (nominal) [mm] 07 720 А 138 12 1200 С 330 Rotary Servo Motors 1440 14 E 522 24 2400 Symbol Height (nominal) [mm] 1 54 2 74.5 3 114.5 Linear Servo Motors Primary side (coil)



Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

5-5

Precautions

Support


Model Designation (Note 1)

•LM-U2 (medium thrust) series


L M - U 2 <u>P A B</u> - <u>0 5</u> <u>M</u> - ___ (Primary side: coil) Symbol Linear servo motor model Symbol Maximum speed [m/s] LM-U2PAB-05M **0SS0** LM-U2PAD-10M Μ 2.0 LM-U2PAF-15M Symbol Continuous thrust [N] LM-U2PBB-07M 05 Symbol Length (nominal) [mm] 50 1SS0 LM-U2PBD-15M 07 75 В 130 LM-U2PBF-22M 10 100 D 250 15 150 F 370 22 225 Symbol Width (nominal) [mm] А 66.5 В 86.5

- Primary side (coil)

L M - U 2 $\underline{S} \underline{A} 0$ - $\underline{240} - \underline{-}$ (Secondary side: magnet)



●LM-U2 (large thrust) series




Secondary side (magnet)

Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

Model Designation (Note 1)

●LM-AU series



Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available. 2. The continuous thrust for LM-AUP3C-09V-JSS0 is 85 N.

The continuous thrust for LM-AUP4B-09R-JSS0 is 88 N.

Support

Precautions

LM-H3 Series Specifications

	servo motor model	_M-H3	P2A-07P-BSS0		P3B-24P-				-	-	P7D-96P-	
Primary	/ side (coil)			CSS0	CSS0	CSS0	CSS0	ASS0	ASS0	ASS0	ASS0	
				S30-288-0				S70-288-A				
	servo motor model	_М-НЗ	S20-384-BSS0					S70-384-ASS0				
Second	lary side (magnet)		S20-480-BSS0					S70-480-ASS0				
Casling				S20-768-BSS0 S30-768-CSS0 S70-768-ASS0								
Cooling	g method		Natural cooling									
Thrust	Continuous (Note 2)	[N]		120	240	360	480	240	480	720	960	
	Maximum	[N]	175	300	600	900	1200	600	1200	1800	2400	
Maximu	um speed (Note 1)	[m/s]	3.0									
Magnet	tic attraction force	[N]	630	1100	2200	3300	4400	2200	4400	6600	8800	
Rated of	current	[A]	1.8	1.7	3.4	5.1	6.8	3.4	6.8	10.2	13.6	
Maximu	um current	[A]	5.8	5.0	9.9	14.9	19.8	9.6	19.1	28.6	38.1	
Recom (Note 3)	mended load to motor mas	s ratio	35 times or less									
Туре			Permanent magnet synchronous motor									
Thermi	stor		Built-in									
Insulati	on class		155 (F)									
Structu	re		Open (IP rating:	IP00)								
Vibratio	on resistance	[m/s ²]	49									
	Primary side (coil)	[kg]	0.9	1.3	2.3	3.3	4.3	2.2	3.9	5.6	7.3	
			288 mm/pc: 0.7	288 mm/p	c: 1.0			288 mm/p	c: 2.8			
Mass	Secondary side (magnet)	[kc]	384 mm/pc: 0.9					384 mm/pc: 3.7				
	Secondary side (magnet)	[kg]	480 mm/pc: 1.1 480 mm/pc: 1.7					480 mm/pc: 4.7				
			768 mm/pc: 1.8	768 mm/p	c: 2.7			768 mm/p	c: 7.4			

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.

Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.
 This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.

Common Specifications

Servo System Controllers

Servo Amplifiers


Rotary Servo Motors

Linear Servo Motors


Direct Drive Motors

LM-H3 Series Thrust Characteristics


LM-H3P2A-07P-BSS0 (Note 1, 2, 3)



LM-H3P3C-36P-CSS0 (Note 1, 2, 3)




LM-H3P7B-48P-ASS0 (Note 1, 2, 3)




Notes: 1. For 3-phase 200 V AC

2. ----: For 1-phase 200 V AC 3. Thrust drops when the power supply voltage is below the specified value.


LM-H3P3A-12P-CSS0 (Note 1, 2, 3)




LM-H3P3D-48P-CSS0 (Note 1, 2, 3)




LM-H3P7C-72P-ASS0 (Note 1, 2, 3)







LM-H3P7A-24P-ASS0 (Note 1, 2, 3)



LM-H3P7D-96P-ASS0 (Note 1, 3)





LM-AJ Series Specifications


Linear	servo motor model	LM-AJ	P1B-	P1D-	P2B-	P2D-	P3B-	P3D-	P4B-	P4D-	
Primary	y side (coil)	LIVI-AJ	07K-JSS0	14K-JSS0	12S-JSS0	23T-JSS0	17N-JSS0	35R-JSS0	22M-JSS0	45N-JSS0	
linoar	servo motor model		S10-080-JS		S20-080-JS		S30-080-JS		S40-080-JS		
	Secondary side (magnet)					S20-200-JSS0		S30-200-JSS0		S40-200-JSS0	
0000110			S10-400-JSS0		S20-400-JS	S0	S30-400-JS	S0	S40-400-JS	S0	
Cooling	g method		Natural cool	ing							
Thrust	Continuous (Note 2)	[N]	68.1	136.2	117.0	234.0	174.5	348.9	223.4	446.8	
musi	Maximum	[N]	214.7	429.4	369.0	738.1	550.2	1100.4	704.5	1409.1	
Maximu	um speed (Note 1)	[m/s]	6.5		4.0	5.0	2.5	3.5	2.0	2.5	
Magnet	tic attraction force	[N]	378.8	757.6	651.1	1302.1	970.7	1941.4	1242.9	2485.9	
Rated of	current	[A]	2.3	4.6	2.3	4.6	2.3	4.6	2.3	4.6	
Maximu	um current	[A]	9.0	18.0	9.0	18.0	9.0	18.0	9.0	18.0	
Recom	mended load to motor mas	ss ratio	10 times or	25 times or	20 times or	25 times or	30 times or less				
(Note 3)			less	less	less	less	So times of less				
Туре			Permanent magnet synchronous motor								
Thermi	stor		None								
Therma	al protector		Built-in								
Insulati	on class		105 (A)								
Structu	re		Open (IP rat	ing: IP00)							
Vibratic	on resistance	[m/s ²]	49								
	Primary side (coil)	[kg]	0.6	1.1	0.9	1.7	1.2	2.3	1.5	2.9	
Mass			80 mm/pc: 0	.26	80 mm/pc: 0	.40	80 mm/pc: 0.56		80 mm/pc: 0).70	
iviass	Secondary side (magnet)) [kg]	200 mm/pc:	0.65	200 mm/pc:	1.00	200 mm/pc:	1.40	200 mm/pc:	1.70	
			400 mm/pc:		400 mm/pc:	2.00	400 mm/pc:	2.80	400 mm/pc:	3.50	

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed. 2. Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.


3. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.

LM-AJ Series Thrust Characteristics


LM-AJP1B-07K-JSS0 (Note 1, 2, 3)




LM-AJP2D-23T-JSS0 (Note 1, 2, 3)




LM-AJP4B-22M-JSS0 (Note 1, 2, 3)




LM-AJP1D-14K-JSS0 (Note 1, 2, 3)




LM-AJP3B-17N-JSS0 (Note 1, 2, 3)




LM-AJP4D-45N-JSS0 (Note 1, 2, 3)





LM-AJP3D-35R-JSS0 (Note 1, 2, 3)





Common Specifications

Servo System Controllers

Contact your local sales office for the thrust characteristics for 1-phase 200 V AC.
 Thrust drops when the power supply voltage is below the specified value.

Notes:

1.

For 3-phase 200 V AC


LM-F Series Specifications

	· servo mo ry side (co		LM-F	P2B-06M-1SS0	P2D-12M-1SS0	P2F-18M-1SS0	P4B-12M-1SS0	P4D-24M-1SS0	
	Linear servo motor model Secondary side (magnet)			S20-480-1SS0 S20-576-1SS0			S40-480-1SS0 S40-576-1SS0		
	ig method	(magnet)		Natural cooling or li	auid coolina		040 070 1000		
	Continuo	cooling) ^(Note 2)	[N]	300	600	900	600	1200	
Thrust	Continuo (liquid co	oling) ^(Note 2)	[N]	600	1200	1800	1200	2400	
	Maximun	n	[N]	1800	3600	5400	3600	7200	
Maxim	num speed	(Note 1)	[m/s]	2.0					
Magne	etic attract	ion force	[N]	4500	9000	13500	9000	18000	
Potod	current	Natural cooling	[A]	4.0	7.8	12	7.8	15	
naleu	current	Liquid cooling	[A]	7.8	16	23	17	31	
Maxim	num currer	nt	[A]	30	58	87	57	109	
Recon (Note 3)	nmended I	oad to motor mas	s ratio	15 times or less					
Туре				Permanent magnet	synchronous motor				
Therm	nistor			Built-in					
Insulat	tion class			155 (F)					
Struct	ure			Open (IP rating: IP0	00)				
Vibrati	ion resista	nce	[m/s ²]	49					
	Primary s	side (coil)	[kg]	9.0	18	27	14	28	
Mass	Seconda	ry side (magnet)	[kg]	480 mm/pc ⁻ 7 0	·		480 mm/pc: 12 576 mm/pc: 15		


 The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.
 Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.
 This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table. Notes:

LM-F Series Thrust Characteristics


LM-FP2B-06M-1SS0 (Note 1, 2, 3)




LM-FP4B-12M-1SS0 (Note 1, 3)



LM-FP2D-12M-1SS0 (Note 1, 3)




LM-FP4D-24M-1SS0 (Note 1, 3)



Notes: 1. For 3-phase 200 V AC

- 2. ----: For 1-phase 200 V AC
- Thrust drops when the power supply voltage is below the specified value.
 Continuous running range (liquid cooling)
- 5. Continuous running range (natural cooling)

LM-FP2F-18M-1SS0 (Note 1, 3)



List

LM-K2 Series Specifications

Linear s	servo motor model	LM-K2	P1A-01M-	P1C-03M-	P2A-02M-	P2C-07M-	P2E-12M-	P3C-14M-	P3E-24M-		
Primary	v side (coil)		2SS1	2SS1	1SS1	1SS1	1SS1	1SS1	1SS1		
			S10-288-2SS	1	S20-288-1SS	1		S30-288-1SS1			
Linear s	servo motor model	LM-K2	S10-384-2SS	1	S20-384-1SS	1		S30-384-1SS1			
Second	ary side (magnet) (Note 2)		S10-480-2SS1		S20-480-1SS	1	S30-480-1S	S1			
			S10-768-2SS	1	S20-768-1SS	1		S30-768-1S	S1		
Cooling	method		Natural cooling								
Thrust	Continuous (Note 3)	[N]	120	360	240	720	1200	1440	2400		
must	Maximum	[N]	300	900	600	1800	3000	3600	6000		
Maximu	Im speed (Note 1)	[m/s]	2.0								
Magnet	ic attraction force (Note 4)	[N]	0)							
Magnet	ic attraction force	INI	800	2400	1100	3200	5300	6400	10700		
(one sic	le) (Note 5)	[14]	800	2400	1100	3200	5500	0400	10700		
Rated c	current	[A]	2.3	6.8	3.7	12	19	15	25		
Maximu	im current	[A]	7.6	23	13	39	65	47	79		
Recomi (Note 6)	mended load to motor ma	iss ratio	30 times or less								
Туре			Permanent magnet synchronous motor								
Thermis	stor		Built-in								
Insulation	on class		155 (F)								
Structu	re		Open (IP rating: IP00)								
Vibratio	n resistance	[m/s ²]	49								
	Primary side (coil)	[kg]	2.5	6.5	4.0	10	16	18	27		
			288 mm/pc: 1	.5	288 mm/pc: 1	.9		288 mm/pc:	5.5		
Mass	Secondary side (magnet)) [leal	384 mm/pc: 2		384 mm/pc: 2.5			384 mm/pc: 7.3			
			480 mm/pc: 2		480 mm/pc: 3	.2		480 mm/pc: 9.2			
			768 mm/pc: 3	.9	768 mm/pc: 5	.0		768 mm/pc:	14.6		


Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.

LM-K2 series has a structure of magnetic attraction counter-force and requires at least two blocks of identical secondary side (magnet).
 Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.
 Magnetic attraction force which occurs on one side of the secondary side is shown.
 The data second second


6. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.

LM-K2 Series Thrust Characteristics


LM-K2P1A-01M-2SS1 (Note 1, 4)



LM-K2P2C-07M-1SS1 (Note 2, 4)




LM-K2P3E-24M-1SS1 (Note 2, 4)




Notes: 1. For 3-phase 200 V AC or 1-phase 200 V AC


- 2. _____: For 3-phase 200 V AC
- 3. ----: For 1-phase 200 V AC
- 4. Thrust drops when the power supply voltage is below the specified value.

LM-K2P1C-03M-2SS1 (Note 2, 3, 4)




LM-K2P2E-12M-1SS1 (Note 2, 4)





LM-K2P3C-14M-1SS1 (Note 2, 4)



Servo Amplifiers Rotary Servo Motors

Common Specifications

Servo System Controllers

Linear Servo Motors

LM-U2 Series Specifications

	servo motor model / side (coil)	LM-U2	PAB-05M- 0SS0	-	PAF-15M- 0SS0	PBB-07M- 1SS0	PBD-15M- 1SS0	PBF-22M- 1SS0	P2B-40M- 2SS0	P2C-60M- 2SS0	P2D-80M- 2SS0	
Linear servo motor model		LM-U2	SA0-300-0SS0			SB0-240-1SS1 SB0-300-1SS1 SB0-420-1SS1			S20-300-2SS1 S20-480-2SS1			
Cooling	g method		Natural cooling									
Thurst	Continuous (Note 2)	[N]	50	100	150	75	150	225	400	600	800	
Thrust	Maximum	[N]	150	300	450	225	450	675	1600	2400	3200	
Maxim	um speed (Note 1)	[m/s]	2.0									
Magnet	tic attraction force	[N]	0)								
Rated of	current	[A]	0.9	1.9	2.7	1.5	3.0	4.6	6.6	9.8	13.1	
Maxim	um current	[A]	2.7	5.5	8.3	4.5	8.9	13.7	26.7	40.3	53.7	
Recom (Note 3)	mended load to motor mas	ss ratio	30 times or less									
Туре			Permanent magnet synchronous motor									
Thermi	stor		Built-in									
Insulati	on class		155 (F)									
Structu	re		Open (IP rating: IP00)									
Vibratio	on resistance	[m/s ²]	49									
	Primary side (coil)	[kg]	0.3	0.6	0.8	0.4	0.8	1.1	2.9	4.2	5.5	
Mass			240 mm/pc: 2.0 300 mm/pc: 2.5			240 mm/pc: 2.6 300 mm/pc: 3.2 420 mm/pc: 4.5			300 mm/pc: 9.6 480 mm/pc: 15.3			

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.
2. Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.
3. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires


Product List

Precautions


Support

LM-U2 Series Thrust Characteristics


LM-U2PAB-05M-0SS0 (Note 1, 4)




LM-U2PBB-07M-1SS0 (Note 1, 4)




LM-U2P2B-40M-2SS0 (Note 2, 3, 4)




LM-U2PAD-10M-0SS0 (Note 1, 4)





LM-U2PBD-15M-1SS0 (Note 1, 4)



LM-U2P2C-60M-2SS0 (Note 2, 4)








Thrust [N]

LM-U2P2D-80M-2SS0 (Note 2, 4)



Notes: 1. For 3-phase 200 V AC or 1-phase 200 V AC

- 2. . For 3-phase 200 V AC
- 3. ----: For 1-phase 200 V AC
- 4. Thrust drops when the power supply voltage is below the specified value.

LM-AU Series Specifications

	servo motor model y side (coil)	LM-AU	P3A-03V-JSS0	P3B-06V-JSS0	P3C-09V-JSS0	P3D-11R-JSS0			
	servo motor model dary side (magnet)		\$30-120-JS\$0 \$30-180-J\$\$0 \$30-240-J\$\$0 \$30-300-J\$\$0 \$30-600-J\$\$0						
Cooling	g method		Natural cooling						
Thrust	Continuous (Note 2)	[N]	28	57	85	113			
must	Maximum	[N]	122	274	411	549			
Maxim	um speed (Note 1)	[m/s]	4.5			3.5			
Magne	tic attraction force	[N]	0						
Rated	current	[A]	1.8						
Maxim	um current	[A]	9.2						
(Note 3)	mended load to motor mas	ss ratio	35 times or less		25 times or less	20 times or less			
Туре			Permanent magnet synchronous motor						
Thermi	stor		None						
Therma	al protector		Built-in						
Insulat	ion class		105 (A)						
Structu	ire		Open (IP rating: IP00)						
Vibratio	on resistance	[m/s ²]	49						
	Primary side (coil)	[kg]	0.22	0.45	0.68	0.91			
Mass	Secondary side (magnet)		120 mm/pc: 1.0 180 mm/pc: 1.5 240 mm/pc: 2.0 300 mm/pc: 2.5 600 mm/pc: 5.0						

	servo motor model y side (coil)	LM-AU	P4A-04R-JSS0	P4B-09R-JSS0	P4C-13P-JSS0	P4D-18M-JSS0	P4F-26P-JSS0	P4H-35M-JSS0			
	servo motor model dary side (magnet)	LM-AU	S40-120-JSS0 S40-180-JSS0 S40-240-JSS0 S40-300-JSS0 S40-600-JSS0								
Cooling	g method		Natural cooling								
Thrust	Continuous (Note 2)	[N]	44	88	132	176	264	350			
musi	Maximum	[N]	280	561	842	970	1684	1764			
Maxim	um speed (Note 1)	3.5		3.0	2.0	3.0	2.0				
Magne	tic attraction force	[N]									
Rated of	current	[A]	1.9								
Maxim	um current	[A]	13.0	13.0 26.0							
Recom	mended load to motor ma	ss ratio	35 times or less								
Туре			Permanent magnet synchronous motor								
Thermi	stor		None								
Therma	al protector		Built-in								
Insulati	on class		105 (A)								
Structu	re		Open (IP rating: IP00)								
Vibratio	on resistance	[m/s ²]	49								
	Primary side (coil)	[kg]	0.28	0.56	0.89	1.2	1.8	2.4			
Mass	Secondary side (magnet) [kg]	120 mm/pc: 1.8 180 mm/pc: 2.7 240 mm/pc: 3.6 300 mm/pc: 4.5 600 mm/pc: 8.9								

Notes: 1. The maximum speed of the linear servo motor or the rated speed of the linear encoder, whichever is smaller, is the upper limit of the linear servo motor speed.
2. Use the linear servo motor at 70 % or less of the effective load ratio when it is in the servo lock state or in a small reciprocating motion.
3. This is the ratio of the load to the linear servo motor primary side mass. Contact your local sales office if the load to motor mass ratio exceeds the value in the table.

Common Specifications

Servo System Controllers

Servo

Amplifiers

Rotary Servo Motors


Linear Servo Motors

Direct Drive Motors


Options/Peripheral Equipment

LM-AU Series Thrust Characteristics


LM-AUP3A-03V-JSS0 (Note 1, 2, 3)




LM-AUP3D-11R-JSS0 (Note 1, 2, 3)



LM-AUP4C-13P-JSS0 (Note 1, 2, 3)




LM-AUP4H-35M-JSS0 (Note 1, 2, 3)




Notes: 1. For 3-phase 200 V AC

- 2. Contact your local sales office for the thrust characteristics for 1-phase 200 V AC.
- 3. Thrust drops when the power supply voltage is below the specified value.


LM-AUP3B-06V-JSS0 (Note 1, 2, 3)




LM-AUP4A-04R-JSS0 (Note 1, 2, 3)




LM-AUP4D-18M-JSS0 (Note 1, 2, 3)









LM-AUP4F-26P-JSS0 (Note 1, 2, 3)







Power Supply Capacity

Linear servo mo	tors (primary side)	Servo amplifier (Note 3)	Power supply capacity [kVA] (Note 1, 2)
	LM-H3P2A-07P-BSS0	MR-J5-40G/B/A MR-J5W2-44G/B, MR-J5W2-77G/B	0.9
	LM-H3P3A-12P-CSS0	MR-J5W2-1010G/B MR-J5W3-444G/B	0.0
	LM-H3P3B-24P-CSS0	MR-J5-70G/B/A	1.3
	LM-H3P3C-36P-CSS0	MR-J5W2-77G/B, MR-J5W2-1010G/B	1.9
_M-H3 series	LM-H3P3D-48P-CSS0	MR-J5-200G/B/A	3.5
	LM-H3P7A-24P-ASS0	MR-J5-70G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	1.3
	LM-H3P7B-48P-ASS0		3.5
	LM-H3P7C-72P-ASS0	MR-J5-200G/B/A	3.8
	LM-H3P7D-96P-ASS0	MR-J5-350G/B/A	5.5
	LM-AJP1B-07K-JSS0	MR-J5-40G/A MR-J5W2-44G, MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G	0.9
	LM-AJP1D-14K-JSS0	MR-J5-70G/A MR-J5W2-77G, MR-J5W2-1010G	1.3
	LM-AJP2B-12S-JSS0	MR-J5-40G/A MR-J5W2-44G, MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G	0.9
LM-AJ series	LM-AJP2D-23T-JSS0	MR-J5-70G/A MR-J5W2-77G, MR-J5W2-1010G	1.3
	LM-AJP3B-17N-JSS0	MR-J5-40G/A MR-J5W2-44G, MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G	0.9
	LM-AJP3D-35R-JSS0	MR-J5-70G/A MR-J5W2-77G, MR-J5W2-1010G	1.3
	LM-AJP4B-22M-JSS0	MR-J5-40G/A MR-J5W2-44G, MR-J5W2-77G MR-J5W2-1010G MR-J5W3-444G	0.9
	LM-AJP4D-45N-JSS0	MR-J5-70G/A MR-J5W2-77G, MR-J5W2-1010G	1.3

Notes: 1. The power supply capacity varies depending on the power supply impedance.
2. The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below: Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors
3. Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

S

Power Supply Capacity


inear servo mo	tors (primary side)	Servo amplifier (Note 3)	Power supply capacity [kVA] (Note 1, 2)	Specifications	
	LM-FP2B-06M-1SS0	MR-J5-200G/B/A	3.5	cati	
	LM-FP2D-12M-1SS0	MR-J5-500G/B/A	7.5	ons	
M-F series	LM-FP2F-18M-1SS0	MR-J5-700G/B/A	10		
	LM-FP4B-12M-1SS0	MR-J5-500G/B/A	7.5		
	LM-FP4D-24M-1SS0	MR-J5-700G/B/A	10	Con	
	LM-K2P1A-01M-2SS1	MR-J5-40G/B/A MR-J5W2-44G/B, MR-J5W2-77G/B MR-J5W2-1010G/B MR-J5W3-444G/B	0.9	Controllers	
	LM-K2P1C-03M-2SS1	MR-J5-200G/B/A	3.5	Serv	
M-K2 series	LM-K2P2A-02M-1SS1	MR-J5-70G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	1.3	Servo Amplifiers	
	LM-K2P2C-07M-1SS1	MR-J5-350G/B/A	5.5	ifier	
	LM-K2P2E-12M-1SS1	MR-J5-500G/B/A	7.5		
	LM-K2P3C-14M-1SS1	MR-J5-350G/B/A	5.5		
	LM-K2P3E-24M-1SS1	MR-J5-500G/B/A	7.5	N N	
	LM-U2PAB-05M-0SS0	MR-J5-20G/B/A MR-J5W2-22G/B, MR-J5W2-44G/B MR-J5W3-222G/B, MR-J5W3-444G/B	0.5	Motors	
	LM-U2PAD-10M-0SS0	MR-J5-40G/B/A MR-J5W2-44G/B, MR-J5W2-77G/B	0.9		
	LM-U2PAF-15M-0SS0	MR-J5W2-1010G/B MR-J5W3-444G/B	0.5	Motors	
M-U2 series	LM-U2PBB-07M-1SS0	MR-J5-20G/B/A MR-J5W2-22G/B, MR-J5W2-44G/B MR-J5W3-222G/B, MR-J5W3-444G/B	0.5	- 11	
	LM-U2PBD-15M-1SS0	MR-J5-60G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	1.0	Motors	
	LM-U2PBF-22M-1SS0	MR-J5-70G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	1.3		
	LM-U2P2B-40M-2SS0	MR-J5-200G/B/A	3.5		
	LM-U2P2C-60M-2SS0	MR-J5-350G/B/A	5.5	E C	
	LM-U2P2D-80M-2SS0	MR-J5-500G/B/A	7.5	quip	
	LM-AUP3A-03V-JSS0	MR-J5-40G/A		mer	
	LM-AUP3B-06V-JSS0	MR-J5W2-44G, MR-J5W2-77G	0.9	Equipment	
	LM-AUP3C-09V-JSS0	MR-J5W2-1010G			
	LM-AUP3D-11R-JSS0	MR-J5W3-444G	1.2		
M-AU series	LM-AUP4A-04R-JSS0			LVS/Wires	
VI-AU Selles	LM-AUP4B-09R-JSS0	MR-J5-70G/A	1.3	Wir	
	LM-AUP4C-13P-JSS0	MR-J5W2-77G, MR-J5W2-1010G	1.5	es	
	LM-AUP4D-18M-JSS0				
	LM-AUP4F-26P-JSS0	MR-J5-200G/A	3.5		
	LM-AUP4H-35M-JSS0		0.0	Product	

The power supply capacity values depending on the power supply impedance.
 The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below: Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors
 Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

List

LM-H3 Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-H3P2A-07P-BSS0



Notes: 1. Power, grounding, and thermistor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

LM-H3P7B-48P-ASS0

LM-H3P7C-72P-ASS0

LM-H3P7D-96P-ASS0

side

224

320

416

*1. Pitch tolerance between holes at both ends: ± 0.3

2× 64(=128)*1

4× 64(=256) ⁻¹

5× 64(=320)*1

64

32

64

9

15

18

[Unit: mm]


5-22 2. Minimum bending radius of the lead wire equals to six times the standard overall diameter of the lead wire.

210±10

400 * 40


(Effective lead wire length)

nounting)




LM-AJ Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AJP1B-07K-JSS0



*1. Pitch tolerance between holes at both ends: ±0.3 [Unit: mm]

●LM-AJP1D-14K-JSS0



*1. Pitch tolerance between holes at both ends: ±0.3


[Unit: mm]

LM-AJ Series Secondary Side (Magnet) Dimensions

●LM-AJS10-080-JSS0

●LM-AJS10-200-JSS0

●LM-AJS10-400-JSS0




Notes: 1. Power, grounding, and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

[Unit: mm]


LM-AJ Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AJP2B-12S-JSS0




*1. Pitch tolerance between holes at both ends: ±0.3

●LM-AJP2D-23T-JSS0



LM-AJ Series Secondary Side (Magnet) Dimensions




Notes: 1. Power, grounding, and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.


2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

LM-AJ Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AJP3B-17N-JSS0




●LM-AJP3D-35R-JSS0



*1. Pitch tolerance between holes at both ends: ±0.3


[Unit: mm]

LM-AJ Series Secondary Side (Magnet) Dimensions




●LM-AJS30-200-JSS0

•LM-AJS30-400-JSS0



Notes: 1. Power, grounding, and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.



Notes: 1. Power, grounding, and thermal protector lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.


2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

LM-F Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-FP2B-06M-1SS0


●LM-FP2D-12M-1SS0

LM-FP2F-18M-1SS0



●LM-FP4B-12M-1SS0

LM-FP4D-24M-1SS0



Notes: 1. Power and thermistor cables do not have a long bending life. Fix the cables led from the primary side (coil) to a moving part to prevent the cables from repetitive bending. 2. Minimum bending radius of the cable equals to six times the standard overall diameter of the cable.

Servo Amplifiers

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product List


Precautions

Support


LM-F Series Secondary Side (Magnet) Dimensions

●LM-FS20-480-1SS0


Common Specifications B-ø9 (for secondary-side mounting) Servo System Controllers L _0. 19.5 (48) М 48±0.2 Mark "N" 96±0.2 (10.5) 9 10 19 -0 -0 -0--¢ 0 00±0.3 120 얾 °C (19) (10) (24) 24 Rotary Servo Motors Mold (epoxy) 4-M8 screw (for hanging) Variable dimensions Model М В K 4× 96(=384)* LM-FS20-480-1SS0 480 10 432 LM-FS20-576-1SS0 576 5× 96(=480)* 12 528 *1. Pitch tolerance between holes at both ends: ±0.2 [Unit: mm] Linear Servo Motors



•LM-FS20-576-1SS0




LM-K2 Series Primary Side (Coil) Dimensions (Note 1, 2)





•LM-K2P2C-07M-1SS1






●LM-K2P3C-14M-1SS1 ●LM





Notes: 1. Power, grounding, and thermistor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires 5-30 from repetitive bending.

2. Minimum bending radius of the lead wire equals to six times the standard overall diameter of the lead wire.



Notes: 1. Longitudinal deviation of the secondary side must be within ±0.1 mm.

LM-U2 Series Primary Side (Coil) Dimensions (Note 1, 2)

LM-U2PAB-05M-0SS0

0.45±0.1

(0.8)

(8.7

0.45±0.1

(0.9)

(8.6)

C0.5

98±0.

(82)

C0.5


78±0.

(62)

●LM-U2PAD-10M-0SS0

LM-U2PBD-15M-1SS0





Model	Variab	le dimensions	Power/gro	unding lead wire					
INIOUEI	L	M	В	Size	Standard OD				
LM-U2PAB-05M-0SS0	130	2× 60(=120)*1	6						
LM-U2PAD-10M-0SS0	250	4× 60(=240)*1	10	AWG 26	1.58				
LM-U2PAF-15M-0SS0	370	6× 60(=360)*1	14						
*1. Pitch tolerance betwe	I. Pitch tolerance between holes at both ends: ±0.3								


LM-U2PBB-07M-1SS0

(25.4)

6.4

(0.8)

(8.7)



Variable dimensions Power/grounding lead wire M В Size Standard OD LM-U2PBB-07M-1SS0 2× 60(=120) 130 6 LM-U2PBD-15M-1SS0 4× 60(=240) AWG 26 1.58 250 10 LM-U2PBF-22M-1SS0 6× 60(=360)* 370 14


[Unit: mm]


*1. Pitch tolerance between holes at both ends: ±0.3

LM-U2PBF-22M-1SS0

LM-U2P2B-40M-2SS0


LM-U2P2C-60M-2SS0






Notes: 1. Power, grounding, and thermistor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

5-32 2. Minimum bending radius of the lead wire equals to six times the standard overall diameter of the lead wire.




LM-AU Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AUP3A-03V-JSS0




LM-AUP3B-06V-JSS0



[Unit: mm]

●LM-AUP3C-09V-JSS0




Notes: 1. Power, grounding, and thermal sensor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

LM-AU Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AUP3D-11R-JSS0



Notes: 1. Power, grounding, and thermal sensor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.


2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

Support


List

LM-AU Series Primary Side (Coil) Dimensions (Note 1, 2)


●LM-AUP4A-04R-JSS0



LM-AUP4B-09R-JSS0



●LM-AUP4C-13P-JSS0




Notes: 1. Power, grounding, and thermal sensor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

[Unit: mm]

[Unit: mm]

LM-AU Series Primary Side (Coil) Dimensions (Note 1, 2)

●LM-AUP4D-18M-JSS0



Notes: 1. Power, grounding, and thermal sensor lead wires do not have a long bending life. Fix the lead wires led from the primary side (coil) to a moving part to prevent the lead wires from repetitive bending.

*1. Pitch tolerance between holes at both ends: ±0.3

2. Minimum bending radius of the lead wire equals to 10 times the standard overall diameter of the lead wire.

(14.55

(14.55)


(39)

LM-AU Series Secondary Side (Magnet) Dimensions

- ●LM-AUS40-120-JSS0
- •LM-AUS40-180-JSS0

•LM-AUS40-240-JSS0

- •LM-AUS40-300-JSS0
- ●LM-AUS40-600-JSS0



Model	Variable dimensions								
WOUEI	L M N		N	В	С				
LM-AUS40-120-JSS0	119.5	60 *1	60 ^{*1}	2	2				
LM-AUS40-180-JSS0	179.5	2× 60(=120) ⁻¹	2× 60(=120) ⁻¹	3	3				
LM-AUS40-240-JSS0	239.5	3× 60(=180) ⁻¹	3× 60(=180)*1	4	4				
LM-AUS40-300-JSS0	299.5	4× 60(=240)*1	4× 60(=240) ^{*1}	5	5				
LM-AUS40-600-JSS0	599.5	9× 60(=540)*1	9× 60(=540)*1	10	10				
*1. Pitch tolerance between holes at both ends: ±0.3 [Unit: mm]									

List of Linear Encoders (Note 1)

Mitsubishi Electric high-speed serial communication-compatible absolute type

		ar encoders and the servo amp al communication-compatik				Common Specifications
Manufacturer	Model	Resolution	Rated speed	Maximum effective measurement length (Note 3)	Communication method (Note 4)	Servo System Controllers
	SR77	0.05 μm/	0.0	2040 mm	The second second	- ont
	SR87	0.01 µm	3.3 m/s	3040 mm	Two-wire type	rolle
Magnescale	SR27A	0.01	0.0	2040 mm		ers
Co., Ltd.	SR67A	0.01 μm	3.3 m/s	3640 mm	Two-wire type/	Ц
	SmartSCALE SQ47			3740 mm	Four-wire type	(0)
	SmartSCALE SQ57	0.005 μm	3.3 m/s	3770 mm		en
	AT343A		2.0 m/s	3000 mm		- °
	AT543A-SC	0.05 μm	2.5 m/s	2200 mm		du
	AT545A-SC	20 μm/4096 (Approx. 0.005 μm)	2.5 m/s	2200 mm		Servo Amplifiers
Mitutoyo	ST743A				Two-wire type	
Corporation	ST744A	0.1 μm	5.0 m/s	6000 mm		Ro
	ST748A	·				Mo
	ST1341A	0.01 µm	<i>.</i> .	12000 mm		Rotary Servo Motors
	ST1342A	0.001 μm	— 8.0 m/s	4200 mm		3M6
		1 nm	100 /	2100 mm		_ 0
Renishaw	RESOLUTE RL40M	50 nm	— 100 m/s	20990 mm	Two-wire type	
	EVOLUTE EL40M	50 nm/100 nm/500 nm	100 m/s	10010 mm		Lin
	LC 495M	0.001 μm/	·	2040 mm		- Mo
	LC 195M	0.01 μm	3.0 m/s	4240 mm	Four-wire type	Linear Servo Motors
	LIC 4193M	· · ·		3040 mm		- [®] N
	LIC 4195M	0.005 μm/		28440 mm	-	
	LIC 4197M	0.01 µm	10.0 m/s	6040 mm	-	
Heidenhain	LIC 4199M			1020 mm	-	
	LIC 3197M				Two-wire type/	Direct Drive Motors
	LIC 3199M	0.01 μm	10.0 m/s	10000 mm	Four-wire type	Dr
	LIC 2197M	0.05 μm/		6020 mm		Ne
	LIC 2199M	0.1 μm	10.0 m/s	6020 mm	-	
RSF Elektronik	MC15M	0.05 μm/ 0.1 μm	10.0 m/s	3020 mm		Option E
Nidec Machine Tool Corporation	e Tool MPFA-HZ-M01 0.1 μm		30.0 m/s	8000 mm	Two-wire type	Options/Peripheral Equipment

Notes: 1. Contact the relevant linear encoder manufacturer for details on operating environment and specifications of the linear encoder such as ambient temperature, vibration resistance and IP rating. 2. The listed values are the manufacturer's specifications. When combined with MR-J5_-_servo amplifiers, the specification value is either the listed value or the servo

motor maximum speed, whichever is lower.

3. The listed values are the manufacturer's specifications. The maximum length of the encoder cable between a linear encoder and a servo amplifier is 30 m. For a linear encoder manufactured by Nidec Machine Tool Corporation, the maximum length of the encoder cable between the linear encoder and a servo amplifier is 20 m. 4. The compatible communication method varies by the servo amplifier and operation mode. Refer to "External Encoder Connection Specifications" in this catalog.

LVS/Wires

List of Linear Encoders (Note 1)

For the available combinations of the linear encoders and the servo amplifiers, contact your local sales office.

Mitsubishi Electric high-speed serial communication-compatible incremental type

Manufacturer	Model Resolution Rated spectrum (Note 2)		Resolution Rated speed measurement length (Note 3)		(Note 2) (Note 3) (Note 3)		Communication method
	SR75	0.05 μm/	0.05 μm/ 3.3 m/s		_		
Magnescale	SR85	0.01 µm	0.0 11/3	3040 mm	Two-wire type		
Co., Ltd.	SL710 + PL101-RM/RHM	0.1 μm	10.0 m/s	100000 mm			
00., Eld.	SQ10 + PQ10 + MQ10	0.1 μm/ 0.05 μm	10.0 m/s	3800 mm	Two-wire type/ Four-wire type		
	LIDA 483 + EIB 3091M (16384-fold subdivision) (Note 7)			3040 mm			
	LIDA 485 + EIB 3091M (16384-fold subdivision) (Note 7)	20 μm/16384		30040 mm			
	LIDA 487 + EIB 3091M (16384-fold subdivision) (Note 7)	(Approx. 1.22 nm)	4.0 m/s	6040 mm			
	LIDA 489 + EIB 3091M (16384-fold subdivision) (Note 7)		4.0 m/s	1020 mm			
Heidenhain	LIDA 287 + EIB 3091M (16384-fold subdivision) ^(Note 7) LIDA 289 + EIB 3091M (16384-fold subdivision) ^(Note 7)	200 μm/16384 (Approx. 12.2 nm)		10000 mm	Four-wire type		
	LIF 481 + EIB 3091M (4096-fold subdivision)	4 μm/4096	1.6 m/s	1020 mm	_		
	LIP 6081 + EIB 3091M (4096-fold subdivision)	(Approx. 0.977 nm)	1.0 11/5	1440 mm			
Nidec Instruments Corporation	PSLH041	0.1 μm	5.0 m/s	2400 mm	Two-wire type		
Nidec Machine Tool Corporation	MPFA-HI-M01 (Note 6)	0.1 μm	30.0 m/s	10000 mm ^(Note 8)	Two-wire type		

A/B/Z-phase differential output type (Note 9)

Manufacturer	Model	Resolution	(Note 2)	Maximum effective measurement length (Note 3)	Communication method (Note 4)
Not designated	-	0.001 μm to 5 $\mu m^{(\text{Note 5})}$	the linear	•	A/B/Z-phase differential output method

Notes: 1. Contact the relevant linear encoder manufacturer for details on operating environment and specifications of the linear encoder such as ambient temperature, vibration resistance and IP rating.

2. The listed values are the manufacturer's specifications. When combined with MR-J5_-_servo amplifiers, the specification value is either the listed value or the servo motor maximum speed, whichever is lower.

3. The listed values are the manufacturer's specifications. The maximum length of the encoder cable between a linear encoder and a servo amplifier is 30 m. For a linear encoder manufactured by Nidec Machine Tool Corporation, the maximum length of the encoder cable between the linear encoder and a servo amplifier is 20 m.


4. The compatible communication method varies by the servo amplifier and operation mode. Refer to "External Encoder Connection Specifications" in this catalog. 5. Select the linear encoder within this range.

6. There are some restrictions on this linear encoder. When using it, contact your local sales office.

7. For this combination, it is recommended using EIB 3091M with a subdivision of 16384. EIB 3091M with a subdivision of 4096 is also available. Contact the manufacturer for details.

8. For the measurement length over 10000 mm, contact Nidec Machine Tool Corporation.


9. The phase difference of the A-phase pulse and the B-phase pulse, and the width of the Z-phase pulse must be 200 ns or wider. The output pulse of A-phase and B-phase of the A/B/Z-phase differential output linear encoder is in the multiply-by-four count method. For linear encoders without Z-phase, some of the homing modes cannot be used. Refer to "MR-J5 User's Manual" for details.



Determining the Number of the Secondary-Side (Magnet) Blocks

The number of the secondary-side (magnet) blocks is determined according to the total distance calculated from the following equation (Note 2) :

(Total length of aligned secondary side (magnet)) ≥ (Maximum feed distance) + (Length of the primary side (coil))



- Notes: 1. Pitch tolerance between any two holes must be within ±0.2 mm. When two or more secondary sides (magnets) are mounted lined up, there may be a gap between each block, depending on the mounting method and the number of the blocks.
 - 2. LM-K2 series has a structure of magnetic attraction counter-force and requires at least two blocks of identical secondary side (magnet). Therefore, the total number of the secondary side necessary equals to twice the number determined from the equation.

Servo System Controllers

Support

Linear Servo Motors

MEMO

6 Direct Drive Motors

Model Designation	6-2
Specifications	
TM-RG2M Series/TM-RU2M Series	6-4
TM-RFM Series	6-6
Machine Accuracy	6-9
Power Supply Capacity	6-10
Dimensions	
TM-RG2M Series	6-12
TM-RU2M Series	6-14
TM-RFM Series	6-16


* Refer to p. 7-78 in this catalog for conversion of units.
 * The characteristics and numerical values without tolerances mentioned in this catalog are representative values.

Model Designation (Note 1, 2)


Low-profile series

Flange type

<u>T M - R G 2 M</u>




•Table type



Notes: 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available. 2. Use the direct drive motors manufactured in June 2019 or later when connecting to MR-J5 servo amplifiers. If the direct drive motors manufactured before the date above are connected, an alarm occurs.

Model Designation (Note 1, 2) High-rigidity series



 Notes:
 1. This section describes what each symbol in a model name indicates. Some combinations of symbols are not available.

 2. Use the direct drive motors manufactured in June 2019 or later when connecting to MR-J5 servo amplifiers. If the direct drive motors manufactured before the date above are connected, an alarm occurs.

Support

TM-RG2M Series/TM-RU2M Series Specifications

Direct drive m	otor model TM-RG2M TM-RU2M	002C30	004E30	009G30			
Motor outer di (frame dimension	Imm	Ø130	ø180	ø230			
Continuous	Rated output (Note 4) [W	69	141 (188)	283			
running duty	Rated torque (Note 3, 4) [N•m]	2.2	4.5 (6)	9			
Maximum toro	que (Note 4) [N•m]	8.8	13.5 (18)	27			
Rated speed	[r/min]	300					
Maximum spe	ed [r/min]	600					
Power rate at rated torque (N		6.1	3.4 (6.0)	5.5			
Rated current	(Note 4) [A	1.2	1.3 (1.7)	2.2			
Maximum cur	rent (Note 4) [A]	4.9	4.0 (5.3)	6.7			
Moment of ine	ertia J [x 10 ⁻⁴ kg·m ²]	7.88	60.2	147			
Recommende (Note 1)	ed load to motor inertia ratio	50 times or less	20 times or less				
Absolute accu	Iracy (Note 5) [S]	±15	±12.5				
Speed/ position detector	Absolute/incremental *1	21-bit encoder 2097152 pulses/rev					
Туре		Permanent magnet synchronous motor					
Thermistor		Built-in					
Insulation class	SS	155 (F)					
Structure		Totally enclosed, natural cooling (IP rating: IP40) (Note 2)					
Vibration resis	stance ^{*2} [m/s ²]	X: 49, Y: 49	X: 49, Y: 49				
Vibration rank		V10 ^{*4}					
Rotor permissible	Moment load [N·m]	15	49	65			
load *3	Axial load [N	770	2300	3800			
Mass	[kg]	2.7	5.5	8.3			
		-	·	*			

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table.

2. Connectors and a gap along the rotor (output shaft) are excluded.

3. When unbalanced torque is generated, such as in a vertical lift machine, use the absolute position detection system, and keep the unbalanced torque under 70 % of the servo motor rated torque.


4. The values in brackets are applicable when the torque is increased in combination with a larger-capacity servo amplifier.

Refer to "Combinations of Direct Drive Motors and Servo Amplifiers" in this catalog for the combination. 5. Absolute accuracy varies according to the mounting state of load and the surrounding environment.

Refer to "Annotations for Direct Drive Motor Specifications" on p. 6-11 in this catalog for the details about asterisks 1 to 4.


TM-RG2M Series/TM-RU2M Series Torque Characteristics

TM-RG2M002C30, TM-RU2M002C30 ^(Note 1, 2, 3)



TM-RG2M009G30,


TM-RU2M009G30 (Note 1, 2, 3)



Notes: 1. For 3-phase 200 V AC or 1-phase 230 V AC

- 2. ----: For 1-phase 200 V AC
- 3. Torque drops when the power supply voltage is below the specified value.
- 4. This value is applicable when the torque is increased in combination with a larger-capacity servo amplifier. Refer to "Combinations of Direct Drive Motors and Servo Amplifiers" in this catalog for the combinations.

Mounting of TM-RG2M Series/TM-RU2M Series



Precautions when mounting the direct drive motor

• Fix the direct drive motor securely on a high-rigid mounting surface because a machine resonance may occur if the rigidity of the mounting surface is low.

- · Fix the mounting screws of the direct drive motor and a rotating table securely to ensure enough rigidity.
- To ensure heat dissipation and accuracy, mount the direct drive motor on a high-rigid mounting surface which has enough heat dissipation area without gaps between the bottom of the direct drive motor and the mounting surface.

• The flange type has a higher mounting accuracy than the table type. When a high-mounting accuracy is required, select the flange type.

Refer to "Direct Drive Motor Machine Accuracy" on p. 6-9 in this catalog for the machine accuracy of each direct drive motor, and refer to the dimensions in this catalog for the dimensional tolerance.

400

Speed [r/min]

600

20

15

5

0

Short-duration

running range

Continuous

running range


200

[N·m]

] 10 Lordne

TM-RG2M004E30, TM-RU2M004E30 (Note 1, 2, 3, 4)

(when torque is increased)



Product

TM-RFM Series Specifications

Direct drive m	otor model	TM-RFM	002C20	004C20	006C20	006E20	012E20	018E20	
Motor outer diameter [mm] (frame dimensions)			ø130			ø180	ø180		
Continuous	Rated output	[W]	42	84	126	126	251	377	
running duty	Rated torque (Note 3)	[N•m]	2	4	6	6	12	18	
Maximum toro	que	[N•m]	6	12	18	18	36	54	
Rated speed		[r/min]	200						
Maximum spe	ed	[r/min]	500						
Power rate at rated torque	continuous	[kW/s]	3.7	9.6	16.1	4.9	12.9	21.8	
Rated current		[A]	1.3	2.2	3.2	3.0	3.8	6.0	
Maximum cur	rent	[A]	3.9	6.6	9.6	9.0	12	18	
Moment of ine	ertia J [× 10) ⁻⁴ kg•m²]	10.9	16.6	22.4	74.0	111	149	
Recommende (Note 1)	ed load to motor inert	tia ratio	50 times or less						
Absolute accu	Iracy (Note 4)	[s]	±15 ±12.5						
Speed/positio	n detector		Absolute/incremental 20-bit encoder ^{*1} (resolution: 1048576 pulses/rev)						
Туре			Permanent magnet synchronous motor						
Thermistor			Built-in						
Insulation clas	SS		155 (F)						
Structure			Totally enclosed, natural cooling (IP rating: IP42) (Note 2)						
Vibration resis	stance *2	[m/s ²]	X: 49, Y: 49						
Vibration rank	Σ.		V10 ^{*4}						
Rotor permissible	Moment load	[N•m]	22.5			70			
load *3	Axial load	[N]	1100			3300			
Mass		[kg]	5.2	6.8	8.4	11	15	18	

Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table. 2. Connectors and a gap along the rotor (output shaft) are excluded.

3. When unbalanced torque is generated, such as in a vertical lift machine, use the absolute position detection system, and keep the unbalanced torque under 70 % of the servo motor rated torque.

4. Absolute accuracy varies according to the mounting state of load and the surrounding environment.

Refer to "Annotations for Direct Drive Motor Specifications" on p. 6-11 in this catalog for the details about asterisks 1 to 4.

S


TM-RFM Series Specifications

Direct drive m	otor model T	M-RFM	012G20	048G20	072G20	040J10	120J10	240J10	specifications	
Motor outer diameter [mm] (frame dimensions)] ø230			ø330	ø330			
Continuous	Rated output	[W]	251	1005	1508	419	1257	2513	ى ا	
running duty	Rated torque (Note 3)	[N•m]	12	48	72	40	120	240		
Maximum torq	ue	[N•m]	36	144	216	120	360	720	Controllers	
Rated speed		[r/min]	200			100			Controllers	
Maximum spe	ed	[r/min]	500			200			ller	
Power rate at rated torque	continuous	[kW/s]	6.0	37.5	59.3	9.4	40.9	91.4	S GI	
Rated current		[A]	3.6	11	16	4.3	11	19	Ser	
Maximum curr	ent	[A]	11	33	48	13	33	57		
Moment of ine	rtia J [× 10 ⁻	⁻⁴ kg•m²]	238	615	875	1694	3519	6303	- Amp	
Recommende (Note 1)	commended load to motor inertia ratio 50 times or less						Servo Amplifiers			
Absolute accu	e accuracy (Note 4) [s] ±12.5 ±10									
Speed/position	n detector		Absolute/incremental 20-bit encoder *1 (resolution: 1048576 pulses/rev)							
Туре			Permanent ma	Permanent magnet synchronous motor						
Thermistor			Built-in	Built-in						
Insulation clas	S		155 (F)						Motors	
Structure			Totally enclose	ed, natural cooli	ng (IP rating: IP4				_	
Vibration resis	tance *2	[m/s ²]	X: 49, Y: 49			X: 24.5, Y: 2	24.5			
Vibration rank			V10*4						Mo	
Rotor permissible	Moment load	[N•m]	93			350			Motors	
load *3	Axial load	[N]	5500			16000			ò	
Mass		[kg]	17	36	52	53	91	146		
 Notes: 1. Contact your local sales office if the load to motor inertia ratio exceeds the value in the table. 2. Connectors and a gap along the rotor (output shaft) are excluded. 3. When unbalanced torque is generated, such as in a vertical lift machine, use the absolute position detection system, and keep the unbalanced torque under 70 % of the servo motor rated torque. 4. Absolute accuracy varies according to the mounting state of load and the surrounding environment. 										

Refer to "Annotations for Direct Drive Motor Specifications" on p. 6-11 in this catalog for the details about asterisks 1 to 4.

Support

TM-RFM Series Torque Characteristics



For 3-phase 200 V AC or 1-phase 230 V AC Notes: 1. =

The following direct drive motors are compatible with 1-phase 230 V AC: TM-RFM002C20, TM-RFM004C20, TM-RFM006C20, TM-RFM006E20, TM-RFM012E20, TM-RFM018E20, TM-RFM012G20, and TM-RFM040J10 2. ----: For 1-phase 200 V AC


3. Torque drops when the power supply voltage is below the specified value.


Direct Drive Motor Machine Accuracy

The machine accuracy related to the direct drive motor rotor (output shaft) and mounting is indicated below:


Item	Measuring position	Accuracy [mm]
Runout of flange surface about rotor (output shaft)	a	0.05
Runout of fitting outer diameter of flange surface	b	0.07
Runout of rotor (output shaft)	с	0.04
Runout of rotor (output shaft) end	d	0.02

●TM-RG2M series





●TM-RFM series



Linear Servo Motors

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Power Supply Capacity

Direct drive motor		Servo amplifier (Note 3)	Power supply capacity [kVA] (Note 1, 2)			
	TM-RG2M002C30	MR-J5-20G/B/A MR-J5W2-22G/B, MR-J5W2-44G/B	0.25			
	TM-RU2M002C30	MR-J5W3-222G/B, MR-J5W3-444G/B				
	TM-RG2M004E30	MR-J5-20G/B/A MR-J5W2-22G/B	0.5			
	TM-RU2M004E30	MR-J5W3-222G/B	0.5			
TM-RG2M series/ TM-RU2M series	TM-RG2M004E30	MR-J5-40G/B/A	0.7			
	TM-RU2M004E30	MR-J5W2-44G/B MR-J5W3-444G/B	0.7			
	TM-RG2M009G30	MR-J5-40G/B/A MR-J5W2-44G/B, MR-J5W2-77G/B	0.9			
	TM-RU2M009G30	MR-J5W2-1010G/B MR-J5W3-444G/B	0.9			
	TM-RFM002C20	MR-J5-20G/B/A MR-J5W2-22G/B, MR-J5W2-44G/B MR-J5W3-222G/B, MR-J5W3-444G/B	0.25			
	TM-RFM004C20	MR-J5-40G/B/A MR-J5W2-44G/B, MR-J5W2-77G/B MR-J5W2-1010G/B MR-J5W3-444G/B	0.38			
	TM-RFM006C20	MR-J5-60G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	0.53			
	TM-RFM006E20	MR-J5-60G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	0.46			
	TM-RFM012E20	MR-J5-70G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	0.81			
TM-RFM series	TM-RFM018E20	MR-J5-100G/B/A MR-J5W2-1010G/B	1.3			
	TM-RFM012G20	MR-J5-70G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	0.71			
	TM-RFM048G20	MR-J5-350G/B/A	2.7			
	TM-RFM072G20	MR-J5-350G/B/A	3.8			
	TM-RFM040J10	MR-J5-70G/B/A MR-J5W2-77G/B, MR-J5W2-1010G/B	1.2			
	TM-RFM120J10	MR-J5-350G/B/A	3.4			
	TM-RFM240J10	MR-J5-500G/B/A	6.6			
			1			

Notes:


The power supply capacity varies depending on the power supply impedance.
 The listed values are the power supply capacity for one servo motor. For the multi-axis servo amplifiers, calculate the power supply capacity with the equation below: Power supply capacity [kVA] = Sum of power supply capacity [kVA] of the connected servo motors
 Note that the power supply capacity for servo amplifiers with special specifications is the same as that for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

Annotations for Direct Drive Motor Specifications


- *1. Connect the following options for absolute position detection system.
 MR-J5-G_/MR-J5-B_/MR-J5-A_: battery (MR-BAT6V1SET or MR-BAT6V1SET-A) and absolute position storage unit (MR-BTAS01) • MR-J5W_: battery case (MR-BT6VCASE), battery (MR-BAT6V1) × 5 pcs., and absolute position storage unit (MR-BTAS01)
 - Refer to "MR-J5 User's Manual" for details.
- *2. The vibration direction is shown in the diagram below. The numerical value indicates the maximum value of the component.
 - Fretting tends to occur on the bearing when the direct drive motor stops. Thus, maintain vibration level at approximately one-half of the allowable value.



*3. The following is calculation examples of axial and moment loads to the rotor (output shaft) of the direct drive motor. The axial and moment loads must be maintained equal to or below the permissible value.



*4. V10 indicates that the amplitude of the direct drive motor itself is 10 µm or less. The following shows mounting orientation and measuring position of the direct drive motor during the measurement:



TM-RFM series

19.1

20.2


24.4

32.5


Support

TM-RG2M Series Dimensions (Note 1, 2)

•TM-RG2M002C30



●TM-RG2M004E30




Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing. 2. ______ indicates rotor.

[Unit: mm]

TM-RG2M Series Dimensions (Note 1, 2)

•TM-RG2M009G30




1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing. 2. _____ indicates rotor. Notes:


Direct Drive Motors

TM-RU2M Series Dimensions (Note 1, 2)

●TM-RU2M002C30



●TM-RU2M004E30



1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing.

[Unit: mm]

Notes: 1. General tolerances are applied to the dimensional 2. Indicates rotor.

6-M5 screw depth 8

S

Q

TM-RU2M Series Dimensions (Note 1, 2)


0

□230

0

 \boxtimes

•TM-RU2M009G30



54

3

26 4

19

2-ø6H7 depth 8 P.C.D.260±0.03 4-ø14 mounting hole Use hexagonal cap

9260

45

head bolts.

Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing. 2. ______ indicates rotor.


[Unit: mm]




Common Specifications

TM-RFM Series Dimensions (Note 1, 2)

•TM-RFM002C20, TM-RFM004C20, TM-RFM006C20



•TM-RFM006E20, TM-RFM012E20, TM-RFM018E20




[Unit: mm]

Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing. The actual dimensions may be 1 mm to 3 mm larger than the dimensions indicated. Make allowances for the tolerance when designing a machine.


indicates rotor.

TM-RFM Series Dimensions (Note 1, 2)

•TM-RFM012G20, TM-RFM048G20, TM-RFM072G20



TM-RFM040J10, TM-RFM120J10, TM-RFM240J10



[Unit: mm]

Notes: 1. General tolerances are applied to the dimensions in which tolerances are not given in the drawing. The actual dimensions may be 1 mm to 3 mm larger than the dimensions indicated. Make allowances for the tolerance when designing a machine.

2. indicates rotor.

Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Support

Direct Drive Motors

MEMO

7 **Options/Peripheral Equipment**

				Sei	vo a	mpli	fier				_
	G	G-RJ	G-HS	WG	DG	В	B-RJ	WB	Α	A-RJ	• : Applicable
Introducing FA Integrated Selection Tool											
Cable and Connector Selection Table for Servo Motors		•	•	•	٠	\bullet	•	•	\bullet	•	7-2
Configuration Example for Servo Motors											
Details of Option Connectors for Servo Motors	\bullet	•	•		•	\bullet	•		\bullet	•	7-19
Products on the Market for Servo Motors											
Configuration Example for MR-J5G(-RJ)/MR-J5G4-HS/MR-J5WG	\bullet										7-28
Configuration Example for MR-J5DG4											7-30
Ethernet Cable Specifications	\bullet										7-30
Configuration Example for MR-J5B(-RJ)/MR-J5WB											7-31
Configuration Example for MR-J5A(-RJ)									ullet		7-32
Bus Bar											7-37
Configuration Example for MR-CM	\bullet					\bullet			ullet		7-38
Configuration Example for MR-J3-D05									\bullet		7-39
Details of Option Connectors for Servo Amplifiers/MR-CM/MR-J3-D05	\bullet					\bullet			ullet		7-40
Products on the Market for Servo Amplifiers											
Safety Logic Unit	\bullet					\bullet			ullet		
Regenerative Option											7-50
Multifunction Regeneration Converter	\bullet					\bullet			ullet		7-53
Battery and Battery Case											7-55
Absolute Position Storage Unit	\bullet								ullet	۲	7-57
Replacement Fan Unit											7-57
Cabinet-Mounting Attachment	\bullet								ullet	۲	7-58
Grounding Terminal Attachment											
Shield Clamp Attachment	\bullet					ullet			ullet		7-59
Mounting Attachment											
Side Protection Cover											
Junction Terminal Block											
Radio Noise Filter/Line Noise Filter/Data Line Filter	\bullet					\bullet			ullet		
Surge Killer											7-63
EMC Filter	\bullet					\bullet			ullet		
Surge Protector									\bullet		
Power Factor Improving Reactor	ullet	•	•			ullet					
AC Reactor											
Motorizer/MR Configurator2	ullet	•	•			ullet			ullet		
Unit Conversion Table											

G MR-J5-G(-N1) G-RJ MR-J5-G-RJ(N1) G-HS MR-J5-G4-HS(N1) WG MR-J5W2-G(-N1)/MR-J5W3-G(-N1) DG MR-J5D1-G4(-N1)/ MR-J5D2-G4(-N1)/MR-J5D3-G4(-N1) B MR-J5-B B-RJ MR-J5-B-RJ WB MR-J5W2-B/MR-J5W3-B A MR-J5-A A-RJ MR-J5-A-RJ

* Note that options/peripheral equipment necessary for servo amplifiers or drive units with special specifications are the same as those for standard servo amplifiers or standard drive units. Refer to the serve amplifiers or drive units with the same rated output. * Refer to p. 7-78 in this catalog for conversion of units.

* In this section, a term of servo amplifier includes a combination of a drive unit and a converter unit.

Introducing FA Integrated Selection Tool

FA Integrated Selection Tool is now available, so you can select options such as encoder cables and power cables which are required to use with controllers, servo motors, servo amplifiers, and regenerative options of your choice.



Cable and Connector Selection Table for Servo Motors

Necessary option cables and connectors vary depending on the servo motor series. Refer to the following tables for necessary options.

Cables for HK-KT series/HK-MT	sorios/HK-BT	$(1 \ 0 \ k)W$ to $2 \ 0 \ kW$	sorios sorvo motors
Capies IOI TR-RT Selles/TR-IVIT	Selles/nk-ni	(I.U KVV 10 Z.U KVV)	

Cable type	Cable length	IP rating (Note 1)	Electromagnetic brake wires	Cable direction	Bending life (Note 5)	Model	Reference			
				In the direction	Long bending life	MR-AEPB2CBL_M-A1-H				
				of the load side	Standard	MR-AEPB2CBL_M-A1-L	1			
			Available	In the opposite	Long bending life	MR-AEPB2CBL_M-A2-H				
				direction of the load side	Standard	MR-AEPB2CBL_M-A2-L				
	10 m or shorter				Long bending life	MR-AEPB2CBL_M-A5-H	-			
	(direct	IP65		Vertical (Note 4)	Standard	MR-AEPB2CBL_M-A5-L	1			
	connection	(Note 3)		In the direction			p. 7-6			
	type)			of the load side	Standard	MR-AEP2CBL_M-A1-L	1			
				In the opposite	Long bending life	MR-AEP2CBL_M-A2-H	-			
			Not available	direction of the load side	Standard	MR-AEP2CBL_M-A2-L	-			
Jal ble be) (ti I (Noto 4)	Long bending life	MR-AEP2CBL_M-A5-H	1			
				Vertical (Note 4)	Standard	MR-AEP2CBL_M-A5-L	-			
				In the direction	Long bending life	MR-AEPB2J10CBL03M-A1-L, MR-AEKCBL_M-H				
			Available	of the load side	Standard	MR-AEPB2J10CBL03M-A1-L, MR-AEKCBL_M-L]			
				In the opposite direction of the	Long bending life	MR-AEPB2J10CBL03M-A2-L, MR-AEKCBL_M-H				
				load side	Standard	andard MR-AEPB2J10CBL03M-A2-L, MR-AEKCBL_M-L				
				Vertical (Note 4)	Long bending life	MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-H]			
		IP20		vertical (Note 4)	Standard	MR-AEPB2J10CBL03M-A5-L, MR-AEKCBL_M-L	p. 7-7			
				In the direction	Long bending life	MR-AEP2J10CBL03M-A1-L, MR-AEKCBL_M-H	p. /-/			
0				of the load side	Standard	MR-AEP2J10CBL03M-A1-L, MR-AEKCBL_M-L				
				In the opposite direction of the	Long bending life	MR-AEP2J10CBL03M-A2-L, MR-AEKCBL_M-H				
				load side	Standard	MR-AEP2J10CBL03M-A2-L, MR-AEKCBL_M-L				
	0			Vertical (Note 4)	Long bending life	MR-AEP2J10CBL03M-A5-L, MR-AEKCBL_M-H				
	Over 10 m (junction type)			Vertical	Standard	MR-AEP2J10CBL03M-A5-L, MR-AEKCBL_M-L				
	(Note 2)			In the direction	Long bending life	MR-AEPB2J20CBL03M-A1-L, MR-AENSCBL_M-H				
				of the load side	Standard	MR-AEPB2J20CBL03M-A1-L, MR-AENSCBL_M-L				
			Available	In the opposite direction of the	Long bending life	MR-AEPB2J20CBL03M-A2-L, MR-AENSCBL_M-H				
			Available	load side	Standard	MR-AEPB2J20CBL03M-A2-L, MR-AENSCBL_M-L				
				Vertical (Note 4)	Long bending life	MR-AEPB2J20CBL03M-A5-L, MR-AENSCBL_M-H				
		IP65		ventical	Standard	MR-AEPB2J20CBL03M-A5-L, MR-AENSCBL_M-L	p. 7-8			
		(Note 3)		In the direction	Long bending life	MR-AEP2J20CBL03M-A1-L, MR-AENSCBL_M-H	p. 7-8			
				of the load side	Standard	MR-AEP2J20CBL03M-A1-L, MR-AENSCBL_M-L				
				In the opposite direction of the	Long bending life	MR-AEP2J20CBL03M-A2-L, MR-AENSCBL_M-H				
			NUL AVAIIADIE	load side	Standard	MR-AEP2J20CBL03M-A2-L, MR-AENSCBL_M-L				
				Vortical (Note 4)	Long bending life	MR-AEP2J20CBL03M-A5-L, MR-AENSCBL_M-H	1			
				Vertical (Note 4)	Standard	MR-AEP2J20CBL03M-A5-L, MR-AENSCBL_M-L	1			

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

2. The two types of cables indicated are required.

3. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

4. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

5. Long bending life cables and standard cables are for moving parts and fixed parts respectively.

Cable and Connector Selection Table for Servo Motors

	Cable and Connector Selection Table for Servo Motors Cables for HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series servo motors								
Cable type	Cable length	IP rating (Note 1)	Electromagnetic brake wires	Cable direction	Bending life (Note 5)	Model	Reference	Common Specifications	
				In the direction	Long bending life	MR-AEPB1CBL_M-A1-H			
				of the load side	Standard	MR-AEPB1CBL_M-A1-L		S	
		t IP65	Available	In the opposite direction of the	Long bending life	MR-AEPB1CBL_M-A2-H		Servo Syste Controllers	
				load side	Standard	MR-AEPB1CBL_M-A2-L	-	System rollers	
	10 m or shorter			Vertical (Note 4)	Long bending life	MR-AEPB1CBL_M-A5-H		em.	
Single cable	(direct		P65	Vertical	Standard	MR-AEPB1CBL_M-A5-L	n 7 0		
type	connection			In the direction	Long bending life	MR-AEP1CBL_M-A1-H	p. 7-9	Servo	
type	type)			of the load side	Standard	MR-AEP1CBL_M-A1-L		No.	
			Not available	In the opposite direction of the	Long bending life	MR-AEP1CBL_M-A2-H		Amplifiers	
			NOL AVAIIADIE	load side	Standard	MR-AEP1CBL_M-A2-L		ifiers	
				Vertical (Note 4)	Long bending life	MR-AEP1CBL_M-A5-H			
				Vertical	Standard	MR-AEP1CBL_M-A5-L		Ro	

Cables for HK-ST series/HK-RT (3.5 kW to 7.0 kW) series servo motors

			Stanuaru		JDL_IVI-AS-L		6			
Cables for HK-ST series/HK-RT (3.5 kW to 7.0 kW) series servo motors Application Compatible servo motor Bending life (Note 1) Length Model Reference										
Application	Compatible servo motor	IP rating (Note 1)		Length	Model	Reference	č			
			Long bending life	2 m to 10 m	MR-J3ENSCBL_M-H		5			
Freedor	HK-ST series	V. IP67		20 m to 50 m	MR-AENSCBL_M-H	n 7 0	Motors			
Encoder	HK-RT353(4)W, 503(4)V 703(4)W	<i>i</i> , iP07	Standard	2 m to 10 m	MR-J3ENSCBL_M-L	p. 7-8	otor			
	703(4)			20 m to 30 m	MR-AENSCBL M-L		S			

Connectors for HK-ST series/HK-RT (3.5 kW to 7.0 kW) series servo motors

Application	Compatible servo motor	IP rating (Note 1)	Connector shape	Type of connection	Model (Note 2)	Reference	Direct Dri Motors
			Otroight	One-touch	MR-J3SCNS	p. 7-9	- 'S
Encoder	HK-ST series HK-RT353(4)W, 503(4)W,	IP67	Straight	Screw	MR-ENCNS2		
Encoder	703(4)W		Angle	One-touch	MR-J3SCNSA		0
	/ 00(4)//		Angle	Screw	MR-ENCNS2A		л. Б
Power supply (Note 6)	HK-ST52(4)(W), 102(4)(W), 172(4)W, 202(4)AW, 302(4)W, 353(4)W, 503(4)W			One-touch	MR-APWCNS4		Options/Peripheral Equipment
	HK-ST7M2UW, 172UW, 202(4)(W), 352(4)(W), 502(4)(W), 702(4)(W) HK-RT353(4)W, 503(4)W, 703(4)W	IP67	Straight	One-touch	MR-APWCNS5	p. 7-10	al LVS/Wires
			Otroinht	One-touch	MR-BKCNS1		res
Electromagnetic	HK-ST series	1007	Straight	Screw	MR-BKCNS2		
brake	HK-RT353(4)WB, 503(4)WB, 703(4)WB	IP67	America	One-touch	MR-BKCNS1A		
	/ 00(4) ***		Angle	Screw	MR-BKCNS2A		Pro

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

Use the option connector set indicated to fabricate a cable.
 When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

4. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

5. Long bending life cables and standard cables are for moving parts and fixed parts respectively.


6. Connectors for HK-ST152(4)G1/G1H/G5/G7 geared servo motors are the same as those for HK-ST172(4)W.


Product

List


Options/Peripheral Equipment

Configuration Example for Rotary Servo Motors (Note 2)






HK-ST series/HK-RT (3.5 kW to 7.0 kW) series




Notes: 1. Secure this cable as it does not have a long bending life.

- 2. Cables drawn with dashed lines need to be fabricated by users. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.
- 3. This is for the servo motors with an electromagnetic brake.
- 4. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.
- 5. The cable direction in the configuration examples is in the opposite direction to the load side.
- Cables can be led out in the direction of the load side, the opposite to the load side, and vertical, depending on the option to be used. These cable directions are shown below.



Options/Peripheral Equipment



1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables.

2. Cables drawn with dashed lines need to be fabricated by users. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when fabricating the cables.

3. Connections other than mentioned are the same as those for each rotary servo motor. Refer to cables and connectors for relevant servo motors in this catalog.

4. Necessary encoder cables vary depending on the servo motor series. Refer to cables and connectors for relevant servo motors in this catalog.

Product List

Precautions

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)
		HK-KT series		2 m	MR-AEPB2CBL2M-A1-H	
1)		HK-MT series	Long bending life	5 m	MR-AEPB2CBL5M-A1-H	Servo motor
		HK-RT103(4)WB,	benuing me	10 m	MR-AEPB2CBL10M-A1-H	connector Servo amplifier connecto
		153(4)WB, 203(4)WB Load-side lead		2 m	MR-AEPB2CBL2M-A1-L	
2)		With electromagnetic	Standard	5 m	MR-AEPB2CBL5M-A1-L	IP65
		brake wires		10 m	MR-AEPB2CBL10M-A1-L	
		HK-KT series	1	2 m	MR-AEPB2CBL2M-A2-H	
3)		HK-MT series	Long bending life	5 m	MR-AEPB2CBL5M-A2-H	Servo motor
		HK-RT103(4)WB,	benuing me	10 m	MR-AEPB2CBL10M-A2-H	connector Servo amplifier connecto
		153(4)WB, 203(4)WB Opposite to load-side lead		2 m	MR-AEPB2CBL2M-A2-L	
4)		With electromagnetic	Standard	5 m	MR-AEPB2CBL5M-A2-L	IP65
		brake wires		10 m	MR-AEPB2CBL10M-A2-L	
		HK-KT series		2 m	MR-AEPB2CBL2M-A5-H	
5)		HK-MT series	Long bending life	5 m	MR-AEPB2CBL5M-A5-H	Servo motor
		HK-RT103(4)WB,		10 m	MR-AEPB2CBL10M-A5-H	connector Servo amplifier connect
		153(4)WB, 203(4)WB Vertical lead (Note 5)		2 m	MR-AEPB2CBL2M-A5-L	
6)	Motor cable (Note 2, 3)	With electromagnetic	Standard	5 m	MR-AEPB2CBL5M-A5-L	IP65
	(dual cable type/	brake wires		10 m	MR-AEPB2CBL10M-A5-L	
	direct connection	HK-KT series		2 m	MR-AEP2CBL2M-A1-H	
7)	shorter)	HK-MT series	Long bending life	5 m	MR-AEP2CBL5M-A1-H	Servo motor
		HK-RT103(4)W,	bending life	10 m	MR-AEP2CBL10M-A1-H	connector Servo amplifier connect
		153(4)W, 203(4)W Load-side lead		2 m	MR-AEP2CBL2M-A1-L	
8)		Without electromagnetic	Standard	5 m	MR-AEP2CBL5M-A1-L	IP65
·		brake wires		10 m	MR-AEP2CBL10M-A1-L	
		HK-KT series		2 m	MR-AEP2CBL2M-A2-H	
9)		HK-MT series	Long	5 m	MR-AEP2CBL5M-A2-H	Servo motor
·		HK-RT103(4)W,	bending life	10 m	MR-AEP2CBL10M-A2-H	connector Servo amplifier connect
	-	153(4)W, 203(4)W Opposite to load-side lead		2 m	MR-AEP2CBL2M-A2-L	
10)		Without electromagnetic	Standard	5 m	MR-AEP2CBL5M-A2-L	IP65
ŕ		brake wires		10 m	MR-AEP2CBL10M-A2-L	_
	-	HK-KT series		2 m	MR-AEP2CBL2M-A5-H	
11)		HK-MT series	Long	5 m	MR-AEP2CBL5M-A5-H	Servo motor
		HK-RT103(4)W,	bending life	10 m	MR-AEP2CBL10M-A5-H	connector Servo amplifier connect
		153(4)W, 203(4)W		2 m	MR-AEP2CBL2M-A5-L	
12)		Vertical lead (Note 5) Without electromagnetic	Standard	5 m	MR-AEP2CBL5M-A5-L	IP65
-/		brake wires		10 m	MR-AEP2CBL10M-A5-L	

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all. 2. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
 When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Long bending life cables and standard cables are for moving parts and fixed parts respectively.

5. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

Options/Peripheral Equipment

ŝ

Cables and Connectors for Rotary Servo Motors

			Bending life		log for the detailed models.		Common ecificatio
No.	Item	Application	(Note 7)	length	Model	Description/IP rating (Note 1)	Common
(13)		HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J10CBL03M-A1-L	Servo motor connector Junction connector IP20 IP65	Servo System Controllers
(14)		HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J10CBL03M-A2-L	Servo motor connector Junction connector IP65	Servo Amplifiers
(15)	Motor cable ^(Note 3, 5) (dual cable type/	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead ^(Note 8) With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J10CBL03M-A5-L	Servo motor connector Junction connector	Rotary Servo Motors
(16)	junction type for over 10 m)	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic	Standard	0.3 m	MR-AEP2J10CBL03M-A1-L	Servo motor connector Junction connector IP20 IP65	Linear Servo Motors
(17)		brake wires HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J10CBL03M-A2-L	Servo motor connector Junction connector IP65	Direct Drive Option Motors Ec
(18)	-	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead (Note 8) Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J10CBL03M-A5-L	Servo motor connector Junction connector	Options/Peripheral LVS, Equipment
(19)	Encoder cable	HK-KT series HK-MT series	Long bending life	20 m 30 m 40 m	MR-AEKCBL20M-H MR-AEKCBL30M-H MR-AEKCBL40M-H	Junction connector Servo amplifier connector	LVS/Wires
(20)	(Note 4, 5, 9)	HK-RT103(4)W, 153(4)W, 203(4)W	Standard	50 m 20 m 30 m	MR-AEKCBL50M-H MR-AEKCBL20M-L MR-AEKCBL30M-L		
(21)	Encoder connector set (Note 2, 4, 6)	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Connecting a load-side encoder	-	-	MR-ECNM	Junction connector Servo amplifier connector IP20 Applicable cable Wire size: AWG 26 to 22 Cable OD: 7 mm to 9 mm	Product List Precautions

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all. 2. The crimping tool (91529-1) manufactured by TE Connectivity Ltd. Company is required. Contact the manufacturer directly.

3. Use this cable in combination with an option from (19) to (21).

4. When using this cable or connector set for HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series, use it in combination with an option from (13) to (18).

5. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp) 6. Use MR-EKCBL_M-H or MR-ECNM to connect to an output cable for AT343A, AT543A-SC or AT545A-SC scales manufactured by Mitutoyo Corporation.

I consider the cables and standard cables are for moving parts and fixed parts respectively.
 When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

9. Encoder cables are not subject to Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).

Support

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life (Note 6)	Cable length	Model	Description/IP rating (Note 1)
(22)		HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J20CBL03M-A1-L	Servo motor connector Junction connector IP65
(23)		HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J20CBL03M-A2-L	Servo motor connector Junction connector IP65
(24)	Motor cable (Note 2, 4, 5)	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead ^(Note 7) With electromagnetic brake wires	Standard	0.3 m	MR-AEPB2J20CBL03M-A5-L	Servo motor connector Junction connector IP65
(25)	(dual cable type/ junction type for over 10 m)	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J20CBL03M-A1-L	Servo motor connector Junction connector IP65
(26)		HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J20CBL03M-A2-L	Servo motor connector Junction connector IP65
(27)		HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead ^(Note 7) Without electromagnetic brake wires	Standard	0.3 m	MR-AEP2J20CBL03M-A5-L	Servo motor connector Junction connector IP65
(28)		HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W	Long bending life	2 m 5 m 10 m	MR-J3ENSCBL2M-H MR-J3ENSCBL5M-H MR-J3ENSCBL10M-H	
(29)	Encoder cable	HK-KT series HK-MT series HK-ST series HK-RT series	Long bending life	20 m 30 m 40 m 50 m	MR-AENSCBL20M-H MR-AENSCBL30M-H MR-AENSCBL40M-H MR-AENSCBL50M-H	Junction connector Servo amplifier or encoder connector connector
(30)	(Note 3, 4, 8)	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W	Standard	2 m 5 m 10 m	MR-J3ENSCBL2M-L MR-J3ENSCBL5M-L MR-J3ENSCBL10M-L	IP67
(31)		HK-KT series HK-MT series HK-ST series	Standard	20 m 30 m	MR-AENSCBL20M-L MR-AENSCBL30M-L	

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

Use this cable in combination with (29), (31), or (32).
 When using this cable or connector set for HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series, use it in combination with an option from (22) to (27).

4. For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp) 5. When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

6. Long bending life cables and standard cables are for moving parts and fixed parts respectively.

7. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

8. Encoder cables are not subject to Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).

Options/Peripheral Equipment

Con Specif

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life (Note 4)	Cable length	Model	Description/IP rating	(Note 1)	ifications
(32)	Encoder connector set (Note 6, 7, 8) (one-touch connection type)	HK-KT series HK-MT series HK-ST series HK-RT series	-	-	MR-J3SCNS	Junction connector or encoder connector IP67 Applicable cable Wire size: 0.5 mm² (AWG Cable OD: 5.5 mm to 9.0		3 Controllers
(33)		HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires HK-KT series HK-KT series HK-RT103(4)WB, 153(4)WB, 203(4)WB	Long bending life Standard	2 m 5 m 10 m 2 m 5 m	MR-AEPB1CBL2M-A1-H MR-AEPB1CBL5M-A1-H MR-AEPB1CBL10M-A1-H MR-AEPB1CBL2M-A1-L MR-AEPB1CBL5M-A1-L	Servo motor connector Servo IP65		Servo Amplifiers
(35)	With electromagnetic brake wires HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires HK-KT series		Long bending life	10 m 2 m 5 m 10 m	MR-AEPB1CBL10M-A1-L MR-AEPB1CBL2M-A2-H MR-AEPB1CBL5M-A2-H MR-AEPB1CBL10M-A2-H		ervo amplifier connector	Motors
(36)		Standard	2 m 5 m 10 m 2 m	MR-AEPB1CBL2M-A2-L MR-AEPB1CBL5M-A2-L MR-AEPB1CBL10M-A2-L MR-AEPB1CBL2M-A5-H	-		Motors	
(37)	Motor cable (Note 2, 3) (single cable type/	e (Note 2,3) le type/ lection	bending life Standard	5 m 10 m 2 m 5 m 10 m	MR-AEPB1CBL5M-A5-H MR-AEPB1CBL10M-A5-H MR-AEPB1CBL2M-A5-L MR-AEPB1CBL5M-A5-L MR-AEPB1CBL10M-A5-L	Servo motor connector Servo a IP65	ervo amplifier connector	
(39)	direct connection type for 10 m or shorter)		Long bending life	2 m 5 m 10 m 2 m	MR-AEP1CBL2M-A1-H MR-AEP1CBL5M-A1-H MR-AEP1CBL10M-A1-H MR-AEP1CBL2M-A1-L	-		Motors
(40)		Load-side lead Without electromagnetic brake wires HK-KT series	Standard	5 m 10 m 2 m	MR-AEP1CBL5M-A1-L MR-AEP1CBL10M-A1-L MR-AEP1CBL2M-A2-H	Servo motor connector Se	ervo amplifier connector	Equipment
(41)		HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W	Long bending life	5 m 10 m	MR-AEP1CBL5M-A2-H MR-AEP1CBL10M-A2-H			int ei ai
(42)		Opposite to load-side lead Without electromagnetic brake wires	Standard	2 m 5 m 10 m	MR-AEP1CBL2M-A2-L MR-AEP1CBL5M-A2-L MR-AEP1CBL10M-A2-L	-		LVS/Wires
(43)		HK-KT series HK-MT series HK-RT103(4)W,	Long bending life	2 m 5 m 10 m	MR-AEP1CBL2M-A5-H MR-AEP1CBL5M-A5-H MR-AEP1CBL10M-A5-H		ervo amplifier connector	
(44)		153(4)W, 203(4)W Vertical lead (Note 5) Without electromagnetic brake wires	Standard	2 m 5 m 10 m	MR-AEP1CBL2M-A5-L MR-AEP1CBL5M-A5-L MR-AEP1CBL10M-A5-L	IP65		Product List

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
 When IP67 cables are required, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

4. Long bending life cables and standard cables are for moving parts and fixed parts respectively.

5. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

6. Cable clamps and bushings for cable OD of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set.

7. The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.

8. When using this cable or connector set for HK-KT series/HK-MT series/HK-TT (1.0 kW to 2.0 kW) series, use it in combination with an option from (22) to (27).

Support

Precautions

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)
(45)	Encoder connector set (Note 2, 3, 4) (screw type)	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W (straight type)	-	-	MR-ENCNS2	Encoder connector Servo amplifier connector IP67 Applicable cable Wire size: 0.5 mm ² (AWG 20) or smaller Cable OD: 5.5 mm to 9.0 mm
(46)	Encoder connector set (Note 2, 3, 4) (one-touch connection type)	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W (angle type)	-	-	MR-J3SCNSA	Encoder connector Servo amplifier connector
(47)	Encoder connector set (Note 2, 3, 4) (screw type)	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W (angle type)	-	-	MR-ENCNS2A	Applicable cable Wire size: 0.5 mm ² (AWG 20) or smaller Cable OD: 5.5 mm to 9.0 mm
(48)	Power connector set (Note 4, 5, 6) (one-touch connection type)	HK-ST52(4)W, 102(4)(W), 172(4)(W), 202(4)AW, 302(4)W, 353(4)W, 503(4)W ^(Note 7)	-	-	MR-APWCNS4	Power connector IP67 Applicable cable Wire size: 3.5 mm ² (AWG 12) or smaller Cable OD: 11 mm to 14.1 mm
(49)	Power connector set (Note 4, 5) (one-touch connection type)	HK-ST7M2UW, 172UW, 202(4)(W), 352(4)(W), 502(4)(W), 702(4)(W) HK-RT353(4)W, 503(4)W, 703(4)W	-	-	MR-APWCNS5	Power connector IP67 Applicable cable Wire size: 8 mm ² (AWG 8) or smaller Cable OD: 12.9 mm to 16 mm
(50)	Electromagnetic brake connector set (Note 3, 4) (one-touch connection type)	HK-ST series HK-RT353(4)WB, 503(4)WB, 703(4)WB	-	-	MR-BKCNS1	Electromagnetic brake connector
(51)	Electromagnetic brake connector set (Note 3, 4) (screw type)	(straight type)	-	-	MR-BKCNS2	Applicable cable Wire size: 1.25 mm ² (AWG 16) or smaller Cable OD: 9.0 mm to 11.6 mm
(52)	Electromagnetic brake connector set (Note 3, 4) (one-touch connection type)	HK-ST series HK-RT353(4)WB, 503(4)WB, 703(4)WB	-	-	MR-BKCNS1A	Electromagnetic brake connector
(53)	Electromagnetic brake connector set (Note 3, 4) (screw type)	(angle type)	-	-	MR-BKCNS2A	Applicable cable Wire size: 1.25 mm ² (AWG 16) or smaller Cable OD: 9.0 mm to 11.6 mm

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

2. Cable clamps and bushings for cable OD of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set.

3. The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.

4. For fabricating cables with these connectors, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION.

(Email: osb.webmaster@melsc.jp)

When the screw type is required, refer to "Products on the Market for Rotary Servo Motors" in this catalog.
 Connectors for HK-ST152(4)G1/G1H/G5/G7 geared servo motors are the same as those for HK-ST172(4)W.

7. When using HK-ST503W for a machine that is required to comply with UL/CSA standards, do not use MR-APWCNS4. Use a cable (SC-PWC403C_M-SBLL or SC-PWC403C_M-SBLH) manufactured by Mitsubishi Electric System & Service Co., Ltd., and fabricate an extension cable with wires of AWG 10. For details of SC-PWC403C_M-SBLL and SC-PWC403C_M-SBLH, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Options/Peripheral Equipment

Cables and Connectors for Rotary Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)	mon cations
(54)	(54)	Connecting	Long	2 m	MR-EKCBL2M-H	Junction connector Servo amplifier connector	
(54)		a load-side encoder	bending life	5 m	MR-EKCBL5M-H		Servo Cont
(55)	Encoder connector set	Connecting a load-side encoder	-	-	MR-J3CN2	Servo amplifier connector	ervo System Controllers
(56)	Junction cable for fully closed loop control (Note 4)	Branching a load-side encoder	Standard	0.3 m	MR-J4FCCBL03M	Junction connector Servo amplifier connector	Servo Amplifie
(57)	Connector set	Branching a load-side encoder	-	-	MR-J3THMCN2	Junction connector Servo amplifier connector	's Rot
Notes:	that of these connec 2. Use MR-EKCBL_M-	tors, overall IP rating depends or H or MR-ECNM to connect to an	n the lowest of al output cable for	l. AT343A, <i>i</i>	AT543A-SC or AT545A-SC scales manuf	factured by Mitutoyo Corporation.	iary Servo Motors

 Use MR-EKCBL_M-H or MR-ECNM to connect to an output cable for AT343A, AT543A-SC or AT545A-SC scales manufactured by Mitutoyo Corporation.
 For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
 Servo system will not operate correctly when the junction cables for fully closed loop control and for linear servo motors are used mistakenly or interchangeably. Make sure of the model before placing an order.

5. Long bending life cables and standard cables are for moving parts and fixed parts respectively.

6. Encoder cables are not subject to Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).


Comr Specific

Configuration Example for Linear Servo Motors (Note 3)

G WG B WB A

MR-J5-G/B/A or MR-J5W_-G/B, and LM-H3 series/LM-K2 series/LM-U2 series


When using a junction cable



Notes: 1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables.

2. Refer to "Products on the Market for Linear Servo Motors" in this catalog for these connectors.

3. Cables drawn with dashed lines need to be fabricated by users. Refer to "Linear Servo Motor User's Manual" when fabricating the cables.




3. Cables drawn with dashed lines need to be fabricated by users. Refer to "Linear Servo Motor User's Manual" when fabricating the cables


Configuration Example for Linear Servo Motors (Note 3)

G-RJ B-RJ A-RJ


MR-J5-G-RJ/B-RJ/A-RJ and LM-H3 series/LM-K2 series/LM-U2 series with an A/B/Z-phase differential output type linear encoder



MR-J5-G-RJ/B-RJ/A-RJ and LM-F series with an A/B/Z-phase differential output type linear encoder



- Notes: 1. Contact the relevant linear encoder manufacturers for connectors to connect with the head cables.
 - 2. Refer to "Products on the Market for Linear Servo Motors" in this catalog for these connectors.
 - 3. Cables drawn with dashed lines need to be fabricated by users. Refer to "Linear Servo Motor User's Manual" when fabricating the cables.



LVS/Wires

Cables and Connectors for Linear Servo Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	ltem	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)
	Encoder cable	Connecting a linear	Long	2 m	MR-EKCBL2M-H	Junction connector Servo amplifier connector
(1)	(Note 3, 4, 7)	encoder	bending life	5 m	MR-EKCBL5M-H	
(2)	Encoder connector set (Note 2, 3)	Connecting a linear encoder	-	-	MR-ECNM	Junction connector Servo amplifier connector IP20 Applicable cable Wire size: AWG 26 to 22 Cable OD: 7 mm to 9 mm
(3)	Encoder connector set	Connecting a linear encoder or a thermistor	-	-	MR-J3CN2	Servo amplifier connector
(4)	Junction cable for linear servo motors	Branching a thermistor	Standard	0.3 m	MR-J4THCBL03M	Junction connector Servo amplifier connector
(5)	Connector set	Branching a thermistor	-	-	MR-J3THMCN2	Junction connector Servo amplifier connector

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.


2. The crimping tool (91529-1) manufactured by TE Connectivity Ltd. Company is required. Contact the manufacturer directly.

3. Use MR-EKCBL_M-H or MR-ECNM to connect to an output cable for AT343A, AT543A-SC or AT545A-SC scales manufactured by Mitutoyo Corporation.

For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)
 Servo system will not operate correctly when the junction cables for fully closed loop control and for linear servo motors are used mistakenly or interchangeably. Make sure of the model before placing an order.

6. Long bending life cables and standard cables are for moving parts and fixed parts respectively.

7. Encoder cables are not subject to Low Voltage Directive (50 V AC to 1000 V AC and 75 V DC to 1500 V DC).



Notes: 1. Cables drawn with dashed lines need to be fabricated by users. Refer to "Direct Drive Motor User's Manual" when fabricating the cables.

Cables and Connectors for Direct Drive Motors

Refer to "Details of Option Connectors for Servo Motors" in this catalog for the detailed models.

No.	Item	Application	Bending life	Cable length	Model	Description/IP rating (Note 1)
(1)	Encoder connector set	TM-RG2M series TM-RU2M series TM-RFM series (Connecting a direct drive motor and a servo amplifier, or an absolute position storage unit and a servo amplifier)	-	-	MR-J3DDCNS	Encoder connector or absolute position storage unit connector IP67 Applicable cable Wire size: 0.25 mm² to 0.5 mm² (AWG 23 to 20) Cable OD: 7.8 mm to 8.2 mm
(2)	Encoder connector set	TM-RG2M series TM-RU2M series TM-RFM series (Connecting a direct drive motor and an absolute position storage unit)	-	-	MR-J3DDSPS	Encoder connector Absolute position storage unit connector IP67 IP67 Applicable cable IP67 Wire size: 0.25 mm² to 0.5 mm² (AWG 23 to 20) Cable OD: 7.8 mm to 8.2 mm
(3)	Power connector set (Note 2, 3)	TM-RG2M series TM-RU2M series TM-RFM_C20 TM-RFM_E20	-	-	MR-PWCNF	Power connector IP67 Applicable cable Wire size: 0.3 mm ² to 1.25 mm ² (AWG 22 to 16) Cable OD: 8.3 mm to 11.3 mm
(4)	Power connector set (Note 2)	TM-RFM_G20	-	-	MR-PWCNS4	Power connector IP67 Applicable cable Wire size: 2 mm ² to 3.5 mm ² (AWG 14 to 12) Cable OD: 10.5 mm to 14.1 mm
(5)	Power connector set (Note 2)	TM-RFM040J10, TM-RFM120J10	-	-	MR-PWCNS5	Power connector IP67 Applicable cable Wire size: 5.5 mm ² to 8 mm ² (AWG 10 to 8) Cable OD: 12.5 mm to 16 mm
(6)	Power connector set (Note 2)	TM-RFM240J10	-	-	MR-PWCNS3	Power connector IP67 Applicable cable Wire size: 14 mm ² to 22 mm ² (AWG 6 to 4) Cable OD: 22 mm to 23.8 mm

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor/absolute position storage unit.

If the IP rating of the servo motor/absolute position storage unit differs from that of these connectors, overall IP rating depends on the lowest of all. 2. For fabricating cables with these connectors, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

3. When using TM-RG2M series/TM-RU2M series/TM-RFM_C20/TM-RFM_E20 for a machine that is required to comply with UL/CSA standards, do not use MR-PWCNF. Use a cable (SC-PWCFCBL_M-L or SC-PWCFCBL_M-H) manufactured by Mitsubishi Electric System & Service Co., Ltd. For details of SC-PWCFCBL_ M-L or SC-PWCFCBL_M-H, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Model	Servo motor connector	Servo amplifier connector	ecific
MR-AEPB2CBL_M-A1-H MR-AEPB2CBL_M-A1-L MR-AEPB2CBL_M-A2-H			Specifications
MR-AEPB2CBL_M-A2-L MR-AEP2CBL_M-A1-H	Connector set: MT50W-8D/2D4ES-CVLD(7.5) Contact for power supply: MT50E-1820SCFA	Connector set: 54599-1016 (Molex, LLC)	0
MR-AEP2CBL_M-A1-L	Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	or Receptacle: 36210-0100PL	ontr
MR-AEP2CBL_M-A2-H MR-AEP2CBL_M-A2-L		Shell kit: 36310-3200-008 (3M)	Controllers
Model	Servo motor connector	Servo amplifier connector	
MR-AEPB2CBL_M-A5-H			Servo Amplifiers
MR-AEPB2CBL_M-A5-L	Connector set: MT50W-8D/2D4ES-CVSD(7.5) Contact for power supply: MT50E-1820SCFA	Connector set: 54599-1016 (Molex, LLC)	lifier
MR-AEP2CBL_M-A5-H MR-AEP2CBL_M-A5-L	Contact for signal: MT50D-2224SCFA	or	
_	(Hirose Electric Co., Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008	
		(3M)	Moto
Model	Servo motor connector	Junction connector	Motors
MR-AEPB2J10CBL03M-A1-L MR-AEPB2J10CBL03M-A2-L			
MR-AEP2J10CBL03M-A1-L	Connector set: MT50W-8D/2D4ES-CVLD(7.5)	Contact: 170361-4	Motors
MR-AEP2J10CBL03M-A2-L	Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA	Housing: 1-172169-9 Cable clamp: 316454-1	Motors
	(Hirose Electric Co., Ltd.)	(TE Connectivity Ltd. Company)	č
Model	Servo motor connector	Junction connector	
MR-AEPB2J10CBL03M-A5-L			Motors
MR-AEP2J10CBL03M-A5-L	Connector set: MT50W-8D/2D4ES-CVSD(7.5)	Contact: 170361-4	
	Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA	Housing: 1-172169-9 Cable clamp: 316454-1	
	(Hirose Electric Co., Ltd.)	(TE Connectivity Ltd. Company)	m
Model	Junction connector	Servo amplifier connector	Equipment
			Equipment
MR-AEKCBL_M-H	Housing: 1-172161-9 Connector pin: 170359-1	Connector set: 54599-1016 (Molex, LLC)	
MR-AEKCBL_M-L	(TE Connectivity Ltd. Company)	or	LVS,
	or an equivalent product Cable clamp: MTI-0002	Receptacle: 36210-0100PL Shell kit: 36310-3200-008	LVS/Wires
	(Toa Electric Industrial Co., Ltd.)	(3M)	S
Vodel	Junction connector	Servo amplifier connector	
			Product List
MR-ECNM	Housing: 1-172161-9 Connector pin: 170359-1	Receptacle: 36210-0100PL Shell kit: 36310-3200-008	List
MR-EKCBL_M-H	(TE Connectivity Ltd. Company)	(3M)	
	or an equivalent product Cable clamp: MTI-0002	or Connector set: 54599-1019	σ
	(Toa Electric Industrial Co., Ltd.)	(Molex, LLC)	reca
Model	Servo motor connector	Junction connector	Precautions
MR-AEPB2J20CBL03M-A1-L MR-AEPB2J20CBL03M-A2-L			ō
MR-AEP2J20CBL03M-A2-L MR-AEP2J20CBL03M-A1-L	Connector set: MT50W-8D/2D4ES-CVLD(7.5)		Support
	Contact for power supply: MT50E-1820SCFA		dr
MR-AEP2J20CBL03M-A2-L	Contact for signal: MT50D-2224SCFA	Cable receptacle: CMV1-CR10P-M2	po

Model	Servo motor connector	Junction connector
MR-AEPB2J20CBL03M-A5-L MR-AEP2J20CBL03M-A5-L	Connector set: MT50W-8D/2D4ES-CVSD(7.5) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Cable receptacle: CMV1-CR10P-M2 (DDK Ltd.)
Model	Encoder connector	Servo amplifier connector
MR-J3ENSCBL_M-H ^(Note 2) MR-J3ENSCBL_M-L ^(Note 2)	Straight plug: CMV1-SP10S-M1 Socket contact: CMV1-#22ASC-C1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)
Model	Junction connector/encoder connector	Servo amplifier connector
MR-AENSCBL_M-H (Note 2) MR-AENSCBL_M-L (Note 2)	Straight plug: CMV1-SP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)
Model	Junction connector/encoder connector	Servo amplifier connector
MR-J3SCNS ^(Note 1, 2, 3)	Straight plug: CMV1-SP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)
Model	Servo motor connector	Servo amplifier connector
MR-AEPB1CBL_M-A1-H MR-AEPB1CBL_M-A1-L MR-AEPB1CBL_M-A2-H MR-AEPB1CBL_M-A2-L MR-AEP1CBL_M-A1-H MR-AEP1CBL_M-A1-L MR-AEP1CBL_M-A2-L MR-AEP1CBL_M-A2-L	Connector set: MT50W-8D/2D4ES-CVL(11.9) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)
Model	Servo motor connector	Servo amplifier connector
MR-AEPB1CBL_M-A5-H MR-AEPB1CBL_M-A5-L MR-AEP1CBL_M-A5-H MR-AEP1CBL_M-A5-L	Connector set: MT50W-8D/2D4ES-CVS(11.9) Contact for power supply: MT50E-1820SCFA Contact for signal: MT50D-2224SCFA (Hirose Electric Co., Ltd.)	Connector set: 54599-1016 (Molex, LLC) or Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)

Notes: 1. Cable clamps and bushings for cable OD of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set. 2. Some cables or connector sets may contain the connectors of different shapes. However, these connectors are all usable.

3. The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.

Details of Option Con	nectors for Servo Motors		S S
Model	Encoder connector	Servo amplifier connector	Com
			Common Specifications
MR-ENCNS2 (Note 2, 3)	Straight plug: CMV1S-SP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)	Servo System Controllers
Model	Encoder connector	Servo amplifier connector	
MR-J3SCNSA (Note 1, 2, 3)	Angle plug: CMV1-AP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)	Servo Amplifiers
		or Connector set: 54599-1019 (Molex, LLC)	Rot
Model	Encoder connector	Servo amplifier connector	Rotary Servo Motors
Wouch			s
MR-ENCNS2A (Note 2, 3)	Angle plug: CMV1S-AP10S-M2 Socket contact: CMV1-#22ASC-S1-100 (DDK Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)	Linear Servo Motors
Model	Power connector		
MR-APWCNS4		Plug: JL10-6A18-10SE-EB (straight) Cable clamp: JL04-18CK(13)-R (Japan Aviation Electronics Industry, Limited)	Direct Drive Motors
Model	Power connector		
MR-APWCNS5		Plug: JL10-6A22-22SE-EB (straight) Cable clamp: JL04-2022CK(14)-R (Japan Aviation Electronics Industry, Limited)	Options/Peripheral Equipment
Model	Electromagnetic brake connector		ent
MR-BKCNS1 (Note 1, 2)		Straight plug: CMV1-SP2S-L Socket contact: CMV1-#22BSC-S2-100 (DDK Ltd.)	
Model	Electromagnetic brake connector		LVS/Wires
MR-BKCNS2 (Note 2)		Straight plug: CMV1S-SP2S-L Socket contact: CMV1-#22BSC-S2-100 (DDK Ltd.)	
Model	Electromagnetic brake connector		Prod
MR-BKCNS1A ^(Note 1, 2)		Angle plug: CMV1-AP2S-L Socket contact: CMV1-#22BSC-S2-100 (DDK Ltd.)	Product List
Model	Electromagnetic brake connector		
MR-BKCNS2A (Note 2)		Angle plug: CMV1S-AP2S-L Socket contact: CMV1-#22BSC-S2-100 (DDK Ltd.)	Precautions
Notes: 1. Some cables or connector s	ets may contain the connectors of different shapes. However	, these connectors are all usable.	<u>ى</u>

The connector set contains a plug and contacts. Using contacts for other plugs may damage the connector. Use the enclosed contacts.
 Cable clamps and bushings for cable OD of 5.5 mm to 7.5 mm and of 7.0 mm to 9.0 mm are included in the set.

Model	Servo amplifier connector	
MR-J3CN2	Receptacle: 36210-0100PL or Shell kit: 36310-3200-008 (3M)	Connector set: 54599-1019 (Molex, LLC)
Model	Junction connector	Servo amplifier connector
MR-J4FCCBL03M MR-J4THCBL03M MR-J3THMCN2	Plug: 36110-3000FD Shell kit: 36310-F200-008 (3M)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M)
Model	Encoder connector/absolute position storage unit connector	Servo amplifier connector
MR-J3DDCNS	Plug: RM15WTPZK-12S Cord clamp: JR13WCCA-8(72) (Hirose Electric Co., Ltd.)	Receptacle: 36210-0100PL Shell kit: 36310-3200-008 (3M) or Connector set: 54599-1019 (Molex, LLC)
Model	Encoder connector	Absolute position storage unit connector
MR-J3DDSPS	Plug: RM15WTPZK-12S Cord clamp: JR13WCCA-8(72) (Hirose Electric Co., Ltd.)	Plug: RM15WTPZ-12P(72) Cord clamp: JR13WCCA-8(72) (Hirose Electric Co., Ltd.)
Model	Power connector	
MR-PWCNF		Plug: CE05-6A14S-2SD-D (straight) (DDK Ltd.) Cable clamp: YSO14-9 to 11 (Daiwa Dengyo Co., Ltd.)
Model	Power connector	
MR-PWCNS4		Plug: CE05-6A18-10SD-D-BSS (straight) Cable clamp: CE3057-10A-1-D (DDK Ltd.)
Model	Power connector	
MR-PWCNS5		Plug: CE05-6A22-22SD-D-BSS (straight) Cable clamp: CE3057-12A-1-D (DDK Ltd.)
Model	Power connector	
MR-PWCNS3		Plug: CE05-6A32-17SD-D-BSS (straight) Cable clamp: CE3057-20A-1-D (DDK Ltd.)

Products on the Market for Rotary Servo Motors

153(4)W,

203(4)W

Applicable

servo motor

HK-ST series

503(4)W,

703(4)W

Contact

Solder type

Press bonding type

HK-RT353(4)W,

Products on	the Marke	et for Rotary Serve	o Motors			S		
Contact the relevant manufacturers directly. When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.								
Encoder conn	ector (servo	amplifier side)				S S		
Application	Connector (3N	I)				Servo Syster Controllers		
	Receptacle: 36210-0100PL Shell kit: 36310-3200-008							
Servo amplifier CN2 connector	Connector (Molex, LLC)							
	54599-1019 (gray) 54599-1016 (black)							
	54599-1016 (black)							
Connector for HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series								
(for dual cable	e type)					-		
Applicable servo motor	IP rating (Note 1) (Hirose Electric Co., Ltd.)		· · · · · · · · · · · · · · · · · · ·	Contact (Hirose Electric Co., Ltd.)	Applicable cable example			
		Cable direction	Model			Servo ors		
HK-KT series HK-MT series		In the direction of the load side/In the opposite	MT50W-8D/ 2D4ES-CVLD(7.5)	For power supply: MT50E-1820SCFA	Refer to "Rotary Servo Motor User's Manual	Ő		

HK-RT103(4)W,	IP67	direction of the load side	2D4ES-CVLD(7.5)	For power supply: MT50E-1820SCFA For signal: MT50D-2224SCFA	Motor User's Manual (For MR-J5)" for the
153(4)W, 203(4)W		Vertical (Note 3)	MT50W-8D/ 2D4ES-CVSD(7.5)	TOT SIGNAL INTSOL 2224001 A	applicable cables.
					ide/opposite Vertical lead -side lead
Connector for (for single cat		es/HK-MT series/HK-	RT (1.0 kW to 2	.0 kW) series	
Applicable servo motor	IP rating (Note 1)	Connector set (Hirose Electric Co., Ltd.) Cable direction	Model	Contact (Hirose Electric Co., Ltd.)	Applicable cable example
HK-KT series HK-MT series HK-RT103(4)W,	IP67	lload side/In the opposite	1204 + S - (3717119)	For power supply: MT50E-1820SCFA For signal: MT50D-2224SCFA	Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for the

MT50W-8D/

Type of connection Plug

2D4ES-CVS(11.9)

CMV1-SP10S-M1

CMV1-SP10S-M2

CMV1S-SP10S-M1

CMV1S-SP10S-M2

CMV1-AP10S-M1

CMV1-AP10S-M2

CMV1S-AP10S-M1

CMV1S-AP10S-M2

Straight type Angle type

Cable OD [mm]

5.5 to 7.5

7.0 to 9.0

Socket contact

bonding type.

Wire size (Note 2)

Select a solder or press

(Refer to the table below.)

0.5 mm² (AWG 20) or smaller 0.2 mm² to 0.5 mm² (AWG 24 to 20)

0.08 mm² to 0.2 mm² (AWG

Crimping tool (357J-53162T) is required.

applicable cables.



Applicable cable example

LVS/Wires

Linear Servo Motors

Direct Drive Motors

Options/Peripheral

Equipment

Product List

Support

CMV1-#22ASC-C2-100		0.08 mm ² to 0.2 mm ² (AWG 28 to 24) Crimping tool (357J-53163T) is required.		
Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor diffe				

that of these connectors, overall IP rating depends on the lowest of all.

2. The wire size shows wiring specifications of the connector

Vertical (Note 3)

Туре

Straight

Angle

IP rating (Note 1)

IP67

Encoder connector for HK-ST series/HK-RT (3.5 kW to 7.0 kW) series

Connector (DDK Ltd.)

One-touch connection type

Screw type

One-touch

Screw type

Socket contact (DDK Ltd.) CMV1-#22ASC-S1-100

CMV1-#22ASC-C1-100

connection type

3. When a vertically mounted cable is led out, the lock lever of the connector must be on the load side.

Products on the Market for Rotary Servo Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.



Angle type Cable Plug clamp

Power connector for HK-ST series/HK-RT (3.5 kW to 7.0 kW) series (Note 3)

Applicable servo	IP rating	Plug (Japan Aviation Electronics Industry, Limited)		Cable clamp (Japan Aviation Applicable cable exam		ample	
motor	(Note 1)	Туре	Type of connection	Model	Electronics Industry, Limited)	Wire size (Note 2)	Cable OD [mm]
			One-touch	JL10-6A18-10SE-EB	JL04-18CK(10)-R		8 to 11
HK-ST52(4)(W),		Straight	connection type	JL10-0A10-103L-LD	JL04-18CK(13)-R		11 to 14.1
102(4)(W),		Straight	Screw type	JL04V-6A18-10SE-EB-R	JL04-18CK(10)-R		8 to 11
172(4)W, 202(4)AW,			Sciew type	3204 V-0A10-1032-2D-11	JL04-18CK(13)-R	8 mm ² (AWG 8) or smaller	11 to 14.1
302(4)W,	IP67	Angle	One-touch	JL10-8A18-10SE-EB	JL04-18CK(10)-R		8 to 11
353(4)W,			connection type	3E10-0A10-103E-ED	JL04-18CK(13)-R		11 to 14.1
503(4)W			Screw type	JL04V-8A18-10SE-EBH-R	JL04-18CK(10)-R		8 to 11
					JL04-18CK(13)-R		11 to 14.1
HK-ST7M2UW.		Straight	One-touch connection type	JL10-6A22-22SE-EB	JL04-2022CK(12)-R		9.5 to 13
172UW,					JL04-2022CK(14)-R		12.9 to 16
202(4)(W),					JL04-2022CK(12)-R		9.5 to 13
352(4)(W),			Screw type	JL04V-6A22-22SE-EB-R	JL04-2022CK(14)-R		12.9 to 16
502(4)(W), 702(4)(W)			One-touch		JL04-2022CK(12)-R		9.5 to 13
HK-RT353(4)W,		Angle	connection type	JL10-8A22-22SE-EB	JL04-2022CK(14)-R		12.9 to 16
503(4)W,		Angle	Corow turno		JL04-2022CK(12)-R		9.5 to 13
703(4)W			Screw type	JL04V-8A22-22SE-EBH-R	JL04-2022CK(14)-R		12.9 to 16

Straight type Angle type

Electromagnetic brake connector for HK-ST series/HK-RT (3.5 kW to 7.0 kW) series

Applicable servo	IP rating (Note 1	Connecto	r (DDK Ltd.)		Applicable cable example	
motor	iP rating (toto)	Туре	Type of connection	Plug	Socket contact	Cable OD [mm]
				CMV1-SP2S-S		4.0 to 6.0
			One-touch	CMV1-SP2S-M1		5.5 to 7.5
			connection type	CMV1-SP2S-M2		7.0 to 9.0
		Straight		CMV1-SP2S-L		9.0 to 11.6
		Straight		CMV1S-SP2S-S		4.0 to 6.0
			Scrow tupo	CMV1S-SP2S-M1		5.5 to 7.5
HK-ST series			Screw type	CMV1S-SP2S-M2	Select a solder or press bonding type. (Refer to the table below.)	7.0 to 9.0
HK-RT353(4)WB,	IP67			CMV1S-SP2S-L		9.0 to 11.6
503(4)WB,		Angle	One-touch connection type	CMV1-AP2S-S		4.0 to 6.0
703(4)WB				CMV1-AP2S-M1		5.5 to 7.5
				CMV1-AP2S-M2		7.0 to 9.0
				CMV1-AP2S-L		9.0 to 11.6
				CMV1S-AP2S-S		4.0 to 6.0
			Screw type	CMV1S-AP2S-M1		5.5 to 7.5
			Sciew type	CMV1S-AP2S-M2		7.0 to 9.0
				CMV1S-AP2S-L		9.0 to 11.6
Contact		Socket cont	tact (DDK Ltd.)		Wire size (Note 2)	
Solder type		CMV1-#22E	3SC-S2-100		1.25 mm ² (AWG 16) or sma	ller
		CMV1-#22BSC-C3-100			0.5 mm ² to 1.25 mm ² (AWG 20 to 16) Crimping tool (357J-53164T) is required.	

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.

The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection.
 Connectors for HK-ST152(4)G1/G1H/G5/G7 geared servo motors are the same as those for HK-ST172(4)W.

Γ

Products on the Market for Linear Servo Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.

Thermistor junction connector for LM-H3 series/LM-K2 series/LM-U2 series/LM-F series

Applicable	IP rating (Note 1)	Connector (3M)	Applicable cable example	00.	
servo motor		Plug	Shell kit	Applicable cable example	
LM-H3 series LM-K2 series	-	36110-3000FD	36310-F200-008	Wire size: 0.3 mm ² (AWG 22) or smaller	0.0
LM-U2 series LM-F series				Cable OD: 7 mm to 9 mm	

Thermistor connector for LM-F series

Applicable servo motor	IP rating (Note 1)	Cable receptacle	Cable clamp	Applicable cable example	lifiers	
Servo motor	_	(DDK Ltd.)	(DDK Ltd.)			
LM-F series	-	D/MS3101A14S-9S	D/MS3057A-6A	Wire size: 0.3 mm ² to 1.25 mm ² (AWG 22 to 16)	Rotar Mc	
				Cable OD: 7.9 mm or smaller	tary Serv Motors	
Power conne	Power connector for LM-E series					

Power connector for LM-F series

Applicable	IP rating (Note 1)	Cable receptacle	Cable clamp	Applicable cable exampl	е	_
servo motor	IF failing ((DDK Ltd.)	(DDK Ltd.)	Wire size (Note 2)	Cable OD [mm]	inea
LM-FP2B, 2D,	_	D/MS3101A18-10S	D/MS3057-10A	2 mm ² to 3.5 mm ²	14.3 or smaller	iear Se Motors
2F	-	D/MI33101A10-103	DINIGGUST-TOA	(AWG 14 to 12)	(bushing ID)	rs
LM-FP4B, 4D		D/MS3101A24-22S	D/MS3057-16A	5.5 mm ² to 8 mm ²	19.1 or smaller	Ő
LIVI-I F 4D, 4D	-	D/MI33101A24-223	D/10/33037-10A	(AWG 10 to 8)	(bushing ID)	

1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from Notes: that of these connectors, overall IP rating depends on the lowest of all.

2. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection.

Common Specifications

Servo System Controllers

Servo Amplifiers

Products on the Market for Direct Drive Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.

Encoder connector for TM-RG2M series/TM-RU2M series/TM-RFM series and absolute position storage unit connector (servo amplifier side)



Applicable servo	Application	IP rating	Plug (Hirose Electric Co., Ltd.)			Applicable cable example
motor	Application		Туре	Plug	Cord clamp	
TM-RG2M series TM-RU2M series	For an encoder or absolute position storage unit (servo amplifier side)	IP67	Straight	RM15WTPZK-12S	JR13WCCA-8(72)	Wire size: 0.5 mm ² (AWG 20) or smaller Cable OD: 7.8 mm to 8.2 mm Wire example: Vinyl jacket cable 20276 VSVPAWG#23 × 6P KB-0492 Bando Densen Co., Ltd. ^(Note 2)

Encoder connector for TM-RG2M series/TM-RU2M series/TM-RFM series and absolute position storage unit connector (encoder side)



Applicable servo	Application		Plug (Hir	ose Electric Co., Ltd.)		Applicable cable example
motor		(Note 1)	Туре	Plug	Cord clamp	
	For an absolute position storage unit (encoder side)	IP67	Straight	RM15WTPZ-12P(72)	JR13WCCA-8(72)	Wire size: 0.5 mm ² (AWG 20) or smaller Cable OD: 7.8 mm to 8.2 mm Wire example: Vinyl jacket cable 20276 VSVPAWG#23 × 6P KB-0492 Bando Densen Co., Ltd. ^(Note 2)

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor/absolute position storage unit. If the IP rating of the servo motor/absolute position storage unit differs from that of these connectors, overall IP rating depends on the lowest of all.
 2. Contact Toa Electric Industrial Co., Ltd.

Products on the Market for Direct Drive Motors

Contact the relevant manufacturers directly.

When fabricating a cable with the following connectors, refer to the relevant manufacturers' instruction manuals for wiring and assembling procedures.



Power connector for TM-RFM series

Applicable servo motor	IP rating (Note 1)	Plug (with backshell) (DDK Ltd.)		Cable clamp (DDK Ltd.)	Applicable cable ex	Applicable cable example	
		Туре	Model	Model	Wire size (Note 2)	Cable OD [mm]	Controllers
	IP67		CE05-6A18-10SD-D-BSS	CE3057-10A-2-D	2 mm ² to 3.5 mm ²	8.5 to 11	Servo /
FM-RFM012G20, 048G20, 072G20	1607		CE05-0A16-105D-D-D55	CE3057-10A-1-D	(AWG 14 to 12)	10.5 to 14.1	Servo Amplifiers
	-		D/MS3106B18-10S	D/MS3057-10A	2 mm ² to 3.5 mm ² (AWG 14 to 12)	14.3 or smaller (bushing ID)	0H
	IP67	7 Straight	CE05-6A22-22SD-D-BSS	CE3057-12A-2-D	5.5 mm ² to 8 mm ²	9.5 to 13	Motors
TM-RFM040J10, 120J10			CE05-0A22-223D-D-B33	CE3057-12A-1-D	(AWG 10 to 8)	12.5 to 16	
	-		D/MS3106B22-22S	D/MS3057-12A	5.5 mm ² to 8 mm ² (AWG 10 to 8)	15.9 or smaller (bushing ID)	Motors
	IP67		CE05-6A32-17SD-D-BSS	CE3057-20A-1-D	14 mm ² to 22 mm ² (AWG 6 to 4)	22 to 23.8	, NO
TM-RFM240J10	-		D/MS3106B32-17S	D/MS3057-20A	14 mm ² to 22 mm ² (AWG 6 to 4)	23.8 or smaller (bushing ID)	Motors

Power connector for TM-RG2M series/TM-RU2M series/TM-RFM series

			Cable ele			Applicable coble ever	un la	Ec
Applicable			Cable cla	mp		Applicable cable example		luip
servo motor		Plug (DDK Ltd.)	Туре	Model	Manufacturer	Wire Size (Note 2)	Cable OD [mm]	otions/Periphe Equipment
TM-RG2M series TM-RU2M series				C2KD0814	Sankei Manufacturing		4 to 8	Ieral
TM-RFM002C20,	IP67	267 CE05-6A14S-2SD-D	Straight	C2KD1214	Co., Ltd. (Note 3)	0.3 mm ² to 1.25 mm ² (AWG 22 to 16)	8 to 12	
004C20, 006C20,				YSO14-5 to 8			5 to 8.3	NSN
006E20,				YSO14-9 to 11	Co., Ltd.		8.3 to 11.3	Vires
012E20, 018E20	-	D/MS3106B14S-2S	Straight	D/MS3057-6A	DDK Ltd.	0.3 mm ² to 1.25 mm ² (AWG 22 to 16)	7.9 or smaller (bushing ID)	

Notes: 1. The IP rating indicated is for the connector's protection against ingress of dust and water when coupled to a servo motor. If the IP rating of the servo motor differs from that of these connectors, overall IP rating depends on the lowest of all.


2. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection. 3. Contact: Sankei Manufacturing Co., Ltd. and Mikuni Electric Co., Ltd.

Options/Peripheral

Common Specifications


Configuration Example for MR-J5-_G(-RJ)





Configuration Example for MR-J5-_G4-HS

G-HS



Notes: 1. Refer to "Junction Terminal Block" in this catalog.

2. When configuring an absolute position detection system with a direct drive motor, use a battery (MR-BAT6V1SET or MR-BAT6V1SET-A), or a battery case (MR-BT6VCASE) and batteries (MR-BAT6V1 × 5 pieces). When using the battery case, use the indicated cables. Refer to "Battery" or "Battery Case and Battery" in this catalog for details of the battery and connections of the battery case.

3. CN2L connector is available for MR-J5-G-RJ servo amplifiers.

4. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details.

5. Refer to p. 7-45 in this catalog for details.

6. Refer to "Ethernet Cable Specifications" in this catalog for specifications of the Ethernet cable.

7. The shape and position of the power connector are different from those of the indicated connector for some servo amplifier capacities. Refer to the dimensions for details.

8. When not using CN7 connector, attach the cap.

Configuration Example for MR-J5W_-_G WG Common Specifications Controller • CC-Link IE TSNcompatible controller RD78G RD78GH (14) •FX5-40SSC-G •FX5-80SSC-G •SWM-G(-N1) • EtherCAT®-compatible CN6 (Note 3) Servo System Controllers Servo amplifier (Note 6) controller •SWM-G-N1 CN1A CN1A (\circ) -De -DI (12) CN1B MR Configurator2 CN1B CNP CNP Network Servo Amplifiers -_____ (15) (Note 5, 6) ⊯ (16) -____ CNP2 CNP2 CN3 (1) CNP3A CNP3A (4) CNP3B CN2A CNP3B CN2A Junction terminal block MR-TB26A (Note 1) CN2B CN2 CNP3C CNP3C Rotary Servo Motors (5) (6) CN20 CN20 CN4 <u>ÇN4</u> ₽ (Note 4) (Note 4) To C-axis servo motor power To C-axis servo motor encoder - -(11) (Note 2) ;> □□₽ To B-axis servo motor power To B-axis servo motor encode (10) (Note 2) (Note 2) To A-axis servo motor power To A-axis servo motor encoder Battery case: MR-BT6VCASE Battery: MR-BAT6V1 × 5 pcs. Linear Servo Motors

Notes: 1. Refer to "Junction Terminal Block" in this catalog.

2. When configuring an absolute position detection system with a direct drive motor, use a battery (MR-BAT6V1SET or MR-BAT6V1SET-A), or a battery case (MR-BT6VCASE) and batteries (MR-BAT6V1 × 5 pieces). When using the battery case, use the indicated cables. Refer to "Battery" or "Battery Case and Battery" in this catalog for details of the battery and connections of the battery case.

3. MR-J5W_-G servo amplifiers have CN6 connector on the top of the unit.

4. CNP3C and CN2C connectors are available for MR-J5W3-G servo amplifiers.

5. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller user's manual for details.

6. Refer to "Ethernet Cable Specifications" in this catalog for specifications of the Ethernet cable.

Direct Drive Motors


Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Configuration Example for MR-J5D_-_G4



DG

Notes: 1. CNP3C and CN2C connectors are available for MR-J5D3- G4 drive units.

2. When branching off CC-Link IE TSN (synchronous communication function) with a switching hub, use a switching hub (class B) recommended by CC-Link Partner Association. When a switching hub (class A) is used, there are restrictions on the topologies to be used. Refer to the controller manual for details

3. Refer to "Ethernet Cable Specifications" in this catalog for specifications of the Ethernet cable.

4. Arrange the drive units in descending order of capacity per axis from the right side of the power regeneration converter unit. When the drive units with the same capacity are used, there are no restrictions on the order.

Ethernet Cable Specifications

Item	CC-Link IE TSN (Note 1, 2)	EtherCAT®
Cable type	Category 5e or higher, (double shielded/STP) straight c	able
Standard		IEEE802.3 (100BASE-TX) ANSI/TIA/EIA-568-B (Category 5e)
Connector	RJ-45 connector with shield	


1. Use wiring parts recommended by CC-Link Partner Association for wiring the CC-Link IE TSN. Notes: 2. Cables for CC-Link IE Controller Network cannot be used with CC-Link IE TSN.

[Products on the Market] **Ethernet Cable**

Application	Model	Specifications	
For indoor	SC-E5EW-S_M	_: cable length (0.5 m, 1 to 100 m (unit of 1 m))	
For indoor and moving part	SC-E5EW-S_M-MV	_: cable length (0.1, 0.2, 0.3, 0.5 m, 1 to 45 m (unit of 1 m))	Double shielded cable (Category 5e)
For indoor/outdoor	SC-E5EW-S_M-L	_: cable length (1 to 100 m (unit of 1 m))	
For details please contact Mitsubishi I	Electric System & Service Co	td_OVERSEAS_SERVICE_SECTION_(Email: osb webmaster)	@melsc in)

details, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

* When using CC-Link IE TSN, refer to the website of CC-Link Partner Association for cables on the market other than above. https://www.cc-link.org/en/




Configuration Example for MR-J5-_B(-RJ) (Note 8)

1. Refer to "Junction Terminal Block" in this catalog. Notes:

2. When configuring an absolute position detection system with a direct drive motor, use a battery (MR-BAT6V1SET or MR-BAT6V1SET-A), or a battery case (MR-BT6VCASE) and batteries (MR-BAT6V1 × 5 pieces). When using the battery case, use the indicated cables. Refer to "Battery" or "Battery Case and Battery" in this catalog for details of the battery and connections of the battery case.

- 3. CN2L connector is available for MR-J5-B-RJ servo amplifiers.
- 4. Attach a cap to CN1B connector of the final axis.
- 5. CNP3C and CN2C connectors are available for MR-J5W3-B servo amplifiers.
- 6. The shape and position of the power connector are different from those of the indicated connector for some servo amplifier capacities. Refer to the dimensions for details
- 7. Refer to "Products on the Market for Servo Amplifiers Mitsubishi Electric Engineering" in this catalog for details.
- 8. Cables drawn with dashed lines need to be fabricated by users. Refer to "MR-J5 User's Manual" when fabricating the cables

Configuration Example for MR-J5-_A(-RJ) (Note 4)



- 1. Refer to "Junction Terminal Block" in this catalog. Notes:
 - When configuring an absolute position detection system with a direct drive motor, use a battery (MR-BAT6V1SET or MR-BAT6V1SET-A), or a battery case (MR-BT6VCASE) and batteries (MR-BAT6V1 × 5 pieces). When using the battery case, use the indicated cables. Refer to "Battery" or "Battery" case and Battery" in this catalog for details of the battery and connections of the battery case.
 - 3. CN2L connector is available for MR-J5-A-RJ servo amplifiers.
 - 4. Cables drawn with dashed lines need to be fabricated by users. Refer to "MR-J5 User's Manual" when fabricating the cables.
 - 5. Refer to p. 7-47 in this catalog for details.
 - 6. The shape and position of the power connector are different from those of the indicated connector for some servo amplifier capacities. Refer to the dimensions for details.

Cables and Connectors for Servo Amplifiers

	Item	Application	Cable length	Model	Description	
		MR-J5-100G(-RJ) or smaller/ MR-J5-100B(-RJ) or smaller/ MR-J5-100A(-RJ) or smaller			CNP1 CNP2 CNP3 Open tool connector connector Connector Applicable wire size ^(kide 1) : AWG 18 to 14 Insulator OD: 3.9 mm or smaller	
		MR-J5-200G(-RJ)/ MR-J5-200B(-RJ)/ MR-J5-200A(-RJ)/ MR-J5-350G(-RJ)/ MR-J5-350B(-RJ)/ MR-J5-350A(-RJ)	_		CNP1 CNP2 CNP3 Open tool connector connector CNP3 CNP3 CNP3 COPENTION CONNECTOR CONNECTOR CNP1/CNP3 connector Applicable wire size (Notes 1): AWG 16 to 10 Insulator OD: 4.7 mm or smaller CNP2 connector	
		MH-J5-350A(-HJ)	_		Applicable wire size (Nder 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller CNP1A CNP1B CNP3 Open tool	
					CNP1A CNP1B CNP3 Open tool connector connector	
		MR-J5-500G(-RJ)/ MR-J5-500B(-RJ)/ MR-J5-500A(-RJ)/ MR-J5-700G(-RJ)/	MR-J5-500B(-RJ)/ MR-J5-500A(-RJ)/			CNP1A/CNP1B/CNP3 connector Applicable wire size ^(Note 1) : AWG 18 to 8 Insulator OD: 7.6 mm or smaller
		MR-J5-700B(-RJ)/ MR-J5-700A(-RJ)			CNP2 Open tool connector	
(1) Servo amplifier power connector set		_	(Standard accessory)	CNP2 connector Applicable wire size (Note 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller		
	connector set	MR-J5-350G4(-RJ) or smaller/ MR-J5-350B4(-RJ) or smaller/ MR-J5-350A4(-RJ) or smaller			CNP1 CNP2 CNP3 Open tool connector connector	
			_		Applicable wire size (Note 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller	
	MR-J5-500B MR-J5-500A	MR-J5-500G4(-HS)/ MR-J5-500B4(-RJ)/ MR-J5-500A4(-RJ)/ MR-J5-700G4(-HS)/			CNP1 CNP2 CNP3 connector connector	
		MR-J5-700B4(-RJ)/ MR-J5-700A4(-RJ)			Applicable wire size (Note 1): AWG 20 to 8 Insulator OD: 6.6 mm or smaller	
		MR-J5W2-44G or smaller/			CNP1 CNP2 CNP3_(Note 2) Open tool connector connector connector	
	MR-J5W2-44B or smaller/ MR-J5W3-444G or smaller/ MR-J5W3-444B or smaller			Applicable wire size ^(ktre 1) : AWG 18 to 14 Insulator OD: 3.9 mm or smaller		
				CNP1 CNP2 CNP3_(Note 2) Open tool connector connector		
		MR-J5W2-77G or larger/				
		MR-J5W2-77B or larger			CNP1 connector Applicable wire size (Note 1): AWG 16 to 10 Insulator OD: 4.7 mm or smaller	

Notes: 1. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection. 2. MR-J5W2-_G/MR-J5W2-_B: CNP3A/CNP3B, MR-J5W3-_G/MR-J5W3-_B: CNP3A/CNP3B/CNP3C

Cables and Connectors for Servo Amplifiers

Refer to "Details of Option Connectors for Servo Amplifiers" in this catalog for the detailed models.

No.		Item	Application	Cable length	Model	Description	
For CNP3	(1)	Drive unit power connector set	MR-J5DG4	-	(Standard accessory)	CNP3_(Note 2) connector CNP3_connector Applicable wire size (Note 1): AWG 24 to 8 Insulator OD: 10 mm or smaller * The open tool is not supplied with a drive unit. The open tool must be prepared by users.	
			Connecting	0.5 m	MR-J2HBUS05M		
	(2)	Junction terminal block cable	MR-J5G_(-RJ)/ MR-J5B_(-RJ) and PS7DW-20V14B-F	1 m	MR-J2HBUS1M	Servo amplifier Junction terminal connector block connector	
			1 37 5 1 200 1 4 5 - 1	5 m	MR-J2HBUS5M		
	(3)	Connector set	MR-J5G_(-RJ)/ MR-J5B_(-RJ)	-	MR-CCN1	Servo amplifier connector	
	(4)	Junction terminal block	Connecting MR-J5WG/	0.5 m	MR-TBNATBL05M	Servo amplifier Junction terminal connector block connector	
<u>0</u>	(.)	cable	MR-J5WB and MR-TB26A	1 m	MR-TBNATBL1M		
For CN3	(5)	Connector set (Qty: 1 pc.)	MR-J5WG/ MR-J5WB	-	MR-J2CMP2	- Servo amplifier connector	
	(6)	Connector set (Qty: 20 pcs.)	MR-J5WG/ MR-J5WB	-	MR-ECN1		
	(7)	I/O and monitor connector	MR-J5DG4	-	MR-ADCN3	Drive unit connector	
	(8)	Junction terminal block	Connecting MR-J5A_(-RJ) and	0.5 m	MR-J2M-CN1TBL05M	Junction terminal block Servo amplifier connector connector	
	(0)	cable	MR-TB50	1 m	MR-J2M-CN1TBL1M		
	(9)	Connector set	MR-J5A_(-RJ)	-	MR-J3CN1	Servo amplifier connector	
	(10)	Battery cable	Connecting MR-J5G(-RJ)/ MR-J5WG/ MR-J5B(-RJ)/	0.3 m	MR-BT6V1CBL03M	Servo amplifier Battery case connector connector	
For CN4			MR-J5WB/ MR-J5A(-RJ), MR-BT6VCASE	1 m	MR-BT6V1CBL1M		
For	(11)	Junction battery cable	MR-J5G(-RJ)/ MR-J5WG/ MR-J5B(-RJ)/	0.3 m	MR-BT6V2CBL03M	Servo amplifier connector	
	(11)	Sanction battery cable	MR-J5WB/ MR-J5A(-RJ)	1 m	MR-BT6V2CBL1M	Junction connector	
For CN5	(12)	Personal computer communication cable (USB cable)	MR-J5G(-RJ)/ MR-J5G4-HS/ MR-J5WG/ MR-J5DG4/ MR-J5B(-RJ)/ MR-J5WB/ MR-J5A(-RJ)	3 m	MR-J3USBCBL3M	Servo amplifier connector Personal computer mini-B connector (5-pin) connector A connector	

Notes: 1. The wire size shows wiring specifications of the connector. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for examples of wire size selection. 2. MR-J5D1-_G4: CNP3A, MR-J5D2-_G4: CNP3A/CNP3B, MR-J5D3-_G4: CNP3A/CNP3B/CNP3C

Cables and Connectors for Servo Amplifiers

Refer to	"Det	ails of Option Connecto	ors for Servo Amplifiers" in th	is catalo	g for the detailed mode	els.	Com
No.		Item	Application	Cable length	Model	Description	Common Specifications
For CN6	(13)	Monitor cable	MR-J5G(-RJ)/ MR-J5A(-RJ)	1 m	MR-ACN6CBL1M	Servo amplifier connector	Servo S Contr
	(14)	Monitor cable	MR-J5WG	1 m	MR-J3CN6CBL1M		Servo System Controllers
	(15)	Short-circuit connector	MR-J5G(-RJ)/ MR-J5WG/ MR-J5DG4/ MR-J5B(-RJ)/ MR-J5WB/ MR-J5A(-RJ)	-	(Standard accessory)	This connector is required when the STO function is not used.	Servo Amplifiers
For CN8	(16)	STO cable	Connecting MR-J3-D05 or another safety control device with MR-J5G(-RJ)/ MR-J5WG/ MR-J5DG4/ MR-J5B(-RJ)/ MR-J5WB/ MR-J5A(-RJ)	3 m	MR-D05UDL3M-B	Servo amplifier connector	Rotary Servo Line Motors N
generation it CN4/drive N40A		Protection	MR-CV11K4 to MR-CV45K4 and MR-J5DG4	0.2 m	MR-ACDL02M	Power regeneration Drive unit connector converter unit connector	Linear Servo Motors
For power regeneration converter unit CN4/drive unit CN40A	(17)	coordination cable	MR-CV55K4/MR-CV75K4 and MR-J5DG4	0.5 m	MR-ACDL05M		Direct Drive Motors
For drive unit CN40A/ CN40B	(18)	Protection coordination cable	MR-J5DG4	0.2 m	MR-ADDL02M	Drive unit connector Drive unit connector	
For power regeneration converter unit CN24	(19)	Connector set (Note 1)	MR-CV_	-	MR-CVCN24S	Power regeneration converter unit connector 田賀	Options/Peripheral Equipment
For power regeneration converter unit CN23	(20)	Magnetic contactor wiring connector	MR-CV_	-	(Standard accessory)	Power regeneration Open tool converter unit connector	LVS/Wires

Notes: 1. A crimping tool (357J-22733) manufactured by DDK Ltd. is required. Contact the manufacturer directly.

Cables and Connectors for Servo Amplifiers

Refer to "Details of Option Connectors for Servo Amplifiers" in this catalog for the detailed models.

No.		Item	Application	Cable length	Model	Description
		SSCNET III cable (Note 1)		0.15 m	MR-J3BUS015M	
		(standard cord inside		0.3 m	MR-J3BUS03M	
	(21)	cabinet)	MR-J5B_(-RJ)/ MR-J5W - B	0.5 m	MR-J3BUS05M	
B		Compatible with	vin-00vvD	1 m	MR-J3BUS1M	
		SSCNET III/H		3 m	MR-J3BUS3M]
/CN1		SSCNET III cable (Note 1) (standard cable outside cabinet) Compatible with		5 m	MR-J3BUS5M-A ^(Note 4)	SSCNET III/H SSCNET III/H connector connector
For controller/CN1A/CN1B	(22)		MR-J5B_(-RJ)/ MR-J5WB	10 m	MR-J3BUS10M-A (Note 4)	
ler/(SSCNET III/H		20 m	MR-J3BUS20M-A (Note 4)	
ontrol		SSCNET III cable (Note 1, 3) (long distance cable, long		30 m	MR-J3BUS30M-B (Note 4)	
-or co	(23)		MR-J5B_(-RJ)/ MR-J5WB	40 m	MR-J3BUS40M-B (Note 4)	
ш.		SSCNET III/H		50 m	MR-J3BUS50M-B (Note 4)	
	(24)	SSCNET III connector set (Note 1, 2) Compatible with SSCNET III/H	MR-J5B_(-RJ)/ MR-J5WB	-	MR-J3BCN1	SSCNET III/H SSCNET III/H connector connector
For CN1B	(25)	SSCNET III connector cap Compatible with SSCNET III/H	MR-J5B_(-RJ)/ MR-J5WB	-	(Standard accessory)	[]p
For CN3	(26)	Connector set	MR-J5G4-HS	-	(Standard accessory)	Servo amplifier connector Applicable wire size: AWG 24 to 16
For CN7	(27)	Analog monitor and A/B/Z-phase pulse output cable	MR-J5G4-HS	10 m/ 2 m	MR-AHSCN7CBL2M10M	Servo amplifier connector 10 m For A/B/Z-phase pulse output: 10 m For analog monitor: 2 m
Fc	(28)	Connector cap	MR-J5G4-HS	-	(Standard accessory)	

Notes: 1. Read carefully through the precautions enclosed with the options before use.

Dedicated tools are required. Contact your local sales office for more details.
 For cables over 50 m or with ultra-long bending life, refer to "Products on the Market for Servo Amplifiers" in this catalog.
 For unlisted lengths of the cables, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

DG

Common Specifications

Servo System Controllers

Servo Amplifiers


Rotary Servo Motors

Linear Servo Motors

res

Bus Bar

For connecting L+/L- terminals between a converter unit and a drive unit and between drive units, use bus bars. Each of the bar models in the table includes a set of two bus bars.



(1) Between power regeneration converter unit and drive unit

(1) Between power regeneration of	converter unit and drive unit		Direct
Unit mounted on the left side (Note 1)	Unit mounted on the right side (Note 1)	Bus bar model	Motors
MR-CV11K4 MR-CV18K4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR077-B02	rs
	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR092-B02	Opti
MR-CV30K4 MR-CV37K4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR097-B02	Equipment
MR-CV45K4	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR112-B02	leral
MR-CV55K4 MR-CV75K4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR099-B03	LVS
	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR114-B03	\$/Wi

(2) Between drive units

Unit mounted on the left side (Note 1)	Unit mounted on the right side (Note 1)	Bus bar model	
MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller,	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR077-B02	Product L
MR-J5D3-200G4 or smaller	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR092-B02	list
MR-J5D2-500G4, MR-J5D2-700G4	MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	MR-DCBAR077-B02	Pre
	MR-J5D2-500G4, MR-J5D2-700G4	MR-DCBAR092-B02	ecal
(3) For final drive unit			utions

(3) For final drive unit

When an even number of drive units is connected to the power regeneration converter unit, a space is formed between the bus bars and the TE2 terminal block of the final drive unit. To fill this space, place adjustment bars (MR-DCBAR024-B05) between the bus bars and the TE2 terminal block, and tighten the screws.


Total number of drive units	Adjustment bar model
Even	MR-DCBAR024-B05
Odd Not required	

Notes: 1. "Unit mounted on the left side" and "Unit mounted on the right side" indicate the position when the units are seen from the front. Install the power regeneration converter unit on the left side of the drive unit


Configuration Example for MR-CM

G G-RJ WG B B-RJ WB A A-RJ

Connectors for MR-CM



Connectors for daisy chain wiring (Note 2)



Cables and Connectors for MR-CM

Refer to "Details of Option Connectors for MR-CM" in this catalog for the detailed models.


No.	Item	Application	Model	Description
(1)	Simple converter connector set	MR-CM3K	(Standard accessory)	CNP1 CNP2 CNP10 Open tool connector connector Connector CNP1, CNP2 connector Applicable wire size (Note 1): AWG 16 to 10 Insulator OD: 4.7 mm or smaller CNP10 connector Applicable wire size (Note 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller
	Daisy chain power	MR-J5-100G(-RJ) or smaller/ MR-J5W2-44G or smaller/ MR-J5W3-444G or smaller/ MR-J5-100B(-RJ) or smaller/ MR-J5W2-44B or smaller/ MR-J5W3-444B or smaller/ MR-J5-100A(-RJ) or smaller	MR-J5CNP12-J1	CNP1 CNP2 connector connector CNP1 connector Applicable wire size (Note 1): AWG 18 to 10 Insulator OD: 4.7 mm or smaller CNP2 connector Applicable wire size (Note 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller
(2)	connector	MR-J5-200G(-RJ)/ MR-J5W2-77G or larger/ MR-J5-200B(-RJ)/ MR-J5W2-77B or larger/ MR-J5-200A(-RJ)	MR-J5CNP12-J2	CNP1 CNP2 connector connector CNP1 connector Applicable wire size (Note 1): AWG 16 to 10 Insulator OD: 4.7 mm or smaller CNP2 connector Applicable wire size (Note 1): AWG 18 to 14 Insulator OD: 3.9 mm or smaller

Notes: 1. The wire size shows wiring specifications of the connector. Refer to "Wires, Molded-Case Circuit Breakers, and Magnetic Contactors" in this catalog for examples of wire size selection.

2. When mounting the servo amplifiers, follow the restrictions indicated in "MR-J5 User's Manual".

Configuration Example for MR-J3-D05





Cables and Connectors for MR-J3-D05

lo.		Item	Application	Cable length	Model	Description	tors
-or CN8	(1)	STO cable	Connecting MR-J3-D05 or another safety control device with MR-J5G(-RJ)/ MR-J5WG/	3 m	MR-D05UDL3M-B	Servo amplifier connector	Motors
For			MR-J5DG4/ MR-J5B(-RJ)/ MR-J5WB/ MR-J5A_(-RJ)				Motors
For CN9	(2)	Connector	MR-J3-D05	-	(Standard accessory of MR-J3-D05)	Safety logic unit connector	Equipment
For CN10	(3)	Connector	MR-J3-D05	-	(Standard accessory of MR-J3-D05)	Safety logic unit connector	nent LVS/VVIres

Common Specifications

Servo System Controllers

Servo Amplifiers

7-39

Details of Option Connectors for Servo Amplifiers

Model	CNP1 connector	CNP2 connector	CNP3 connector	Open tool
Servo amplifier power connector set For MR-J5-100G(-RJ) or smaller/ MR-J5-100B(-RJ) or smaller/ MR-J5-100A(-RJ) or smaller				GT
(standard accessory)	06JFAT-SAXGDK-K7.5 (LA) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-K5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	03JFAT-SAXGDK-K7.5 (J.S.T. Mfg. Co., Ltd.)	(LA) J-FAT-OT-K (J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector	CNP2 connector	CNP3 connector	Open tool
Servo amplifier power connector set For MR-J5-200G(-RJ)/ MR-J5-200B(-RJ)/ MR-J5-200A(-RJ)/ MR-J5-350G(-RJ)/ MR-J5-350B(-RJ)/				
MR-J5-350A(-RJ) (standard accessory)	06JFAT-SAXGFK-XL (LA) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-H5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	03JFAT-SAXGFK-XL(I (J.S.T. Mfg. Co., Ltd.)	LA) J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)
Model	CNP1A/CNP1B connector	CNP2 connector	CNP3 connector	Open tool
Servo amplifier power connector set For MR-J5-500G(-RJ)/ MR-J5-500B(-RJ)/ MR-J5-500A(-RJ)/ MR-J5-700G(-RJ)/ MR-J5-700B(-RJ)/ MR-J5-700A(-RJ) (standard accessory)	CNP1A connector 03JFAT-SAXGDK-P15 (LA) (J.S.T. Mfg. Co., Ltd.) CNP1B connector	CNP2 connector	CNP3 connector	For CNP1A/CNP1B/CNP3 connectors J-FAT-OT-P (J.S.T. Mfg. Co., Ltd.) For CNP2 connector
	03JFAT-SAYGDK-P15 (LB) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-H5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	03JFAT-SAZGDK-P15 (J.S.T. Mfg. Co., Ltd.)	(LC) J-FAT-OT (N) (J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector	CNP2 connector	CNP3 connector	Open tool
Servo amplifier power connector set For MR-J5-350G4(-RJ) or smaller/ MR-J5-350B4(-RJ) or smaller/ MR-J5-350A4(-RJ) or smaller				ST
(standard accessory)	06JFAT-SAXGDK-HT10.5 (LA) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-HT7.5 (LA) (J.S.T. Mfg. Co., Ltd.)	03JFAT-SAXGDK-HT10 (J.S.T. Mfg. Co., Ltd.)	.5 (LA) J-FAT-OT-XL (J.S.T. Mfg. Co., Ltd.)
Model	CNP1 connector	CNP2 connector	C	CNP3 connector
Servo amplifier power connector set For MR-J5-500G4(-HS)/ MR-J5-500B4(-RJ)/ MR-J5-500A4(-RJ)/ MR-J5-700G4(-HS)/ MR-J5-700G4(-HS)/ MR-J5-700B4(-RJ)/				
MR-J5-700A4(-RJ) (standard accessory)	831-1108/MNC (WAGO)	831-1103/MNB (WAGO)		31-1103/MNA NAGO)

Details of Option Connectors for Servo Amplifiers

Model	CNP1 connector	CNP2 connector	CNP3_ connector	Open tool	ecifi
Servo amplifier power connector set For MR-J5W2-44G or smaller/ MR-J5W3-444G or smaller/ MR-J5W2-44B or smaller/				ST	Common Specifications
MR-J5W3-444B or smaller (standard accessory)	06JFAT-SAXGDK-K7.5 (LB) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-K5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	04JFAT-SAGG-G-KK (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-K (J.S.T. Mfg. Co., Ltd.)	Servo System Controllers
Model	CNP1 connector	CNP2 connector	CNP3_ connector	Open tool	ystem
Servo amplifier power connector set For MR-J5W2-77G or larger/ MR-J5W2-77B or larger					
(standard accessory)	06JFAT-SAXGFK-XL (LB) (J.S.T. Mfg. Co., Ltd.)	05JFAT-SAXGDK-H5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	04JFAT-SAGG-G-KK (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)	Servo Amplifiers
Model	CNP3_ connector		Open tool *		
Drive unit power connector set For MR-J5DG4			[Rotary Servo Motors
(standard accessory)	BVF 7.62HP/04/180MF4 SN BI (Weidmüller Interface GmbH &		 SDS 0.8X4.5X125 (Weidmüller Interface GmbH & Co. KG) * The open tool is not supplied with a drive unit. The open tool must be prepared by users. 		Linear Servo Motors
Model	Servo amplifier connecto	r	Junction terminal block connector		near Ser Motors
MR-J2HBUS_M	Connector: 10120-6000EL Shell kit: 10320-3210-000		Press bonding type (Note 2) Connector: 10120-6000EL Shell kit: 10320-3210-000 (3M) or an equivalent product		o Direct Drive Motors
Model	Servo amplifier connecto	r			ę
MR-CCN1	(Solder type ^(Note 1) Connector: 10120-3000PE Shell kit: 10320-52F0-008 (3M) or an equivalent product		Options/Peripheral Equipment
Model	Servo amplifier connecto	r	Junction terminal block of	connector	
MR-TBNATBL_M	Connector: 10126-6000EL		Connector: 10126-6000EL		LVS/Wires
	Shell kit: 10326-3210-000 (3M) or an equivalent product		Shell kit: 10326-3210-000 (3M) or an equivalent product		Pro
Model	Servo amplifier connecto	r			Product List
MR-J2CMP2 MR-ECN1			Connector: 10126-3000PE Shell kit: 10326-52F0-008 (3M) or an equivalent product		
Model	I/O and monitor connecto	or			Preca
MR-ADCN3			Connector: DFMC 1,5/16-STF	-3,5	Precautions
			(Phoenix Contact)		Support

Notes: 1. The press bonding type (connector: 10120-6000EL and shell kit: 10320-3210-000) (3M) is also usable. Contact the manufacturer directly. 2. The solder type (connector: 10120-3000PE and shell kit: 10320-52F0-008) (3M) is also usable. Contact the manufacturer directly.

Details of Option Connectors for Servo Amplifiers

Model	Junction terminal block connector	Servo amplifier connector
MR-J2M-CN1TBL_M	Connector: D7950-B500FL (3M)	Press bonding type (Note 1) Connector: 10150-6000EL Shell kit: 10350-3210-000 (3M)
Model	Servo amplifier connector	
MR-J3CN1		Connector: 10150-3000PE Shell kit: 10350-52F0-008 (3M) or an equivalent product
Model	Servo amplifier connector	Battery case connector
MR-BT6V1CBL_M	Contact: SPHD-001G-P0.5 Housing: PAP-02V-O (J.S.T. Mfg. Co., Ltd.)	Solder type (Note 2) Connector: 10114-3000PE Shell kit: 10314-52F0-008 (3M) or an equivalent product
Model	Servo amplifier connector	Junction connector
MR-BT6V2CBL_M	Contact: SPHD-001G-P0.5 Housing: PAP-02V-O (J.S.T. Mfg. Co., Ltd.)	Contact: SPAL-001GU-P0.5 Housing: PALR-02VF-O (J.S.T. Mfg. Co., Ltd.)
Model	Servo amplifier connector	
MR-ACN6CBL1M		Housing: SHR-03V-S Contact: SSH-003T-P0.2-H (J.S.T. Mfg. Co., Ltd.)
Model	Servo amplifier connector	
MR-J3CN6CBL1M		Housing: 51004-0300 Terminal: 50011-8100 (Molex, LLC)
Model	Servo amplifier connector	
MR-D05UDL3M-B		Connector set: 2069250-1 (TE Connectivity Ltd. Company)
Model	SSCNET III/H connector	SSCNET III/H connector
MR-J3BUS_M MR-J3BUS_M-A MR-J3BCN1	Connector: PF-2D103 (Japan Aviation Electronics Industry, Limited)	Connector: PF-2D103 (Japan Aviation Electronics Industry, Limited)
MR-J3BUS_M-B	Connector: CF-2D103-S (Japan Aviation Electronics Industry, Limited)	Connector: CF-2D103-S (Japan Aviation Electronics Industry, Limited)
Model	Servo amplifier connector	
Connector set For MR-J5-500G4-HS/ MR-J5-700G4-HS (standard accessory)		DFMC 1,5/16-ST-3,5-LRBK (Phoenix Contact) or an equivalent product
Model	Servo amplifier connector	
MR-AHSCN7CBL2M10M		IX30G-B-10S-CVL1(7.0) (Hirose Electric Co., Ltd.)

Notes: 1. The solder type (connector: 10150-3000PE and shell kit: 10350-52F0-008) (3M) is also usable. Contact the manufacturer directly. 2. The press bonding type (connector: 10114-6000EL and shell kit: 10314-3210-000) (3M) is also usable. Contact the manufacturer directly.

S

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Support

Details of Option Connectors for Drive Unit/MR-CV_

Model	Power regeneration co	onverter unit connector	Drive unit connector		cifi
MR-ACDL_M		Plug: 10120-3000PE Shell kit: 10320-56F0-008 (3M) or an equivalent product		Plug: HDR-E26MG1+ Shell kit: HDR-E26LPJP+ (Honda Tsushin Kogyo Co., Ltd.)	Common
Madal					Servo
Model	Drive unit connector		Drive unit connector		
MR-ADDL02M		Connector: IX30G-A-10S- CV(7.0) (Hirose Electric Co., Ltd.)		Plug: HDR-E26MG1+ Shell kit: HDR-E26LPJP+ (Honda Tsushin Kogyo Co., Ltd.)	ervo System Controllers
Model	Power regeneration converter unit connector				S
MR-CVCN24S			Connector: DK-2100D-08 Contact: DK-2RECSLP1-1 (DDK Ltd.)		Servo Amplifiers
Model	Power regeneration co	onverter unit connector	Open tool		fiers
Magnetic contactor wiring connector (Standard accessory of power regeneration converter unit)	Connector: 03JFAT-SAXGSA-L (J.S.T. Mfg. Co., Ltd.)		J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)		Rotary Servo Motors

Details of Option Connectors for MR-CM

Model	CNP1 connector	CNP2 connector	CNP10 connector	Open tool
Simple converter connector set (standard accessory)	03JFAT-SAYGFK-XL (LB) (J.S.T. Mfg. Co., Ltd.)	02(16.0)JFAT-SAZGFK-XL (LA) (J.S.T. Mfg. Co., Ltd.)	02(3-2)JFAT-SAYDFK-K7.5 (J.S.T. Mfg. Co., Ltd.)	J-FAT-OT-EXL (J.S.T. Mfg. Co., Ltd.)
				· · ·
Model	CNP1 connector		CNP2 connector	
MR-J5CNP12-J1			05JFAT-SAXGDK-KC5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	
Model	CNP1 connector		CNP2 connector	
MR-J5CNP12-J2			05JFAT-SAXGDK-HC5.0 (LA) (J.S.T. Mfg. Co., Ltd.)	

Details of Option Connectors for MR-J3-D05

Model	Servo amplifier connector	
MR-D05UDL3M-B		Connector set: 2069250-1 (TE Connectivity Ltd. Company)
Model	Safety logic unit connector	
Connector for CN9 of safety logic unit (Standard accessory of MR-J3-D05)		Connector: 1-1871940-4 (TE Connectivity Ltd. Company)
Model	Safety logic unit connector	
Connector for CN10 of safety logic unit (Standard accessory of MR-J3-D05)		Connector: 1-1871940-8 (TE Connectivity Ltd. Company)

Products on the Market for Servo Amplifiers

SSCNET III Cable

Application	Model	Description	
Standard cable inside cabinet for SSCNET III/H	SC-JXBUS_M	_ = cable length [m] 0.15, 0.3, 0.5, 1, 2, 3	
Standard cable outside cabinet for SSCNET III/H	SC-J4BUS_M-A	_ = cable length	
Long distance cable, ultra-long bending life cable for SSCNET III/H	SC-J3BUS_M-C	(100 m maximum, unit of 1 m)	Mitsubishi Electric System & Service Co., Ltd. (Note 1)

Notes: 1. For details, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

Shield connection clamp

The shield connection clamp is used to ground the shield of a servo amplifier I/O signal cable on the top surface of the servo amplifier.

Application	Model	Description	
I/O cable shield connection for MR-J5-500_4_/ MR-J5-700_4_	S(:(: 15-F (NOLE 2)	Supported cable diameter: 8 mm to 15 mm	Phoenix Contact (Note 1)

Notes: 1. For details, please contact the relevant manufacturers directly.

2. For installation of this clamp, two screws (M4 \times 6 to 12) are required. 7-44

40



Mitsubishi Electric Engineering

Network amplifier junction terminal block

Features

- The spring clamp type reduces the installation area by about 40 % compared to the screw type (based on the research of Mitsubishi Electric Engineering).
- When multiple servo amplifiers are connected, the interface power supply can be connected in series across terminal blocks.

40

Model

Connection with servo amplifier

Servo amplifier connection cable

Dimensions

■DG2SV3TB



5

33

[Unit: mm]

5.5

DIN rail cente

[Unit: mm]

ü

Servo Amplifiers

Servo System Controllers

Common Specifications

Linear Servo Motors


Direct Drive Motors

ptions/Peripheral Equipment

LVS/Wires



List



Junction terminal block for servo motors with brakes

Features

MR-J5-G(-RJ)

Item

Product models

Easy to build a brake sequence circuit recommended for MR-J5-G servo amplifiers. The new terminal block reduces the installation area by up to 50 % compared to preceding types. In addition, fewer wires are required inside the cabinet.


Description

Length: 0.5 m

Length: 1 m

Length: 5 m


Connection with servo amplifier



* The DG2BK1TB-D is without mounting tabs

Dimensions

External power supply voltage: 24 V DC ± 10 %



For network-connectable 1-axis servo amplifier, sink/source common type

Maximum usable current: 0.5 A for signal/6 A for common line

* The DG2BK1TB-D is without mounting tabs

Product models


Item	Model	Description	
Junction terminal block for motor with brake For network-connectable 1-axis servo amplifier Sink/source common type*	DG2BK1TB	Screw mounting/ DIN rail installation	Applicable servo motor capacity: 50 W to 22 kW External power supply voltage
	DG2BK1TB-D	For DIN rail installation	For servo amplifier interface: 24 V DC (-5 % to 10 %), 0.3 A (max.) For electromagnetic brake: 24 V DC (-10 % to 0 %), 1.43 A (max.) Relay: DSP1a-DC24V (Panasonic Corporation)
Servo amplifier connection cable	DG4SV2CB05	Length: 0.5 m	
	DG4SV2CB10	Length: 1 m	
	DG4SV2CB50	Length: 5 m	


FLS/RLS/DOG signal-specialized network amplifier terminal block

Features

- Compact terminal blocks designed specifically for the FLS/RLS (stroke limit) and DOG (proximity dog) signals.
- Long cables are available to install the terminal block near the machine. (Long bending life cables are also available.)









Dimensions

■ DG2SV2TB2 (for 2-axis servo amplifier)



Dimensions

DG2SV2TB3 (for 3-axis servo amplifier)



Product models

Item	Model	Description	
	DG2SV2TB	For network-connectable 1-axis servo amplifier	
FLS/RLS/DOG signal-specialized (for 1-axis		Sink/source common type, dedicated for FLS/RLS/DOG signals	
network amplifier terminal block servo amplifier)		External power supply voltage: 24 V DC ± 10 %	
		Maximum usable current: 0.5 A for signal / 6 A for common line	
Sink-interface servo amplifier connection cable	DG4SV2CB05	Length: 0.5 m	
(for 1-axis servo amplifier)	DG4SV2CB10	Length: 1 m	
(Ior 1-axis servo ampiner)	DG4SV2CB50	Length: 5 m	
Sink-interface servo amplifier connection cable	DG4SV2CB50H	Length: 5 m	
(for 1-axis servo amplifier / long bending life)	DG4SV2CB100H	Length: 10 m	
	DG4SV2CB05-P01	Length: 0.5 m	
Source-interface servo amplifier connection cable	DG4SV2CB10-P01	Length: 1 m	
(for 1-axis servo amplifier)	DG4SV2CB50-P01	Length: 5 m	
Source-interface servo amplifier connection cable	DG4SV2CB50H-P01	Length: 5 m	
(for 1-axis servo amplifier / long bending life)	DG4SV2CB100H-P01	Length: 10 m	
		For network-connectable 2-axis servo amplifier	
	DG2SV2TB2	Sink/source common type, dedicated for FLS/RLS/DOG signals	
		External power supply voltage: 24 V DC ± 10 %	
FLS/RLS/DOG signal-specialized (for 2-axis/3-axis		Maximum usable current: 0.5 A for signal / 6 A for common line	
network amplifier terminal block servo amplifier)	DG2SV2TB3	For network-connectable 3-axis servo amplifier	
		Sink/source common type, dedicated for FLS/RLS/DOG signals	
		External power supply voltage: 24 V DC ± 10 %	
		Maximum usable current: 0.5 A for signal / 6 A for common line	
Sink-interface servo amplifier connection cable	DG4SV3CB05	Length: 0.5 m	
(for 2-axis/3-axis servo amplifier)	DG4SV3CB10	Length: 1 m	
	DG4SV3CB50	Length: 5 m	
Sink-interface servo amplifier connection cable	DG4SV3CB50H	Length: 5 m	
(for 2-axis/3-axis servo amplifier/long bending life)	DG4SV3CB100H	Length: 10 m	
Source-interface servo amplifier connection cable	DG4SV3CB05-P01	Length: 0.5 m	
(for 2-axis/3-axis servo amplifier)	DG4SV3CB10-P01	Length: 1 m	
	DG4SV3CB50-P01	Length: 5 m	
Source-interface servo amplifier connection cable	DG4SV3CB50H-P01	Length: 5 m	
(for 2-axis/3-axis servo amplifier/long bending life)	DG4SV3CB100H-P01	Length: 10 m	

Common Specifications

Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral

LVS/Wires

Product

List

Precautions

Support

Equipment

Servo amplifier connection cable for pulse train Positioning modules

Features	·	Servo amplifier connection cable for pulse train Positioning modules FA-CBL075M233
This servo amplifier connection modules enables easy wiring is used to control the MR-J5-A	when the MELSEC Po	
Dimensions		MR-JS-A
■ FA-CBLQ75M2J3, FA-CBLQ7	5PM2J3	■FA-CBLQ75M2J3-P
RD75-side connector 45 45 45 45 45 45 45 45 45 45	Servo amplifier-sid connector	le Servo amplifier-side connector 45 000 2000 (Unit: mm]
Item	Model	Description
	FA-CBLQ75M2J3-P	Supported Positioning module: RD75D2, RD75D4, FX5-20PG-D Length: 2 m, with pulsar cables
Servo amplifier connection cable for pulse train Positioning modules	FA-CBLQ75M2J3	Supported Positioning module: RD75D2, RD75D4, FX5-20PG-D Length: 2 m, without pulsar cables

Supported Positioning module: RD75P2, RD75P4, FX5-20PG-P

Length: 2 m, without pulsar cables


General-purpose interface amplifier junction terminal block



The spring clamp type reduces the installation area by approximately 50 % compared to the screw type (based on the research of Mitsubishi Electric Engineering).

FA-CBLQ75PM2J3

When multiple servo amplifiers are connected, the interface power supply can be connected in series across up to four terminal blocks.



Product models

Item	Model	Description
General-purpose interface amplifier junction terminal block	DG2SV1TB	For general-purpose interface servo amplifier, sink/source common type External power supply voltage: 24 V DC ± 10 %, current capacity 1 A (max.)
Servo amplifier connection cable	DG4SV1CB05	Length: 0.5 m
	DG4SV1CB10	Length: 1 m

For inquiries about Mitsubishi Electric Engineering products, please contact us at the following email address. (Supported languages: English and Japanese).

fagoods.products.faq@mitsubishielectricengineering.com

Safety Logic Unit (MR-J3-D05)

G G-RJ WG DG B B-RJ WB A A-RJ


The safety logic unit (MR-J3-D05) has SS1 (Safe Stop1) and STO functions. A combination of the servo amplifier and the safety logic unit achieves SS1 function.

Specifications

Safety logic u	init model	MR-J3-D05	
Voltage		24 V DC	
Control circuit power	Permissible voltage fluctuation	24 V DC ± 10 %	
supply	Required current [A] capacity	0.5 (Note 1, 2)	
Compatible sy	ystem	2 systems (A-axis, B-axis independent)	
Shut-off input	1	2 points (double wiring) SDI_: source/sink compatible (Note 3)	
Shut-off relea	ise input	1 point (double wiring) SRES_: source/sink compatible (Note 3)	
Feedback inp	but	1 point (double wiring) TOF_: source compatible (Note 3)	
Input type		Photocoupler insulation, 24 V DC (external supply), internal limited resistance 5.4 k Ω	
Shut-off outpu	ut	4 points (double wiring) STO_: source compatible (Note 3) SDO_: source/sink compatible (Note 3)	
Output type		Photocoupler insulation, open-collector type Permissible current: 40 mA or less per output, Inrush current: 100 mA or less per output	
Delay time se	etting	A-axis: select from 0 s, 1.4 s, 2.8 s, 5.6 s, 9.8 s or 30.8 s B-axis: select from 0 s, 1.4 s, 2.8 s, 9.8 s or 30.8 s Accuracy: ±2 %	
Safety sub-fu	nction	STO, SS1 (IEC/EN 61800-5-2) EMG STOP, EMG OFF (IEC/EN 60204-1)	
	Standards	ISO 13849-1:2015 Category 3 PL d, EN IEC 62061, EN 61508 SIL2, IEC 61800-5-2	
_	Response performance (when delay time is set to 0 s) (Note 4)	10 ms or less (STO input OFF \rightarrow shut-off output OFF)	
	Mean time to dangerous failure (MTTFd)	MTTFd ≥ 100 [years] (516a)	
-	Diagnostic coverage (DC)	DC = Medium, 93.1 %	
	Probability of dangerous Failure per Hour (PFH)	4.75 × 10 ^{.9} [1/h]	
Standards	CE marking	LVD: EN 61800-5-1 EMC: EN 61800-3 MD: EN ISO 13849-1:2015, EN 61800-5-2, EN IEC 62061	
Structure (IP	rating)	Natural cooling, open (IP00)	
	Ambient temperature	Operation: 0 °C to 55 °C (non-freezing), storage: -20 °C to 65 °C (non-freezing)	
Environment A	Ambient humidity	Operation/storage: 5 %RH to 90 %RH (non-condensing)	
	Ambience	Indoors (no direct sunlight); no corrosive gas, inflammable gas, oil mist or dust	
	Altitude	1000 m or less	
	Vibration resistance	5.9 m/s ² at 10 Hz to 55 Hz (directions of X, Y, and Z axes)	
Mass	[ka]	0.2 (including CN9 and CN10 connectors)	


Notes: 1. Inrush current of approximately 1.5 A flows instantaneously when the power is switched on. Select an appropriate capacity of a power supply considering the inrush current. 2. Power-on duration of the safety logic unit is 100,000 times.

3. _ in signal name indicates a number and axis name.
 4. Contact your local sales office for test pulse input.



Notes: 1. Set delay time of STO output with SW1 and SW2. 2. This connection is for source interface.

Dimensions



Mounting screw size: M4

[Unit: mm]

Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Regenerative Option

G G-RJ G-HS WG B B-RJ WB A A-RJ

For 200 V (MR-RB_)

	Permissible r	egene	rative p	ower [W] (Note 2)								
		Reger	nerative	e optio	n								
Servo amplifier	Built-in	MR-R	В										
	regenerative resistor	032	12	14	30 (Note 3)	3N (Note 3)	31 (Note 3)	3Z (Note 3, 4)	34 (Note 3)	50 (Note 1)	5N (Note 1)	51 (Note 1)	5Z (Note 1, 4)
		40 Ω	40 Ω	26 Ω	13 Ω	9Ω	6.7 Ω	5.5 Ω	26 Ω	13 Ω	9Ω	6.7 Ω	5.5 Ω
MR-J5-10G/B/A	-	30	-	-	-	-	-	-	-	-	-	-	-
MR-J5-20G/B/A	10	30	100	-	-	-	-	-	-	-	-	-	-
MR-J5-40G/B/A	10	30	100	-	-	-	-	-	-	-	-	-	-
MR-J5-60G/B/A	10	30	100	-	-	-	-	-	-	-	-	-	-
MR-J5-70G/B/A	30	-	-	100	-	-	-	-	300	-	-	-	-
MR-J5-100G/B/A	30	-	-	100	-	-	-	-	300	-	-	-	-
MR-J5-200G/B/A	100	-	-	-	300	-	-	-	-	500	-	-	-
MR-J5-350G/B/A	100	-	-	-	-	300	-	-	-	-	500	-	-
MR-J5-500G/B/A	130	-	-	-	-	-	300	-	-	-	-	500	-
MR-J5-700G/B/A	170	-	-	-	-	-	-	300	-	-	-	-	500
MR-J5W2-22G/B	20	-	-	100	-	-	-	-	-	-	-	-	-
MR-J5W2-44G/B	20	-	-	100	-	-	-	-	-	-	-	-	-
MR-J5W2-77G/B	100	-	-	-	-	300	-	-	-	-	-	-	-
MR-J5W2-1010G/B	100	-	-	-	-	300	-	-	-	-	-	-	-
MR-J5W3-222G/B	30	-	-	100	-	-	-	-	300	-	-	-	-
MR-J5W3-444G/B	30	-	-	100	-	-	-	-	300	-	-	-	-

For 400 V (MR-RB_-4)

	Permissible r	egene	egenerative power [W] (Note 2)											
		Rege	Regenerative option											
	Built-in	MR-R	MR-RB											
model	regenerative resistor	1H-4	3M-4 (Note 1)	3G-4 (Note 1)	3Y-4 (Note 1)	34-4 (Note 1)	3U-4 (Note 1)	5G-4 (Note 1)	5Y-4 (Note 1)	54-4 (Note 1)	5U-4 (Note 1)			
		82 Ω	120 Ω	47 Ω	36 Ω	26 Ω	22 Ω	47 Ω	36 Ω	26 Ω	22 Ω			
MR-J5-60G4/B4/A4	15	100	300	-	-	-	-	-	-	-	-			
MR-J5-100G4/B4/A4	15	100	300	-	-	-	-	-	-	-	-			
MR-J5-200G4/B4/A4	100	-	-	300	-	-	-	500	-	-	-			
MR-J5-350G4/B4/A4	120	-	-	-	300	-	-	-	500	-	-			
MR-J5-500G4/B4/A4	130	-	-	-	-	300	-	-	-	500	-			
MR-J5-700G4/B4/A4	170	-	-	-	-	-	300	-	-	-	500			

Notes: 1. Cool the unit forcibly with a cooling fan (92 mm × 92 mm, minimum air flow: 1.0 m³/min). The cooling fan must be prepared by users.

2. The power values in this table are resistor-generated powers, not rated powers.


3. Depending on the operating environment, it may be necessary to cool the unit forcibly with a cooling fan (92 mm × 92 mm, minimum air flow: 1.0 m³/min).

Refer to "MR-J5 User's Manual" for details. The cooling fan must be prepared by users. 4. Use the servo amplifier with firmware version B6 or later.

* Precautions when installing and connecting the regenerative option


1. The regenerative option causes a temperature rise of 100 °C or higher relative to the ambient temperature. Fully examine heat dissipation, installation position, wires used before installing the unit. Use flame-retardant wires or apply flame retardant on wires, and keep the wires clear of the unit.

Use twisted wires for connecting the regenerative option to the servo amplifier, and keep the wire length to a maximum of 5 m.
 Use twisted wires for connecting a thermal sensor so that the sensor does not fail to work properly because of inducted noise.
 There are restrictions on the mounting direction of the regenerative option. Refer to "MR-J5 User's Manual" for details.



Notes: 1. Create a sequence circuit that turns off the magnetic contactor when abnormal overheating occurs.

 G3 and G4 terminals are thermal sensor. G3-G4 opens when the regenerative option overheats abnormally.
 The wire size shows wiring specifications of the connector. Refer to "Wires, Molded-Case Circuit Breakers, and Magnetic Contactors" in this catalog for examples of wire size selection.



Notes: 1. Create a sequence circuit that turns off the magnetic contactor when abnormal overheating occurs.

2. When using MR-RB3M-4, MR-RB3G-4, MR-RB3Y-4, MR-RB3U-4, MR-RB50, MR-RB50, MR-RB51, MR-RB52, MR-RB52, MR-RB54-4, MR-RB54-4, or MR-RB5U-4, cool the unit forcibly with a cooling fan (92 mm × 92 mm, minimum air flow: 1.0 m³/min). The cooling fan must be prepared by users.

3. When MR-RB30, MR-RB31, MR-RB31, MR-RB32, or MR-RB34 is used, it may be necessary to cool the unit forcibly with a cooling fan (92 mm × 92 mm, minimum air flow: 1.0 m⁹/min), depending on the operating environment. Refer to "MR-J5 User's Manual" for details. The cooling fan must be prepared by users.

4. G3 and G4 terminals are thermal sensor. G3-G4 opens when the regenerative option overheats abnormally.

G G-RJ G-HS B B-RJ

Common Specifications

A-RJ

Α

Multifunction Regeneration Converter (FR-XC, FR-XC-H) (Note 5)

FR-XC multifunction regeneration converter is suitable for 200 V class servo amplifiers ranged from 100 W to 7 kW and FR-XC-H for 400 V class servo amplifiers ranged from 600 W to 7 kW. The multifunction regeneration converter is not compatible with multi-axis servo amplifiers and drive units.

200 V class

									Servo Cont		
200 V class) System trollers	
Multifunction regene	eration converter FF	R-XC-	7.5K	11K	15K	22K	30K	37K	55K	tem rs	
Capacity		[kW]	7.5	11	15	22	30	37	55		
	of connectable servo amplifiers		10							S	
	nnectable servo amplifiers (Note 1)	[kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	22	30	37	55	Servo Amplifiers	
Continuous output (*	Note 1)	[kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	18.5	22	30	45	A	
Rated input	Power driving		33	47	63	92	124	151	223	qu	
current [A]	Regenerative driving		26	37	51	74	102	125	186	lifie	
Overload current rat	ting		100 % cont	tinuous / 150) % 60 s					S	
	Rated input AC voltage/frequency	l .	3-phase 20	0 V AC to 24	40 V AC, 50	Hz/60 Hz					
Power source Permissible AC voltage fluctuation		า	3-phase 170 V AC to 264 V AC, 50 Hz/60 Hz								
Fower source	Permissible frequency fluctuation	±5 %							Rotary Mote		
	Power supply capacity	[kVA]	17	20	28	41	52	66	100	tary Se Motors	
IP rating (IEC 60529	9)		Open type	(IP00)						Servo ors	
Cooling system			Forced air							SO	
	Ambient temperature		-10 °C to 50	0 °C (non-fre	ezing)						
	Ambient humidity		90 %RH or	less (non-co	ondensing)						
	Storage temperature		-20 °C to 65							_ Lin	
Environment	Ambience		Indoors (wit	thout corrosi	ive gas, flarr	nmable gas,	oil mist, dus	t and dirt)		ear Se Motors	
	Altitude		2500 m or l	less (For the	installation	at an altitude	e above 100	0 m, consid	er a 3 %	tor	
	Annude		reduction in	the rated cr	urrent per 50	00 m increas	e in altitude	.)		Linear Servo Motors	
	Vibration resistance		5.9 m/s ² at	10 Hz to 55	Hz (directio	ns of X, Y, ar	nd Z axes)			0	
Molded-case circuit	breaker or earth-leakage current		100 AF 60 A	100 AF 75 A	225 AF 125 A	225 AF 175 A	225 AF 225 A	400 AF 250 A	400 AF 400 A		
breaker (Note 4)			(30 AF 30 A)	(50 AF 50 A)	(100 AF 75 A)	(100 AF 100 A)	(125 AF 125 A)	(125 AF 125 A)	(225 AF 175 A)		
Magnatia contactor		S-T35	S-T50	S-T65	S-T100	S-N125	S-N150	S-N220	Dire		
Magnetic contactor			(S-T21)	(S-T35)	(S-T50)	(S-T65)	(S-T80)	(S-T100)	(S-N125)	rect Dri Motors	
400 V class									······	Direct Drive Motors	

400 V class

Multifunction reger	neration converter	FR-XC-H	7.5K	11K	15K	22K	30K	37K	55K		
Capacity		[kW]	7.5	11	15	22	30	37	55	Options/Peripheral Equipment	
Maximum number	of connectable servo amplifie	ers	10							Ēq	
Total capacity of co	onnectable servo amplifiers ^{(N}	lote 1) [kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	22	30	37	55	s/Pe	
Continuous output	(Note 1)	[kW]	3.5 (5.5)	5.5 (7.5)	7.5 (11)	18.5	22	30	45	ərip	
Rated input	Power driving		18	25	34	49	65	80	118	her	
current [A]	Regenerative driving		14	20	27	39	54	66	98	al	
Overload current ra		100 % cont	inuous / 150) % 60 s							
	uency (Note 2)	3-phase 38	0 to 500 V A	C, 50 Hz/60) Hz						
Power cource	Power source Permissible AC voltage fluctuation Permissible frequency fluctuation			3 to 550 V A	AC, 50 Hz/60) Hz				LVS/Wires	
Fower source										\leq	
	Power supply capacity	[kVA]	17	20	28	41	52	66	100	res	
IP rating (IEC 6052	29)		Open type	(IP00)							
Cooling system			Forced air								
	Ambient temperature		-10 °C to 50 °C (non-freezing)								
	Ambient humidity		90 %RH or	less (non-co	ondensing)					Product	
	Storage temperature		-20 °C to 6	5 °C						duo	
Environment	Ambience		Indoors (wi	thout corros	ive gas, flan	nmable gas,	oil mist, dus	st and dirt)		ot List	
	Altitude		2500 m or less (For the installation at an altitude above 1000 m, consider a 3 %								
	Allitude		reduction in	reduction in the rated current per 500 m increase in altitude.)							
	5.9 m/s ² at	5.9 m/s ² at 10 Hz to 55 Hz (directions of X, Y, and Z axes)									
Molded-case circui	t breaker or earth-leakage cu	urrent	30 AF 30 A	50 AF 50 A	100 AF 60 A	100 AF 100 A	225 AF 125 A	225 AF 150 A	225 AF 200 A	P	
breaker (Note 4)			(30 AF 15 A)	(30 AF 20 A)	(30 AF 30 A)	(50 AF 50 A)	(60 AF 60 A)	(100 AF 75 A)) (100 AF 100 A)	.ec	
Magnatia contacto	(Note 4)		S-T21	S-T25	S-T35	S-T50	S-T65	S-T80	S-N125	aut	
Magnetic contactor			3-121	(S-T21)	(S-T21)	(S-T25)	(S-T35)	(S-T50)	(S-T65)	Precautions	
										0	

Notes: 1. The values in brackets are applicable when the number of connected servo amplifiers is six or less.

2. When connecting to a servo amplifier, use with a voltage range of 380 V to 480 V.

When connecting to a servo amplifier, use with a voltage range of 323 V to 528 V.
 The models in brackets are applicable when the capacity [kW] of FR-XC-(H) ≥ Total rated capacity [kW] of servo amplifiers connected to FR-XC-(H) × 2.

5. The following are specifications at the time of December 2023.

For selecting an FR-XC-(H) multifunction regeneration converter, refer to the latest "FR-XC Instruction Manual" and "MR-J5 User's Manual".

* Precautions when selecting the multifunction regeneration converter

Drive system sizing software Motorizer does not support combinations of servo amplifiers and a multifunction regeneration converter.

Select a multifunction regeneration converter which meets the following conditions.


1. Total rated capacity [kW] of servo amplifiers connected to FR-XC-(H) ≤ Capacity [kW] of FR-XC-(H)

2. Effective value [kW] of total output power of servo motors ≤ Continuous output [kW] of FR-XC-(H)

Maximum value [kW] of total output power of servo motors ≤ FR-XC-(H) capacity [kW] × 1.5

Multifunction Regeneration Converter (FR-XC, FR-XC-H) G G-RJ G-HS B B-RJ A A-RJ

Connection example



1. Create a sequence that shuts off the main circuit power when either: Notes:

An alarm occurs on FR-XC-(H) or the servo amplifier, or

- EM1 (Forced stop 1) is enabled.
- 2. For the servo amplifier, create a sequence that switches the servo-on after FR-XC-(H) is ready.
- 3. Create a sequence that stops the servo motor with the emergency stop input to the controller when an alarm occurs on FR-XC-(H). When the emergency stop input is not available in the controller, stop the servo motor with the forced stop input to the servo amplifier as shown in the diagram.
- 4. Disconnect the short-circuit bar between P3 and P4 when using FR-XC-(H).
- 5. Set [Pr. PA04.3] and [Pr. PA04.2] to "0" to enable EM1 (Forced stop 1).
- When wires used for L11 and L21 are thinner than those for L1, L2, and L3, use a molded-case circuit breaker. 6.
- 7. When using a separate power supply for the control circuit, remove the short-circuit bars between R/L1 and R1/L11, and S1/L21.
- 8. When FR-XC-H is used, a step-down transformer is required if coil voltage of the magnetic contactor is in 200 V class.
- 9. Use twisted wires for connecting the DC power supply between FR-XC-(H) and the servo amplifiers, and keep the wire length to a maximum of 5 m (3 m for EMC compliance).
- 10. Install a fuse between each FR-XC-(H) and servo amplifier.
- 11. Do not connect anything to the P4 terminal of FR-XC-(H).
- 12. Inputs/outputs (main circuit) of FR-XC-(H) and the servo amplifier include high frequency components, and they may interfere with peripheral communication devices. In that case, the interference can be reduced with the installation of a radio noise filter (FR-BIF or FR-BIF-H) or line noise filter (FR-BSF01 or FR-BLF).
- 13. When using 7 kW or smaller servo amplifiers, do not disconnect the short-bar between P+ and D.
- 14. For convenience of illustration, the diagram shows separate 24 V DC power supplies for input and output signals. However, the input and output signals can share a common power supply
- 15. When using FR-XC-(H), use the following dedicated stand-alone reactor (FR-XCL or FR-XCL-H). Do not use a power factor improving AC reactor (FR-HAL or FR-HAL-H) or a power factor improving DC reactor (FR-HEL or FR-HEL-H) with FR-XC-(H).


Multifunction regeneration converter	Dedicated stand-alone reactor	Multifunction regeneration converter	Dedicated stand-alone reactor
FR-XC-7.5K	FR-XCL-7.5K	FR-XC-H7.5K	FR-XCL-H7.5K
FR-XC-11K	FR-XCL-11K	FR-XC-H11K	FR-XCL-H11K
FR-XC-15K	FR-XCL-15K	FR-XC-H15K	FR-XCL-H15K
FR-XC-22K	FR-XCL-22K	FR-XC-H22K	FR-XCL-H22K
FR-XC-30K	FR-XCL-30K	FR-XC-H30K	FR-XCL-H30K
FR-XC-37K	FR-XCL-37K	FR-XC-H37K	FR-XCL-H37K
FR-XC-55K	FR-XCL-55K	FR-XC-H55K	FR-XCL-H55K

Battery (MR-BAT6V1SET, MR-BAT6V1SET-A)

Battery (MR-B	BAT6V1SET, MR-BAT6V1SET-A)	G	G-RJ B E	3-RJ A A-RJ	S	
when the battery is	configure an absolute position detection system with a s mounted on the servo amplifier. The battery is not re s out, please replace the built-in MR-BAT6V1 battery.	quired for rotary serve	o motors and linear s	servo motors. When	Common Specifications	
			Fully closed loop co	ontrol system		
		Semi closed loop	Load side		S S	
Servo amplifier	Motor side	control system	Battery-less absolute position encoder	Linear encoder	Servo System Controllers	
	Servo motor with battery-less absolute position encoder	Not required	Not required	Not required	s. em	
MR-J5-G/A	Direct drive motor	Required (Note 1)	Required (Note 2)	Required (Note 2)	လူ	
	Linear servo motor	Not required	Not supported	Not supported	Servo	
	Servo motor with battery-less absolute position encoder	Not required	Not required	Not required	Amplifiers	
MR-J5-B	Direct drive motor	Required (Note 1)	Not supported Not supported		fier	
	Linear servo motor	Not required	Not supported	S		

Notes: 1. An absolute position storage unit (MR-BTAS01) is required.

2. An absolute position storage unit (MR-BTAS01) may be required depending on the parameter setting. Refer to "MR-J5 User's Manual" for details.



Model		MR-BAT6V1SET/MR-BAT6V1SET-A
Nominal voltage	[V]	6
Nominal capacity	[mAh]	1650
Lithium content	[g]	1.2
Primary battery		2CR17335A (CR17335A × 2 pcs. in series)
Mass	[g]	55 (including MR-BAT6V1 battery)
* MP I2PAT batton	annat	ha used because of the difference in voltage

MR-J3BAT battery cannot be used because of the difference in voltage

* MR-BAT6V1 is an assembled battery composed of lithium metal batteries of CR17335A. This battery is not subject to the dangerous goods (Class 9) of the UN Recommendations.

To transport lithium metal batteries and lithium metal batteries contained in equipment, take actions to comply with the following regulations: the United Nations Recommendations on the Transport of Dangerous Goods, the Technical Instruction (ICAO-TI) by the International Civil Aviation Organization (ICAO), and the International Maritime Dangerous Goods Code (IMDG Code) by the International Maritime Organization (IMO). To transport the batteries, check the latest standards or the laws of the destination country and take actions. Contact your local sales office for more details.

* Please dispose of the battery according to your local laws and regulations.


Precautions

Battery Case (MR-BT6VCASE) and Battery (MR-BAT6V1)

Absolute position data of up to four axes of direct drive motors can be retained when the battery case and the batteries are used. Direct drive motors used in incremental systems are also included in the number of the connectable axes. The synchronous encoders used for load side in the fully closed loop control system are also included in the number of the connectable axes. The linear servo motors are not included in the number of the connectable axes. The linear servo motors and batteries and multi-axis servo amplifiers.

G G-RJ WG B B-RJ WB A A-RJ


The case stores five batteries by connecting to the connectors. The batteries are not included in the battery case. Please purchase the batteries separately.




* MR-BAT6V1 is an assembled battery composed of lithium metal batteries of CR17335A. This battery is not subject to the dangerous goods (Class 9) of the UN Recommendations. To transport lithium metal batteries and lithium metal batteries contained in equipment, take actions to comply with the following regulations: the United Nations Recommendations on the Transport of Dangerous Goods, the Technical Instruction (ICAO-TI) by the International Civil Aviation Organization (ICAO), and the International Maritime Dangerous Goods Code (IMDG Code) by the International Maritime Organization (IMO). To transport the batteries, check the latest standards or the laws of the destination country and take actions.

* Please dispose of the battery according to your local laws and regulations.

Connections






Absolute Position Storage Unit (MR-BTAS01)

G G-RJ WG B B-RJ WB A-RJ Α

This absolute position storage unit is required for configuring an absolute position detection system using the direct drive motor. This unit is not required when the servo system is used in incremental system.



Notes: 1. When mounting the absolute position storage unit outside a cabinet, mount the surface A with four screws. When mounting the unit inside a cabinet, mounting the surface B with two screws is also possible.

Replacement Fan Unit (MR-J5-FAN)

G G-RJ G-HS WG DG B B-RJ WB

The cooling fan of the servo amplifier has a fan and a fan cover as a unit. Replace the fan unit when the fan needs to be replaced. Refer to "MR-J5 User's Manual" or "MR-J5D User's Manual" for replacement of the cooling fan.

Servo amplifier model	Replacement fan unit model	Eq
MR-J5-70G/B/A MR-J5-100G/B/A	MR-J5-FAN1	Options/Peripheral Equipment
MR-J5-200G/B/A MR-J5-350G/B/A MR-J5-200G4/B4/A4 MR-J5-350G4/B4/A4	MR-J5-FAN6	
MR-J5-500G/B/A	MR-J5-FAN3	LVS/Wires
MR-J5-700G/B/A	MR-J5-FAN4	Vire
MR-J5-500G4/B4/A4 MR-J5-700G4/B4/A4	MR-J5-FAN7	S S
MR-J5W2-44G/B	MR-J5W-FAN1	-
MR-J5W2-77G/B MR-J5W2-1010G/B	MR-J5W-FAN3	Product List
MR-J5W3-222G/B MR-J5W3-444G/B	MR-J5W-FAN2	t List
MR-J5D1-500G4 MR-J5D1-700G4 MR-J5D2-200G4 MR-J5D2-350G4 MR-J5D3-200G4	MR-J5D-FAN1	Precautions
MR-J5D2-500G4 MR-J5D2-700G4	MR-J5D-FAN2	ns

Support

Direct Drive Motors

A-RJ

Α


Cabinet-Mounting Attachment (J5-CHP07-10P)

G G-RJ WG B B-RJ WB A A-RJ

G G-RJ B B-RJ A A-RJ

The cabinet-mounting attachment is used when a servo amplifier is mounted on a cabinet with a screwdriver. A screw can be tightened horizontally at the upper side of the servo amplifier.


Compatible model: MR-J5-350G_/B_/A_ or smaller/MR-J5W_/MR-CM3K



Grounding Terminal Attachment (J5-CHP08)

The grounding terminal attachment extends grounding terminals to the front side of the servo amplifier and clamps cables at the front side.

Compatible servo amplifier: MR-J5-350G_/B_/A_ or smaller



Notes: 1. For a bundle diameter other than that of the attachment, aluminum clamps in ALC series (manufactured by Takeuchi Industry Co., Ltd.) can be used. For details, please contact the relevant manufacturers directly.


2. When a battery (MR-BAT6V1SET or MR-BAT6V1SET-A) is used, the grounding terminal attachment cannot be used.

Options/Peripheral Equipment

Shield Clamp Attachment (MR-ASCHP06)

G G-HS B B-RJ A-RJ Α

The shield clamp attachment clamps the shield of a servo motor power cable on the bottom surface of the servo amplifier. Compatible servo amplifier: MR-J5-500G4_/B4_/A4_/MR-J5-700G4_/B4_/A4_



Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Mounting Attachment

Power regeneration converter unit attachment (MR-ADCACN)

Attach a mounting attachment to a power regeneration converter unit.

Power regeneration	Attachment model	Variable	dimensi	ons [mm]		Dimension with		
converter unit model	Attachment model	D	Da Db		Dc	attachment [Unit:	mm]	
MR-CV11K4 MR-CV18K4	MR-ADCACN090	280	80	255.5	258.5			
MR-CV30K4 MR-CV37K4 MR-CV45K4	MR-ADCACN150							
MR-CV55K4 MR-CV75K4	MR-ADCACN300	310	110	285.5	288.5			


Drive unit attachment (MR-ADACN)

Select a drive unit attachment that supports a power regeneration converter unit to be connected.

Power regeneration converter unit model Drive unit model	MR-CV11K4 MR-CV18K4	MR-CV30K4 MR-CV37K4 MR-CV45K4 MR-CV55K4 MR-CV75K4	Dimension with attachment [Unit: mm]
MR-J5D1-700G4 or smaller, MR-J5D2-350G4 or smaller, MR-J5D3-200G4 or smaller	Attachment not required	MR-ADACN060	
MR-J5D2-500G4 MR-J5D2-700G4	Attachment not required	MR-ADACN075	

Side Protection Cover (MR-J5DCASE01)

By attaching a side protection cover to the outside of the final drive unit, the terminal block conforms to IP20.



Notes: 1. Attaching the side protection cover does not change the dimensions of the drive unit. 7-60 DG

DG

G-RJ

G-RJ

G

G

В

B-RJ

Linear Servo Motors

ptions/Peripheral

LVS/Wires

Product List

Precautions


Support

B B-RJ

[Products on the Market] Junction Terminal Block (DG2SV3TB),

Servo Amplifier Connection Cable (DG4SV2CB_)


This terminal block is used for wiring signals.



[Products on the Market] Junction Terminal Block (PS7DW-20V14B-F)

This terminal block is used for wiring signals.


Dimensions



Notes: 1. For details, please contact the relevant manufacturers directly.

Junction Terminal Block (MR-TB26A)

This terminal block is used for wiring signals.



WG WB


A A-RJ

Notes: 1. The lengths in brackets are applicable when the junction terminal block is mounted on a 35 mm wide DIN rail.

Junction Terminal Block (MR-TB50)


This terminal block is used for wiring signals.

Dimensions



[Products on the Market] Junction Terminal Block (DG2SV1TB), Servo Amplifier Connection Cable (DG4SV1CB_)

This terminal block is used for wiring signals.




Notes: 1. For details, please contact the relevant manufacturers directly.

Radio Noise Filter (FR-BIF, FR-BIF-H)

G G-RJ G-HS WG B B-RJ WB A A-RJ

This filter suppresses noise from the power supply side of the servo amplifier, especially effective for the radio frequency bands of 10 MHz or lower. The radio noise filter is designed to be installed on the input side.



Line Noise Filter (FR-BSF01, FR-BLF)

Line Noise Filter (FR-	BSF01, FR-BLF)	G-RJ G-HS WG B B-RJ WB A A-RJ	Л
	o	upply side or the output side of the servo amplifier, and also in specially within 0.5 MHz to 5 MHz band.	Rotary Servo Motors
Dimensions	[Unit: mm]	Connections	rvo
FR-BSF01 For wire size of 3.5 mm ² (AWG 12) or smaller	FR-BLF For wire size of 5.5 mm ² (AWG 10) or larger	The line noise filters can be mounted on lines of the main circuit power supply (L1/L2/L3) and of the servo motor power (U/V/W). Pass each of the wires through the line noise filter an equal number of times in the same direction. For wires of the main circuit power supply, the effect of the filter rises as the number of passes increases, but generally four passes would be appropriate. For the servo motor power lines, passes must be four times or less. Do not pass the grounding wire through the filter. Otherwise, the effect of the filter will drop. Wind the wires by passing through the filter to satisfy the required number of passes as	Linear Servo Motors
		shown in Example 1. If the wires are too thick to wind, use two or more filters to have the required number of passes as shown in Example 2. Place the line noise filters as close to the servo amplifier as possible for their best performance. Example 1 Example 2	Direct Drive Motors
		Power supply Line noise filter	Options/Peripheral Equipment

Data Line Filter

G G-RJ G-HS WG DG B B-RJ WB Α A-RJ This filter is effective in preventing noise when attached to the pulse output cable of the pulse train output controller or the motor encoder cable.

Example) ESD-SR-250 (manufactured by TOKIN Corporation)

ZCAT3035-1330 (manufactured by TDK)

GRFC-13 (manufactured by Kitagawa Industries Co., Ltd.)

E04SRM563218 (manufactured by Seiwa Electric Mfg. Co., Ltd.)

Surge Killer

G G-RJ G-HS WG DG B B-RJ WB A A-RJ

Attach surge killers to AC relays and AC valves around the servo amplifier. Attach diodes to DC relays and DC valves. Example) Surge killer: CR-50500 (manufactured by Okaya Electric Industries Co., Ltd. (Note 1))

Diode: A diode with breakdown voltage four or more times greater than the relay drive voltage, and with current capacity two or more times greater than the relay drive current.

Notes: 1. For details, please contact the relevant manufacturers directly.

LVS/Wires

Product List

Precautions

Options/Peripheral Equipment

EMC Filter

G G-RJ G-HS WG DG B B-RJ WB A A-RJ

For servo amplifiers

The following filters are recommended as a filter compliant with the EMC directive for the power supply of the servo amplifier.

A surge protector is separately required to use the filters. Refer to "MR-J5 User's Manual" for details.

Fulfill the following requirements when connecting one or more units of servo amplifiers to one EMC filter.

• Rated voltage [V] of EMC filter ≥ Rated input voltage [V] of servo amplifier

• Rated current [A] of EMC filter ≥ Total rated input current [A] of servo amplifiers connected to EMC filter

		EMC filter							
Operating environment	Total length of servo motor power cables	Model	Rated current [A]	Rated voltage [V AC]	Operating temperature [°C]	Mass [kg]	Fig.	Manufacturer	
		FSB-10-254-HU	10		-40 to 85				
		FSB-20-254-HU	20	250		1.8	A		
		FSB-30-254-HU	30						
		FSB-40-324-HU	40			3.3	В	COSEL Co., Ltd.	
IEC/EN 61800-3		FSB-10-355	10	500		1.0	А	-	
Category C2/C3 (Note 1)		FSB-20-355	20	500		1.8	A		
	50 m or shorter	FN3288-16-44-C35-R65 (Note 3)	16	530	-40 to 50	1.0			
		FN3288-40-33-C35-R65 (Note 3)	40			1.8	J	Schaffner EMC K.K.	
		FN3288-63-53-C35-R65	63			2.7			
		HF3010C-SZB	10			0.9			
		HF3020C-SZB	20	500	00 45 50	1.0	E		
		HF3030C-SZB	30	500	-20 to 50	1.3			
IEC/EN 61800-3		HF3040C-SZB	40	1		2.0	F	Coopin Flootrin Co. 1 td	
Category C3 (Note 1)	100 m or shorter	HF3030C-SZL	30			1.3	G	Soshin Electric Co., Ltd.	
	200 m or shorter	HF3060C-SZL	60	500	00 to 50	2.1	G		
	050 m or abortor	HF3100C-SZL	100	500	-20 to 50	5.8	Н]	
	250 m or shorter	HF3150C-SZL	150			9.0	I	1	

For power regeneration converter units

The following filters are recommended as a filter compliant with the EMC directive for the power supply of the power regeneration converter unit.

A surge protector is separately required to use the filters. Refer to "MR-CV Power Regeneration Converter Unit User's Manual" for details.

Fulfill the following requirements when connecting one or more power regeneration converter units to one EMC filter.

• Rated voltage [V] of EMC filter ≥ Rated input voltage [V] of power regeneration converter unit

• Rated current [A] of EMC filter ≥ Total rated input current [A] of power regeneration converter units connected to EMC filter


	EMC filter							
Operating environment	Model	Rated current [A]	Rated voltage [V AC]	Operating temperature [°C]	Mass [kg]	Fig.	Manufacturer (Note 2)	
	FSB-20-355	20		-40 to 85	1.8	А		
	FSB-30-355	30			1.0	A		
	FSB-40-355	40	500		3.3	В		
	FSB-80-355	80	500		6.3	С	-COSEL Co., Ltd.	
IEC/EN 61800-3 Category C2, C3 (Note 1)	FSB-100-355	100	1					
Category Cz, Co Category	FSB-150-355	150			8.8	D		
	FN3288-16-44-C35-R65	16		-40 to 50	1.0		Schaffner EMC K.K.	
	FN3288-40-33-C35-R65	40	530		1.8	J		
	FN3288-63-53-C35-R65	63	7		2.7]		
	HF3030C-SZL	30		00 to 50	1.3	G		
IEC/EN 61800-3 Category C3 (Note 1)	HF3060C-SZL	60	500		2.1	G	Sophin Electric Co. 1 td	
	HF3100C-SZL	100	300	-20 to 50	5.8	Н	Soshin Electric Co., Ltc	
	HF3150C-SZL	150			9.0	I		

Notes: 1. Category C2: Intended to be installed in either the first environment (residential environment) by a professional or in the second environment (commercial, light industrial, and industrial environments).


Category C3: Intended to be installed in the second environment (commercial, light industrial, and industrial environments).

2. For details, please contact the relevant manufacturers directly.


3. FN3288-16-44-C17-R65 and FN3288-40-33-C17-R65, which feature low leakage current from the EMC filter, can also be used for 200 V class servo amplifiers.



Options/Peripheral Equipment



Options/Peripheral Equipment



Surge Protector

G G-RJ G-HS WG DG B B-RJ WB A

Attach surge protectors of RSPD series (manufactured by Okaya Electric Industries Co., Ltd. (Note 1)) or LT-CS-WS series (manufactured by Soshin Electric Co., Ltd. (Note 1)) to the servo amplifiers.

Notes: 1. For details, please contact the relevant manufacturers directly.

Direct Drive Motors

Options/Peripheral Equipment

A-RJ


Power Factor Improving DC Reactor (FR-HEL, FR-HEL-H)

This boosts the power factor of servo amplifier and reduces the power supply capacity. Use either the DC reactor or the AC reactor.

As compared to the AC reactor (FR-HAL, FR-HAL-H), the DC reactor (FR-HEL, FR-HEL-H) is more recommended since the DC reactor is more effective in power factor improvement, smaller and lighter, and its wiring is easier. (The DC reactor uses two wires, while the AC reactor uses six wires.)

Connections


Servo amplifier model	Power factor improving DC reactor model	Fig.
MR-J5-10G/B/A	FB-HEL-0.4K	
MR-J5-20G/B/A		A
MR-J5-40G/B/A	FR-HEL-0.75K	
MR-J5-60G/B/A	FR-HEL-1.5K	
MR-J5-70G/B/A	FR-HEL-1.5K	
MR-J5-100G/B/A	FR-HEL-2.2K]
MR-J5-200G/B/A	FR-HEL-3.7K	В
MR-J5-350G/B/A	FR-HEL-7.5K	С
MR-J5-500G/B/A	FR-HEL-11K	D
MR-J5-700G/B/A	FR-HEL-15K	טן
MR-J5-60G4/B4/A4	FR-HEL-H1.5K	E
MR-J5-100G4/B4/A4	FR-HEL-H2.2K	
MR-J5-200G4/B4/A4	FR-HEL-H3.7K	F
MR-J5-350G4/B4/A4	FR-HEL-H7.5K	
MR-J5-500G4/B4/A4	FR-HEL-H11K	G
MR-J5-700G4/B4/A4	FR-HEL-H15K	Н



G G-RJ G-HS B B-RJ A A-RJ

Notes: 1. Disconnect a short-circuit bar between P3 and P4 when using the power factor improving DC reactor.

Dimensions




Medal	Variable dimensions [mm]						Mass	Wire size	
Model	D (Note 1)	D1	W	W1	н	H1	H2	[kg]	[mm ²] (Note 2)
FR-HEL-0.4K	61	28	70	60	71	61	48	0.4	
FR-HEL-0.75K	61	28	85	74	81	71	59	0.5	
FR-HEL-1.5K	70	33	85	74	81	71	59	0.8	2 (AWG 14)
FR-HEL-2.2K	70	33	85	74	81	71	59	0.9	

	Terminal screw M4 Terminal screw M4 × 8 D or shorter
В	
	Mounting screw M4

Model	Variable	dimer	sions	[mm]	Mass	Wire size
	D (Note 1)	D1	D2	D3	[kg]	[mm ²] (Note 2)
FR-HEL-3.7K	82	39	66	56	1.4	2 (AWG 14)

Notes: 1. This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines. 2. The wire size is applicable when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used.




Notes: 1. This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines.


2. The wire size is applicable when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used.

Power Factor Improving DC Reactor (FR-HEL, FR-HEL-H)





This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines.
 The wire size is applicable when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used.



Power Factor Improving DC Reactor (FR-HEL, FR-HEL-H)

1. This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines. 2. The wire size is applicable when 600 V grade heat-resistant polyvinyl chloride insulated wire (HIV wires) is used. Notes:

Product List

Precautions

Power Factor Improving AC Reactor (FR-HAL, FR-HAL-H)

G G-RJ G-HS WG B B-RJ WB A A-RJ

Total output of direct

Power factor

improving AC

Fig.

This boosts the power factor of servo amplifier and reduces the power supply capacity.

MR-J5-G/B/A.	MB-CM3K

MR-J5W2-G/B (Note 1)

Total output of rotary

Servo amplifier/ simple converter	Power factor improving AC	Fig	
model	reactor model (Note 2)	Fig.	
MR-J5-10G/B/A	FR-HAL-0.4K		
MR-J5-20G/B/A			
MR-J5-40G/B/A	FR-HAL-0.75K	A	
MR-J5-60G/B/A	FR-HAL-1.5K		
MR-J5-70G/B/A			
MR-J5-100G/B/A			
(3-phase power	FR-HAL-2.2K		
input)			
MR-J5-100G/B/A			
(1-phase power		в	
input)	FB-HAI -3 7K		
MR-J5-200G/B/A			
(3-phase power			
input)			
MR-J5-200G/B/A			
(1-phase power	FR-HAL-5.5K		
input)			
MR-J5-350G/B/A	FR-HAL-7.5K		
MR-CM3K	FR-RAL-7.5K		
MR-J5-500G/B/A	FR-HAL-11K	С	
MR-J5-700G/B/A	FR-HAL-15K		
MR-J5-60G4/B4/A4	FR-HAL-H1.5K		
MR-J5-100G4/B4/A4	FR-HAL-H2.2K	D	
MR-J5-200G4/B4/A4	FR-HAL-H3.7K		
MR-J5-350G4/B4/A4	FR-HAL-H7.5K	E	
MR-J5-500G4/B4/A4	FR-HAL-H11K	F	
MR-J5-700G4/B4/A4	FR-HAL-H15K		


servo motors	motors	drive motors	reactor model (Note 2)			
450 W or less	150 N or less	100 W or less	FR-HAL-0.75K	A		
Over 450 W to 600 W	Over 150 N to 240 N	Over 100 W to 377 W	FR-HAL-1.5K	A		
Over 600 W to 1 kW	Over 240 N to 300 N	Over 377 W to 545 W	FR-HAL-2.2K	в		
Over 1 kW to 2 kW	Over 300 N to 720 N	Over 545 W to 838 W	FR-HAL-3.7K	P		
MR-J5W3-G/B (Note 1)						
Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct drive motors	Power factor improving AC reactor model (Note 2)	Fig.		
	thrust of linear servo	· ·	improving AC			
servo motors	thrust of linear servo motors	drive motors	improving AC reactor model (Note 2)	Fig.		
servo motors 450 W or less	thrust of linear servo motors 150 N or less	drive motors - 378 W or less	improving AC reactor model (Note 2) FR-HAL-0.75K			


Total continuous

thrust of linear servo

Notes: 1. Refer to "MR-J5 User's Manual" for selecting a power factor improving AC reactor when combining multiple servo motors among the rotary servo motor, the linear servo motor or the direct drive motor.

2. When using the power factor improving AC reactor, install one reactor for each servo amplifier.






Power Factor Improving AC Reactor (FR-HAL, FR-HAL-H)


Notes: 1. This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines.

Power Factor Improving AC Reactor (FR-HAL, FR-HAL-H)



Notes: 1. This indicates the maximum dimension. The dimension varies depending on the bending degree of the input/output lines.

Options/Peripheral Equipment



Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Drive System Sizing Software MELSOFT Motorizer

MELSOFT

Specifications

Item	Description
Types of motor/drive	Servo, Inverter, Sensorless servo
Types of load mechanism	Ball screw, Rack and pinion, Roll feed, Rotary table, Cart, Elevator/Hoist, Conveyor, Fan, Pump, Crank, Generic (Rotary), Generic (Linear), Linear servo
Types of transmission mechanism	Coupling, External gear reducer, V belt and pulley, Toothed belt/roller chain
Operation pattern	Constant speed/Pause, Acceleration/Deceleration, Trapezoid, Triangle, Speed CSV File, MELSOFT GX LogViewer file
Types of input support of moment of inertia calculation function	Solid cylinder, Hollow cylinder, Disk, Rectangular solid, Truncated cone, Sphere, Generic
Sizing results	Result, Motor type, Power supply voltage, Motor, Motor capacity, Drive, Drive capacity, Effective torque, Torque effective load rate, Peak torque, Peak load rate, Effective torque at stop, Effective load rate at stop, Motor output, Motor output rate, Maximum speed, Maximum speed rate, Maximum load inertia moment, Inertia moment ratio, Regenerative power, Regenerative load ratio, Regenerative option, Maximally increased torque, Rated speed, Brake, Oil seal, Structure specification, Graph of Motor side speed/Motor side torque/Motor output
Printing of output of results	Prints load mechanism, transmission mechanism, operation pattern, and sizing results.
Data saving	Load mechanism, transmission mechanism, operation pattern, motor selection, drive selection, and sizing results are saved with a file name.

Operating environment (Note 1, 2)

Item		Description
OS		Microsoft® Windows® 11 Microsoft® Windows® 10 (64-bit/32-bit)
.NET Framewor	rk	.NET Framework 4.6 or later
	Windows [®] 11	2 or more cores on a compatible 64-bit processor or System on a Chip (SoC)
CPU	Windows® 10	Desktop PC: Intel [®] Celeron [®] processor 2.4 GHz or more recommended Laptop PC: Intel [®] Pentium [®] processor 1.9 GHz or more recommended
Maman	Windows [®] 11	4 GB or more recommended
Memory Windows [®] 10		For 64-bit OS: 2 GB or more recommended, For 32-bit OS:1 GB or more recommended
Required hard disk space		For installation: 1 GB or more free hard disk space For operation: 512 MB or more free virtual memory space
Monitor		Resolution 1024 × 768 or more (XGA) Compatible with above personal computers

Notes: 1. This software may not run correctly on some personal computers.

2. Surrogate pair characters and environment dependent characters are not available.

MELSOFT

Common Specifications

Servo Engineering Software MELSOFT MR Configurator2 (SW1DNC-MRC2-E) (Note 1)

MR Configurator2 can be obtained by either of the following:

• Purchase MR Configurator2 alone.

• Purchase GX Works3 or MT Works2: MR Configurator2 is included in GX Works3 and MT Works2 with software version 1.34L or later.

Specification (Note 2)

Item	Description	Servo
Project	New/Open/Save/Save As/Delete Project, Read Other Format, Write Other Format, System Setting, Print	Servo System Controllers
Parameter	Parameter Setting, Network Parameter, Axis Name Setting, Parameter Converter	Syst
Safety	Safety parameter setting, Change password, Initialize password	rs
Positioning-data	Point Table, Program, Indirect Addressing, Cam Data	
Monitor	Display All, I/O Monitor, Graph, ABS Data Display, Object Monitor	Ser
Diagnosis	Alarm Display, Alarm Onset Data, Drive recorder, No Motor Rotation, System Configuration, Life Diagnosis, Machine Diagnosis, Linear Diagnosis, Fully Closed Loop Diagnosis, Gear Failure Diagnosis, Encoder Communication Diagnosis	vo Amplifi
Test Operation	JOG Operation, Positioning Operation, Motor-Less Operation, DO Forced Output, Program Operation, Single-Step Feed, Test Operation Information	iers
Adjustment	One-Touch Tuning, Tuning, Multi-Axis Tuning, Machine Analyzer, Advanced Gain Search	ਸ਼
Others	Servo Assistant, Update Parameter Setting Range, Machine Unit Conversion Setting, Switch Display Language, Axis Label Name Settings, Add-ons, Help	Rotary Ser Motors
	s supported by MR Configurator2 with the following or later software version. : 1.100E • MR-J5DG: 1.125F • MR-J5-G4-HS: 1.150G • MR-J5-B: 1.130L	Servo

2. Supported items vary depending on the servo amplifiers. Refer to "MR Configurator2 SW1DN_-MRC2-E_ Installation Guide" for details.

Operating environment (Note 1, 3, 4)

0	Near Sei Motors	
0	Linear Servo Motors	
	Ŭ	
IVIC	Direct Drive Motors	
U	S	
	e	
	Opt	
Ę	Equ	
	Options/Periphera Equipment	
	riph	
	ieral	
_		
_	LVS/Wires	
	\leq	
	es.	
_		
	P	
_	Product List	
	Jct	
	Lis	
_	_	

Precautions

Options/Peripheral Equipment

Unit Conversion Table

Quantity	SI (metric) unit	U.S. customary unit
Mass	1 [kg]	2.2046 [lb]
Length	1 [mm]	0.03937 [in]
Torque	1 [N•m]	141.6 [oz•in]
Moment of inertia	1 [(× 10 ⁻⁴ kg•m ²)]	5.4675 [oz•in²]
Load (thrust load/axial load)	1 [N]	0.2248 [lbf]
Temperature	n [°C]	n × 9/5 + 32 [°F]

B Low-Voltage Switchgear/ Wires

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors	8-2
Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274	8-5
Type E Combination Motor Controller	8-9
Selection Example in HIV Wires for Servo Motors	.8-10

^{*} Note that low-voltage switchgears/wires necessary for servo amplifiers/drive units with special specifications are the same as those for standard servo amplifiers/ drive units. Refer to the serve amplifiers or drive units with the same rated output. * Refer to p. 7-78 in this catalog for conversion of units.

Low-Voltage Switchgear/Wires

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors

G G-RJ G-HS B B-RJ A A-RJ

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used. The wire size for U/V/W/E varies depending on the servo motor. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for details on wires for each servo motor.

Wires and molded-case circuit breakers (MR-J5-G/MR-J5-B/MR-J5-A)

	Molded-case circuit breaker	Wire size [mm ²] (Note 4)	1		
Servo amplifier model	(Note 4, 5, 6)	L1/L2/L3/	L11/L21	P+/C (Note 1)	U/V/W/E
MR-J5-10G/B/A	30 A frame 5 A (30 A frame 5 A)				
MR-J5-20G/B/A	30 A frame 5 A (30 A frame 5 A)				
MR-J5-40G/B/A	30 A frame 10 A (30 A frame 5 A)				
MR-J5-60G/B/A	30 A frame 15 A (30 A frame 10 A)			2 (AWG 14)	0.75 to 2 (AWG 18 to 14) (Note 3)
MR-J5-70G/B/A	30 A frame 15 A (30 A frame 10 A)	2 (AWG 14)	1.25 to 2		
MR-J5-100G/B/A (3-phase power input)	30 A frame 15 A (30 A frame 10 A)				
MR-J5-100G/B/A (1-phase power input)	30 A frame 15 A (30 A frame 15 A)		(AWG 16 to 14)		
MR-J5-200G/B/A (3-phase power input)	30 A frame 20 A (30 A frame 20 A)				
MR-J5-200G/B/A (1-phase power input)	30 A frame 20 A (30 A frame 20 A)	2 E (A)M(C 12)			0.75 to 5.5 (AWG 18 to 10) ^(Note 3)
MR-J5-350G/B/A	30 A frame 30 A (30 A frame 30 A)	-3.5 (AWG 12) 5.5 (AWG 10)			
MR-J5-500G/B/A	50 A frame 50 A (50 A frame 50 A)				0.75 to 8
MR-J5-700G/B/A	100 A frame 75 A (60 A frame 60 A)	8 (AWG 8)			(AWG 18 to 8) (Note 3)

Wires and molded-case circuit breakers (MR-J5-G4/MR-J5-B4/MR-J5-A4)

Servo amplifier model	Molded-case circuit breaker	Wire size [mm ²] (Note 4)			
Servo ampliner model	(Note 4, 5, 6)	L1/L2/L3/	L11/L21	P+/C (Note 1)	U/V/W/E
MR-J5-60G4/B4/A4	30 A frame 5 A (30 A frame 5 A)	-			
MR-J5-100G4/B4/A4	30 A frame 10 A (30 A frame 5 A)				0.75 to 2
MR-J5-200G4/B4/A4	30 A frame 15 A (30 A frame 10 A)		1.25 to 2		(AWG 18 to 14) (Note 3)
MR-J5-350G4/B4/A4	30 A frame 20 A (30 A frame 15 A)		(AWG 16 to 14)	2 (AWG 14)	
MR-J5-500G4/B4/A4	30 A frame 20 A (30 A frame 20 A)				0.5 to 10
MR-J5-700G4/B4/A4	30 A frame 30 A (30 A frame 30 A)				(AWG 20 to 8)

Magnetic contactors (MR-J5-G/MR-J5-B/MR-J5-A)

Magnetic contactors (MR-J5-G4/MR-J5-B4/MR-J5-A4)

0	(,	Ũ	•	,	
	Magnetic contactor	Note 2, 5)		Magnetic contactor	(Note 2, 5)	
Servo amplifier model	On/off of main circui	t power supply	Servo amplifier model	On/off of main circu	it power supply	
	AC power supply	DC power supply		AC power supply	DC power supply	
MR-J5-10G/B/A			MR-J5-60G4/B4/A4			
MR-J5-20G/B/A			MR-J5-100G4/B4/A4	S-T10	SD-T12	
MR-J5-40G/B/A	S-T10	SD-T12	MR-J5-200G4/B4/A4			
MR-J5-60G/B/A		50-112	MR-J5-350G4/B4/A4			
MR-J5-70G/B/A]		MF	MR-J5-500G4/B4/A4	S-T21	SD-T21
MR-J5-100G/B/A	1		MR-J5-700G4/B4/A4			
MR-J5-200G/B/A	S-T10, S-T21	-SD-T21				
MR-J5-350G/B/A	S-T21					
MR-J5-500G/B/A	S-T25, S-T35	SD-T35				
MR-J5-700G/B/A	S-T35, S-T50	SD-T50				

Notes: 1. Keep the wire length to the regenerative option within 5 m.

2. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of contacts.

3. The wire size shows applicable size for the servo amplifier connector.

4. When complying with IEC/EN/UL/CSA standard, refer to "Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274" in this catalog.

8-2 5. These selection examples are for when one molded-case circuit breaker and one magnetic contactor are installed for one unit of servo amplifier. When connecting multiple units of servo amplifiers, refer to "MR-J5 User's Manual".

6. When using a power improving reactor, use a molded-case circuit breaker listed in the brackets.

Low-Voltage Switchgear/Wires

WG WB

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used. The wire size for U/V/W/E varies depending on the servo motor. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for details on wires for each servo motor.

Wires (MR-J5W2-G/MR-J5W3-G/MR-J5W2-B/MR-J5W3-B)

Servo amplifier model	Wire size [mm ²] (Note 3)				
Servo ampliner moder	L1/L2/L3/	L11/L21	P+/C (Note 5)	U/V/W/E	ontrollers
MR-J5W2-22G/B					oller
MR-J5W2-44G/B					S
MR-J5W2-77G/B	2 (AWG 14)	2 (AWG 14)	2 (AWG 14)	0.75 to 2	
MR-J5W2-1010G/B	2 (AVVG 14)	2 (AVVG 14)	2 (AVIG 14)	(AWG 18 to 14) (Note 2)	Sen
MR-J5W3-222G/B					
MR-J5W3-444G/B					Ampii

Molded-case circuit breakers (MR-J5W2-G/MR-J5W2-B) (Note 4)

Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct drive motors	Molded-case circuit breaker (Note 3, 6)
300 W or less	-	-	30 A frame 5 A
Over 300 W to 600 W	150 N or less	100 W or less	30 A frame 10 A
Over 600 W to 1 kW	Over 150 N to 300 N	Over 100 W to 252 W	30 A frame 15 A
Over 1 kW to 2 kW	Over 300 N to 720 N	Over 252 W to 838 W	30 A frame 20 A

Magnetic contactor (MR-J5W2-G/MR-J5W2-B) (Note 4)

Total autout of vatars a area	Total continuous through of		Magnetic contactor (Note 1, 6)	
Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct drive motors	s On/off of main circuit power supply	
motors			AC power supply	DC power supply
300 W or less	-	-		
Over 300 W to 600 W	150 N or less	100 W or less	S-T10	SD-T12
Over 600 W to 1 kW	Over 150 N to 300 N	Over 100 W to 252 W		
Over 1 kW to 2 kW	Over 300 N to 720 N	Over 252 W to 838 W	S-T21	SD-T21

Molded-case circuit breakers (MR-J5W3-G/MR-J5W3-B) (Note 4)

	Total continuous thrust of linear servo motors	Total output of direct drive motors	Molded-case circuit breaker (Note 3, 6)	Equipr
450 W or less	150 N or less	-	30 A frame 10 A	nent
Over 450 W to 800 W	Over 150 N to 300 N	252 W or less	30 A frame 15 A	4
Over 800 W to 1.5 kW	Over 300 N to 450 N	Over 252 W to 378 W	30 A frame 20 A	_

Magnetic contactor (MR-J5W3-G/MR-J5W3-B) (Note 4)

Magnetic contactor (MR-J5W3-G/MR-J5W3-B) (Note 4)					LVS/
	Tatal continuous thrust of		Magnetic contactor (Note 1, 6)		Wir
Total output of rotary servo motors	Total continuous thrust of linear servo motors	Total output of direct drive motors	On/off of main circuit power supply		es
motors	Inteal servo motors	1015		DC power supply	
450 W or less	150 N or less	-	S-T10	SD-T12	
Over 450 W to 800 W	Over 150 N to 300 N	252 W or less	5-110	50-112	Pro
Over 800 W to 1.5 kW	Over 300 N to 450 N	Over 252 W to 378 W	S-T21	SD-T21	oduc
	· · · · · · · · · · · · · · · · ·				¥

Notes: 1. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of contacts.

2. The wire size shows applicable size for the servo amplifier connector.

3. When complying with IEC/EN/UL/CSA standard, refer to "Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274" in this catalog.

4. When multiple different types of servo motors (rotary servo motor, linear servo motor, or direct drive motor) are connected to the multi-axis servo amplifier, refer to "MR-J5 User's Manual" for selecting a molded-case circuit breaker and a magnetic contactor.

5. Keep the wire length to the regenerative option within 5 m.

6. These selection examples are for when one molded-case circuit breaker and one magnetic contactor are installed for one unit of servo amplifier. When connecting multiple units of servo amplifiers, refer to "MR-J5 User's Manual".

Precautions

List

Common Specifications

8-3

Wires, Molded-Case Circuit Breakers, and Magnetic Contactors

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) are used. The wire size for U/V/W/E varies depending on the servo motor. Refer to "Selection Example in HIV Wires for Servo Motors" in this catalog for details on wires for each servo motor.

Wires (MR-J5D1-G4/MR-J5D2-G4/MR-J5D3-G4)

Drive unit model (Note 1)	Wire size [mm ²] (Note 2, 3)		
Drive unit model (100 1)	L11/L21/@	U/V/W/E	
MR-J5D1-100G4		4.05.4.0	
MR-J5D1-200G4		1.25 to 2 (AWG 16 to 14)	
MR-J5D1-350G4			
MR-J5D1-500G4		3.5 (AWG 12)	
MR-J5D1-700G4		5.5 (AWG 10)	
MR-J5D2-100G4	1.25 to 5.5		
MR-J5D2-200G4	(AWG 16 to 10) (Note 8)	1.25 to 2 (AWG 16 to 14)	
MR-J5D2-350G4			
MR-J5D2-500G4		3.5 (AWG 12)	
MR-J5D2-700G4		5.5 (AWG 10)	
MR-J5D3-100G4		1.25 to 2	
MR-J5D3-200G4		(AWG 16 to 14)	

Wires (MR-CM3K)

Simple converter unit	Wire size [mm ²] (Note 2, 3)		
model	L1/L2/L3/	P4/N-	
MR-CM3K	3.5 (AWG 12)	3.5 (AWG 12)	

Molded-case circuit breaker and magnetic contactor (MR-CM3K)

•		Note 3, 5, 6)	Magnetic contactor (Note 4, 6)	
			On/off of main circuit power supply	
			AC power supply	DC power supply
MR-CM3K	I less than 2 kW	30 to 125 A frame 15 to 20 A	S-T21	SD-T21
		(30 to 125 A frame 15 to 20 A)		
	2 kW or over	30 to 125 A frame 20 to 30 A	S-T21	SD-T21
		(30 to 125 A frame 20 to 30 A)		

Wires, molded-case circuit breaker, and magnetic contactor (MR-CV_4)

Power regeneration converter unit	nverter unit Molded-case circuit breaker (Note 3, 6) Magnetic contactor (Note 4, 6)	Magnetic contenter (Note 4 6)	Wire size [mm ²] (Note 2, 3)	
model (Note 1)		L1/L2/L3/	L11/L21	
MR-CV11K4	30 A frame 30 A	S-T21	5.5 (AWG 10)	
MR-CV18K4	50 A frame 50 A	S-T35	8 (AWG 8)	
MR-CV30K4	100 A frame 80 A	S-T65	14 (AWG 6)	
MR-CV37K4	100 A frame 100 A	S-T80	1.25 to 2	(AWG 16 to 14)
MR-CV45K4	125 A frame 125 A	S-T100	22 (AWG 4) (AWG 16 to 14)	
MR-CV55K4	225 A frame 150 A	S-N125	38 (AWG 2) 60 (AWG 2/0)	
MR-CV75K4	225 A frame 200 A	S-N150		

Notes: 1. When connecting the wires to the terminal blocks, use the screws attached to the terminal blocks.

2. Wires are selected based on the highest rated current among the servo motors to be combined.

3. When complying with IEC/EN/UL/CSA standard, refer to "Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274" in this catalog.

4. Use a magnetic contactor with an operation delay time of 80 ms or less. The operation delay time is the time interval from current being applied to the coil until closure of contacts.

5. When using a power improving reactor, use a molded-case circuit breaker listed in the brackets.

6. Install one molded-case circuit breaker and one magnetic contactor for one converter unit.

7. The sum of rated capacities [kW] of connected servo amplifiers ≤ 3 kW (MR-CM3K rated output)

When using a multi-axis servo amplifier, calculate the sum of the rated capacities of all axes as the rated capacity of the servo amplifier.

8. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²).

DG

G G-RJ WG B B-RJ WB A A-RJ

Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274

Selection Example According to I	EC/EN/UL 61800-5-1 and CSA C22	.2 No. 274	S
The following are examples of molded-case circuit breakers and semiconductor fuses selected on the basis of the rated inputs/outputs of the servo amplifiers.			Common Specifications
Molded-case circuit breakers/semicondu	Ictor fuses G G-RJ WG	B B-RJ WB A A-RJ	ns -
(MR-J5-G/MR-J5W2-G/MR-J5W3-G/MR	-J5-B/MR-J5W2-B/MR-J5W3-B/MR-J5	-A)	
	Molded-case circuit breaker (240 V AC)	Semiconductor fuse (700 V)	Sen
Servo amplifier model	SCCR 50 kA (Mitsubishi Electric)	SCCR 100 kA (Bussmann)	Servo System Controllers
MR-J5-10G/B/A			yste
MR-J5-20G/B/A		170M1408 (10 A)	
MR-J5-40G/B/A			
MR-J5-60G/B/A (3-phase power input)			Serv
MR-J5-60G/B/A (1-phase power input)	NF125-SVU-15A (125 A frame 15 A)	170M1409 (16 A)	
MR-J5-70G/B/A (3-phase power input)	NF125-3V0-15A (125 A frame 15 A)	170M1408 (10 A)	
MR-J5-70G/B/A (1-phase power input)		70M1409 (16 A)	Servo Amplifiers
MR-J5-100G/B/A (3-phase power input)			
MR-J5-100G/B/A (1-phase power input)		170M1412 (32 A)	
MR-J5-200G/B/A (3-phase power input)			
MR-J5-200G/B/A (1-phase power input)	NF125-SVU-20A (125 A frame 20 A)	170M1413 (40 A)	
MR-J5-350G/B/A	, , , , , , , , , , , , , , , , , , ,		Rotary Servo Motors
MR-J5-500G/B/A	NF125-SVU-30A (125 A frame 30 A) (Note 1)	170M1415 (63 A)	Ŭ
MR-J5-700G/B/A	NF125-SVU-40A (125 A frame 40 A) (Note 1)	170M1416 (80 A)	_
MR-J5W2-22G/B (3-phase power input)		170M1408 (10 A)	
MR-J5W2-22G/B (1-phase power input)		170M1409 (16 A)	
MR-J5W2-44G/B (3-phase power input)	NF125-SVU-15A (125 A frame 15 A)		
MR-J5W2-44G/B (1-phase power input)		170M1412 (32 A)	Linear Servo Motors
MR-J5W2-77G/B (3-phase power input)			-
MR-J5W2-77G/B (1-phase power input)	NF125-SVU-20A (125 A frame 20 A)	170M1413 (40 A)	Direct Drive Motors
MR-J5W2-1010G/B		170M1412 (32 A)	
MR-J5W3-222G/B (3-phase power input)	NF125-SVU-15A (125 A frame 15 A)	170M1409 (16 A)	
MR-J5W3-222G/B (1-phase power input)		170M1412 (32 A)	
MR-J5W3-444G/B (3-phase power input)			-

Molded-case circuit breakers/semiconductor fuses

MR-J5W3-444G/B (1-phase power input)

Options/Peripheral Equipment (MR-J5-G4/MR-J5-B4/MR-J5-A4) Molded-case circuit breaker (480 V AC) Semiconductor fuse (700 V) Servo amplifier model SCCR 30 kA (Mitsubishi Electric) SCCR 100 kA (Bussmann) LVS/Wires MR-J5-60G4/B4/A4 170M1408 (10 A) MR-J5-100G4/B4/A4 NF125-SVU-15A (125 A frame 15 A) (Note 1) MR-J5-200G4/B4/A4 170M1409 (16 A) MR-J5-350G4/B4/A4 170M1412 (32 A) NF125-SVU-20A (125 A frame 20 A) (Note 1) MR-J5-500G4/B4/A4 170M1413 (40 A) MR-J5-700G4/B4/A4 NF125-SVU-30A (125 A frame 30 A) (Note 1) 170M1414 (50 A) Product

NF125-SVU-20A (125 A frame 20 A)

G

170M1413 (40 A)

G-RJ G-HS B B-RJ

Notes: 1. For the use under the conditions of UL Listed, select a semiconductor fuse.

8-5

List

Precautions

Support

A-RJ

Α

Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274

The following are examples of molded-case circuit breakers and semiconductor fuses selected on the basis of the rated inputs/outputs of the converter units.

Molded-case circuit breakers/semiconductor fuses (MR-CM3K)

		G G-RJ WG B I	B-RJ WB A A-RJ
Simple converter unit model	Total capacity of	Molded-case circuit breaker (240 V AC)	Semiconductor fuse (700 V)
	servo amplifiers	SCCR 50 kA (Mitsubishi Electric)	SCCR 100 kA (Bussmann)
MR-CM3K	Less than 2 kW	NF125-SVU-15A (125 A frame 15 A)	170M1409 (16 A)
	2 kW or over	NF125-SVU-20A (125 A frame 20 A)	170M1413 (40 A)

Semiconductor fuses (MR-CV_4)

Power regeneration converter unit model (Note 1)	Semiconductor fuse (700 V) SCCR 100 kA (Bussmann)	
MR-CV11K4	170M1413 (40 A)	
MR-CV18K4	170M1416 (80 A)	
MR-CV30K4	— 170M1419 (160 A)	
MR-CV37K4		
MR-CV45K4	170M1420 (200 A)	
MR-CV55K4	170M1421 (250 A)	
MR-CV75K4	170M1422 (315 A)	

Notes: 1. When connecting the wires to the terminal blocks, use the screws attached to the terminal blocks.

DG

Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274

The following are examples of recommended wire sizes selected on the basis of the rated inputs/outputs of the servo amplifiers or the drive units.

Common Specifications Recommended wires G G-RJ WG B B-RJ WB Α (MR-J5-G/MR-J5W2-G/MR-J5W3-G/MR-J5-B/MR-J5W2-B/MR-J5W3-B/MR-J5-A) Servo System Controllers 75 °C stranded wire [AWG] Servo amplifier model L1/L2/L3/ L11/L21 P+/C U/V/W/E MR-J5-10G/B/A MR-J5-20G/B/A MR-J5-40G/B/A Servo Amplifiers MR-J5-60G/B/A 14 14 MR-J5-70G/B/A MR-J5-100G/B/A MR-J5-200G/B/A (3-phase power input) MR-J5-200G/B/A (1-phase power input) 12 Rotary Servo Motors MR-J5-350G/B/A 14 14 12 MR-J5-500G/B/A 10 8 MR-J5-700G/B/A 8 MR-J5W2-22G/B MR-J5W2-44G/B MR-J5W2-77G/B Linear Servo Motors 14 14 MR-J5W2-1010G/B MR-J5W3-222G/B MR-J5W3-444G/B

Recommended wires (MF	R-J5-G4/MR-J5-B4/MR-	J5-A4)	G G-RJ G-HS	B B-RJ A	A-RJ
Carvo amplifiar model	75 °C stranded wire	e [AWG]			Dire
Servo amplifier model	L1/L2/L3/	L11/L21	P+/C	U/V/W/E	Motors
MR-J5-60G4/B4/A4					Sec.
MR-J5-100G4/B4/A4				14	Ô
MR-J5-200G4/B4/A4	14	14	14	14	0
MR-J5-350G4/B4/A4		14	14		Options Equ
MR-J5-500G4/B4/A4				12	quip
MR-J5-700G4/B4/A4	12			10	Equipmen

Recommended wires (MR-J5D1-G4/MR-J5D2-G4/MR-J5D3-G4)

75 °C stranded wire [AWG]		
L11/L21/	U/V/W/E	
	14	
	12	
	10	
14		
14	14	
	12	
	10	
	14	
	14	
	· · ·	L11/L21/ U/V/W/E 14 14 14 12 14 14 12 12 12 12

Notes: 1. When connecting the wires to the terminal blocks, use the screws attached to the terminal blocks.

8-7

Support

DG

Selection Example According to IEC/EN/UL 61800-5-1 and CSA C22.2 No. 274

The following are examples of recommended wire sizes selected on the basis of the rated inputs/outputs of the converter units.

Recommended wires (MR-CM	3K) G G-R	JWGBB-RJWBAA-RJ
Simple converter unit model	75 °C stranded wire [AWG]	
	L1/L2/L3/ 🕀	P4/N-
MR-CM3K	14/12 (Note 2)	14/12 (Note 2)

DG

Recommended wires (MR-CV_4)

Power regeneration	75 °C stranded wire [AWG]	75 °C stranded wire [AWG]				
converter unit model (Note 1)	L1/L2/L3/	L11/L21				
MR-CV11K4	10					
MR-CV18K4	8					
MR-CV30K4	6					
MR-CV37K4	4	14				
MR-CV45K4	4					
MR-CV55K4	2					
MR-CV75K4	1/0					

Notes: 1. When connecting the wires to the terminal blocks, use the screws attached to the terminal blocks.

2. The wire size varies depending on a total current of connected servo amplifiers. When the total current is larger than 12 A, use AWG 12.

Type E Combination Motor Controller

The Type E Combination Terminal Cover Kit "UT-0		s comprised of the		ter, Short-circuit Dispi	ay onit offor,	and I ower Side	Common Specifications
	Dated input		Manual Motor Starte	∋r ^(Note 4)			n ons
Servo amplifier model	Rated input voltage AC [V]	Input phase (Note 2)	Model (Mitsubishi Electric)	Rated voltage AC [V]	Rated current [A] (Heater design)	SCCR [kA] (Note 1)	
MR-J5-10G/B/A					1.6		Cont
MR-J5-20G/B/A					2.5]	
MR-J5-40G/B/A					4]	System
MR-J5-60G/B/A					6.3	50	s
MR-J5-70G/B/A					0.5		
MR-J5-100G/B/A					8		Servo
MR-J5-200G/B/A					18		
MR-J5-350G/B/A	200 to 240	3-phase	MMP-T32	240	25	-25	Amplifiers
MR-J5-500G/B/A ^(Note 3)					32	20	plifi
MR-J5W2-22G/B					6.3	-	ers
MR-J5W2-44G/B					8	-	
MR-J5W2-77G/B					13	50	R
MR-J5W2-1010G/B					18		Rotary Mot
MR-J5W3-222G/B					8	-	tary Se Motors
MR-J5W3-444G/B					13		s.

 The value is applicable when the Type E Combination Motor Controller is combined with the servo amplifier.
 1-phase power input is not supported. Notes:

3. For the use under the conditions of UL Listed, select a semiconductor fuse.

4. Use the MMP-T series products that bear the UL mark.

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Low-Voltage Switchgear/Wires

Selection Example in HIV Wires for Servo Motors

G	G-RJ	WG	DG	В	B-RJ	WB	Α	A-RJ
Ğ		i a	DG	6			2-A-	

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) with a length of 30 m are used.

Dotony constants	dol	Wire size [mm ²] (Note 6)		
Rotary servo motor model		For power and grounding (U/V/W/E)	For electromagnetic brake (B1/B2)	
	HK-KT053W			
	HK-KT13W			
	HK-KT1M3W			
	HK-KT13UW			
	HK-KT23W			
	HK-KT43W			
	HK-KT63W			
	HK-KT23UW	0.75 (AWG 18) (Note 1, 2, 3)		
HK-KT_W	HK-KT43UW			
	HK-KT7M3W			
	HK-KT103W			
	HK-KT63UW			
	HK-KT7M3UW			
	HK-KT103UW			
	HK-KT153W			
	HK-KT203W	0.75 (AWG 18) (Note 1, 3, 7)		
	HK-KT202W			
	HK-KT434W			
	HK-KT634W			
	HK-KT7M34W			
	HK-KT1034W		0.2 (AWG 24) (Note 4, 5)	
HK-KT_4_W	HK-KT634UW			
	HK-KT1034UW			
	HK-KT1534W			
	HK-KT2034W			
	HK-KT2024W			
	HK-MT053W			
	HK-MT13W			
	HK-MT1M3W			
LUZ NAT IN/	HK-MT23W	0.75 (AWG 18) (Note 1, 2, 3)		
HK-MT_W	HK-MT43W			
	HK-MT63W			
	HK-MT7M3W			
	HK-MT103W			
	HK-MT053VW			
	HK-MT13VW			
	HK-MT1M3VW			
LUCIAT NAM	HK-MT23VW			
HK-MT_VW	HK-MT43VW			
	HK-MT63VW			
	HK-MT7M3VW			
	HK-MT103VW			

Notes: 1. Use fluorine resin wires of 0.75 mm² (AWG 18) for wiring to the servo motor power supply.

2. This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, or MR-AEP2J20CBL03M-_-L, and extend it with HIV wires of 1.25 mm² (AWG 16).

3. Use a cable provided by Mitsubishi Electric or Mitsubishi Electric System & Service Co., Ltd. When fabricating a cable, select wires applicable for the usage. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²). 4. Use fluorine resin wires of 0.2 mm² (AWG 24) for wiring to the electromagnetic brake. 5. This size is applicable for wiring length of 10 m or shorter. For over 10 m, extend the wires with HIV wires of 1.25 mm² (AWG 16).

6. The same wire size is applicable when the torques are increased. 7. This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, or MR-AEP2J20CBL03M-_-L, and extend it with HIV wires of 2 mm² (AWG 14).

Common Specifications

Selection Example in HIV Wires for Servo Motors

G G-RJ G-HS WG DG B B-RJ WB A A-RJ

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) with a length of 30 m are used. Refer to "Rotary Servo Motor User's Manual (For MR-J5)" when using cab-tire cables for supplying power (U/V/W) to HK-RT series.

Rotary servo motor mo	odel	Wire size [mm ²] (Note 6)		Se
notary serve motor me	ouei	For power and grounding (U/V/W/E)	For electromagnetic brake (B1/B2)	Controllers
	HK-ST52W	1.25 (AWG 16) (Note 5)		troll
	HK-ST102W	1.25 (AWG 10) (ers
	HK-ST172W			Ц
	HK-ST202AW	2 (AWG 14)		()
	HK-ST302W			Servo Amplifiers
	HK-ST353W	3.5 (AWG 12)		ΟA
K-ST_W (Note 7)	HK-ST503W	3.5 (AWG 12) (Note 8)	1.25 (AWG 16)	dum
	HK-ST7M2UW	1.25 (AWG 16) (Note 5)		lifie
	HK-ST172UW	1.25 (AWG 10) (******)		Sle
	HK-ST202W	2 (AWG 14)		
	HK-ST352W	3.5 (AWG 12)		Ro
	HK-ST502W			Rotary Servo Motors
	HK-ST702W	8 (AWG 8)		Motors
	HK-ST524W			- She
	HK-ST1024W			0
	HK-ST1724W	1.25 (AWG 16) (Note 5)		
	HK-ST2024AW			L.
	HK-ST3024W			Linear Servo Motors
IK-ST_4_W (Note 7)	HK-ST3534W		1.25 (AWG 16)	tors
	HK-ST5034W	2 (AWG 14)		\$ NO
	HK-ST2024W	1.25 (AWG 16) (Note 5)		
	HK-ST3524W	2 (AWG 14)		
	HK-ST5024W			_ =
	HK-ST7024W			Direct Drive Motors
	HK-RT103W	0.75 (AWG 18) (Note 1, 2, 5)		Dri
	HK-RT153W		0.2 (AWG 24) ^(Note 4, 9)	Ve
	HK-RT203W	0.75 (AWG 18) (Note 1, 3, 5)		
IK-RT_W	HK-RT353W	3.5 (AWG 12)		0
	HK-RT503W		1.25 (AWG 16)	Options/Peripheral Equipment
	HK-RT703W	5.5 (AWG 10)		quip
	HK-RT1034W			erip mer
	HK-RT1534W	0.75 (AWG 18) (Note 1, 2, 5)	0.2 (AWG 24) (Note 4, 9)	nt
	HK-RT2034W			<u>a</u>
IK-RT_4W	HK-RT3534W	1.25 (AWG 16) (Note 5)		
	HK-RT5034W		1.25 (AWG 16)	
	HK-RT7034W	2 (AWG 14)		LVS/Wir

Notes: 1. Use fluorine resin wires of 0.75 mm² (AWG 18) for wiring to the servo motor power supply.

 This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, or MR-AEP2J20CBL03M-_-L, and extend it with HIV wires of 1.25 mm² (AWG 16).

3. This size is applicable for wiring length of 10 m or shorter. For over 10 m, use MR-AEPB2J10CBL03M-_-L, MR-AEP2J10CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, MR-AEPB2J20CBL03M-_-L, and extend it with HIV wires of 2 mm² (AWG 14).

4. Use fluorine resin wires of 0.2 mm² (AWG 24) for wiring to the electromagnetic brake.

5. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²). Refer to "Rotary Servo Motor User's Manual (For MR-J5)" for details.

6. The same wire size is applicable when the torques are increased.

7. Wires for HK-ST152(4)G1/G1H/G5/G7 geared servo motors are the same as those for HK-ST172(4)W.

8. When using HK-ST503W for a machine that is required to comply with UL/CSA standards, use a cable (SC-PWC403C_M-SBLL or SC-PWC403C_M-SBLH) manufactured by Mitsubishi Electric System & Service Co., Ltd., and fabricate an extension cable with wires of AWG 10. For details of SC-PWC403C_M-SBLL and SC-PWC403C_M-SBLH, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp)

9. This size is applicable for wiring length of 10 m or shorter. For over 10 m, extend the wires with HIV wires of 1.25 mm² (AWG 16).

ires

Product List

Precautions

Selection Example in HIV Wires for Servo Motors G G-RJ WG B B-RJ WB A A-RJ

The following are examples of wire sizes when 600 V grade heat-resistant polyvinyl chloride insulated wires (HIV wires) with a length of 30 m are used.

Linear servo motor model		Wire size [mm ²]		
Primary side		For power and grounding (U/V/W/E)	For thermistor (G1/G2)	
LM-H3P2A-07P-BSS0				
		-		
LM-H3P3A-12P-CSS0		1.25 (AWG 16) (Note 1)		
LM-H3P3B-24P-CSS0		-		
LM-H3P3C-36P-CSS0				
LM-H3P3D-48P-CSS0		2 (AWG 14)		
LM-H3P7A-24P-ASS0		1.25 (AWG 16) (Note 1)		
LM-H3P7B-48P-ASS0		2 (AWG 14)		
LM-H3P7C-72P-ASS0		· · ·		
LM-H3P7D-96P-ASS0		3.5 (AWG 12)		
LM-FP2B-06M-1SS0	Natural cooling	_		
	Liquid cooling	2 (AWG 14)		
LM-FP2D-12M-1SS0	Natural cooling			
	Liquid cooling	3.5 (AWG 12)		
LM-FP2F-18M-1SS0	Natural cooling	2 (AWG 14)		
	Liquid cooling	3.5 (AWG 12) (Note 3)		
LM-FP4B-12M-1SS0	Natural cooling		0.2 (AWG 24)	
	Liquid cooling	5 5 (A)WG 10)		
	Natural cooling	-5.5 (AWG 10)		
LM-FP4D-24M-1SS0	Liquid cooling			
LM-K2P1A-01M-2SS1		1.25 (AWG 16) (Note 1)		
LM-K2P1C-03M-2SS1		2 (AWG 14)	—	
LM-K2P2A-02M-1SS1		1.25 (AWG 16) (Note 1)		
LM-K2P2C-07M-1SS1		3.5 (AWG 12)		
LM-K2P2E-12M-1SS1		5.5 (AWG 10)		
LM-K2P3C-14M-1SS1		3.5 (AWG 12)		
LM-K2P3E-24M-1SS1		5.5 (AWG 10)		
LM-U2PAB-05M-0SS0, LM-U2PAD-10M-03	 SS0			
LM-U2PAF-15M-0SS0, LM-U2PBB-07M-1		1.25 (AWG 16) (Note 1)		
LM-U2PBD-15M-1SS0, LM-U2PBF-22M-1				
LM-U2P2B-40M-2SS0	000	2 (AWG 14)		
LM-U2P2C-60M-2SS0		3.5 (AWG 12)		
LM-U2P2D-80M-2SS0		5.5 (AWG 10)		
		[3.5 (AWG 10)		
Linear servo motor model		Wire size [mm ²]		
Primary side		For power and grounding (U/V/W/E)	For thermal protector	
LM-AJP1B-07K-JSS0, LM-AJP1D-14K-JSS	S0,			
LM-AJP2B-12S-JSS0, LM-AJP2D-23T-JSS	S0,			
LM-AJP3B-17N-JSS0, LM-AJP3D-35R-JS	S0,			
LM-AJP4B-22M-JSS0, LM-AJP4D-45N-JS				
LM-AUP3A-03V-JSS0, LM-AUP3B-06V-JS	S0,	1.25 (AWG 16) (Note 1)	0.2 (AWG 24)	
LM-AUP3C-09V-JSS0, LM-AUP3D-11R-JS	,			
LM-AUP4A-04R-JSS0, LM-AUP4B-09R-JS				
LM-AUP4C-13P-JSS0, LM-AUP4D-18M-JSS0,				
LM-AUP4F-26P-JSS0, LM-AUP4H-35M-JSS0				
		Mine size [resp2]		
Direct drive motor model		Wire size [mm ²]		
		For power and grounding (U/V/W/E)		
TM-RG2M002C30, TM-RG2M004E30, TM-RG2M009G30, TM-RU2M002C30, TM-RU2M004E30, TM-RU2M009G30		0.75 (AWG 18) (Note 1, 2)		
TM-RFM002C20, TM-RFM004C20, TM-RFM006C20, TM-RFM006E20, TM-RFM012E20, TM-RFM018E20,				
		1.25 (AWG 16) (Note 1)		
TM-RFM012G20				
TM-RFM048G20, TM-RFM072G20		3.5 (AWG 12)		
TM-RFM040J10		1.25 (AWG 16) (Note 1)		
TM-RFM120J10		3.5 (AWG 12)		
TM-RFM240J10		5.5 (AWG 10)		

Notes: 1. The National Electrical Code recommends that the wire size should be a minimum of AWG 14 (2 mm²). Refer to the servo motor User's Manual for details. 2. The same wire size is applicable when the torques are increased.

3. Use a wire which has a heat resistance temperature of 105 °C for wiring to the servo motor power supply.

Low-Voltage Switchgear/Wires

MEMO

Common Specifications

Servo system controllers

Item		Model	Application		
		RD78G4	Maximum number of control axes: 4 axes	CC-Link IE TSN master station	
		RD78G8	Maximum number of control axes: 8 axes	CC-Link IE TSN master station	
RD78G16			Maximum number of control axes: 16 axes	CC-Link IE TSN master station	
		RD78G32	Maximum number of control axes: 32 axes	CC-Link IE TSN master station	
Motion module		RD78G64 Maximum number of control axes: 64 axes		CC-Link IE TSN master station	
		RD78GHV	Maximum number of control axes: 128 axes	CC-Link IE TSN master station	
		RD78GHW	Maximum number of control axes: 256 axes	CC-Link IE TSN master station	
		FX5-40SSC-G	Maximum number of control axes: 4 axes	CC-Link IE TSN master station	
		FX5-80SSC-G	Maximum number of control axes: 8 axes	CC-Link IE TSN master station	
			SWM-G Engine SWM-G Operating Station		
	SWM-G	SW1DNN-SWMG-M	Network API SWM-G API	CC-Link IE TSN compatible	
Motion Control Software (Note 1)			Real Time OS (RTX64)		
viotion Control Software			SWM-G Engine · SWM-G Operating Station	CC-Link IE TSN/	
	SWM-G-N1	SW1DNN-SWMGN1-M	Network API SWM-G API	EtherCAT [®] compatible	
			EcConfigurator Real Time OS (RTX64)	EtherCAT [®] compatible	
	SWM-G	MR-SWMG16-U Maximum number of control axes: 16 axes		USB key (license)	
		MR-SWMG32-U	Maximum number of control axes: 32 axes	USB key (license)	
		MR-SWMG64-U	Maximum number of control axes: 64 axes	USB key (license)	
USB key for Motion Control		MR-SWMG128-U	Maximum number of control axes: 128 axes	USB key (license)	
Software		MR-SWMG16N1-U	Maximum number of control axes: 16 axes	USB key (license)	
	SWM-G-N1	MR-SWMG32N1-U	Maximum number of control axes: 32 axes	USB key (license)	
	SWIVI-G-INT	MR-SWMG64N1-U	Maximum number of control axes: 64 axes	USB key (license)	
		MR-SWMG128N1-U	Maximum number of control axes: 128 axes	USB key (license)	
		RD77MS2	Maximum number of control axes: 2 axes	SSCNET III/H compatible	
		RD77MS4	Maximum number of control axes: 4 axes	SSCNET III/H compatible	
		RD77MS8	Maximum number of control axes: 8 axes	SSCNET III/H compatible	
Simple Motion module (Note 2)		RD77MS16	Maximum number of control axes: 16 axes	SSCNET III/H compatible	
		QD77MS2	Maximum number of control axes: 2 axes	SSCNET III/H compatible	
		QD77MS4	Maximum number of control axes: 4 axes	SSCNET III/H compatible	
		QD77MS16	Maximum number of control axes: 16 axes	SSCNET III/H compatible	
R16MTCPU			Maximum number of control axes: 16 axes	SSCNET III/H compatible	
		R32MTCPU	Maximum number of control axes: 32 axes	SSCNET III/H compatible	
Motion controller		R64MTCPU	Maximum number of control axes: 64 axes	SSCNET III/H compatible	
		Q172DSCPU	Maximum number of control axes: 16 axes	SSCNET III/H compatible	
		Q173DSCPU	Maximum number of control axes: 32 axes	SSCNET III/H compatible	
		Q170MSCPU	Maximum number of control axes: 16 axes	SSCNET III/H compatible	

Notes:

1. Download and install Motion Control Software from Mitsubishi Electric FA global website.

2. Connectors are not included. Please purchase A6CON1, A6CON2, or A6CON4 separately.

.....

Servo amplifiers

Item		Model	Rated output	Main circuit power supply	spec
		MR-J5-10G	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	cifica
		MR-J5-20G	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Specifications
		MR-J5-40G	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	
		MR-J5-60G	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Controllers
Servo amplifier MR-J5-G	200 V class	MR-J5-70G	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	lers
		MR-J5-100G	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Ser
		MR-J5-200G	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Servo Amplifiers
		MR-J5-350G	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	plifi
		MR-J5-500G	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	iers
		MR-J5-700G	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	
		MR-J5-60G4	0.6 kW	3-phase 380 V AC to 480 V AC	;
		MR-J5-100G4	1 kW	3-phase 380 V AC to 480 V AC	Motors
Servo amplifier	400 V	MR-J5-200G4	2 kW	3-phase 380 V AC to 480 V AC	loto
MR-J5-G4	class	MR-J5-350G4	3.5 kW	3-phase 380 V AC to 480 V AC	S
		MR-J5-500G4	5 kW	3-phase 380 V AC to 480 V AC	Č
		MR-J5-700G4	7 kW	3-phase 380 V AC to 480 V AC	
		MR-J5-10G-RJ	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_
		MR-J5-20G-RJ	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Motors
		MR-J5-40G-RJ	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	
	200 V	MR-J5-60G-RJ	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Ţ
Servo amplifier MR-J5-G-RJ	200 V class	MR-J5-70G-RJ	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Motors
		MR-J5-100G-RJ	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	0
		MR-J5-200G-RJ	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Equipment
		MR-J5-350G-RJ	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	liqu
		MR-J5-500G-RJ	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	ipm
		MR-J5-700G-RJ	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	ent
		MR-J5-60G4-RJ	0.6 kW	3-phase 380 V AC to 480 V AC	9
0		MR-J5-100G4-RJ	1 kW	3-phase 380 V AC to 480 V AC	
Servo amplifier MR-J5-G4-RJ/	400 V	MR-J5-200G4-RJ	2 kW	3-phase 380 V AC to 480 V AC	
MR-J5-G4-HS	class	MR-J5-350G4-RJ	3.5 kW	3-phase 380 V AC to 480 V AC	LVS/Wires
		MR-J5-500G4-HS	5 kW	3-phase 380 V AC to 480 V AC	
		MR-J5-700G4-HS	7 kW	3-phase 380 V AC to 480 V AC	lire
		MR-J5W2-22G	0.2 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	0
Servo amplifier	200 V	MR-J5W2-44G	0.4 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Pro
MR-J5W2-G	class	MR-J5W2-77G	0.75 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Product List
		MR-J5W2-1010G	1 kW x 2 axes	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	rst
Servo amplifier	200 V	MR-J5W3-222G	0.2 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Pr
MR-J5W3-G	class	MR-J5W3-444G	0.4 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Precautions

Servo amplifiers

Item		Model	Rated output	Main circuit power supply
		MR-J5-10G-N1	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20G-N1	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40G-N1	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
	000 V (MR-J5-60G-N1	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier MR-J5-G-N1	200 V class	MR-J5-70G-N1	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-100G-N1	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200G-N1	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350G-N1	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-500G-N1	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-700G-N1	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-60G4-N1	0.6 kW	3-phase 380 V AC to 480 V AC
		MR-J5-100G4-N1	1 kW	3-phase 380 V AC to 480 V AC
	400 V	MR-J5-200G4-N1	2 kW	3-phase 380 V AC to 480 V AC
	class	MR-J5-350G4-N1	3.5 kW	3-phase 380 V AC to 480 V AC
	0,000	MR-J5-500G4-N1		
			5 kW	3-phase 380 V AC to 480 V AC
		MR-J5-700G4-N1	7 kW	3-phase 380 V AC to 480 V AC
		MR-J5-10G-RJN1	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20G-RJN1	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40G-RJN1	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5-60G-RJN1	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5-G-RJN1	class	MR-J5-70G-RJN1	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-100G-RJN1	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200G-RJN1	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350G-RJN1	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-500G-RJN1	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-700G-RJN1	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
	I	MR-J5-60G4-RJN1	0.6 kW	3-phase 380 V AC to 480 V AC
		MR-J5-100G4-RJN1	1 kW	3-phase 380 V AC to 480 V AC
Servo amplifier	400 V	MR-J5-200G4-RJN1	2 kW	3-phase 380 V AC to 480 V AC
/R-J5-G4-RJN1/	class	MR-J5-350G4-RJN1	3.5 kW	3-phase 380 V AC to 480 V AC
/R-J5-G4-HSN1		MR-J5-500G4-HSN1	5 kW	3-phase 380 V AC to 480 V AC
		MR-J5-700G4-HSN1	7 kW	3-phase 380 V AC to 480 V AC
		MR-J5W2-22G-N1	0.2 kW x 2 axes	3-phase of 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier MR-J5W2-G-N1	200 V	MR-J5W2-44G-N1	0.4 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
	class	MR-J5W2-77G-N1	0.75 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5W2-1010G-N1	1 kW x 2 axes	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5W3-222G-N1	0.2 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5W3-G-N1	class	MR-J5W3-444G-N1	0.4 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC

Drive units

Item		Model	Rated output	Main circuit power supply	pecificatio
		MR-J5D1-100G4	1 kW		Specifications
D:	400.14	MR-J5D1-200G4	2 kW		cal
Drive unit MR-J5D1-G4	400 V class	MR-J5D1-350G4	3.5 kW	Main circuit power is supplied from the power regeneration converter unit to the drive unit.	one
MIX-33D1-04	61035	MR-J5D1-500G4	5 kW	converter unit to the drive unit.	0
		MR-J5D1-700G4	7 kW	<u> </u>	
		MR-J5D2-100G4	1 kW x 2 axes		C
Defense sumit	400.1/	MR-J5D2-200G4	2 kW x 2 axes	Addition of the second is supplied from the neuron presention	Controllers
Drive unit MR-J5D2-G4	400 V class	MR-J5D2-350G4	3.5 kW x 2 axes	Main circuit power is supplied from the power regeneration converter unit to the drive unit.	roll
MIX-3302-04	01033	MR-J5D2-500G4	5 kW x 2 axes		ers
		MR-J5D2-700G4	7 kW x 2 axes	<u> </u>	
Drive unit	400 V	MR-J5D3-100G4	1 kW x 3 axes	Main circuit power is supplied from the power regeneration	
MR-J5D3-G4	class	MR-J5D3-200G4	2 kW x 3 axes	converter unit to the drive unit.	
		MR-J5D1-100G4-N1	1 kW		
D i wali	400.14	MR-J5D1-200G4-N1	2 kW		
Drive unit MR-J5D1-G4-N1	400 V class	MR-J5D1-350G4-N1	3.5 kW	Main circuit power is supplied from the power regeneration converter unit to the drive unit.	
WIR-35D1-04-N1	61035	MR-J5D1-500G4-N1	5 kW		-
		MR-J5D1-700G4-N1	7 kW	<u> </u>	
		MR-J5D2-100G4-N1	1 kW x 2 axes		
During space	400.1/	MR-J5D2-200G4-N1	2 kW x 2 axes	Addition of the second is supplied from the neuron presention	V
Drive unit MR-J5D2-G4-N1	400 V class	MR-J5D2-350G4-N1	3.5 kW x 2 axes	Main circuit power is supplied from the power regeneration converter unit to the drive unit.	MOIOIS
WIN-3302-04-INT	01033	MR-J5D2-500G4-N1	5 kW x 2 axes		SIC
		MR-J5D2-700G4-N1	7 kW x 2 axes	<u> </u>	
Drive unit	400 V	MR-J5D3-100G4-N1	1 kW x 3 axes	Main circuit power is supplied from the power regeneration	
MR-J5D3-G4-N1	class	MR-J5D3-200G4-N1	2 kW x 3 axes	converter unit to the drive unit.	
		-			

Servo amplifiers

Item		Model	Rated output	Main circuit power supply
		MR-J5-10B	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20B	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40B	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
en le ener lifier	200 V	MR-J5-60B	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
ervo amplifier IR-J5-B	200 V class	MR-J5-70B	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-100B	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200B	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350B	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-500B	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-700B	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
	1	MR-J5-60B4	0.6 kW	3-phase 380 V AC to 480 V AC
		MR-J5-100B4	1 kW	3-phase 380 V AC to 480 V AC
Servo amplifier	400 V	MR-J5-200B4	2 kW	3-phase 380 V AC to 480 V AC
/R-J5-B4	class	MR-J5-350B4	3.5 kW	3-phase 380 V AC to 480 V AC
	01233			
		MR-J5-500B4	5 kW	3-phase 380 V AC to 480 V AC
		MR-J5-700B4	7 kW	3-phase 380 V AC to 480 V AC
		MR-J5-10B-RJ	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-20B-RJ	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-40B-RJ	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5-60B-RJ	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5-B-RJ	class	MR-J5-70B-RJ	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-100B-RJ	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-200B-RJ	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5-350B-RJ	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-500B-RJ	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-700B-RJ	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC
		MR-J5-60B4-RJ	0.6 kW	3-phase 380 V AC to 480 V AC
		MR-J5-100B4-RJ	1 kW	3-phase 380 V AC to 480 V AC
ervo amplifier	400 V	MR-J5-200B4-RJ	2 kW	3-phase 380 V AC to 480 V AC
IR-J5-B4-RJ	class	MR-J5-350B4-RJ	3.5 kW	3-phase 380 V AC to 480 V AC
		MR-J5-500B4-RJ	5 kW	3-phase 380 V AC to 480 V AC
		MR-J5-700B4-RJ	7 kW	3-phase 380 V AC to 480 V AC
		MR-J5W2-22B	0.2 kW x 2 axes	3-phase of 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier MR-J5W2-B	200 V	MR-J5W2-44B	0.4 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
	class	MR-J5W2-77B	0.75 kW x 2 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
		MR-J5W2-1010B	1 kW x 2 axes	3-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
Servo amplifier	200 V	MR-J5W3-222B	0.2 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC
MR-J5W3-B	class	MR-J5W3-444B	0.4 kW x 3 axes	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC

..... 5

Servo amplifiers

Item		Model	Rated output	Main circuit power supply	ope
		MR-J5-10A	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Specifications
ervo amplifier R-J5-A ervo amplifier R-J5-A4		MR-J5-20A	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Ions
		MR-J5-40A	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	C
		MR-J5-60A	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Controllers
Servo amplifier /IR-J5-A	200 V class	MR-J5-70A	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	ers
		MR-J5-100A	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	_
		MR-J5-200A	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	
		MR-J5-350A	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	
		MR-J5-500A	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	
		MR-J5-700A	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	
		MR-J5-60A4	0.6 kW	3-phase 380 V AC to 480 V AC	
		MR-J5-100A4	1 kW	3-phase 380 V AC to 480 V AC	Motors
Servo amplifier MR-J5-A4	400 V	MR-J5-200A4	2 kW	3-phase 380 V AC to 480 V AC	100
	class	MR-J5-350A4	3.5 kW	3-phase 380 V AC to 480 V AC	SIC
		MR-J5-500A4	5 kW	3-phase 380 V AC to 480 V AC	
		MR-J5-700A4	7 kW	3-phase 380 V AC to 480 V AC	
		MR-J5-10A-RJ	0.1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	
		MR-J5-20A-RJ	0.2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Motors
		MR-J5-40A-RJ	0.4 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	
		MR-J5-60A-RJ	0.6 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	
Servo amplifier MR-J5-A-RJ	200 V class	MR-J5-70A-RJ	0.75 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Motors
		MR-J5-100A-RJ	1 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	ى ە
		MR-J5-200A-RJ	2 kW	3-phase or 1-phase 200 V AC to 240 V AC 283 V DC to 340 V DC	Equipment
		MR-J5-350A-RJ	3.5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	
		MR-J5-500A-RJ	5 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	
		MR-J5-700A-RJ	7 kW	3-phase 200 V AC to 240 V AC, 283 V DC to 340 V DC	
		MR-J5-60A4-RJ	0.6 kW	3-phase 380 V AC to 480 V AC	
		MR-J5-100A4-RJ	1 kW	3-phase 380 V AC to 480 V AC	
Servo amplifier	400 V	MR-J5-200A4-RJ	2 kW	3-phase 380 V AC to 480 V AC	
/IR-J5-A4-RJ	class	MR-J5-350A4-RJ	3.5 kW	3-phase 380 V AC to 480 V AC	
		MR-J5-500A4-RJ	5 kW	3-phase 380 V AC to 480 V AC	—
		MR-J5-700A4-RJ	7 kW	3-phase 380 V AC to 480 V AC	

Converter units

Item		Model	Rated output	Main circuit power supply	
Simple converter MR-CM	200 V class	MR-CM3K	3 kW	3-phase 200 V AC to 240 V AC	
		MR-CV11K4	11 kW	3-phase 380 V AC to 480 V AC	
		MR-CV18K4	18 kW	3-phase 380 V AC to 480 V AC	
Power regeneration	400.14	MR-CV30K4	30 kW	3-phase 380 V AC to 480 V AC	
converter unit	400 V class	MR-CV37K4	37 kW	3-phase 380 V AC to 480 V AC	
MR-CV	01233	MR-CV45K4	45 kW	3-phase 380 V AC to 480 V AC	
		MR-CV55K4	55 kW	3-phase 380 V AC to 480 V AC	
		MR-CV75K4	75 kW	3-phase 380 V AC to 480 V AC	

Support

Item		Flange size [mm]	Model	Rated output	Rated speed
			HK-KT053W(B)	0.05 kW	3000 r/min
		40 x 40	HK-KT13W(B)	0.1 kW	3000 r/min
			HK-KT1M3W(B)	0.15 kW	3000 r/min
			HK-KT13UW(B)	0.1 kW	3000 r/min
		60 x 60	HK-KT23W(B)	0.2 kW	3000 r/min
		00 x 00	HK-KT43W(B)	0.4 kW	3000 r/min
			HK-KT63W(B)	0.6 kW	3000 r/min
			HK-KT23UW(B)	0.2 kW	3000 r/min
	HK-KT_W	80 x 80	HK-KT43UW(B)	0.4 kW	3000 r/min
		00 X 00	HK-KT7M3W(B)	0.75 kW	3000 r/min
			HK-KT103W(B)	1.0 kW	3000 r/min
IK-KT series			HK-KT63UW(B)	0.6 kW	3000 r/min
			HK-KT7M3UW(B)	0.75 kW	3000 r/min
: With an electromagnetic		~ ~	HK-KT103UW(B)	1.0 kW	3000 r/min
rake		90 x 90	HK-KT153W(B)	1.5 kW	3000 r/min
			HK-KT203W(B)	2.0 kW	3000 r/min
			HK-KT202W(B)	2.0 kW	2000 r/min
			HK-KT434W(B)	0.4 kW	3000 r/min
		60 x 60	HK-KT634W(B)	0.6 kW	3000 r/min
			HK-KT7M34W(B)	0.75 kW	3000 r/min
		80 x 80	HK-KT1034W(B)	1.0 kW	3000 r/min
	HK-KT_4_W		HK-KT634UW(B)	0.6 kW	3000 r/min
			HK-KT1034UW(B)	1.0 kW	3000 r/min
		90 x 90	HK-KT1534W(B)	1.5 kW	3000 r/min
			HK-KT2034W(B)	2.0 kW	3000 r/min
			HK-KT2024W(B)	2.0 kW	2000 r/min
		40 x 40	HK-KT053W(B)WS	0.05 kW	3000 r/min
			HK-KT13W(B)WS	0.1 kW	3000 r/min
			HK-KT1M3W(B)WS	0.15 kW	3000 r/min
		60 x 60	HK-KT13UW(B)WS	0.1 kW	3000 r/min
			HK-KT23W(B)WS	0.2 kW	3000 r/min
			HK-KT43W(B)WS	0.4 kW	3000 r/min
			HK-KT63W(B)WS	0.6 kW	3000 r/min
			HK-KT23UW(B)WS	0.2 kW	3000 r/min
	HK-KT_W_WS		HK-KT43UW(B)WS	0.4 kW	3000 r/min
		80 x 80	HK-KT7M3W(B)WS	0.75 kW	3000 r/min
			HK-KT103W(B)WS	1.0 kW	3000 r/min
ervo motors with functional			HK-KT63UW(B)WS	0.6 kW	3000 r/min
afety IK-KT series			HK-KT7M3UW(B)WS	0.75 kW	3000 r/min
			HK-KT103UW(B)WS	1.0 kW	3000 r/min
: With an electromagnetic		90 x 90	HK-KT153W(B)WS	1.5 kW	3000 r/min
rake				0.0.111	0000 / J
			HK-KT203W(B)WS HK-KT202W(B)WS	2.0 KW	2000 r/min
			HK-KT434W(B)WS	2.0 kW 0.4 kW	3000 r/min
		60 x 60			
			HK-KT634W(B)WS	0.6 kW	3000 r/min
		80 x 80	HK-KT7M34W(B)WS	0.75 kW	3000 r/min
			HK-KT1034W(B)WS	1.0 kW	3000 r/min
	HK-KT_4_W_WS		HK-KT634UW(B)WS	0.6 kW	3000 r/min
		0000	HK-KT1034UW(B)WS	1.0 kW	3000 r/min
		90 x 90	HK-KT1534W(B)WS	1.5 kW	3000 r/min
			HK-KT2034W(B)WS	2.0 kW	3000 r/min
			HK-KT2024W(B)WS	2.0 kW	2000 r/min

Rotary servo motors

tem		Model		Rated output	Rated speed	Reduction ratio	000
		HK-KT053(B)G1	1/5	0.05 kW	3000 r/min	1/5	ŝ
		HK-KT053(B)G1	1/12	0.05 kW	3000 r/min	1/12	001
		HK-KT053(B)G1	1/20	0.05 kW	3000 r/min	1/20	
		HK-KT13(B)G1	1/5	0.1 kW	3000 r/min	1/5	0
		HK-KT13(B)G1	1/12	0.1 kW	3000 r/min	1/12	
K-KT series		HK-KT13(B)G1	1/20	0.1 kW	3000 r/min	1/20	
/ith a gear reducer for		HK-KT23(B)G1	1/5	0.2 kW	3000 r/min	1/5	917
eneral industrial machines	HK-KT_G_	HK-KT23(B)G1	1/12	0.2 kW	3000 r/min	1/12	(
With an electromagnetic		HK-KT23(B)G1	1/20	0.2 kW	3000 r/min	1/20	
ake		HK-KT43(B)G1	1/5	0.4 kW	3000 r/min	1/5	
		HK-KT43(B)G1	1/12	0.4 kW	3000 r/min	1/12	
		HK-KT43(B)G1	1/20	0.4 kW	3000 r/min	1/20	
		HK-KT7M3(B)G1	1/5	0.75 kW	3000 r/min	1/5	
		HK-KT7M3(B)G1	1/12	0.75 kW	3000 r/min	1/12	
		HK-KT7M3(B)G1	1/20	0.75 kW	3000 r/min	1/20	
		HK-KT053(B)G5	1/5 (40 x 40)	0.05 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm)	
		HK-KT053(B)G5	1/5 (60 x 60)	0.05 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm)	
		HK-KT053(B)G5	1/9	0.05 kW	3000 r/min	1/9	
		HK-KT053(B)G5	1/11	0.05 kW	3000 r/min	1/11	
		HK-KT053(B)G5	1/21	0.05 kW	3000 r/min	1/21	
		HK-KT053(B)G5	1/33	0.05 kW	3000 r/min	1/33	
		HK-KT053(B)G5	1/45	0.05 kW	3000 r/min	1/45	NIOLOIS
		HK-KT13(B)G5	1/5 (40 x 40)	0.1 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm)	
		HK-KT13(B)G5	1/5 (60 x 60)	0.1 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm)	
		HK-KT13(B)G5	1/11	0.1 kW	3000 r/min	1/11	
		HK-KT13(B)G5	1/21	0.1 kW	3000 r/min	1/21	
-KT series		HK-KT13(B)G5	1/33	0.1 kW	3000 r/min	1/33	
h a flange-output type gear		HK-KT13(B)G5	1/45	0.1 kW	3000 r/min	1/45	
ucer for high precision		HK-KT23(B)G5	1/5	0.2 kW	3000 r/min	1/5	
plications, flange mounting	HK-KT_G_	HK-KT23(B)G5	1/11	0.2 kW	3000 r/min	1/11	
With an electromagnetic		HK-KT23(B)G5	1/21	0.2 kW	3000 r/min	1/21	
ke		HK-KT23(B)G5	1/33	0.2 kW	3000 r/min	1/33	
		HK-KT23(B)G5	1/45	0.2 kW	3000 r/min	1/45	
		HK-KT43(B)G5	1/5	0.4 kW	3000 r/min	1/5	
		HK-KT43(B)G5	1/11	0.4 kW	3000 r/min	1/11	
		HK-KT43(B)G5	1/21	0.4 kW	3000 r/min	1/21	
		HK-KT43(B)G5	1/33	0.4 kW	3000 r/min	1/33	
		HK-KT43(B)G5	1/45	0.4 kW	3000 r/min	1/45	
		HK-KT7M3(B)G5	1/5	0.75 kW	3000 r/min	1/5	
		HK-KT7M3(B)G5	1/11	0.75 kW	3000 r/min	1/11	
		HK-KT7M3(B)G5	1/21	0.75 kW	3000 r/min	1/21	
		HK-KT7M3(B)G5	1/33	0.75 kW	3000 r/min	1/33	
		HK-KT7M3(B)G5	1/45	0.75 kW	3000 r/min	1/45	

Item		Model		Rated output	Rated speed	Reduction ratio
		HK-KT053(B)G7	1/5 (40 x 40)	0.05 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm)
		HK-KT053(B)G7	1/5 (60 x 60)	0.05 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm)
		HK-KT053(B)G7	1/9	0.05 kW	3000 r/min	1/9
		HK-KT053(B)G7	1/11	0.05 kW	3000 r/min	1/11
		HK-KT053(B)G7	1/21	0.05 kW	3000 r/min	1/21
		HK-KT053(B)G7	1/33	0.05 kW	3000 r/min	1/33
		HK-KT053(B)G7	1/45	0.05 kW	3000 r/min	1/45
		HK-KT13(B)G7	1/5 (40 x 40)	0.1 kW	3000 r/min	1/5 (flange dimensions: 40 mm x 40 mm
		HK-KT13(B)G7	1/5 (60 x 60)	0.1 kW	3000 r/min	1/5 (flange dimensions: 60 mm x 60 mm
		HK-KT13(B)G7	1/11	0.1 kW	3000 r/min	1/11
		HK-KT13(B)G7	1/21	0.1 kW	3000 r/min	1/21
HK-KT series	HK-KT_G_	HK-KT13(B)G7	1/33	0.1 kW	3000 r/min	1/33
With a shaft-output type gear		HK-KT13(B)G7	1/45	0.1 kW	3000 r/min	1/45
reducer for high precision applications, flange mounting		HK-KT23(B)G7	1/5	0.2 kW	3000 r/min	1/5
applications, narige mounting		HK-KT23(B)G7	1/11	0.2 kW	3000 r/min	1/11
B: With an electromagnetic		HK-KT23(B)G7	1/21	0.2 kW	3000 r/min	1/21
brake		HK-KT23(B)G7	1/33	0.2 kW	3000 r/min	1/33
		HK-KT23(B)G7	1/45	0.2 kW	3000 r/min	1/45
		HK-KT43(B)G7	1/5	0.4 kW	3000 r/min	1/5
		HK-KT43(B)G7	1/11	0.4 kW	3000 r/min	1/11
		HK-KT43(B)G7	1/21	0.4 kW	3000 r/min	1/21
		HK-KT43(B)G7	1/33	0.4 kW	3000 r/min	1/33
		HK-KT43(B)G7	1/45	0.4 kW	3000 r/min	1/45
		HK-KT7M3(B)G7	1/5	0.75 kW	3000 r/min	1/5
		HK-KT7M3(B)G7	1/11	0.75 kW	3000 r/min	1/11
		HK-KT7M3(B)G7	1/21	0.75 kW	3000 r/min	1/21
		HK-KT7M3(B)G7	1/33	0.75 kW	3000 r/min	1/33
		HK-KT7M3(B)G7	1/45	0.75 kW	3000 r/min	1/45

Item		Flange size [mm]	Model	Rated output	Rated speed	
			HK-MT053W(B)	0.05 kW	3000 r/min	
		40 x 40	HK-MT13W(B)	0.1 kW	3000 r/min	
			HK-MT1M3W(B)	0.15 kW	3000 r/min	
	HK-MT W		HK-MT23W(B)	0.2 kW	3000 r/min	
		60 x 60	HK-MT43W(B)	0.4 kW	3000 r/min	
			HK-MT63W(B)	0.6 kW	3000 r/min	
HK-MT series		80 x 80	HK-MT7M3W(B)	0.75 kW	3000 r/min	
		00 X 00	HK-MT103W(B)	1.0 kW	3000 r/min	
3: With an electromagnetic			HK-MT053VW(B)	0.05 kW	3000 r/min	
orake		40 x 40	HK-MT13VW(B)	0.1 kW	3000 r/min	
	HK-MT VW		HK-MT1M3VW(B)	0.15 kW	3000 r/min	
			HK-MT23VW(B)	0.2 kW	3000 r/min	
		60 x 60	HK-MT43VW(B)	0.4 kW	3000 r/min	
			HK-MT63VW(B)	0.6 kW	3000 r/min	
		80 x 80	HK-MT7M3VW(B)	0.75 kW	3000 r/min	
		00 X 00	HK-MT103VW(B)	1.0 kW	3000 r/min	
			HK-MT053W(B)WS	0.05 kW	3000 r/min	
		40 x 40	HK-MT13W(B)WS	0.1 kW	3000 r/min	
			HK-MT1M3W(B)WS	0.15 kW	3000 r/min	
	HK-MT_W_WS		HK-MT23W(B)WS	0.2 kW	3000 r/min	
		60 x 60	HK-MT43W(B)WS	0.4 kW	3000 r/min	
Servo motors with functional			HK-MT63W(B)WS	0.6 kW	3000 r/min	
afety		80 x 80	HK-MT7M3W(B)WS	0.75 kW	3000 r/min	
IK-MT series		00 X 00	HK-MT103W(B)WS	1.0 kW	3000 r/min	
			HK-MT053VW(B)WS	0.05 kW	3000 r/min	
3: With an electromagnetic		40 x 40	HK-MT13VW(B)WS	0.1 kW	3000 r/min	
rake			HK-MT1M3VW(B)WS	0.15 kW	3000 r/min	
			HK-MT23VW(B)WS	0.2 kW	3000 r/min	
	HK-MT_VW_WS	60 x 60	HK-MT43VW(B)WS	0.4 kW	3000 r/min	
			HK-MT63VW(B)WS	0.6 kW	3000 r/min	
		80 x 80	HK-MT7M3VW(B)WS	0.75 kW	3000 r/min	
		00 X 80	HK-MT103VW(B)WS	1.0 kW	3000 r/min	

Item		Flange size [mm]	Model	Rated output	Rated speed
			HK-ST52W(B)	0.5 kW	2000 r/min
			HK-ST102W(B)	1.0 kW	2000 r/min
		130 x 130	HK-ST172W(B)	1.75 kW	2000 r/min
			HK-ST202AW(B)	2.0 kW	2000 r/min
			HK-ST302W(B)	3.0 kW	2000 r/min
			HK-ST353W(B)	3.5 kW	3000 r/min
	HK-ST_W		HK-ST503W(B)	5.0 kW	3000 r/min
			HK-ST7M2UW(B)	0.75 kW	2000 r/min
			HK-ST172UW(B)	1.75 kW	2000 r/min
		176 x 176	HK-ST202W(B)	2.0 kW	2000 r/min
IK-ST series		170 X 170	HK-ST352W(B)	3.5 kW	2000 r/min
			HK-ST502W(B)	5.0 kW	2000 r/min
: With an electromagnetic			HK-ST702W(B)	7.0 kW	2000 r/min
rake			HK-ST524W(B)	0.5 kW	2000 r/min
			HK-ST1024W(B)	1.0 kW	2000 r/min
			HK-ST1724W(B)	1.75 kW	2000 r/min
		130 x 130	HK-ST2024AW(B)	2.0 kW	2000 r/min
	HK-ST_4_W		HK-ST3024W(B)	3.0 kW	2000 r/min
			HK-ST3534W(B)	3.5 kW	3000 r/min
			HK-ST5034W(B)	5.0 kW	3000 r/min
		176 x 176	HK-ST2024W(B)	2.0 kW	2000 r/min
			HK-ST3524W(B)	3.5 kW	2000 r/min
			HK-ST5024W(B)	5.0 kW	2000 r/min
			HK-ST7024W(B)	7.0 kW	2000 r/min
		130 x 130	HK-ST52W(B)WS	0.5 kW	2000 r/min
			HK-ST102W(B)WS	1.0 kW	2000 r/min
			HK-ST172W(B)WS	1.75 kW	2000 r/min
			HK-ST202AW(B)WS	2.0 kW	2000 r/min
			HK-ST302W(B)WS	3.0 kW	2000 r/min
			HK-ST353W(B)WS	3.5 kW	3000 r/min
	HK-ST_W_WS		HK-ST503W(B)WS	5.0 kW	3000 r/min
			HK-ST7M2UW(B)WS	0.75 kW	2000 r/min
			HK-ST172UW(B)WS	1.75 kW	2000 r/min
ervo motors with functional		176 x 176	HK-ST202W(B)WS	2.0 kW	2000 r/min
afety		110 X 170	HK-ST352W(B)WS	3.5 kW	2000 r/min
K-ST series			HK-ST502W(B)WS	5.0 kW	2000 r/min
			HK-ST702W(B)WS	7.0 kW	2000 r/min
: With an electromagnetic			HK-ST524W(B)WS	0.5 kW	2000 r/min
rake			HK-ST1024W(B)WS	1.0 kW	2000 r/min
			HK-ST1724W(B)WS	1.75 kW	2000 r/min
		130 x 130	HK-ST2024AW(B)WS	2.0 kW	2000 r/min
			HK-ST3024W(B)WS	3.0 kW	2000 r/min
	HK-ST_4_W_WS		HK-ST3534W(B)WS	3.5 kW	3000 r/min
			HK-ST5034W(B)WS	5.0 kW	3000 r/min
			HK-ST2024W(B)WS	2.0 kW	2000 r/min
		176 x 176	HK-ST3524W(B)WS	3.5 kW	2000 r/min
		1/0 X 1/0	HK-ST5024W(B)WS	5.0 kW	2000 r/min
			HK-ST7024W(B)WS	7.0 kW	2000 r/min

Rotary servo motors

Item		Model	Rated output	Rated speed	Reduction ratio	
		HK-ST52(B)G1(H) 1/6	0.5 kW	2000 r/min	1/6	
		HK-ST52(B)G1(H) 1/11	0.5 kW	2000 r/min	1/11	
		HK-ST52(B)G1(H) 1/17	0.5 kW	2000 r/min	1/17	
		HK-ST52(B)G1(H) 1/29	0.5 kW	2000 r/min	1/29	
		HK-ST52(B)G1(H) 1/35	0.5 kW	2000 r/min	1/35	
		HK-ST52(B)G1(H) 1/43	0.5 kW	2000 r/min	1/43	
		HK-ST52(B)G1(H) 1/59	0.5 kW	2000 r/min	1/59	
		HK-ST102(B)G1(H) 1/6	1.0 kW	2000 r/min	1/6	
		HK-ST102(B)G1(H) 1/11	1.0 kW	2000 r/min	1/11	
		HK-ST102(B)G1(H) 1/17	1.0 kW	2000 r/min	1/17	
		HK-ST102(B)G1(H) 1/29	1.0 kW	2000 r/min	1/29	
		HK-ST102(B)G1(H) 1/35	1.0 kW	2000 r/min	1/35	
		HK-ST102(B)G1(H) 1/43	1.0 kW	2000 r/min	1/43	
		HK-ST102(B)G1(H) 1/59	1.0 kW	2000 r/min	1/59	
		HK-ST152(B)G1(H) 1/6	1.5 kW	2000 r/min	1/6	
		HK-ST152(B)G1(H) 1/11	1.5 kW	2000 r/min	1/11	
		HK-ST152(B)G1(H) 1/17	1.5 kW	2000 r/min	1/17	
		HK-ST152(B)G1(H) 1/29	1.5 kW	2000 r/min	1/29	
		HK-ST152(B)G1(H) 1/35	1.5 kW	2000 r/min	1/35	
		HK-ST152(B)G1(H) 1/43	1.5 kW	2000 r/min	1/43	
			1.5 kW		1/59	
-ST series h a gear reducer for neral industrial machines		2.0 kW	2000 r/min	1/6		
		HK-ST202(B)G1(H) 1/6		2000 r/min		
		HK-ST202(B)G1(H) 1/11	2.0 kW	2000 r/min	1/11	
		HK-ST202(B)G1(H) 1/17	2.0 kW	2000 r/min	1/17	
With an electromagnetic	HK-ST_G_	HK-ST202(B)G1(H) 1/29	2.0 kW	2000 r/min	1/29	
ake		HK-ST202(B)G1(H) 1/35	2.0 kW	2000 r/min	1/35	
I: Flange mounting		HK-ST202(B)G1(H) 1/43	2.0 kW	2000 r/min	1/43	
1H: Foot mounting		HK-ST202(B)G1(H) 1/59	2.0 kW	2000 r/min	1/59	
		HK-ST352(B)G1(H) 1/6	3.5 kW	2000 r/min	1/6	
		HK-ST352(B)G1(H) 1/11	3.5 kW	2000 r/min	1/11	
		HK-ST352(B)G1(H) 1/17	3.5 kW	2000 r/min	1/17	
		HK-ST352(B)G1(H) 1/29	3.5 kW	2000 r/min	1/29	
		HK-ST352(B)G1(H) 1/35	3.5 kW	2000 r/min	1/35	
		HK-ST352(B)G1(H) 1/43	3.5 kW	2000 r/min	1/43	
		HK-ST352(B)G1(H) 1/59	3.5 kW	2000 r/min	1/59	
		HK-ST502(B)G1(H) 1/6	5.0 kW	2000 r/min	1/6	
		HK-ST502(B)G1(H) 1/11	5.0 kW	2000 r/min	1/11	
		HK-ST502(B)G1(H) 1/17	5.0 kW	2000 r/min	1/17	
		HK-ST502(B)G1(H) 1/29	5.0 kW	2000 r/min	1/29	
		HK-ST502(B)G1(H) 1/35	5.0 kW	2000 r/min	1/35	
		HK-ST502(B)G1(H) 1/43	5.0 kW	2000 r/min	1/43	
		HK-ST502(B)G1(H) 1/59	5.0 kW	2000 r/min	1/59	
		HK-ST702(B)G1(H) 1/6	7.0 kW	2000 r/min	1/6	
		HK-ST702(B)G1(H) 1/11	7.0 kW	2000 r/min	1/11	
		HK-ST702(B)G1(H) 1/17	7.0 kW	2000 r/min	1/17	
		HK-ST702(B)G1(H) 1/29	7.0 kW	2000 r/min	1/29	
		HK-ST702(B)G1(H) 1/35	7.0 kW	2000 r/min	1/35	
		HK-ST702(B)G1(H) 1/43	7.0 kW	2000 r/min	1/43	
		HK-ST702(B)G1(H) 1/59	7.0 kW	2000 r/min	1/59	

Item		Model	Rated output	Rated speed	Reduction ratio
		HK-ST524(B)G1(H) 1/6	0.5 kW	2000 r/min	1/6
		HK-ST524(B)G1(H) 1/11	0.5 kW	2000 r/min	1/11
		HK-ST524(B)G1(H) 1/17	0.5 kW	2000 r/min	1/17
		HK-ST524(B)G1(H) 1/29	0.5 kW	2000 r/min	1/29
		HK-ST524(B)G1(H) 1/35	0.5 kW	2000 r/min	1/35
		HK-ST524(B)G1(H) 1/43	0.5 kW	2000 r/min	1/43
		HK-ST524(B)G1(H) 1/59	0.5 kW	2000 r/min	1/59
		HK-ST1024(B)G1(H) 1/6	1.0 kW	2000 r/min	1/6
		HK-ST1024(B)G1(H) 1/11	1.0 kW	2000 r/min	1/11
		HK-ST1024(B)G1(H) 1/17	1.0 kW	2000 r/min	1/17
		HK-ST1024(B)G1(H) 1/29	1.0 kW	2000 r/min	1/29
		HK-ST1024(B)G1(H) 1/35	1.0 kW	2000 r/min	1/35
		HK-ST1024(B)G1(H) 1/43	1.0 kW	2000 r/min	1/43
		HK-ST1024(B)G1(H) 1/59	1.0 kW	2000 r/min	1/59
		HK-ST1524(B)G1(H) 1/6	1.5 kW	2000 r/min	1/6
		HK-ST1524(B)G1(H) 1/11	1.5 kW	2000 r/min	1/11
		HK-ST1524(B)G1(H) 1/17	1.5 kW	2000 r/min	1/17
		HK-ST1524(B)G1(H) 1/29	1.5 kW	2000 r/min	1/29
		HK-ST1524(B)G1(H) 1/35	1.5 kW	2000 r/min	1/35
		HK-ST1524(B)G1(H) 1/43	1.5 kW	2000 r/min	1/43
		HK-ST1524(B)G1(H) 1/59	1.5 kW	2000 r/min	1/59
HK-ST series	HK-ST_4_G_	HK-ST2024(B)G1(H) 1/6	2.0 kW	2000 r/min	1/6
Nith a gear reducer for		HK-ST2024(B)G1(H) 1/11	2.0 kW	2000 r/min	1/11
general industrial machines		HK-ST2024(B)G1(H) 1/17	2.0 kW	2000 r/min	1/17
P: With an algotromognotic		HK-ST2024(B)G1(H) 1/29	2.0 kW	2000 r/min	1/29
B: With an electromagnetic prake		HK-ST2024(B)G1(H) 1/35	2.0 kW	2000 r/min	1/35
G1: Flange mounting		HK-ST2024(B)G1(H) 1/43	2.0 kW	2000 r/min	1/43
G1H: Foot mounting		HK-ST2024(B)G1(H) 1/59	2.0 kW	2000 r/min	1/59
		HK-ST3524(B)G1(H) 1/6	3.5 kW	2000 r/min	1/6
		HK-ST3524(B)G1(H) 1/11	3.5 kW	2000 r/min	1/11
		HK-ST3524(B)G1(H) 1/17	3.5 kW	2000 r/min	1/17
		HK-ST3524(B)G1(H) 1/29	3.5 kW	2000 r/min	1/29
		HK-ST3524(B)G1(H) 1/35	3.5 kW	2000 r/min	1/35
		HK-ST3524(B)G1(H) 1/43	3.5 kW	2000 r/min	1/43
		HK-ST3524(B)G1(H) 1/59	3.5 kW	2000 r/min	1/59
		HK-ST5024(B)G1(H) 1/6	5.0 kW	2000 r/min	1/6
		HK-ST5024(B)G1(H) 1/11	5.0 kW	2000 r/min	1/11
		HK-ST5024(B)G1(H) 1/17	5.0 kW	2000 r/min	1/17
		HK-ST5024(B)G1(H) 1/29	5.0 kW	2000 r/min	1/29
		HK-ST5024(B)G1(H) 1/35	5.0 kW	2000 r/min	1/35
		HK-ST5024(B)G1(H) 1/43	5.0 kW	2000 r/min	1/43
		HK-ST5024(B)G1(H) 1/59	5.0 kW	2000 r/min	1/59
		HK-ST7024(B)G1(H) 1/6	7.0 kW	2000 r/min	1/6
		HK-ST7024(B)G1(H) 1/11	7.0 kW	2000 r/min	1/11
		HK-ST7024(B)G1(H) 1/17	7.0 kW	2000 r/min	1/17
		HK-ST7024(B)G1(H) 1/29	7.0 kW	2000 r/min	1/29
		HK-ST7024(B)G1(H) 1/35	7.0 kW	2000 r/min	1/35
		HK-ST7024(B)G1(H) 1/43	7.0 kW	2000 r/min	1/43
		HK-ST7024(B)G1(H) 1/59	7.0 kW	2000 r/min	1/59

Rotary servo motors

		Model	Rated output	Rated speed	Reduction ratio	
	Τ	HK-ST52(B)G5 1/5	0.5 kW	2000 r/min	1/5	
		HK-ST52(B)G5 1/1	1 0.5 kW	2000 r/min	1/11	
		HK-ST52(B)G5 1/2	1 0.5 kW	2000 r/min	1/21	
		HK-ST52(B)G5 1/3	3 0.5 kW	2000 r/min	1/33	
		HK-ST52(B)G5 1/4	5 0.5 kW	2000 r/min	1/45	_
		HK-ST102(B)G5 1/5		2000 r/min	1/5	
		HK-ST102(B)G5 1/1		2000 r/min	1/11	
		HK-ST102(B)G5 1/2		2000 r/min	1/21	
		HK-ST102(B)G5 1/3		2000 r/min	1/33	
		HK-ST102(B)G5 1/4		2000 r/min	1/45	
		HK-ST152(B)G5 1/5		2000 r/min	1/5	
		HK-ST152(B)G5 1/1		2000 r/min	1/11	
		HK-ST152(B)G5 1/2		2000 r/min	1/21	
	HK-ST_G_	HK-ST152(B)G5 1/3		2000 r/min	1/33	
				2000 r/min	1/45	
		HK-ST152(B)G5 1/4 HK-ST202(B)G5 1/5		2000 r/min	1/5	
				2000 r/min	1/11	
		HK-ST202(B)G5 1/1			1/21	
		HK-ST202(B)G5 1/2		2000 r/min		
		HK-ST202(B)G5 1/3		2000 r/min	1/33	
K-ST series		HK-ST202(B)G5 1/4		2000 r/min	1/45	
		HK-ST352(B)G5 1/5		2000 r/min	1/5	
		HK-ST352(B)G5 1/1		2000 r/min	1/11	
		HK-ST352(B)G5 1/2		2000 r/min	1/21	
		HK-ST502(B)G5 1/5		2000 r/min	1/5	
th a flange-output type gear lucer for high precision		HK-ST502(B)G5 1/1		2000 r/min	1/11	
plications, flange mounting		HK-ST702(B)G5 1/5		2000 r/min	1/5	
piloudorio, nurigo mountailg		HK-ST524(B)G5 1/5	0.5 kW	2000 r/min	1/5	
With an electromagnetic		HK-ST524(B)G5 1/1	1 0.5 kW	2000 r/min	1/11	
ake		HK-ST524(B)G5 1/2	1 0.5 kW	2000 r/min	1/21	
		HK-ST524(B)G5 1/3	3 0.5 kW	2000 r/min	1/33	
		HK-ST524(B)G5 1/4	5 0.5 kW	2000 r/min	1/45	
		HK-ST1024(B)G5 1/5	1.0 kW	2000 r/min	1/5	
		HK-ST1024(B)G5 1/1	1 1.0 kW	2000 r/min	1/11	
		HK-ST1024(B)G5 1/2	1 1.0 kW	2000 r/min	1/21	
		HK-ST1024(B)G5 1/3	3 1.0 kW	2000 r/min	1/33	
		HK-ST1024(B)G5 1/4	5 1.0 kW	2000 r/min	1/45	
		HK-ST1524(B)G5 1/5	1.5 kW	2000 r/min	1/5	
		HK-ST1524(B)G5 1/1	1 1.5 kW	2000 r/min	1/11	
		HK-ST1524(B)G5 1/2		2000 r/min	1/21	
	HK-ST_4_G_	HK-ST1524(B)G5 1/3	3 1.5 kW	2000 r/min	1/33	
		HK-ST1524(B)G5 1/4		2000 r/min	1/45	
		HK-ST2024(B)G5 1/5		2000 r/min	1/5	
		HK-ST2024(B)G5 1/1		2000 r/min	1/11	
		HK-ST2024(B)G5 1/2		2000 r/min	1/21	
		HK-ST2024(B)G5 1/3		2000 r/min	1/33	
		HK-ST2024(B)G5 1/4		2000 r/min	1/45	
		HK-ST3524(B)G5 1/5		2000 r/min	1/5	
		HK-ST3524(B)G5 1/5		2000 r/min	1/11	
				2000 r/min 2000 r/min	1/21	— i
		HK-ST3524(B)G5 1/2				
		HK-ST5024(B)G5 1/5 HK-ST5024(B)G5 1/1		2000 r/min 2000 r/min	1/5 1/11	

Item		Model		Rated output	Rated speed	Reduction ratio
		HK-ST52(B)G7	1/5	0.5 kW	2000 r/min	1/5
		HK-ST52(B)G7	1/11	0.5 kW	2000 r/min	1/11
		HK-ST52(B)G7	1/21	0.5 kW	2000 r/min	1/21
		HK-ST52(B)G7	1/33	0.5 kW	2000 r/min	1/33
		HK-ST52(B)G7	1/45	0.5 kW	2000 r/min	1/45
		HK-ST102(B)G7	1/5	1.0 kW	2000 r/min	1/5
		HK-ST102(B)G7	1/11	1.0 kW	2000 r/min	1/11
		HK-ST102(B)G7	1/21	1.0 kW	2000 r/min	1/21
		HK-ST102(B)G7	1/33	1.0 kW	2000 r/min	1/33
		HK-ST102(B)G7	1/45	1.0 kW	2000 r/min	1/45
		HK-ST152(B)G7	1/5	1.5 kW	2000 r/min	1/5
		HK-ST152(B)G7	1/11	1.5 kW	2000 r/min	1/11
		HK-ST152(B)G7	1/21	1.5 kW	2000 r/min	1/21
	HK-ST_G_	HK-ST152(B)G7	1/33	1.5 kW	2000 r/min	1/33
		HK-ST152(B)G7	1/45	1.5 kW	2000 r/min	1/45
		HK-ST202(B)G7	1/5	2.0 kW	2000 r/min	1/5
		HK-ST202(B)G7	1/11	2.0 kW	2000 r/min	1/11
		HK-ST202(B)G7	1/21	2.0 kW	2000 r/min	1/21
		HK-ST202(B)G7	1/33	2.0 kW	2000 r/min	1/33
		HK-ST202(B)G7	1/45	2.0 kW	2000 r/min	1/45
		HK-ST352(B)G7	1/5	3.5 kW	2000 r/min	1/5
		HK-ST352(B)G7	1/11	3.5 kW	2000 r/min	1/11
		HK-ST352(B)G7	1/21	3.5 kW	2000 r/min	1/21
HK-ST series		HK-ST502(B)G7	1/5	5.0 kW	2000 r/min	1/5
Nith a shaft-output type gear		HK-ST502(B)G7	1/11	5.0 kW	2000 r/min	1/11
educer for high precision		HK-ST702(B)G7	1/5	7.0 kW	2000 r/min	1/5
applications, flange mounting			1/5	0.5 kW	2000 r/min	1/5
5 M.C.U. 1. 1. 1. 1.		HK-ST524(B)G7	1/11	0.5 kW	2000 r/min	1/11
3: With an electromagnetic prake		HK-ST524(B)G7	1/11	0.5 kW	2000 r/min	1/21
Jake		HK-ST524(B)G7				1/33
		HK-ST524(B)G7	1/33	0.5 kW 0.5 kW	2000 r/min	1/45
		HK-ST524(B)G7	1/45 1/5	1.0 kW	2000 r/min 2000 r/min	1/45
		HK-ST1024(B)G7	1/5	1.0 kW		1/11
		HK-ST1024(B)G7			2000 r/min	
		HK-ST1024(B)G7	1/21	1.0 kW	2000 r/min	1/21
		HK-ST1024(B)G7	1/33	1.0 kW	2000 r/min	1/33
		HK-ST1024(B)G7	1/45	1.0 kW	2000 r/min	1/45
		HK-ST1524(B)G7	1/5	1.5 kW	2000 r/min	1/5
		HK-ST1524(B)G7	1/11	1.5 kW	2000 r/min	1/11
	HK-ST_4_G_	HK-ST1524(B)G7	1/21	1.5 kW	2000 r/min	1/21
		HK-ST1524(B)G7	1/33	1.5 kW	2000 r/min	1/33
		HK-ST1524(B)G7	1/45	1.5 kW	2000 r/min	1/45
		HK-ST2024(B)G7	1/5	2.0 kW	2000 r/min	1/5
		HK-ST2024(B)G7	1/11	2.0 kW	2000 r/min	1/11
		HK-ST2024(B)G7	1/21	2.0 kW	2000 r/min	1/21
		HK-ST2024(B)G7	1/33	2.0 kW	2000 r/min	1/33
	1	HK-ST2024(B)G7	1/45	2.0 kW	2000 r/min	1/45
	1	HK-ST3524(B)G7	1/5	3.5 kW	2000 r/min	1/5
	1	HK-ST3524(B)G7	1/11	3.5 kW	2000 r/min	1/11
	1	HK-ST3524(B)G7	1/21	3.5 kW	2000 r/min	1/21
	1	HK-ST5024(B)G7	1/5	5.0 kW	2000 r/min	1/5
	1	HK-ST5024(B)G7	1/11	5.0 kW	2000 r/min	1/11
		HK-ST7024(B)G7	1/5	7.0 kW	2000 r/min	1/5

Rotary servo motors

Item		Flange size [mm]	Model	Rated output	Rated speed	
			HK-RT103W(B)	1.0 kW	3000 r/min	
		90 x 90	HK-RT153W(B)	1.5 kW	3000 r/min	
нк	HK-RT W		HK-RT203W(B)	2.0 kW	3000 r/min	
			HK-RT353W(B)	3.5 kW	3000 r/min	
HK-RT series		130 x 130	HK-RT503W(B)	5.0 kW	3000 r/min	
			HK-RT703W(B)	7.0 kW	3000 r/min	
3: With an electromagnetic			HK-RT1034W(B)	1.0 kW	3000 r/min	
orake		90 x 90	HK-RT1534W(B)	1.5 kW	3000 r/min	
	HK-RT 4W		HK-RT2034W(B)	2.0 kW	3000 r/min	
nk-k1_4			HK-RT3534W(B)	3.5 kW	3000 r/min	
		130 x 130	HK-RT5034W(B)	5.0 kW	3000 r/min	
			HK-RT7034W(B)	7.0 kW	3000 r/min	
			HK-RT103W(B)WS	1.0 kW	3000 r/min	
		90 x 90	HK-RT153W(B)WS	1.5 kW	3000 r/min	
	HK-RT W WS		HK-RT203W(B)WS	2.0 kW	3000 r/min	
Servo motors with functional			HK-RT353W(B)WS	3.5 kW	3000 r/min	
safety		130 x 130	HK-RT503W(B)WS	5.0 kW	3000 r/min	
HK-RT series			HK-RT703W(B)WS	7.0 kW	3000 r/min	
			HK-RT1034W(B)WS	1.0 kW	3000 r/min	
B: With an electromagnetic		90 x 90	HK-RT1534W(B)WS	1.5 kW	3000 r/min	
orake	HK-RT 4W WS		HK-RT2034W(B)WS	2.0 kW	3000 r/min	
	nk-k1_4W_W3		HK-RT3534W(B)WS	3.5 kW	3000 r/min	
		130 x 130	HK-RT5034W(B)WS	5.0 kW	3000 r/min	
			HK-RT7034W(B)WS	7.0 kW	3000 r/min	

Linear servo motors

tem	Model	Continuous thrust	Maximum thrust	Maximum speed	Length
	LM-H3P2A-07P-BSS0	70 N	175 N	3.0 m/s	—
	LM-H3P3A-12P-CSS0	120 N	300 N	3.0 m/s	—
	LM-H3P3B-24P-CSS0	240 N	600 N	3.0 m/s	—
	LM-H3P3C-36P-CSS0	360 N	900 N	3.0 m/s	—
M-H3 series rimary side (coil)	LM-H3P3D-48P-CSS0	480 N	1200 N	3.0 m/s	_
	LM-H3P7A-24P-ASS0	240 N	600 N	3.0 m/s	_
	LM-H3P7B-48P-ASS0	480 N	1200 N	3.0 m/s	_
	LM-H3P7C-72P-ASS0	720 N	1800 N	3.0 m/s	_
	LM-H3P7D-96P-ASS0	960 N	2400 N	3.0 m/s	—
	LM-H3S20-288-BSS0	—	—	_	288 mm
	LM-H3S20-384-BSS0	_	_	_	384 mm
	LM-H3S20-480-BSS0	_	_	_	480 mm
	LM-H3S20-768-BSS0	_	_	—	768 mm
	LM-H3S30-288-CSS0	_	_	_	288 mm
И-H3 series	LM-H3S30-384-CSS0	_	_	_	384 mm
econdary side (magnet)	LM-H3S30-480-CSS0	_	_	_	480 mm
	LM-H3S30-768-CSS0	_	1_	1_	768 mm
	LM-H3S70-288-ASS0	_	<u> </u>	1_	288 mm
	LM-H3S70-384-ASS0	_		1_	384 mm
	LM-H3S70-480-ASS0	_			480 mm
	LM-H3S70-768-ASS0	_			768 mm
	LM-AJP1B-07K-JSS0			6.5 m/s	_
	LM-AJP1D-14K-JSS0	136.2 N	429.4 N	6.5 m/s	_
	LM-AJP2B-12S-JSS0	117.0 N	369.0 N	4.0 m/s	
M-AJ series	LM-AJP2D-23T-JSS0	234.0 N	738.1 N	5.0 m/s	_
imary side (coil)	LM-AJP3B-17N-JSS0	174.5 N	550.2 N	2.5 m/s	
	LM-AJP3D-35R-JSS0	348.9 N	1100.4 N	3.5 m/s	
	LM-AJP4B-22M-JSS0	223.4 N	704.5 N	2.0 m/s	
	LM-AJP4D-45N-JSS0	446.8 N	1409.1 N	2.5 m/s	
	LM-AJS10-080-JSS0	440.0 N	1409.111	2.5 11/5	 80 mm
	LM-AJS10-000-JSS0				200 mm
	LM-AJS10-200-JSS0				400 mm
				_	
	LM-AJS20-080-JSS0			_	80 mm
	LM-AJS20-200-JSS0			_	200 mm
M-AJ series econdary side (magnet)	LM-AJS20-400-JSS0		—		400 mm
condary side (magnet)	LM-AJS30-080-JSS0				80 mm
	LM-AJS30-200-JSS0	—	_		200 mm
	LM-AJS30-400-JSS0	—	_		400 mm
	LM-AJS40-080-JSS0	—	_		80 mm
	LM-AJS40-200-JSS0		_	_	200 mm
	LM-AJS40-400-JSS0		—	—	400 mm
	LM-FP2B-06M-1SS0	300 N (natural cooling)/ 600 N (force cooling)	1800 N	2.0 m/s	—
	LM-FP2D-12M-1SS0	600 N (natural cooling)/ 1200 N (force cooling)	3600 N	2.0 m/s	_
M-F series imary side (coil)	LM-FP2F-18M-1SS0	900 N (natural cooling)/ 1800 N (force cooling)	5400 N	2.0 m/s	_
	LM-FP4B-12M-1SS0	600 N (natural cooling)/ 1200 N (force cooling)	3600 N	2.0 m/s	_
	LM-FP4D-24M-1SS0	1200 N (natural cooling)/ 2400 N (force cooling)	7200 N	2.0 m/s	_
	LM-FS20-480-1SS0	_	_	_	480 mm
M-F series	LM-FS20-576-1SS0	_	1_	1_	576 mm
econdary side (magnet)	LM-FS40-480-1SS0	_		1_	480 mm
,	LM-FS40-576-1SS0				576 mm

Linear servo motors

tem	Model	Continuous thrust	Maximum thrust	Maximum speed	Length
	LM-K2P1A-01M-2SS1	120 N	300 N	2.0 m/s	—
	LM-K2P1C-03M-2SS1	360 N	900 N	2.0 m/s	_
_M-K2 series	LM-K2P2A-02M-1SS1	240 N	600 N	2.0 m/s	—
primary side (coil)	LM-K2P2C-07M-1SS1	720 N	1800 N	2.0 m/s	_
Shinary Side (COII)	LM-K2P2E-12M-1SS1	1200 N	3000 N	2.0 m/s	_
	LM-K2P3C-14M-1SS1	1440 N	3600 N	2.0 m/s	_
	LM-K2P3E-24M-1SS1	2400 N	6000 N	2.0 m/s	_
	LM-K2S10-288-2SS1	—	—	—	288 mm
	LM-K2S10-384-2SS1	—	—	—	384 mm
	LM-K2S10-480-2SS1	—	—	—	480 mm
	LM-K2S10-768-2SS1	—	—	—	768 mm
И-K2 series			—	—	288 mm
	LM-K2S20-384-1SS1	—	—	—	384 mm
econdary side (magnet)	LM-K2S20-480-1SS1	_	_	_	480 mm
	LM-K2S20-768-1SS1	_	—	_	768 mm
	LM-K2S30-288-1SS1	_	_	_	288 mm
	LM-K2S30-384-1SS1	_		_	384 mm
	LM-K2S30-480-1SS1	_		_	480 mm
	LM-K2S30-768-1SS1			_	768 mm
	LM-U2PAB-05M-0SS0		 150 N	 2.0 m/s	
	LM-U2PAD-10M-0SS0	100 N	300 N	2.0 m/s	
	LM-U2PAF-15M-0SS0	150 N	450 N	2.0 m/s	
	LM-U2PBB-07M-1SS0	75 N	430 N 225 N	2.0 m/s	
M-U2 series					
rimary side (coil)	LM-U2PBD-15M-1SS0	150 N	450 N	2.0 m/s	
	LM-U2PBF-22M-1SS0	225 N	675 N	2.0 m/s	
	LM-U2P2B-40M-2SS0	400 N	1600 N	2.0 m/s	_
	LM-U2P2C-60M-2SS0	600 N	2400 N	2.0 m/s	—
	LM-U2P2D-80M-2SS0	800 N	3200 N	2.0 m/s	
	LM-U2SA0-240-0SS0	—	—	_	240 mm
	LM-U2SA0-300-0SS0	_	_	_	300 mm
	LM-U2SA0-420-0SS0		—	_	420 mm
M-U2 series	LM-U2SB0-240-1SS1	—	—	—	240 mm
econdary side (magnet)	LM-U2SB0-300-1SS1	—	—	—	300 mm
	LM-U2SB0-420-1SS1	—	—	—	420 mm
	LM-U2S20-300-2SS1	—	—	—	300 mm
	LM-U2S20-480-2SS1	—	—	—	480 mm
	LM-AUP3A-03V-JSS0	28 N	122 N	4.5 m/s	—
	LM-AUP3B-06V-JSS0	57 N	274 N	4.5 m/s	—
	LM-AUP3C-09V-JSS0	85 N	411 N	4.5 m/s	—
	LM-AUP3D-11R-JSS0	113 N	549 N	3.5 m/s	—
M-AU series	LM-AUP4A-04R-JSS0	44 N	280 N	3.5 m/s	—
rimary side (coil)	LM-AUP4B-09R-JSS0	88 N	561 N	3.5 m/s	—
	LM-AUP4C-13P-JSS0	132 N	842 N	3.0 m/s	—
	LM-AUP4D-18M-JSS0	176 N	970 N	2.0 m/s	—
	LM-AUP4F-26P-JSS0	264 N	1684 N	3.0 m/s	—
	LM-AUP4H-35M-JSS0	350 N	1764 N	2.0 m/s	—
	LM-AUS30-120-JSS0	_	<u> </u>		120 mm
	LM-AUS30-180-JSS0	_		_	180 mm
	LM-AUS30-240-JSS0	_		_	240 mm
	LM-AUS30-300-JSS0			_	300 mm
M-AU series	LM-AUS30-600-JSS0				600 mm
econdary side (magnet)	LM-AUS30-600-JSS0				120 mm
	LM-AUS40-120-JSS0				120 mm 180 mm
	LM-AUS40-180-JSS0				240 mm
	LM-AUS40-300-JSS0	—			300 mm
	LM-AUS40-600-JSS0	I-	I-	I—	600 mm

Direct drive motors

Item	Model	Rated torque	Maximum torque	Rated speed
	TM-RG2M002C30	2.2 N•m	8.8 N•m	300 r/min
TM-RG2M series	TM-RG2M004E30	4.5 N•m	13.5 N•m	300 r/min
	TM-RG2M009G30	9 N•m	27 N•m	300 r/min
	TM-RU2M002C30	2.2 N•m	8.8 N•m	300 r/min
TM-RU2M series	TM-RU2M004E30	4.5 N•m	13.5 N•m	300 r/min
	TM-RU2M009G30	9 N•m	27 N•m	300 r/min
	TM-RFM002C20	2 N•m	6 N•m	200 r/min
	TM-RFM004C20	4 N•m	12 N•m	200 r/min
	TM-RFM006C20	6 N•m	18 N•m	200 r/min
	TM-RFM006E20	6 N•m	18 N•m	200 r/min
	TM-RFM012E20	12 N•m	36 N•m	200 r/min
TM-RFM series	TM-RFM018E20	18 N•m	54 N•m	200 r/min
	TM-RFM012G20	12 N•m	36 N•m	200 r/min
	TM-RFM048G20	48 N•m	144 N•m	200 r/min
	TM-RFM072G20	72 N•m	216 N•m	200 r/min
	TM-RFM040J10	40 N•m	120 N•m	100 r/min
	TM-RFM120J10	120 N•m	360 N•m	100 r/min
	TM-RFM240J10	240 N•m	720 N•m	100 r/min

Cables for rotary servo motors

Item	Model	Length	Bending life	IP rating	Application	, poor
	MR-AEPB2CBL2M-A1-H	2 m	Long bending life	IP65		
	MR-AEPB2CBL5M-A1-H	5 m	Long bending life	IP65	HK-KT series	ġ
	MR-AEPB2CBL10M-A1-H	10 m	Long bending life	IP65		Specifications
	MR-AEPB2CBL2M-A1-L	2 m	Standard	IP65	HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead	
	MR-AEPB2CBL5M-A1-L	5 m	Standard	IP65	With electromagnetic brake wires	
	MR-AEPB2CBL10M-A1-L	10 m	Standard	IP65	Ŭ	Controllers
	MR-AEPB2CBL2M-A2-H	2 m	Long bending life	IP65		
	MR-AEPB2CBL5M-A2-H	5 m	Long bending life	IP65	HK-KT series	
	MR-AEPB2CBL10M-A2-H	10 m	Long bending life	IP65		
	MR-AEPB2CBL2M-A2-L	2 m	Standard	IP65	HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead	
	MR-AEPB2CBL5M-A2-L	5 m	Standard	IP65	With electromagnetic brake wires	
	MR-AEPB2CBL10M-A2-L	10 m	Standard	IP65	5	
	MR-AEPB2CBL2M-A5-H	2 m	Long bending life	IP65		
	MR-AEPB2CBL5M-A5-H	5 m	Long bending life	IP65	HK-KT series	
	MR-AEPB2CBL10M-A5-H	10 m	Long bending life	IP65	HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB	
	MR-AEPB2CBL2M-A5-L	2 m	Standard	IP65	With electromagnetic brake wires	
lotor cable	MR-AEPB2CBL5M-A5-L	5 m	Standard	IP65		
lual cable type/	MR-AEPB2CBL10M-A5-L	10 m	Standard	IP65		
irect connection type for 10 m or	MR-AEP2CBL2M-A1-H	2 m	Long bending life	IP65		•
horter)	MR-AEP2CBL5M-A1-H	5 m	Long bending life	IP65	HK-KT series	
	MR-AEP2CBL10M-A1-H	10 m	Long bending life	IP65		
	MR-AEP2CBL2M-A1-L	2 m	Standard	IP65	HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead	
	MR-AEP2CBL5M-A1-L	5 m	Standard	IP65	Without electromagnetic brake wires	
	MR-AEP2CBL10M-A1-L	10 m	Standard	IP65		
	MR-AEP2CBL2M-A2-H	2 m	Long bending life	IP65		•
	MR-AEP2CBL5M-A2-H	5 m	Long bending life	IP65	HK-KT series	
	MR-AEP2CBL10M-A2-H	10 m	Long bending life	IP65		
	MR-AEP2CBL2M-A2-L	2 m	Standard	IP65	HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead	
	MR-AEP2CBL5M-A2-L	5 m	Standard	IP65	Without electromagnetic brake wires	
	MR-AEP2CBL10M-A2-L	10 m	Standard	IP65	······g······	
	MR-AEP2CBL2M-A5-H	2 m	Long bending life	IP65		•
	MR-AEP2CBL5M-A5-H	5 m	Long bending life	IP65	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead	
	MR-AEP2CBL10M-A5-H	10 m	Long bending life	IP65		
	MR-AEP2CBL2M-A5-L	2 m	Standard	IP65		
	MR-AEP2CBL5M-A5-L	5 m	Standard	IP65	Without electromagnetic brake wires	
	MR-AEP2CBL10M-A5-L	10 m	Standard	IP65		

Cables for rotary servo motors

Item	Model	Length	Bending life	IP rating	Application
Motor cable ^(Note 1) (dual cable type/	MR-AEPB2J10CBL03M-A1-L	0.3 m	Standard	IP20	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires
	MR-AEPB2J10CBL03M-A2-L	0.3 m	Standard	IP20	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires
	MR-AEPB2J10CBL03M-A5-L	0.3 m	Standard	IP20	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead With electromagnetic brake wires
junction type for over 10 m)	MR-AEP2J10CBL03M-A1-L	0.3 m	Standard	IP20	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires
	MR-AEP2J10CBL03M-A2-L	0.3 m	Standard	IP20	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires
	MR-AEP2J10CBL03M-A5-L	0.3 m	Standard	IP20	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead Without electromagnetic brake wires
	MR-AEKCBL20M-H	20 m	Long bending life	IP20	
	MR-AEKCBL30M-H	30 m	Long bending life	IP20	1
Encoder cable (Note 2)	MR-AEKCBL40M-H	40 m	Long bending life	IP20	HK-KT series HK-MT series
Encoder Cable '	MR-AEKCBL50M-H	50 m	Long bending life	IP20	HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W
	MR-AEKCBL20M-L	20 m	Standard	IP20	
	MR-AEKCBL30M-L	30 m	Standard	IP20	

Notes:

1. Use this cable in combination with MR-AEKCBL_M-H, MR-AEKCBL_M-L, or MR-ECNM.

2. Use this cable in combination with MR-AEPB2J10CBL03M-_-L or MR-AEP2J10CBL03M-_-L.

Cables for rotary servo motors

Item	Model	Length	Bending life	IP rating	Application	Specificatio
	MR-AEPB2J20CBL03M-A1-L	0.3 m	Standard	IP65	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Load-side lead With electromagnetic brake wires	Specifications
	MR-AEPB2J20CBL03M-A2-L	0.3 m	Standard	IP65	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Opposite to load-side lead With electromagnetic brake wires	Controllers
	MR-AEPB2J20CBL03M-A5-L	0.3 m Standard		IP65	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)WB Vertical lead With electromagnetic brake wires	
dual cable type/ unction type for over 10 m)	MR-AEP2J20CBL03M-A1-L	0.3 m	Standard	IP65	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Load-side lead Without electromagnetic brake wires	Motors
	MR-AEP2J20CBL03M-A2-L	0.3 m	Standard	IP65	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Opposite to load-side lead Without electromagnetic brake wires	
	MR-AEP2J20CBL03M-A5-L	0.3 m	Standard	IP65	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Vertical lead Without electromagnetic brake wires	MOTOLS
Notes: 1. Use this cable in combination wi	th MR-AENSCBL_M-H, MR-AENSC	BL_M-L, or	• MR-J3SCNS.	•	·	Motors

Connector sets for rotary servo motors

Item	Model	Descriptio	on	IP rating	Application	
	MR-J3ENSCBL2M-H	2 m	Long bending life	IP67		
	MR-J3ENSCBL5M-H	5 m	Long bending life	IP67		
	MR-J3ENSCBL10M-H	10 m	Long bending life	IP67	HK-RT353(4)W, 503(4)W, 703(4)W	
	MR-AENSCBL20M-H (Note 1)	20 m	Long bending life	IP67	HK-KT series	
	MR-AENSCBL30M-H (Note 1)	30 m	Long bending life	IP67	HK-MT series	
	MR-AENSCBL40M-H (Note 1)	40 m	Long bending life	IP67	HK-ST series	
	MR-AENSCBL50M-H (Note 1)	50 m	Long bending life	IP67	HK-RT series	
Encoder cable	MR-J3ENSCBL2M-L	2 m	Standard	IP67	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W	
	MR-J3ENSCBL5M-L	5 m	Standard	IP67		
	MR-J3ENSCBL10M-L	10 m	Standard	IP67	HK-K1353(4)W, 503(4)W, 703(4)W	
	MR-AENSCBL20M-L (Note 1)	20 m	Standard	IP67	HK-KT series HK-MT series	
	MR-AENSCBL30M-L (Note 1)	30 m	Standard	IP67	HK-ST series HK-RT series	
	MR-AEPB1CBL2M-A1-H	2 m	Long bending life	IP65		
	MR-AEPB1CBL5M-A1-H	5 m	Long bending life	IP65	HK-KT series	
	MR-AEPB1CBL10M-A1-H	10 m	Long bending life	IP65		
	MR-AEPB1CBL2M-A1-L	2 m	Standard	IP65	HK-RT103(4)WB, 153(4)WB, 203(4)W Load-side lead	
	MR-AEPB1CBL5M-A1-L	5 m	Standard	IP65	With electromagnetic brake wires	
	MR-AEPB1CBL10M-A1-L	10 m	Standard	IP65	3	
	MR-AEPB1CBL2M-A2-H	2 m	Long bending life	IP65		
	MR-AEPB1CBL5M-A2-H	5 m	Long bending life	IP65	HK-KT series	
	MR-AEPB1CBL10M-A2-H	10 m	Long bending life	IP65	HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4)W	
	MR-AEPB1CBL2M-A2-L	2 m	Standard	IP65	Opposite to load-side lead	
	MR-AEPB1CBL5M-A2-L	5 m	Standard	IP65	With electromagnetic brake wires	
	MR-AEPB1CBL10M-A2-L	10 m	Standard	IP65		
	MR-AEPB1CBL2M-A5-H	2 m	Long bending life	IP65		
	MR-AEPB1CBL5M-A5-H	5 m	Long bending life	IP65	HK-KT series HK-MT series HK-RT103(4)WB, 153(4)WB, 203(4 Vertical lead	
	MR-AEPB1CBL10M-A5-H	10 m	Long bending life	IP65		
	MR-AEPB1CBL2M-A5-L	2 m	Standard	IP65		
Aotor cable	MR-AEPB1CBL5M-A5-L	5 m	Standard	IP65	With electromagnetic brake wires	
single cable type/	MR-AEPB1CBL10M-A5-L	10 m	Standard	IP65	_	
lirect connection type for 10 m or	MR-AEP1CBL2M-A1-H	2 m	Long bending life	IP65		
shorter)	MR-AEP1CBL5M-A1-H	5 m	Long bending life	IP65	HK-KT series	
	MR-AEP1CBL10M-A1-H	10 m	Long bending life	IP65	HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W	
	MR-AEP1CBL2M-A1-L	2 m	Standard	IP65	Load-side lead	
	MR-AEP1CBL5M-A1-L	5 m	Standard	IP65	Without electromagnetic brake wires	
	MR-AEP1CBL10M-A1-L	10 m	Standard	IP65		
	MR-AEP1CBL2M-A2-H	2 m	Long bending life	IP65		
	MR-AEP1CBL5M-A2-H	5 m	Long bending life	IP65	HK-KT series HK-MT series	
	MR-AEP1CBL10M-A2-H	10 m	Long bending life	IP65	HK-RT103(4)W, 153(4)W, 203(4)W	
	MR-AEP1CBL2M-A2-L	2 m	Standard	IP65	Opposite to load-side lead	
	MR-AEP1CBL5M-A2-L	5 m	Standard	IP65	Without electromagnetic brake wires	
	MR-AEP1CBL10M-A2-L	10 m	Standard	IP65		
	MR-AEP1CBL2M-A5-H	2 m	Long bending life	IP65		
	MR-AEP1CBL5M-A5-H	5 m	Long bending life	IP65	HK-KT series HK-MT series	
	MR-AEP1CBL10M-A5-H	10 m	Long bending life	IP65	HK-RT103(4)W, 153(4)W, 203(4)W	
	MR-AEP1CBL2M-A5-L	2 m	Standard	IP65	Vertical lead Without electromagnetic brake wires	
	MR-AEP1CBL5M-A5-L	5 m	Standard	IP65		
	MR-AEP1CBL10M-A5-L	10 m	Standard	IP65		
Encoder cable	MR-EKCBL2M-H	2 m	Long bending life	IP20	Connecting a load-side encoder	
	MR-EKCBL5M-H	5 m	Long bending life	IP20		
lunction cable or fully closed loop control	MR-J4FCCBL03M	0.3 m	Standard	_	Branching a load-side encoder	

Notes:

1. When using this cable for HK-KT/HK-MT/HK-RT (1.0 kW to 2.0 kW), use it in combination with MR-AEPB2J20CBL03M-_-L or MR-AEP2J20CBL03M-_-L.

Connector sets for rotary servo motors

Item	Model	Description	IP rating	Application	Specif
	MR-ECNM ^(Note 1)	Encoder connector × 1 Servo amplifier connector × 1	IP20	HK-KT series HK-MT series HK-RT103(4)W, 153(4)W, 203(4)W Connecting a load-side encoder	Specifications
	MR-J3SCNS ^(Note 2)	R-J3SCNS ^(Note 2) Junction connector or encoder connector × 1 Servo amplifier connector × 1		HK-KT series HK-MT series HK-ST series HK-RT series (one-touch connection type)	Controllers
Encoder connector set	MR-ENCNS2	Encoder connector × 1 Servo amplifier connector × 1	IP67	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W (straight type) (screw type)	Servo
	MR-J3SCNSA	Encoder connector × 1 Servo amplifier connector × 1	IP67	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W (angle type) (one-touch connection type)	Servo Amplifiers
	MR-ENCNS2A	Encoder connector × 1 Servo amplifier connector × 1	IP67	HK-ST series HK-RT353(4)W, 503(4)W, 703(4)W (angle type) (screw type)	
	MR-APWCNS4	Power connector × 1	IP67	HK-ST52(4)(W), 102(4)(W), 172(4)W, 202(4)AW, 302(4)W, 353(4)W, 503(4)W ^(Note 3) (one-touch connection type)	Motors
Power connector set	MR-APWCNS5	Power connector × 1	IP67	HK-ST7M2UW, 172UW, 202(4)(W), 352(4)(W), 502(4)(W), 702(4)(W) HK-RT353(4)W, 503(4)W, 703(4)W (one-touch connection type)	Motors
	MR-BKCNS1	Electromagnetic brake connector × 1	IP67	HK-ST series HK-RT353(4)WB, 503(4)WB, 703(4)WB (straight type) (one-touch connection type)	
Electromagnetic brake connector set	MR-BKCNS2	Electromagnetic brake connector × 1	IP67	HK-ST series HK-RT353(4)WB, 503(4)WB, 703(4)WB (straight type) (screw type)	Motors
	MR-BKCNS1A	Electromagnetic brake connector × 1	IP67	HK-ST series HK-RT353(4)WB, 503(4)WB, 703(4)WB (angle type) (one-touch connection type)	Equipment
	MR-BKCNS2A	Electromagnetic brake connector × 1	IP67	HK-ST series HK-RT353(4)WB, 503(4)WB, 703(4)WB (angle type) (screw type)	It Ida
Encoder connector set	MR-J3CN2	Servo amplifier connector × 1	_	Connecting a load side encoder	LVS/Wires
Connector set	MR-J3THMCN2	Junction connector × 2 Servo amplifier connector × 1	_	Branching a load-side encoder	Nires

Notes:

1. When using this connector set for HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series, use it in combination with MR-AEPB2J10CBL03M- -L or MR-AEP2J10CBL03M- -L.

2. When using this connector set for HK-KT series/HK-MT series/HK-RT (1.0 kW to 2.0 kW) series, use it in combination with MR-AEPB2J20CBL03M-_-L or MR-AEP2J20CBL03M-_-L.

3. When using HK-ST503W for a machine that is required to comply with UL/CSA standards, do not use MR-APWCNS4. Use a cable (SC-PWC403C_M-SBLL or SC-PWC403C_M-SBLH) manufactured by Mitsubishi Electric System & Service Co., Ltd., and fabricate an extension cable with wires of AWG 10. For details of SC-PWC403C_M-SBLL and SC-PWC403C_M-SBLH, please contact Mitsubishi Electric System & Service Co., Ltd. OVERSEAS SERVICE SECTION. (Email: osb.webmaster@melsc.jp) Product List

Cables and connector sets for linear servo motors

Item	Model	Description		IP rating	Application
Encoder cable	MR-EKCBL2M-H	2 m	Long bending life	IP20	Connecting a linear encoder
	MR-EKCBL5M-H	5 m	Long bending life	IP20	
Junction cable for linear servo motors	MR-J4THCBL03M	0.3 m Standard		_	Branching a thermistor
Encoder connector set	MR-ECNM	-	onnector × 1 lifier connector × 1	IP20	Connecting a linear encoder
	MR-J3CN2	Servo amplifier connector × 1			Connecting a linear encoder or a thermistor
Connector set	MR-J3THMCN2	Junction connector × 2 Servo amplifier connector × 1			Branching a thermistor

Connector sets for direct drive motors

Item	Model	Description	IP rating	Application
Encoder connector set	MR-J3DDCNS	Encoder connector or absolute position storage unit connector × 1 Servo amplifier connector × 1	IP67	TM-RG2M series TM-RU2M series TM-RFM series (For connecting a direct drive motor and a servo amplifier, or an absolute position storage unit and a servo amplifier)
	MR-J3DDSPS	Encoder connector × 1 Absolute position storage unit connector × 1	IP67	TM-RG2M series TM-RU2M series TM-RFM series (For connecting a direct drive motor and an absolute position storage unit)
Dawar connector oct	MR-PWCNF	Power connector × 1	IP67	TM-RG2M series TM-RU2M series TM-RFM_C20 TM-RFM_E20
Power connector set	MR-PWCNS4	Power connector × 1	IP67	TM-RFM_G20
	MR-PWCNS5	Power connector × 1		TM-RFM040J10, TM-RFM120J10
	MR-PWCNS3	Power connector × 1	IP67	TM-RFM240J10

Connectors for servo amplifiers/drive units

Item	Model	Description	IP rating	Application (Note 1)	Com Specifi
Connector set	MR-CCN1	Servo amplifier connector × 1		MR-J5G_/MR-J5B_	nmon ications
	MR-J2CMP2	Servo amplifier connector × 1		MR-J5W - G/MR-J5W - B	tion
	MR-ECN1	Servo amplifier connector × 20	NIK-J5WG/MR-J5WB		Ω.
Connector set	MR-ADCN3	Drive unit connector × 1	—	MR-J5DG4	
	MR-J3CN1	Servo amplifier connector × 1	—	MR-J5A_	C e
	MR-CVCN24S	Power regeneration converter unit connector × 1	—	MR-CV_	in vo
SSCNET III cable	es/SSCNET III connecto	pr set			ervo System Controllers
Item	Model	Length Bending life	Applic	ation	_ >

SSCNET III cables/SSCNET III connector set

Item	Model	Length	Bending life	Application	
	MR-J3BUS015M	0.15 m	Standard	MR-J5B_/MR-J5WB	S
SSCNET III cable	MR-J3BUS03M	0.3 m	Standard	MR-J5B_/MR-J5WB	er
(standard cord inside cabinet)	MR-J3BUS05M	0.5 m	Standard	MR-J5B_ /MR-J5WB	O A
compatible with SSCNET III/H	MR-J3BUS1M	1 m	Standard	MR-J5B_/MR-J5WB	ģ
	MR-J3BUS3M	3 m	Standard	MR-J5B_ /MR-J5WB	olifie
SSCNET III cable	MR-J3BUS5M-A	5 m	Standard	MR-J5B_ /MR-J5WB	Brs
(standard cable outside cabinet)	MR-J3BUS10M-A	10 m	Standard	MR-J5B_/MR-J5WB	
compatible with SSCNET III/H	MR-J3BUS20M-A	20 m	Standard	MR-J5B_ /MR-J5WB	Ro
SSCNET III cable (long distance cable) compatible with SSCNET III/H	MR-J3BUS30M-B	30 m	Long bending life	MR-J5B_/MR-J5WB	
	MR-J3BUS40M-B	40 m	Long bending life	MR-J5B_ /MR-J5WB	e -
	MR-J3BUS50M-B	50 m	Long bending life	MR-J5B_/MR-J5WB	Serv
SSCNET III connector set compatible with SSCNET III/H	MR-J3BCN1	_	—	MR-J5B_/MR-J5WB	0

Bus bars

Item	Model	Length	Application (Note 1)
	MR-DCBAR077-B02	—	Connecting between power regeneration converter unit and drive unit,
	MR-DCBAR092-B02	—	and between drive units
Bus bar	MR-DCBAR097-B02	—	
Bus bai	MR-DCBAR112-B02	—	Connecting between power regeneration converter unit and drive unit
	MR-DCBAR099-B03	—	
	MR-DCBAR114-B03	—	
Adjustment bar (Note 2)	MR-DCBAR024-B05	—	-

Junction terminal blocks/Junction terminal block cables

Junction terminal blocks	s/Junction terminal b	DIOCK Cabi	es	0
Item	Model	Length	Application (Note 1)	E
Junction terminal block (26 pins)	MR-TB26A	—	MR-J5WG/MR-J5WB	:qui
Junction terminal block (50 pins)	MR-TB50	—	MR-J5A_	tions/Periph Equipment
	MR-J2HBUS05M	0.5 m		iphe ent
	MR-J2HBUS1M	1 m	Connecting MR-J5G_/MR-J5B_ and PS7DW-20V14B-F	
	MR-J2HBUS5M	5 m		
Junction terminal block cable	MR-TBNATBL05M	0.5 m	Connecting MR-J5WG/MR-J5WB and MR-TB26A	
	MR-TBNATBL1M	1 m		
	MR-J2M-CN1TBL05M	0.5 m		
	MR-J2M-CN1TBL1M	1 m	Connecting MR-J5A_ and MR-TB50	lirea

Batteries/Battery cases/Battery cables

Item	Model	Length	Application (Note 1)	υ	
Battery	MR-BAT6V1SET	—	MR-J5- G /MR-J5- B /MR-J5- A	n od	
	MR-BAT6V1SET-A	—	MR-JJG_MR-JJB_MR-JJA_	uct	
	MR-BAT6V1	—	MR-BAT6V1SET, MR-BAT6V1SET-A, MR-BT6VCASE	List	
Battery case	MR-BT6VCASE	—	MR-J5G_/MR-J5WG/MR-J5B_/MR-J5WB/MR-J5A		
Battery cable	MR-BT6V1CBL03M	0.3 m	Connecting MR-J5G_/MR-J5WG/MR-J5B_/MR-J5WB/MR-J5A with MR-BT6VCASE		
Battery cable	MR-BT6V1CBL1M	1 m			
lunction botton/ apple	MR-BT6V2CBL03M	0.3 m			
Junction battery cable	MR-BT6V2CBL1M	1 m	MR-J5G_/MR-J5WG/MR-J5B_/MR-J5WB/MR-J5A		
Notes: 1 Note that options/peripheral	equipment necessary for servo amr	olifiers with spe	cial specifications are the same as those for standard servo amplifiers.	tions	

1. Note that options/peripheral equipment necessary for servo amplifiers with special specifications are the same as those for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

2. When an even number of MR-J5D_-G4 drive units is connected to the power regeneration converter unit, use the adjustment bars. Each of the bar models in the table includes a set of two bus bars.

Support

Linear Servo Motors

Direct Drive Motors

Regenerative options

Item	Model	Permissible regenerative power	Resistance value	Application (Note 1)
	MR-RB032	30 W	40 Ω	MR-J5-10G/B/A to 60G/B/A
	MR-RB12	100 W	40 Ω	MR-J5-20G/B/A to 60G/B/A
	MR-RB14	100 W	26 Ω	MR-J5-70G/B/A, 100G/B/A MR-J5W2-22G/B, 44G/B MR-J5W3-222G/B, 444G/B
	MR-RB30	300 W	13 Ω	MR-J5-200G/B/A
	MR-RB3N	300 W	9 Ω	MR-J5-350G/B/A MR-J5W2-77G/B, 1010G/B
Regenerative option (200 V)	MR-RB31	300 W	6.7 Ω	MR-J5-500G/B/A
	MR-RB3Z	300 W	5.5 Ω	MR-J5-700G/B/A
	MR-RB34	300 W	26 Ω	MR-J5-70G/B/A, 100G/B/A MR-J5W3-222G/B, 444G/B
	MR-RB50	500 W	13 Ω	MR-J5-200G/B/A
	MR-RB5N	500 W	9 Ω	MR-J5-350G/B/A
	MR-RB51	500 W	6.7 Ω	MR-J5-500G/B/A
	MR-RB5Z	500 W	5.5 Ω	MR-J5-700G/B/A
	MR-RB1H-4	100 W	82 Ω	MR-J5-60G4/B4/A4, 100G4/B4/A4
	MR-RB3M-4	300 W	120 Ω	MR-J5-60G4/B4/A4, 100G4/B4/A4
	MR-RB3G-4	300 W	47 Ω	MR-J5-200G4/B4/A4
	MR-RB3Y-4	300 W	36 Ω	MR-J5-350G4/B4/A4
Regenerative option (400 V)	MR-RB34-4	300 W	26 Ω	MR-J5-500G4/B4/A4
	MR-RB3U-4	300 W	22 Ω	MR-J5-700G4/B4/A4
	MR-RB5G-4	500 W	47 Ω	MR-J5-200G4/B4/A4
	MR-RB5Y-4	500 W	36 Ω	MR-J5-350G4/B4/A4
	MR-RB54-4	500 W	26 Ω	MR-J5-500G4/B4/A4
	MR-RB5U-4	500 W	22 Ω	MR-J5-700G4/B4/A4

Peripheral units

Item	Model	Application (Note 1)			
Safety logic unit	MR-J3-D05	MR-J5G_/MR-J5WG/MR-J5DG4/MR-J5B_/MR-J5WB/MR-J5A_			
Absolute position storage unit	MR-BTAS01	MR-J5G/MR-J5WG/MR-J5B/MR-J5WB/MR-J5A			
	MR-J5-FAN1	MR-J5-70G/B/A, 100G/B/A			
	MR-J5-FAN6	MR-J5-200G_/B_/A_, 350G_/B_/A_			
	MR-J5-FAN3	MR-J5-500G/B/A			
	MR-J5-FAN4	MR-J5-700G/B/A			
	MR-J5-FAN7	MR-J5-500G4/B4/A4, 700G4/B4/A4			
Replacement fan unit	MR-J5W-FAN1	MR-J5W2-44G/B			
Replacement fan unit	MR-J5W-FAN3	MR-J5W2-77G/B, 1010G/B			
	MR-J5W-FAN2	MR-J5W3-222G/B, 444G/B			
	MR-J5D-FAN1	MR-J5D1-500G4, 700G4 MR-J5D2-200G4, 350G4 MR-J5D3-200G4			
	MR-J5D-FAN2	MR-J5D2-500G4, 700G4			
	MR-AL-11K4	MR-CV11K4			
	MR-AL-18K4	MR-CV18K4			
	MR-AL-30K4	MR-CV30K4			
AC reactor	MR-AL-37K4	MR-CV37K4			
	MR-AL-45K4	MR-CV45K4			
	MR-AL-55K4	MR-CV55K4			
	MR-AL-75K4	MR-CV75K4			

Notes:

1. Note that options/peripheral equipment necessary for servo amplifiers with special specifications are the same as those for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

Peripheral cables/connector sets

Item	Model	Length	Application (Note 1)		èpe c
Personal computer communication cable (USB cable)	MR-J3USBCBL3M	3 m	MR-J5G_/MR-J5WG/MR-J5DG4/ MR-J5B_/MR-J5WB/MR-J5A_		Specifications
Monitor cable	MR-ACN6CBL1M	1 m	MR-J5G_/MR-J5A_		0
	MR-J3CN6CBL1M	1 m	MR-J5WG		
Analog monitor and A/B/Z-phase pulse output cable	MR-AHSCN7CBL2M10M	10 m/ 2 m	MR-J5G4-HS		Controllers
STO cable	MR-D05UDL3M-B	3 m	Connecting MR-J3-D05 or a safety control device with MR-J5G_/MR-J5WG/MR-J5DG4/MR-J5B_/MR-J5WB/MR-J5A_		rollers
	MR-ACDL02M	0.2 m	Connecting between power regeneration converter unit and drive unit		(0)
Protection coordination cable	MR-ACDL05M	0.5 m	Connecting between power regeneration converter unit and drive unit		
	MR-ADDL02M	0.2 m	Connecting between drive units		Servo /
Daisy chain power connector	MR-J5CNP12-J1	_	MR-J5-10G/B/A to MR-J5-100G/B/A MR-J5W2-22G/B, MR-J5W2-44G/B MR-J5W3-222G/B, and MR-J5W3-444G/B		Amplifiers
	MR-J5CNP12-J2	—	MR-J5-200G/B/A MR-J5W2-77G/B, 1010G/B		
Peripheral attachment	ts	-			Motors
Item	Model	Descripti	on	Application (Note 1)	s
		Compone	ents (1 pc.)	MR-J5-10G_/B_/A_ to 350G_/B_/A_	0

Peripheral attachments

Item	Model	Description	Application (Note 1)	rs I
Cabinet-mounting attachment J5-CHP07-10P		Components (1 pc.) Attachment × 1 Flat head screw (M4 × 10) × 1 Packing quantity: 10 pcs./packing	MR-J5-10G_/B_/A_ to 350G_/B_/A_ MR-J5WG/B MR-CM3K	5
Grounding terminal attachment	J5-CHP08	Attachment × 1 Cable clamp × 2 Screw (M4 × 12) × 4	MR-J5-10G_/B_/A_ to 350G_/B_/A_	Motors
Shield clamp attachment	MR-ASCHP06	Attachment × 1 Cable clamp × 2 Flat head screw (M4) × 2	MR-J5-500G4/B4/A4, 700G4/B4/A4	Motors
Mounting attachment	MR-ADCACN090	Attachment × 1	MR-CV11K4, 18K4	Motors
(Power regeneration converter unit	MR-ADCACN150	Attachment × 1	MR-CV30K4 to 45K4	ors
attachment)	MR-ADCACN300	Attachment × 1	MR-CV55K4 to 75K4	é
Mounting attachment (Drive unit attachment)	MR-ADACN060	Attachment × 1	MR-J5D1-100G4 to 700G4, MR-J5D2-100G4 to 350G4, MR-J5D3-100G4, 200G4	Equipment
	MR-ADACN075	Attachment × 1	MR-J5D2-500G4, 700G4	Equipment
	MR-J5DCASE01	Side protection cover × 1	MR-J5D - G4	T e

1. Note that options/peripheral equipment necessary for servo amplifiers with special specifications are the same as those for standard servo amplifiers. Refer to the servo amplifiers with the same rated output.

LVS/Wires

Product List

Precautions

Engineering software

Item	Model	Application
MELSOFT iQ Works	SW2DND-IQWK-E	FA engineering software
MELSOFT GX Works3	SW1DND-GXW3-E	Programmable controller engineering software (including motion control setting)
MELSOFT MT Works2	SW1DND-MTW2-E	Motion controller engineering software
MELSOFT MR Configurator2 (Note1)	SW1DNC-MRC2-E	Servo engineering software

Notes:

1. MR Configurator2 can be obtained by either of the following:

• Purchase MR Configurator2 alone.

• Purchase GX Works3 or MT Works2: MR Configurator2 is included in GX Works3 and MT Works2 with software version 1.34L or later.

Product List

MEMO	S
	Common Specifications
	Servo System Controllers
	Servo Amplifiers
	Rotary Servo Motors
	Linear Servo Motors
	Direct Drive Motors
	Options/Peripheral Equipment

LVS/Wires

Product List

Precautions

Support

For your safety

- To use the products given in this catalog safely, read the User's Manuals and the appended document prior to use.
- In this catalog, the safety instruction levels are classified into "WARNING" and "CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.

Indicates that incorrect handling may cause hazardous conditions, resulting in medium or slight injury.

Note that the CAUTION level may lead to a serious consequence depending on conditions.

Please follow the instructions of both levels because they are important to personnel safety.

In the following precautions, a term of servo amplifier includes a combination of a drive unit and a converter unit.

Safety instructions

[Wiring]

- To prevent an electric shock, turn off the servo amplifier power and wait for 15 minutes or more before starting wiring and/or inspection. For the drive unit, wait for 20 minutes or more before starting wiring and/or inspection.
- To prevent an electric shock, ground the servo amplifier.
- To prevent an electric shock, any person who is involved in wiring should be fully competent to do the work.
- To prevent an electric shock, mount the servo amplifier and the servo motor before wiring.
- To prevent an electric shock, connect the grounding wire to the cabinet protective earth (PE) terminal via the servo amplifier protective earth (PE) terminal.
- To prevent an electric shock, do not touch the conductive parts.
- To prevent an electric shock and burn injury, do not operate the servo amplifier and the servo motor with wet hands.

[Operation]


• To prevent an electric shock and burn injury, do not operate the servo amplifier and the servo motor with wet hands.

[Maintenance]

- To prevent an electric shock, any person who is involved in wiring should be fully competent to do the work.
- To prevent an electric shock and burn injury, do not operate the servo amplifier and the servo motor with wet hands.

[Transportation/installation]

- To prevent injury, transport the products correctly according to their mass.
- To prevent injury, do not touch the sharp edges of the servo motor, shaft keyway, or others with bare hands when handling the servo motor.
- For the linear servo motor, attraction force is generated between the permanent magnet on the secondary side and the magnetic materials. To prevent injury to fingers and other body parts due to the attraction force between the secondary side and the magnetic material side, take special care in handling the linear servo motor.



[Operation]

 To prevent injury, do not touch the rotor of the servo motor during operation.

[Disposal of linear servo motors]

• To prevent burn injury, do not touch the secondary side after the demagnetization of the secondary side by heating over 300 °C until it becomes cool enough.

Suppor


For proper use

- To use the products given in this catalog properly, read the User's Manuals and the appended document prior to use.
- In this catalog, instructions for incorrect handling which may cause physical damage, instructions for other functions, and so on are classified into "NOTICES".
- In the following precautions, a term of servo amplifier includes a combination of a drive unit and a converter unit.

INOTICES

[Model selection]

- Select a rotary servo motor or a direct drive motor which has the rated torque equal to or higher than the continuous effective torque.
- Select a linear servo motor which has the continuous thrust equal to or higher than the continuous effective load thrust.
- When the linear servo motor is used for vertical axis, it is necessary to have an anti-drop mechanism using springs and counter balances in the machine side.
- For the system where the unbalanced torque occurs, such as a vertical axis, the unbalanced torque of the machine should be kept at 70 % or lower of the rated torque.
- Create operation patterns by considering the settling time (ts) to complete positioning.
- Load to motor inertia ratio or load to mass ratio must be below the recommended ratio. If the ratio is too large,



the expected performance may not be achieved, and the dynamic brake may be damaged.

• Use the servo motor with the specified servo amplifier.

[Transportation/installation]

- To prevent a malfunction, do not drop or strike the servo amplifier and servo motor.
- When fumigants that contain halogen materials, such as fluorine, chlorine, bromine, and iodine, are used for disinfecting and protecting wooden packaging from insects, they cause a malfunction when entering our products. Please take necessary precautions to ensure that any residual materials from fumigant do not enter our products, or perform disinfection and pest control using methods other than fumigation, such as heat treatment. Perform disinfection and pest control at timbering stage before packing the products.
- Do not get on or place heavy objects on the servo amplifier or the servo motor.
- The system must withstand high speeds and high acceleration/ deceleration.
- To enable high-accuracy positioning, ensure the machine rigidity, and keep the machine resonance point at a high level.
- Install the servo amplifier and the servo motor on incombustible material. Installing them directly or close to combustibles will lead to smoke or a fire. In addition, the servo amplifier must be installed in a metal cabinet.
- The regenerative option becomes hot (the temperature rise of 100 °C or higher) with frequent use. Do not install within combustibles or objects subject to thermal deformation. Make sure that wires do not come into contact with the unit.
- Securely fix the servo motor onto the machine. If attached insecurely, the motor may come off during operation.
- Install electrical and mechanical stoppers at the stroke end.
- Mount the servo amplifier on a perpendicular wall in the correct vertical direction.

- To prevent a malfunction, do not block the intake and exhaust areas of the servo amplifier.
- When installing multiple servo amplifiers in a row in a sealed cabinet, leave space around the servo amplifiers as described in User's Manuals. To ensure the service life and reliability of the servo amplifiers, prevent heat accumulation by keeping space as open as possible toward the top plate.
- Do not disassemble, repair, or modify the product.

[Environment]

- Use the servo amplifier and the servo motor in the designated environment.
- Avoid installing the servo amplifier and the servo motor in areas with oil mist or dust. When installing in such areas, enclose the servo amplifier in a sealed cabinet, and protect the servo motor by furnishing a cover or by taking similar measures.
- In the condition where cutting fluid or lubricating oil are constantly applied, and condensation occurs due to excessive humidity, continuous operation of the servo motor for a long period of time may result in the deterioration on the insulation of the servo motor. Provide measures such as oil proof, dust proof cover, and dew condensation prevention to protect the servo motor.
- To prevent a malfunction or a failure, do not use the servo system products under a strong electric field, magnetic field, or radiation environment.

[Wiring]

- To prevent a fire, use a molded-case circuit breaker or a fuse for the main circuit power supply (L1/L2/L3) of the servo amplifier.
- Connect a magnetic contactor between the power supply and the main circuit power supply (L1/L2/L3) of the servo amplifier so that the main circuit power supply can be shut off when a malfunction or an alarm occurs in the servo amplifier.
- The grounding must be connected to prevent faults such as a position mismatch.
- Do not supply power to the output terminals (U/V/W) of the servo amplifier or the input terminals (U/V/W) of the servo motor.
 Doing so damages the servo amplifier and the servo motor.
- To prevent abnormal operation and malfunction, connect the servo amplifier power outputs (U/V/W) to the servo motor power inputs (U/V/W) directly. Do not connect a magnetic contactor and others between them.
- The phases (U/V/W) of the servo amplifier power outputs and the phases (U/V/W) of the servo motor power inputs should match with each other.
- Check the wiring and sequence program thoroughly before switching the power on.
- Carefully select the cable clamping method, and make sure that bending stress and the stress of the cable's own weight are not applied on the cable connection section.
- In an application where the servo motor moves, determine the cable bending radius based on the cable bending life and wire type.
- To prevent malfunction, avoid bundling the servo amplifier's power lines (input/output) and signal cables together or running them in parallel to each other. Separate the power lines from the signal cables.
- Do not apply excessive tension on the cable when cabling.

- The minimum bending radius of the SSCNET III cable is 25 mm for MR-J3BUS_M and 50 mm for MR-J3BUS_M-A/-B. If using these cables under the minimum bending radius, performance cannot be guaranteed.
- If the ends of the SSCNET III cable are dirty, the light will be obstructed, causing malfunctions. Keep the ends clean.
- Do not tighten the SSCNET III cable with cable ties, etc.
- Do not look at the light directly when the SSCNET III cable is not connected.

[Initial settings]

- For MR-J5-A_, select a control mode from position, speed or torque with [Pr. PA01.0]. Position control mode is set as default. Change the parameter setting value when using the other control modes. For MR-J5_-G_ and MR-J5_-B_, the control mode is set by the controller.
- When using the regenerative option, change [Pr. PA02.0-1]. The regenerative option is disabled as default.

[Operation]

- Do not use a product which is damaged or has missing parts. In that case, replace the product.
- Turn on the stroke limit signals (FLS/RLS), or the stroke end signals (LSP/LSN) in position or speed control mode. The servo motor will not start if the signals are off.
- When a magnetic contactor is installed on the primary side of the servo amplifier, do not perform frequent starts and stops with the magnetic contactor. Doing so may damage the servo amplifier.
- Do not use the dynamic brake to stop in a normal operation as it is the function to stop in emergency.
- Note that the number of operation times of the dynamic brake is limited. For example, when a machine operates at the recommended load to motor inertia ratio or less and decelerates from the rated speed to a stop once in 10 minutes, the estimated number of operation times is 1000.
- If the protective functions of the servo amplifier activate, turn the power off immediately. Remove the cause before turning the power on again.
- The servo amplifier, the regenerative resistor, and the servo motor can be very hot. Take safety measures such as covering them.
 In addition, do not directly touch the servo amplifier, the regenerative resistor, and the servo motor during or right after operation.

[Maintenance]

- When an error occurs, ensure safety by turning the power off, etc., before dealing with the error. Otherwise, it may cause an accident.
- Before wiring or inspection, turn off the power, wait for 15 minutes or more until the charge light turns off, and then check the voltage between P+ and N- with a voltage tester. For the drive unit, turn off the power, wait for 20 minutes or more until the charge light turns off, and then check the voltage between L+ and L- with a voltage tester.
- In a maintenance inspection, make sure that the emergency stop circuit operates properly such that an operation can be stopped immediately and a power can be shut off by the emergency stop switch.

[Use of rotary servo motors and direct drive motors]

- To prevent a malfunction on the encoder, do not apply shocks, e.g. hit with a hammer, when coupling the shaft end of the rotary drive motor.
- When mounting a pulley to the rotary servo motor with a keyed shaft, use the screw hole in the shaft end.
- When removing the pulley, use a pulley remover to protect the shaft from excessive load and impact.
- Do not apply a load exceeding the tolerable load onto the rotary servo motor shaft or the direct drive motor rotor. The shaft or the rotor may break.
- When the rotary servo motor is mounted with the shaft vertical (shaft up), provide measures so that the servo motor is not exposed to oil and water entering from the machine side, gear box, etc.
- Mount the rotary servo motor in the specified direction.
- When the direct drive motor is used in a machine such as vertical axis which generates unbalanced torque, use it in absolute position detection system.
- Do not use the 24 V DC interface power supply for the electromagnetic brake. To prevent malfunction, use the power supply designed exclusively for the electromagnetic brake.
- Do not apply the electromagnetic brake when the servo is on. Doing so may cause the servo amplifier overload or shorten the brake life. Apply the electromagnetic brake when the servo is off.
- Torque may drop due to temperature increase of the rotary servo motor or the direct drive motor. Use the motor within the specified ambient temperature.
- The temperature rise of the rotary servo motors and the direct drive motors varies depending on the installation environment and the operation conditions. Conduct a test run on the servo motors before an actual operation to make sure that no alarm occurs.

[Use of linear encoders]

• When the linear encoder is incorrectly installed, an alarm or a position mismatch may occur. In this case, refer to the following checking points for the linear encoder to check the mounting condition.

- Checking points for the linear encoder
 - (a) Check that the gap between the head and scale is proper.
 - (b) Check the scale head for rolling and yawing (decrease in rigidity of scale head section).
 - (c) Check the scale surface for dust and scratches.
 - (d) Check that the vibration and temperature are within the specified range.
 - (e) Check that the speed is within the permissible range without overshooting.

[Use of linear servo motors]

- The linear servo system uses powerful magnets on the secondary side. Magnetic force is inversely proportional to the square of the distance from the magnetic material. Therefore, the magnetic force will be significantly stronger as closer to the magnetic material. When mounting the secondary side of linear servo motor, ensure the sufficient distance from the magnetic bodies around it and securely fix those magnetic bodies.
- One who uses a medical device like a pacemaker must keep away from the product and equipment.
- Do not wear metals such as watches, pierced earrings, necklaces, etc.
- Do not put magnetic cards, watches, portable phones, etc. close to the motor.
- Place a caution sign such as "CAUTION! POWERFUL MAGNET" to give warning against the machine.
- Use non-magnetic tools, when installing or working near the linear servo motor.
 - e.g., explosion-proof beryllium copper alloy safety tools (BEALON manufactured by NGK Insulators, Ltd.)
- If the linear servo motor is used in such an environment where there is magnetic powder, the powder may adhere to the permanent magnets of the secondary side and cause a damage. In that case, take measures to prevent the magnetic powder or pieces from being attracted to the permanent magnets of the secondary side or from going into the gap between primary side and secondary side.
- The linear servo motor is rated IP00. Provide protection measures to prevent dust and oil, etc., as necessary.
- Install the linear servo motor so that the thrust is applied to the center of gravity of the moving part. Failing to do so will cause a moment to occur.
- The cables such as the power cable deriving from the primary side cannot withstand the long-term bending action. Avoid the bending action by fixing the cables to the moving part or others. Also, use the cable that can withstand the long-term bending action for the wiring to the servo amplifier.
- Increase in the temperature of the linear servo motor causes a thrust drop. Use the motor within the specified ambient temperature.

[Disposal of linear servo motors]

- $lace{\mbox{Dispose}}$ the primary side as industrial waste.
- Demagnetize the secondary side with a heat of 300 °C or higher, and dispose as industrial waste.
- Do not leave the product unattended.

For safety enhancement

When the MELSERVO-J5 series servo amplifiers, servo motors, options, and peripheral equipment are installed in machines/systems, make sure the machines/systems conform to relevant standards and regulations. The entire system shall observe the following:

- For safety circuits, use parts and/or devices whose safety are confirmed or which comply with safety standards for the application.
- (2) For details regarding the use of the servo amplifiers and other cautionary information, refer to relevant User's Manuals.
- (3) Perform risk assessment on the entire machine/system. Using Certification Body for final safety certification is recommended.

Specifications

Common

List

LVS/Wires

Servo system controller

Warranty

1. Warranty period and coverage

We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

[Term]

For terms of warranty, please contact your original place of purchase.

[Limitations]

 You are requested to conduct an initial failure diagnosis by yourself, as a general rule.

It can also be carried out by us or our service company upon your request and the actual cost will be charged.

However, it will not be charged if we are responsible for the cause of the failure.

- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
 - a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
 - (ii) a failure caused by any alteration, etc. to the Product made on your side without our approval
 - (iii) a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
 - (iv) a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
 - (v) any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
 - (vi) a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
 - (vii) a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
 - (viii) any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA Center for details.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

- (1) For the use of our servo system controller, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in the servo system controller, and a backup or fail-safe function should operate on an external system to the servo system controller when any failure or malfunction occurs.
- (2) Our servo system controller is designed and manufactured as general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.

In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used.

We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

(3) Mitsubishi Electric shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks.

Warranty

1. Warranty period and coverage

We will repair any failure or defect hereinafter referred to as "failure" in our FA equipment hereinafter referred to as the "Product" arisen during warranty period at no charge due to causes for which we are responsible through the distributor from which you purchased the Product or our service provider. However, we will charge the actual cost of dispatching our engineer for an on-site repair work on request by customer in Japan or overseas countries. We are not responsible for any on-site readjustment and/or trial run that may be required after a defective unit is repaired or replaced.

[Term]

For terms of warranty, please contact your original place of purchase.

[Limitations]

- (1) You are requested to conduct an initial failure diagnosis by yourself, as a general rule. It can also be carried out by us or our service company upon your request and the actual cost will be charged. However, it will not be charged if we are responsible for the cause of the failure.
- (2) This limited warranty applies only when the condition, method, environment, etc. of use are in compliance with the terms and conditions and instructions that are set forth in the instruction manual and user manual for the Product and the caution label affixed to the Product.
- (3) Even during the term of warranty, the repair cost will be charged on you in the following cases;
 - a failure caused by your improper storing or handling, carelessness or negligence, etc., and a failure caused by your hardware or software problem
 - (ii) a failure caused by any alteration, etc. to the Product made on your side without our approval
 - (iii) a failure which may be regarded as avoidable, if your equipment in which the Product is incorporated is equipped with a safety device required by applicable laws and has any function or structure considered to be indispensable according to a common sense in the industry
 - (iv) a failure which may be regarded as avoidable if consumable parts designated in the instruction manual, etc. are duly maintained and replaced
 - (v) any replacement of consumable parts (battery, fan, smoothing capacitor, etc.)
 - (vi) a failure caused by external factors such as inevitable accidents, including without limitation fire and abnormal fluctuation of voltage, and acts of God, including without limitation earthquake, lightning and natural disasters
 - (vii) a failure generated by an unforeseeable cause with a scientific technology that was not available at the time of the shipment of the Product from our company
 - (viii) any other failures which we are not responsible for or which you acknowledge we are not responsible for

2. Term of warranty after the stop of production

- (1) We may accept the repair at charge for another seven (7) years after the production of the product is discontinued. The announcement of the stop of production for each model can be seen in our Sales and Service, etc.
- (2) Please note that the Product (including its spare parts) cannot be ordered after its stop of production.

3. Service in overseas countries

Our regional FA Center in overseas countries will accept the repair work of the Product. However, the terms and conditions of the repair work may differ depending on each FA Center. Please ask your local FA Center for details.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation to:

- (1) Damages caused by any cause found not to be the responsibility of Mitsubishi.
- (2) Loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products.
- (3) Special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products.
- (4) Replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Change of Product specifications

Specifications listed in our catalogs, manuals or technical documents may be changed without notice.

6. Application and use of the Product

- (1) For the use of our AC Servo, its applications should be those that may not result in a serious damage even if any failure or malfunction occurs in AC Servo, and a backup or fail-safe function should operate on an external system to AC Servo when any failure or malfunction occurs.
- (2) Our AC Servo is designed and manufactured as a general purpose product for use at general industries. Therefore, applications substantially influential on the public interest for such as atomic power plants and other power plants of electric power companies, and also which require a special quality assurance system, including applications for railway companies and government or public offices are not recommended, and we assume no responsibility for any failure caused by these applications when used.

In addition, applications which may be substantially influential to human lives or properties for such as airlines, medical treatments, railway service, incineration and fuel systems, man-operated material handling equipment, entertainment machines, safety machines, etc. are not recommended, and we assume no responsibility for any failure caused by these applications when used.

We will review the acceptability of the abovementioned applications, if you agree not to require a specific quality for a specific application. Please contact us for consultation.

(3) Mitsubishi Electric shall have no responsibility or liability for any problems involving programmable controller trouble and system trouble caused by DoS attacks, unauthorized access, computer viruses, and other cyberattacks. Servo System Controllers

Servo Amplifiers

Rotary Servo Motors

Linear Servo Motors

Direct Drive Motors

Options/Peripheral Equipment

LVS/Wires

Extensive global support coverage providing expert help whenever needed

Global FA centers
EMEA

Europe FA Center

MITSUBISHI ELECTRIC EUROPE B.V. Polish Branch Tel: +48-12-347-65-00

Germany FA Center MITSUBISHI ELECTRIC EUROPE B.V. German Branch Tel: +49-2102-486-0

UK FA Center MITSUBISHI ELECTRIC EUROPE B.V. UK Branch Tel: +44-1707-27-8780

Czech Republic FA Center MITSUBISHI ELECTRIC EUROPE B.V. Czech Branch Tel: +420-734-402-587

Italy FA Center MITSUBISHI ELECTRIC EUROPE B.V. Italian Branch Tel: +39-039-60531

Turkey FA Center MITSUBISHI ELECTRIC TURKEY Elektrik Urunleri A.S. Tel: +90-216-969-2500

Asia-Pacific

China

Beijing FA Center MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Beijing FA Center Tel: +86-10-6518-8830

Guangzhou FA Center MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Guangzhou FA Center Tel: +86-20-8923-6730

Shanghai FA Center MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Shanghai FA Center Tel: +86-21-2322-3030

Tianjin FA Center MITSUBISHI ELECTRIC AUTOMATION (CHINA) LTD. Tianjin FA Center Tel: +86-22-2813-1015

161. +00-22-2013-1013

Taiwan

Taipei FA Center setsuyo enterprise co., LTD. Tel: +886-2-2299-9917

Korea

Korea FA Center MITSUBISHI ELECTRIC AUTOMATION KOREA CO., LTD. Tel: +82-2-3660-9630

Thailand

Thailand FA Center MITSUBISHI ELECTRIC FACTORY AUTOMATION (THAILAND) CO., LTD. Tel: +66-2682-6522 to 31

ASEAN

ASEAN FA Center MITSUBISHI ELECTRIC ASIA PTE. LTD. Tel: +65-6470-2475

Malaysia

Malaysia FA Center Malaysia FA Center Tel: +60-3-7626-5080

Indonesia

Indonesia FA Center PT. MITSUBISHI ELECTRIC INDONESIA Cikarang Office Tel: +62-21-2961-7797

Vietnam

Hanoi FA Center MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED Hanoi Branch Office Tel: +84-24-3937-8075

Ho Chi Minh FA Center MITSUBISHI ELECTRIC VIETNAM COMPANY LIMITED Tel: +84-28-3910-5945

Philippines

Philippines FA Center MELCO Factory Automation Philippines Inc. Tel: +63-(0)2-8256-8042

India

India Ahmedabad FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Ahmedabad Branch Tel: +91-7965120063

India Bangalore FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Bangalore Branch Tel: +91-80-4020-1600

India Chennai FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Chennai Branch Tel: +91-4445548772

India Coimbatore FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Coimbatore Branch Tel: +91-422-438-5606

India Gurgaon FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Gurgaon Head Office Tel: +91-124-463-0300

India Pune FA Center MITSUBISHI ELECTRIC INDIA PVT. LTD. Pune Branch Tel: +91-20-2710-2000

Americas

USA

North America FA Center MITSUBISHI ELECTRIC AUTOMATION, INC. Tel: +1-847-478-2100

Mexico

Mexico City FA Center MITSUBISHI ELECTRIC AUTOMATION, INC. Mexico Branch Tel: +52-55-3067-7500

Mexico FA Center

MICRICO FA CETTEI MITSUBISHI ELECTRIC AUTOMATION, INC. Queretaro Office Tel: +52-442-153-6014

Mexico Monterrey FA Center MITSUBISHI ELECTRIC AUTOMATION, INC. Monterrey Office Tel: +52-55-3067-7599

Brazil

Brazil FA Center MITSUBISHI ELECTRIC DO BRASIL COMERCIO E SERVICOS LTDA. Tel: +55-11-4689-3000

Support

Support

List of Instruction Manuals

Relevant manuals are listed below:

Servo System Controller

Manual name	Manual No.
MELSEC iQ-R Motion Module User's Manual (Application for Simple Motion Mode)	IB-0300572ENG
MELSEC iQ-R Motion Module (Simple Motion Mode) Function Block Reference	BCN-B62005-1040ENG
MELSEC iQ-R Motion Module User's Manual (Advanced Synchronous Control for Simple Motion Mode)	IB-0300575ENG
MELSEC iQ-R Motion Module User's Manual (Startup)	IB-0300406ENG
MELSEC iQ-R Motion Module User's Manual (Application)	IB-0300411ENG
MELSEC iQ-R Motion Module User's Manual (Network)	IB-0300426ENG
MELSEC iQ-R Programming Manual (Motion Module Instructions, Standard Functions/Function Blocks)	IB-0300431ENG
MELSEC iQ-R Programming Manual (Motion Control Function Blocks)	IB-0300533ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module User's Manual (Startup)	IB-0300251ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module User's Manual (Application)	IB-0300253ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module User's Manual (Advanced Synchronous Control)	IB-0300255ENG
MELSEC iQ-F FX5 Motion Module User's Manual (CC-Link IE TSN)	IB-0300568ENG
MELSEC iQ-F FX5 Motion Module/Simple Motion Module Function Block Reference	BCN-B62005-719
Motion Control Software SWM-G User's Manual (Startup)	IB-0300562ENG
Motion Control Software SWM-G Operating Manual	IB-0300563ENG
MELSEC iQ-R Motion Controller User's Manual	IB-0300235
MELSEC iQ-R Motion Controller Programming Manual (Common)	IB-0300237
MELSEC iQ-R Motion Controller Programming Manual (Program Design)	IB-0300239
MELSEC iQ-R Motion Controller Programming Manual (Positioning Control)	IB-0300241
MELSEC iQ-R Motion Controller Programming Manual (Advanced Synchronous Control)	IB-0300243
MELSEC iQ-R Motion Controller Programming Manual (Machine Control)	IB-0300309
MELSEC iQ-R Motion Controller Programming Manual (G-Code Control)	IB-0300371
MELSEC iQ-R Simple Motion Module User's Manual (Startup)	IB-0300245ENG
MELSEC iQ-R Simple Motion Module User's Manual (Application)	IB-0300247ENG
MELSEC iQ-R Simple Motion Module User's Manual (Advanced Synchronous Control)	IB-0300249ENG
MELSEC iQ-R Simple Motion Module Function Block Reference	BCN-B62005-691ENG
Q173D(S)CPU/Q172D(S)CPU Motion Controller User's Manual	IB-0300133
Q173D(S)CPU/Q172D(S)CPU Motion Controller Programming Manual (COMMON)	IB-0300134
Q173D(S)CPU/Q172D(S)CPU Motion Controller (SV13/SV22) Programming Manual (Motion SFC)	IB-0300135
Q173D(S)CPU/Q172D(S)CPU Motion Controller (SV13/SV22) Programming Manual (REAL MODE)	IB-0300136
Q173D(S)CPU/Q172D(S)CPU Motion Controller (SV22) Programming Manual (VIRTUAL MODE)	IB-0300137
Q173D(S)CPU/Q172D(S)CPU Motion Controller Programming Manual (Safety Observation)	IB-0300183
Q173DSCPU/Q172DSCPU Motion Controller (SV22) Programming Manual (Advanced Synchronous Control)	IB-0300198
Q170MSCPU User's Manual	IB-0300212
MELSEC-Q QD77MS Simple Motion Module User's Manual (Positioning Control)	IB-0300185
MELSEC-Q/L QD77MS/QD77GF/LD77MS/LD77MH Simple Motion Module User's Manual (Synchronous Control)	IB-0300174

Common Specifications **Servo Amplifier** Manual name Manual No. Servo System Controllers MR-J5 User's Manual (Hardware) SH-030298ENG MR-J5 User's Manual (Function) SH-030300ENG MR-J5 User's Manual (Adjustment) SH-030306ENG MR-J5 User's Manual (Troubleshooting) SH-030312ENG MR-J5-G/MR-J5W-G User's Manual (Introduction) SH-030294ENG MR-J5-G/MR-J5W-G User's Manual (Parameters) SH-030308ENG Servo Amplifiers MR-J5-G/MR-J5W-G User's Manual (Communication Function) SH-030302ENG MR-J5-G/MR-J5W-G User's Manual (Object Dictionary) SH-030304ENG MR-J5-G-N1/MR-J5W-G-N1 User's Manual (Introduction) SH-030366ENG MR-J5-G-N1/MR-J5W-G-N1 User's Manual (Communication Function) SH-030371ENG MR-J5-G-N1/MR-J5W-G-N1 User's Manual (Object Dictionary) SH-030376ENG Rotary Servo Motors MR-J5D User's Manual (Hardware) IB-0300548ENG MR-J5D-G User's Manual (Introduction) IB-0300538ENG MR-J5D-G-N1 User's Manual (Introduction) IB-0300543ENG MR-CV Power Regeneration Converter Unit User's Manual IB-0300553ENG IB-0300578ENG MR-J5-B/MR-J5W-B User's Manual (Introduction) MR-J5-B/MR-J5W-B User's Manual (Parameters) IB-0300581ENG Linear Servo Motors MR-J5-A User's Manual (Introduction) SH-030296ENG MR-J5-A User's Manual (Parameters) SH-030310ENG

Servo Motor

Manual name	Manual No.	_
Rotary Servo Motor User's Manual (For MR-J5)	SH-030314ENG	Motors
Linear Servo Motor User's Manual (LM-H3/LM-U2/LM-F/LM-K2)	SH-030316ENG	otor
Linear Servo Motor User's Manual (LM-AJ/LM-AU)	IB-0300518ENG	Ors
Direct Drive Motor User's Manual	SH-030318ENG	_
Others		Options/Peripheral Equipment
Manual name	Manual No.	Equipment
EMC Installation Guidelines	IB-67310	ent
MR-J5 Partner's Encoder User's Manual	SH-030320ENG	grai

Others

Others		Equ
Manual name	Manual No.	ipme
EMC Installation Guidelines	IB-67310	ent
MR-J5 Partner's Encoder User's Manual	SH-030320ENG	2

LVS/Wires

Product List

Precautions

Support

Android and Google Play are trademarks of Google LLC.

Apple, iPad, iPad Air, iPad mini, and App Store are trademarks of Apple Inc., registered in the U.S. and other countries.

Microsoft, Windows, Visual C++, Visual Studio, and IntelliSense are either registered trademarks or trademarks of

Microsoft Corporation in the United States and/or other countries.

Celeron and Pentium are either registered trademarks or trademarks of Intel Corporation in the United States and/or other countries. PLCopen and related logos are registered trademarks of PLCopen.

EtherCAT is a registered trademark and patented technology, licensed by Beckhoff Automation GmbH, Germany.

All other company names and product names used in this document are trademarks or registered trademarks of their respective companies.

Precautions before use

This publication explains the typical features and functions of the products herein and does not provide restrictions or other information related to usage and module combinations. Before using the products, always read the product user manuals. Mitsubishi Electric will not be held liable for damage caused by factors found not to be the cause of Mitsubishi Electric; opportunity loss or lost profits caused by faults in Mitsubishi Electric products; damage, secondary damage, or accident compensation, whether foreseeable or not, caused by special factors; damage to products other than Mitsubishi Electric products; or any other duties.

🚹 For safe use

- To use the products given in this publication properly, always read the relevant manuals before beginning operation.
- The products have been manufactured as general-purpose parts for general industries, and are not designed or manufactured to be incorporated in a device or system used in purposes related to human life.
- · Before using the products for special purposes such as nuclear power, electric power, aerospace, medicine or passenger-carrying vehicles, consult with Mitsubishi Electric. The products have been manufactured under strict quality control. However, when
- installing the products where major accidents or losses could occur if the products fail, install appropriate backup or fail-safe functions in the system.





Automating the World

Creating Solutions Together.





Low-voltage Power Distribution Products



Compact and Modular Controllers



Numerical Control (NC)





Servos, Motors and Inverters



Collaborative and Industrial Robots



Power Monitoring and Energy Saving

Products



Processing machines: EDM, Lasers



Power (UPS) and Environmental Products



Edge Computing Products



SCADA, analytics and simulation software

Mitsubishi Electric's product lineup, from various controllers and drives to energy-saving devices and processing machines, all help you to automate your world. They are underpinned by software, innovative data monitoring, and modelling systems supported by advanced industrial networking and Edgecross IT/OT connectivity. Together with a worldwide partner ecosystem, Mitsubishi Electric factory automation (FA) has everything to make IoT and Digital Manufacturing a reality.

With a complete portfolio and comprehensive capabilities that combine synergies with diverse business units, Mitsubishi Electric provides a one-stop approach to how companies can tackle the shift to clean energy and energy conservation, carbon neutrality and sustainability, which are now a universal requirement of factories, buildings, and social infrastructure.

We at Mitsubishi Electric FA are your solution partners waiting to work with you as you take a step toward the realization of sustainable manufacturing and society through the application of automation. Let's automate the world together!

Mitsubishi Electric AC Servo System MELSERVO-J5

Country/Region	Sales office	
USA	Mitsubishi Electric Automation, Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, U.S.A.	Tel : +1-847-478-2100
Mexico	Mitsubishi Electric Automation, Inc. Mexico Branch Boulevard Miguel de Cervantes Saavedra 301, Torre Norte Piso 5, Int. 502, Ampliacion Granada, Miguel Hidalgo, Ciudad de Mexico, Mexico, C.P.11520	Tel : +52-55-3067-7500
Brazil	Mitsubishi Electric do Brasil Comercio e Servicos Ltda. Avenida Adelino Cardana, 293, 21 andar, Bethaville, Barueri SP, Brazil	Tel : +55-11-4689-3000
Germany	Mitsubishi Electric Europe B.V. German Branch Mitsubishi-Electric-Platz 1, 40882 Ratingen, Germany	Tel : +49-2102-486-0
UK	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, UK-Hatfield, Hertfordshire, AL10 8XB, U.K.	Tel : +44-1707-28-8780
Italy	Mitsubishi Electric Europe B.V. Italian Branch Campus, Energy Park Via Energy Park 14, Vimercate 20871 (MB) Italy	Tel : +39-039-60531
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi, 76-80-Apdo. 420, E-08174 Sant Cugat del Valles (Barcelona), Spain	Tel : +34-935-65-3131
France	Mitsubishi Electric Europe B.V. French Branch 2, rue de l'Union-92565 Rueil-Malmaison Cedex-France	Tel : +33-1-55-68-55-68
Czech Republic	Mitsubishi Electric Europe B.V. Czech Branch, Prague Office Pekarska 621/7, 155 00 Praha 5, Czech Republic	Tel : +420-734-402-587
Poland	Mitsubishi Electric Europe B.V. Polish Branch ul. Krakowska 48, 32-083 Balice, Poland	Tel : +48-12-347-65-00
Sweden	Mitsubishi Electric Europe B.V. (Scandinavia) Hedvig Mollersgata 6, 223 55 Lund, Sweden	Tel : +46-8-625-10-00
Turkey	Mitsubishi Electric Turkey Elektrik Urunleri A.S. Serifali Mah. Kale Sok. No:41 Umraniye / Istanbul, Turkey	Tel : +90-216-969-2500
UAE	Mitsubishi Electric Europe B.V. Dubai Branch Dubai Silicon Oasis, P.O.BOX 341241, Dubai, U.A.E.	Tel : +971-4-3724716
South Africa	Adroit Technologies 20 Waterford Office Park, 189 Witkoppen Road, Fourways, South Africa	Tel : +27-11-658-8100
China	Mitsubishi Electric Automation (China) Ltd. Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Shanghai, China	Tel : +86-21-2322-3030
Taiwan	SETSUYO ENTERPRISE CO., LTD. 5F, No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan	Tel : +886-2-2299-2499
Korea	Mitsubishi Electric Automation Korea Co., Ltd. 7F to 9F, Gangseo Hangang Xi-tower A, 401, Yangcheon-ro, Gangseo-Gu, Seoul, Korea	Tel : +82-2-6103-9474
Singapore	Mitsubishi Electric Asia Pte. Ltd. 307 Alexandra Road, Mitsubishi Electric Building, Singapore 159943	Tel : +65-6473-2486
Thailand	Mitsubishi Electric Factory Automation (Thailand) Co., Ltd. 101, True Digital Park Office, 5th Floor, Sukhumvit Road, Bang Chak, Prakanong, Bangkok, Thailand	Tel : +66-2092-8600
Indonesia	PT. Mitsubishi Electric Indonesia Gedung Jaya 8th Floor, JL. MH. Thamrin No.12, Jakarta Pusat 10340, Indonesia	Tel : +62-21-3192-6461
Vietnam	Mitsubishi Electric Vietnam Company Limited 11th & 12th Floor, Viettel Tower B, 285 Cach Mang Thang Tam Street, Ward 12, District 10, Ho Chi Minh City, Vietnam.	Tel : +84-28-3910-5945
India	Mitsubishi Electric India Pvt. Ltd. Pune Branch ICC-Devi Gaurav Technology Park, Unit no. 402, Fourth Floor, Survey no. 191-192 (P), Opp. Vallabh Nagar Bus Depot, Pune - 411018, Maharashtra, India	Tel : +91-20-4624-2100
Australia	Mitsubishi Electric Australia Pty. Ltd. 348 Victoria Road, P.O. Box 11, Rydalmere, N.S.W 2116, Australia	Tel : +61-2-9684-7777



Mitsubishi Electric's e-F@ctory concept utilizes both FA and IT technologies, to reduce the total cost of development, production and maintenance, with the aim of achieving manufacturing that is a "step ahead of the times". It is supported by the e-F@ctory Alliance Partners covering software, devices, and system integration, creating the optimal e-F@ctory architecture to meet the end users needs and investment plans.



MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BLDG., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN NAGOYA WORKS: 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA 461-8670, JAPAN